

# Frequency Inverters

## Beginner's Guide

**FR-D700**  
**FR-E700/E700SC**  
**FR-F700**  
**FR-A700**



# About This Manual

The texts, illustration, diagrams and examples in this manual are provided for information purposes only. They are intended as aids to help explain the installation and operation of the inverter of the FR-D700, FR-E700/E700SC, FR-F700 and FR-A700 series.

If you have any questions about the installation and operation of any of the products described in this manual please contact your local sales office or distributor (see back cover).

You can find the latest information and answers to frequently asked questions on our website at [www.mitsubishi-automation.com](http://www.mitsubishi-automation.com).

MITSUBISHI ELECTRIC EUROPE BV reserves the right to make changes to this manual or the technical specifications of its products at any time without notice.

© 04/2011

**Beginner's Guide for Frequency Inverters of the  
FR-D700, FR-E700/E700SC, FR-F700 and FR-A700 Series**  
Art. no.: 203603

Version	Revisions / Additions / Corrections	
A 02/2007	pdp-dk	First edition
B 08/2008	pdp-gb	General: Replacement of the inverters FR-S500 and FR-E500 by the models FR-D700 and FR-E700
C 04/2011	akl	General: Additions: <ul style="list-style-type: none"><li>● New parameters and setting values</li><li>● Alarm displays</li><li>● Models FR-E700SC</li></ul>



# Safety Guidelines

## For use by qualified staff only

This manual is only intended for use by properly trained and qualified electrical technicians who are fully acquainted with the relevant automation technology safety standards. All work with the hardware described, including system design, installation, configuration, maintenance, service and testing of the equipment, may only be performed by trained electrical technicians with approved qualifications who are fully acquainted with all the applicable automation technology safety standards and regulations. Any operations or modifications to the hardware and/or software of our products not specifically described in this manual may only be performed by authorised Mitsubishi Electric staff.

## Proper use of the products

The inverters of the FR- D700, FR-E700/E700SC, FR-F700 and FR-A700 series are only intended for the specific applications explicitly described in this manual. All parameters and settings specified in this manual must be observed. The products described have all been designed, manufactured, tested and documented in strict compliance with the relevant safety standards. Unqualified modification of the hardware or software or failure to observe the warnings on the products and in this manual may result in serious personal injury and/or damage to property. Only peripherals and expansion equipment specifically recommended and approved by Mitsubishi Electric may be used with the inverters of the FR-D700, FR-E700/E700SC, FR-F700 and FR-A700 series.

All and any other uses or application of the products shall be deemed to be improper.

## Relevant safety regulations

All safety and accident prevention regulations relevant to your specific application must be observed in the system design, installation, configuration, maintenance, servicing and testing of these products. The regulations listed below are particularly important in this regard. This list does not claim to be complete, however; you are responsible for being familiar with and conforming to the regulations applicable to you in your location.

- VDE Standards
  - VDE 0100  
Regulations for the erection of power installations with rated voltages below 1000 V
  - VDE 0105  
Operation of power installations
  - VDE 0113  
Electrical installations with electronic equipment
  - EN 50178  
Electronic equipment for use in power installations
- Fire safety regulations
- Accident prevention regulation
  - VBG No. 4  
Electrical systems and equipment

---

### Safety warnings in this manual

Do not use the inverter until you have a full knowledge of the equipment, safety information and instructions. In this manual, the safety instruction levels are classified into "WARNING" and "DANGER".

**DANGER:**

*Failure to observe the safety warnings identified with this symbol can result in health and injury hazards for the user.*

**WARNING:**

*Failure to observe the safety warnings identified with this symbol can result in damage to the equipment or other property.*

Note that even warnings may lead to a serious consequence according to conditions. Please follow strictly the instructions of both levels because they are important to personnel safety.

## Electric shock prevention



### DANGER

- **While power is on or when the inverter is running, do not open the front cover. Otherwise you may get an electric shock.**
- **Do not run the inverter with the front cover removed. Otherwise, you may access the exposed high-voltage terminals or the charging part of the circuitry and get an electric shock.**
- **Even if power is off, do not remove the front cover except for wiring or periodic inspection. You may access the charged inverter circuits and get an electric shock**
- **Before starting wiring or inspection, check to make sure that the operation panel indicator is off, wait for at least 10 minutes after the power supply has been switched off, and check that there are no residual voltage using a tester or the like. The capacitor is charged with high voltage for some time after power off and it is dangerous.**
- **This inverter must be earthed. Earthing must conform to the requirements of national and local safety regulations and electrical codes. (JIS, NEC section 250, IEC 536 class 1 and other applicable standards)**
- **Any person who is involved in the wiring or inspection of this equipment should be fully competent to do the work.**
- **Always install the inverter before wiring. Otherwise, you may get an electric shock or be injured.**
- **If your application requires by installation standards an RCD (residual current device) as up stream protection please select according to DIN VDE 0100-530 as following:**  
**Single phase inverter type A or B**  
**Three phase inverter only type B**
- **Perform setting dial and key operations with dry hands to prevent an electric shock. Otherwise you may get an electric shock.**
- **Do not subject the cables to scratches, excessive stress, heavy loads or pinching. Otherwise you may get an electric shock.**
- **Do not replace the cooling fan while power is on. It is dangerous to replace the cooling fan while power is on.**
- **Do not touch the printed circuit board with wet hands. You may get an electric shock.**

---

## Fire prevention



### WARNING

- *Mount the inverter to incombustible material. Mounting it to or near combustible material can cause a fire.*
- *If the inverter has become faulty, switch off the inverter power. A continuous flow of large current could cause a fire.*
- *Do not connect a resistor directly to the DC terminals P and N. This could cause a fire and destroy the inverter. The surface temperature of braking resistors can far exceed 100°C for brief periods. Make sure that there is adequate protection against accidental contact and a safe distance is maintained to other units and system parts.*

## Injury prevention



### WARNING

- *Apply only the voltage specified in the instruction manual to each terminal. Otherwise, burst, damage, etc. may occur.*
- *Ensure that the cables are connected to the correct terminals. Otherwise, burst, damage, etc. may occur.*
- *Always make sure that polarity is correct to prevent damage, etc. Otherwise, burst, damage, etc. may occur.*
- *While power is on or for some time after power-off, do not touch the inverter as it is hot and you may get burnt.*

### Additional instructions

Also note the following points to prevent an accidental failure, injury, electric shock, etc.

### Transportation and installation



#### WARNING

- *When carrying products, use correct lifting gear to prevent injury.*
- *Do not stack the inverter boxes higher than the number recommended.*
- *Ensure that installation position and material can withstand the weight of the inverter. Install according to the information in the instruction manual.*
- *Do not install or operate the inverter if it is damaged or has parts missing. This can result in breakdowns.*
- *When carrying the inverter, do not hold it by the front cover or setting dial; it may fall off or fail.*
- *Do not stand or rest heavy objects on the product.*
- *Check the inverter mounting orientation is correct.*
- *Prevent other conductive bodies such as screws and metal fragments or other flammable substance such as oil from entering the inverter.*
- *Prevent other conductive bodies such as screws and metal fragments or other flammable substance such as oil from entering the inverter.*
- *Use the inverter under the environmental conditions mentioned in chapter 1. Otherwise, the inverter may be damaged.*

### Wiring



#### WARNING

- *Do not install assemblies or components (e. g. power factor correction capacitors) on the inverter output side, which are not approved from Mitsubishi.*
- *The direction of rotation of the motor corresponds to the direction of rotation commands (STF/STR) only if the phase sequence (U, V, W) is maintained.*

### Test operation and adjustment



#### WARNING

- *Before starting operation, confirm and adjust the parameters. A failure to do so may cause some machines to make unexpected motions.*



### WARNING

- When you have chosen the retry function, stay away from the equipment as it will restart suddenly after an alarm stop.
- The STOP/RESET key is valid only when the appropriate function setting has been made. Prepare an emergency stop switch separately.
- Make sure that the start signal is off before resetting the inverter alarm. A failure to do so may restart the motor suddenly.
- The inverter can be started and stopped via the serial port communications link or the field bus. However, please note that depending on the settings of the communications parameters it may not be possible to stop the system via these connections if there is an error in the communications system or the data line. In configurations like this it is thus essential to install additional safety hardware that makes it possible to stop the system in an emergency (e.g. controller inhibit via control signal, external motor contactor etc). Clear and unambiguous warnings about this must be posted on site for the operating and service staff.
- The connected load of a inverter should be a three-phase induction motor only. Connection of any other electrical equipment to the inverter output may damage the inverter as well as the equipment.
- Do not modify the equipment.
- Do not perform parts removal which is not instructed in this manual. Doing so may lead to fault or damage of the inverter.
- The electronic thermal relay function does not guarantee protection of the motor from overheating. It is recommended to install both an external thermal and PTC thermistor for overheat protection.
- Do not use a magnetic contactor on the inverter input for frequent starting/stopping of the inverter.
- Use a noise filter to reduce the effect of electromagnetic interference and follow the accepted EMC procedures for proper installation of frequency inverters. Otherwise nearby electronic equipment may be affected.
- Take appropriate measures regarding harmonics. Otherwise this can endanger compensation systems or overload generators.
- Use a motor designed for inverter operation. (The stress for motor windings is bigger than in line power supply).
- When parameter clear or all clear is performed, set again the required parameters before starting operations. Each parameter returns to the initial value.
- The inverter can be easily set for high-speed operation. Before changing its setting, fully examine the performances of the motor and machine.
- The DC braking function of the frequency inverter is not designed to continuously hold a load. Use an electro-mechanical holding brake on the motor for this purpose.
- Before running an inverter which had been stored for a long period, always perform inspection and test operation.
- For prevention of damage due to static electricity, touch nearby metal before touching this product to eliminate static electricity from your body.

### Emergency stop



#### WARNING

- *Provide a safety backup such as an emergency brake which will prevent the machine and equipment from hazardous conditions if the inverter fails.*
- *When the breaker on the inverter primary side trips, check for the wiring fault (short circuit), damage to internal parts of the inverter, etc. Identify the cause of the trip, then remove the cause and power on the breaker.*
- *When the protective function is activated (i. e. the frequency inverter switches off with an error message), take the corresponding corrective action as described in the inverter manual, then reset the inverter, and resume operation.*

### Maintenance, inspection and parts replacement



#### WARNING

- *Do not carry out a megger (insulation resistance) test on the control circuit of the inverter.*



# Contents

## 1 Introduction

1.1	What is a Frequency Inverter? . . . . .	1-1
1.2	Ambient Conditions . . . . .	1-2
1.3	Terminology . . . . .	1-3

## 2 Introduction to the Inverters

2.1	FR-D700 . . . . .	2-1
2.2	FR-E700/E700SC . . . . .	2-2
2.3	FR-F700 and FR-A700 . . . . .	2-3
2.4	Removing and Replacing the Front Cover . . . . .	2-4
2.4.1	FR-D700 Series Inverters . . . . .	2-4
2.4.2	FR-E700/E700SC Series Inverters . . . . .	2-7
2.4.3	FR-F700 and FR-A700 Series Inverters . . . . .	2-9

## 3 Connections

3.1	Power Supply, Motor and Earth Connections . . . . .	3-1
3.2	Control Terminals . . . . .	3-3
3.3	EM-Compatible Installation . . . . .	3-5
3.3.1	EM-Compatible Switchgear Cabinet Installation . . . . .	3-5
3.3.2	Wiring . . . . .	3-6
3.3.3	EMC Filters . . . . .	3-7

## 4 Start-Up

4.1	Preparations . . . . .	4-1
4.1.1	Before switching on the inverter for the first time . . . . .	4-1
4.1.2	Important settings before switching on the motor for the first time . . . . .	4-1
4.2	Functional Test . . . . .	4-2

## 5 Operation and Settings

5.1	Operating FR-D700 and FR-E700/E700SC Inverters . . . . .	5-2
5.2	Operating FR-F700 and FR-A700 Inverters . . . . .	5-5
5.3	Operating Mode Selection . . . . .	5-8
5.4	Setting the Frequency and Starting the Motor . . . . .	5-9
5.5	Editing Parameter Settings . . . . .	5-11

---

## 6 Parameter

6.1	Basic Parameters.....	6-1
6.2	The Basic Parameters in Detail.....	6-3
6.2.1	Torque Boost (Parameter 0) .....	6-3
6.2.2	Minimum/Maximum Output Frequency (Parameters 1 and 2) .....	6-3
6.2.3	Base Frequency (Parameter 3).....	6-4
6.2.4	Multi-speed Settings (Parameters 4 to 6) .....	6-4
6.2.5	Acceleration and Deceleration Times (Parameters 7 and 8) .....	6-6
6.2.6	Electronic Thermal Overload Relay (Parameter 9).....	6-6
6.2.7	Operation Mode Selection (Parameter 79) .....	6-7

## 7 Protective and Diagnostics Functions

7.1	Troubleshooting .....	7-2
7.2	List of Alarm Displays .....	7-4
7.3	Resetting the Inverter (Reset) .....	7-7

## A Appendix

A.1	Parameter List .....	A-1
A.1.1	FR-D700 .....	A-1
A.1.2	FR-E700/E700SC .....	A-5
A.1.3	FR-F700 .....	A-10
A.1.4	FR-A700 .....	A-17
A.2	Sample Applications .....	A-27
A.2.1	Conveyor Belt .....	A-27
A.2.2	Lifting Drive.....	A-29
A.2.3	PID Controller .....	A-31

# 1 Introduction

## 1.1 What is a Frequency Inverter?

Asynchronous three-phase electric motors are simple, reliable and inexpensive, which makes them a particularly popular choice for industrial applications.



The speed of an asynchronous three-phase motor is determined by two factors:

- The frequency of the three-phase current.
- The design of the motor winding (number of poles or pole pairs).

Since the frequency of the power supply is generally a constant 50Hz this means that the speed of the motor is inherently fixed – you can only change it for different applications by changing the construction of the winding. Once that has been chosen the motor will always run at a fixed speed, for example approximately 3,000 rpm or 1,500 rpm.

Providing more than one speed is only possible with “pole-changing” motors that have two sets of windings (2 windings enable up to 4 different speeds). That is the end of the line, however. Neither more speeds nor continuously-variable speeds are possible with pole-changing motors.

The solution to this problem is to use a frequency inverter, or inverter for short, which is a device that converts the fixed voltage and frequency of the mains power supply into a variable voltage with a variable frequency. It is installed between the mains supply and the motor and makes continuously-variable speed adjustment possible, turning a standard motor with a single winding into a flexible variable-speed drive system.



The speed of the connected motor can be adjusted continuously by changing the output voltage and frequency of the inverter.

Inverters also have other benefits, including adjustable acceleration and braking times, torque boosting, integrated electronic overcurrent protection and even integrated PID controllers, another advanced feature that has already been realised.

## 1.2 Ambient Conditions

Please observe the ambient conditions limits listed in the table below when operating the frequency inverters described in this guide.

Specification	FR-D700	FR-E700/ E700SC	FR-F700		FR-A700				
			FR-F740	FR-F746					
Ambient temperature	for operation	-10°C to 50°C		-10°C to 50°C* -10°C to 40°C*	-10°C to 50°C* -10°C to 40°C*				
		Non freezing							
for storage		-20°C to 65°C			These temperatures are allowed for a short period only e.g. during shipping.				
Ambient humidity for operation and storage		90% or less (non condensing)							
Vibration		5.9m/s <sup>2</sup> (0.6g) or less	5.9m/s <sup>2</sup> (0.6g) or less 2.9m/s <sup>2</sup> (0.3g) or less for inverter capacities 04320 or more						
Installation environment		Indoors (free from corrosive or flammable gas, oil mist, dust and dirt)							
Installation altitude		Maximum 1000m above sea level with no limitations. For altitudes above 1000m derate the inverter capacity by 3% for every additional 500m. Maximum installation altitude: 2500m (with 91% of the inverter rated capacity)							

\* The specific acceptable ambient temperature depends on the overload capacity of the individual inverter.

## 1.3 Terminology

The terms and concepts below are important for frequency inverters and are used frequently in this guide.

### **Direction of rotation of electric motors**

The direction (or sense) of rotation of electric motors is defined looking at the end of the motor shaft. If the motor has two shaft ends the direction is defined looking at the main drive shaft end, which is defined as the shaft end away from the end where the cooling fan or the brake are installed.

The direction of rotation is described as:

- **Clockwise / Forward**  
or
- **Anticlockwise / Reverse**

### **PU Mode**

In PU (parameter unit) mode the inverter can be controlled with the integrated control unit or an optional external control unit (inverter control units often referred to as “parameter units”). The PU indicator LED lights up with the inverter is in PU mode.


### **PU Interface**

An external control unit (parameter unit) can be connected to the inverter’s PU interface. Since this interface is actually an RS-485 port some inverters can also use it to communicate with other external devices.




## 2 Introduction to the Inverters

### 2.1 FR-D700

**NOTE**


Location of the capacity plate and the rating plate differs according to the inverter capacity.

## 2.2 FR-E700/E700SC

**NOTE**

Location of the capacity plate and the rating plate differs according to the inverter capacity.

## 2.3 FR-F700 and FR-A700



## 2.4 Removing and Replacing the Front Cover

Before connecting the inverter you must remove the front cover so that you can access the terminal blocks. The different series have different cover types and the procedure for removing and replacing the cover varies.

However, the safety warnings below must always be observed for all inverter models.

**DANGER:**


- **Always SWITCH OFF the mains power supply before removing the front cover or performing any work on the inverter.**
- **After switching off the power WAIT AT LEAST 10 MINUTES before removing the front cover to allow the charge in the inverter's power capacitors to fall to a safe level.**

### 2.4.1 FR-D700 Series Inverters

Removing and replacing on models from FR-D720S-008 through FR-D720S-100 and from FR-D740-012 through FR-D740-080


- **Removing the front cover**

Loosen the installation screws of the front cover. (The screws cannot be removed.) Remove the front cover by pulling it like the direction of arrow.




**● Replacing the front cover**

Place the front cover in front of the inverter, and install it straight. Tighten the installation screws on the front cover.




**Removing and replacing on models FR-D740-120 and FR-D740-160****● Removing the front cover**

Loosen the installation screws of the front cover. (The screws cannot be removed.) Remove the front cover by pulling it like the direction of arrow with holding an installation hook on the front cover.

**● Replacing the front cover**

Insert the two fixed hooks on the lower side of the front cover into the sockets of the inverter. Tighten the installation screws on the front cover.




## 2.4.2 FR-E700/E700SC Series Inverters

### Removing and replacing on models from FR-E740-012 through FR-E740-095


#### ● Removing the front cover

Remove the front cover by pulling it toward you in the direction of arrow (refer to the figure below).



#### ● Replacing the front cover

To reinstall, match the cover to the inverter front and install it straight.




### Removing and replacing on models FR-E740-230 and FR-E740-300

#### ● Removing the front cover

Loosen the installation screws of the front cover 1. Remove the front cover 1 by pulling it toward you in the direction of arrow.

Remove the front cover 2 by pulling it toward you in the direction of arrow (refer to the figure below).




#### ● Replacing the front cover

Match the front cover 2 to the inverter front and install it straight.

Insert the two fixed hooks on the lower side of the front cover 1 into the sockets of the inverter.

Tighten the screws of the front cover 1.




## 2.4.3 FR-F700 and FR-A700 Series Inverters

### Removing and replacing on models up to FR-F740-00620/FR-A740-00620

#### ● Removing the front cover

Loosen the cover's two retaining screws. Press on the latch on the right side of the cover to release it, then open the cover slightly and lift it away from the inverter.




#### ● Replacing the front cover

Insert the hinge pins on the left side of the cover in the matching sockets on the left side of the inverter casing.

Once the hinge pins are in the sockets press the cover shut until the latch snaps firmly into place. When replacing a front cover with the control unit installed take care to ensure that the control unit's connector plugs into the inverter correctly.


Finally, re-tighten the retaining screws to fasten the cover into place.



### Removing and replacing on models from FR-F740-00770/FR-A740-00770

#### ● Removing the front cover


Loosen the retaining screws of the outer cover and remove the outer cover. Then loosen the screws of the inner cover and press on the retaining latch on the side of the inverter to release it and open the cover slightly. After this you can remove the inner cover by lifting it forwards.



#### ● Replacing the front cover

Insert the hinge pins on the left side of the inner cover in the matching sockets on the left side of the inverter casing.


Once the hinge pins are in the sockets press the cover shut until the retaining latch snaps firmly into place. When replacing the front cover with the control unit installed take care to ensure that the control unit's connector plugs into the inverter correctly. Fasten the retaining screws of the inner cover. Then re-install the outer cover and fasten it with its retaining screws.



**Removing and replacing on models from FR-F746-00023 through FR-F746-01160****● Removing the front cover**

Unscrew the retaining screws of the front cover. Then carefully lift up the front cover very slightly – the cover is connected to the main inverter chassis with a metal chain.

Unplug the control unit cable and unhook the metal chain from the inverter. Now you can remove the front cover completely.

**● Replacing the front cover**

First hook the end of the chain back into its original place in the inverter and reconnect the control unit cable with the inverter.

You can then replace the front cover and fasten it with the screws. Take care that no cables or the metal chain get caught between the cover and the inverter casing.



# 3 Connections

**DANGER:**

*Always disconnect the power before performing any wiring work on frequency inverters. Frequency inverters contain high voltages that are potentially lethal. After switching off the power supply always wait for at least 10 minutes before proceeding to allow the charge in the inverter's capacitors to drop to safe levels.*

## 3.1 Power Supply, Motor and Earth Connections

Some inverters of the FR-D700 and the FR-E700/E700SC series can be connected to a single-phase AC power supply (230V). Other models of these series and all the models of the FR-F700 and FR-A700 series must be connected directly to a 3-phase AC power supply.

**FR-D700 and FR-E700/E700SC mains power supply specifications**

Power supply	FR-D720S, FR-E720S/E720SSC	FR-D740, FR-E740/E740SC
Voltage	1-phase, 200–240V AC, -15% / +10%	3-phase, 300–480V AC, -15% / +10%
Permissible input voltage range	170–264V AC	323–528V AC
Frequency	50 / 60Hz ± 5%	50 / 60Hz ± 5%

**FR-F700, FR-A700 mains power supply specifications**

Power supply	FR-F740, FR-A740
Voltage	3-phase, 380–500V AC, -15% / +10%
Permissible input voltage range	323–550V AC
Frequency	50 / 60Hz ± 5%

**NOTE**

You must also connect 3-phase AC motors to the outputs of the inverters that are powered by a single-phase 200–240V mains power supply. These inverters also output 3-phase AC power with a range from 0V to the input voltage.

The single-phase AC mains power supply is connected to terminals L1 and N. The three-phase AC mains power supply is connected to terminals L1, L2 and L3.

The motor is connected to terminals U, V and W.


The inverter must also be grounded with a cable connected to the protective earth terminal.



**WARNING:**

***Never connect mains power to the output terminals U, V or W! This would cause permanent damage to the inverter and would also create a serious shock hazard for the operator!***

The schematic illustration below shows the basic input and output connections of a frequency inverter.



The following table lists the power connection terminals found on the various inverter models.

Terminals	Function	Description
L1, N	Mains power supply (single-phase)	Mains power supply input for the frequency inverter
L1, L2, L3	Mains power supply (3-phase)	
U, V, W	Motor output	This is the inverter's power output (3-phase, 0V to input voltage, 0.2 or 0.5 to 400 Hz)
L11, L21	Control circuit power	FR-F700 and FR-A700 only
+, PR	Brake resistor connection	Except FR-A700
P/+, PR		
+, -	External brake unit	An optional external brake unit can be connected to these terminals.
P/+, N/-		
+, P1	DC reactor	A DC reactor can be connected to these terminals. You must remove the jumper before connecting the reactor.
P/+, P1		
PR, PX	Only fitted on FR-F700 and FR-A700 inverters. Do not use these terminals and do not remove the jumper.	
<u>  </u>	PE	Earth (ground) connection


## 3.2 Control Terminals

In addition to the power terminals for the mains power supply and the motor there are also a large number of additional terminals that are used for controlling the frequency inverter. The table below only lists the most important control terminals – there are more.

Type	Terminal	Function	Description
Contact inputs	STF	Start forward	Applying a signal to terminal STF starts the motor with forward rotation (clockwise).
	STR	Start reverse	Applying a signal to terminal STR starts the motor with reverse rotation (anticlockwise).
	RH, RM, RL	Speed selection	Up to 15 different speeds (output frequencies) can be selected by combining these signals (see also section 6.2.4)
	MRS	Output stop	Applying a signal to this input for more than 20ms switches off the inverter output without delay.
	RES	RESET input	Used to reset the inverter and clear the alarm state after a protective function has been triggered (see section 7.3). A signal must be applied to RES for at least 0.1s to execute a reset.
	SD <sup>①</sup>	Common terminal for control inputs using sink logic	
Analog	PC <sup>①</sup>	24V DC output and common terminal for control inputs using source logic	
	10	Power supply for frequency setting potentiometer	Output 5V DC, max current 10 mA. Recommended potentiometer: 1 kΩ, 2W linear, (multi-potentiometer)
	2	Input for frequency setting voltage signal (0 to 5V or 0 to 10V DC)	A setpoint signal of 0–5V or 0–10V is applied to this terminal. The range is preset to 0–5V. The input resistance is 10 kΩ; the maximum permissible voltage is 20V.
	5	Common terminal for frequency setting signal	Terminal 5 is the common terminal for the analog setting signals connected to terminals 2 and 4. Terminal 5 is isolated and to prevent interference it should not be earthed.
	4	Input for frequency setting current signal (4 to 20mA DC)	If a current signal (0 to 20mA or 4 to 20mA DC) is used as the frequency setting signal it is connected to this terminal. The input resistance is 250 Ω, the maximum permissible current is 30mA. The factory default setting is 0Hz at 4mA and 50Hz at 20mA. Note that a signal must be applied to control input AU at the same time to activate this terminal.

<sup>①</sup> Never connect terminals PC and SD to one another! These terminals are the common terminals for the control inputs when you use source (PC, factory default) or sink logic (SD).

The following illustration shows the connection of the control terminals when source logic (factory default) is used. The inputs are connected to 24V DC.



The manuals of the individual frequency inverters also include diagrams showing the connections for controlling the inverter inputs with PLC outputs and with sink logic.

## 3.3 EM-Compatible Installation

Fast switching of electrical currents and voltages, which naturally also occurs when frequency inverters are used, generates radio frequency interference (RF noise) that can be propagated both along cables and through the air. The power and signal cables of the inverter can act as noise transmission antennas. Because of this the cabling work needs to be performed with the utmost care. The cables connecting the inverter and the motor are a particularly powerful source of potential interference.

In the European Union several EMC (electromagnetic compatibility) directives have been passed with regulations for the limitation of interference generated by variable-speed drive systems. To conform to these regulations you must observe some basic guidelines when you are planning, installing and wiring your systems:

- To reduce noise radiation install the equipment in a closed and properly earthed switchgear cabinet made of metal.
- Install an EMC filter (mains RFI suppression filter).
- Ensure that everything is properly earthed.
- Use shielded cables.
- Install sensitive equipment as far away as possible from interference sources or install the interference sources in a separate switchgear cabinet.
- Keep signal and power cables separate. Avoid routing interference-suppressed cables (e.g. power supply cables) and interference-prone cables (e.g. shielded motor cables) together for more than short distances.

### 3.3.1 EM-Compatible Switchgear Cabinet Installation

The design of the switchgear cabinet is critical for compliance with the EMC directives. Please follow the following guidelines:


- Use an earthed cabinet made of metal.
- Use conductive seals between the cabinet door and chassis and connect the door and the chassis with a thick, braided earth cable.
- If an EMC filter is installed make sure that it has a good electrically conductive connection to the installation panel (remove paint etc). Ensure that the base on which the equipment is installed is also properly connected to the switchgear cabinet earth.
- All cabinet plates should be welded or screwed together not more than 10cm apart to limit transparency to RF noise. The diameters of any openings and cable glands in the cabinet should not exceed 10cm and there should not be any unearthing components anywhere in the cabinet. If larger openings are required they must be covered with wire mesh. Always remove paint etc. between all metal-on-metal contacts to ensure good conductivity – for example between the wire mesh covers and the cabinet.
- If inverters and controllers must be installed in the same cabinet they should be kept as far away from one another as possible. It is better to use separate cabinets if possible. If you must install everything in a single cabinet you can separate the inverters and controllers with a metal panel.
- Earth the installed equipment with short, thick earth conductors or suitable earthing strips. Earthing strips with a large surface area are better for earthing RFI signals than equipotential bonding conductors with large cross-sections.

### 3.3.2 Wiring

All analog and digital signal cables should be shielded or routed in metal cable conduits.

At the entrance point to the chassis run the cable through a metal cable gland or fasten it with a P or U type cable clamp, connecting the shielding to the earth either with the gland or the clamp (see illustration below). If you use a cable clamp install it as near as possible to the cable entry point to keep the distance to the earthing point as short as possible. To keep the unshielded portion of the cable (RFI transmission antenna!) as short as possible ensure that the end of the motor cable shielding is as close as possible to the connection terminal without causing a risk of earth faults or short circuits.

When using a P or U clamp make sure that the clamp is installed cleanly and that it does not pinch the cable more than necessary.



Route control signal cables at least 30cm away from all power cables. Do not route the power supply cables or the cables connecting the frequency inverter and the motor in parallel to control signal cables, telephone cables or data cables.

If possible, all control signal cables to and from the inverter should only be routed inside the earthed switchgear cabinet. If routing control signal cables outside the cabinet is not possible always use shielded cables, as signal cables can also function as antennas. The shielding of the cables must always be earthed. To prevent corruption of sensitive analog signals (e.g. the 0-5V analog frequency setting signal) by currents circulating in the earthing system it may be necessary to earth only one end of the cable shielding. In such cases always earth the shielding at the inverter end of the cable.

Installation of standard ferrite cores on the signal cables can further improve RFI suppression. The cable should be wound around the core several times and the core should be installed as close to the inverter as possible.


Motor connection cables should always be as short as possible. Long cables can sometimes trigger earth fault protection mechanisms. Avoid unnecessarily long cables and always use the shortest possible route for the cables.

It should go without saying that the motor itself should also be properly earthed.


### 3.3.3 EMC Filters

EMC filters (mains RFI suppression filters) significantly reduce interference. They are installed between the mains power supply and the frequency inverter.

#### Installation of a EMC filter for a single-phase power supply




#### Installation of a EMC filter for a 3-phase power supply



#### WARNING:


*These filters are NOT designed for use in IT networks. When in operation these EMC filters discharge leakage currents to earth by design. This can trigger upstream protective devices, in particular in combination with asymmetrical mains voltages, mains phase failures and switching operations upstream from the filter. For more information please refer to the Mitsubishi frequency inverters EMC manual, which contains detailed instructions for EM-compatible installation.*



The EMC filters of the FR-D700 and FR-E700/E700S series are installed beside or behind the inverter, depending on their design. Installing the filter behind the inverter has the advantage that the filter does not take up any additional space in the switchgear cabinet.

The illustration on the left shows the installation of an EMC filter for a series FR-D700 inverter.

The inverters of the FR-F700 and FR-A700 series have an integrated EMC filter, which is activated by default at the factory. The filter can be disabled by moving the EMC on/off connector to the FILTER OFF position. The filter must be deactivated when the inverter is used in isolated neutral networks (IT networks).



The connector must always be installed, either in the ON position or in the OFF position.



**DANGER:**

*To avoid serious shock hazard always turn off the inverter power supply before removing the front cover to activate or deactivate the EMC filter.*

Optional external EMC filters are also available for the inverters of the FR-F700 and FR-A700 series.

# 4 Start-Up

## 4.1 Preparations

### 4.1.1 Before switching on the inverter for the first time

Check all the following points carefully before switching on a frequency inverter for the first time:

- Has all the wiring been performed correctly? Check the power supply connections particularly carefully: Single-phase to L1 and N, 3-phase to L1, L2 and L3.
- Double-check for damaged cables and insufficiently insulated terminals to eliminate any possibility of short circuits.
- Is the inverter properly earthed? Double-check for possible earth faults and short circuits in the output circuit.
- Check that all screws, connection terminals and other cable connections are connected correctly and firmly.

### 4.1.2 Important settings before switching on the motor for the first time

All settings necessary for the operation of the inverter, like acceleration and deceleration times or the trigger threshold for the electronic motor protection relay, are programmed and changed with either the inverter's own integrated control unit or with a connected external control unit.

The following settings must be checked before switching on the motor for the first time:

- Maximum output frequency (parameter 1)
- V/f pattern (parameter 3)
- Acceleration and deceleration times (parameters 7 and 8)

See Chapter 6 for detailed descriptions of these parameters and what they are for. See section 5.5 for examples of parameter settings.



#### WARNING:


*Incorrect parameter settings can damage or (in extreme cases) even destroy the connected motor. Take great care when you are setting the parameters and double-check the electrical and mechanical specifications of the motor, your entire drive system and the connected machine before proceeding.*

## 4.2 Functional Test

For a functional test the inverter is operated with minimum external wiring. The motor should be allowed to run free without any connected load. You need to check whether the connected motor runs properly and that you can adjust its speed with the inverter. There are two ways to perform this test:

- Controlling the inverter with external signals

The commands for starting the motor in forward or reverse mode are activated with external pushbuttons. Motor speed is adjusted with the help of the frequencies stored in parameters 4 through 6 (see section 6.2.4). To do this you can either connect switches to terminals RH, RM and RL of the inverter or connect the appropriate terminals to the PC terminal with a wire jumper.




Some external components like pushbuttons and switches are required for this method but it has advantages over performing the test with the integrated or external control unit:

- When the inverter is switched on for the first time control with external signals is activated by default – you don't need the control unit to switch to this mode.
- In normal operation inverters are also usually operated via external signals, either by activating stored parameter values or by sending external analog setpoint values to the inverter. For example, start commands can be sent by a PLC or executed manually with switches or pushbuttons. Testing the system with external signals enables you to simultaneously test the control inputs for proper functioning.

- Controlling the inverter with the integrated or external control unit

The inverters of the FR-D700, FR-E700/E700SC, FR-F700 and FR-A700 series have an integrated control unit with which you can operate the inverter and the connected motor. This makes it possible to perform the functional test without connecting anything to the control inputs.



Please note that when the inverter is switched on for the first time control via external signals is activated by default. Press the PU/EXT key to select the PU operation mode (see section 5.3).

**NOTE**

Do not switch the motor on and off by turning the frequency inverter's power supply on and off. Repeated switching of the inverter's mains power supply at short intervals can damage the inrush current limiter. Switch the inverter's power supply on first and then control the motor with the forward/reverse commands via terminals STF and STR or with the control unit.

### Performing the test

During the test run pay particular attention to the following points:

- The motor should not generate any unusual noises or vibrations.
- Changing the frequency setting value should change the speed of the motor.
- If a protective function triggers during motor acceleration or deceleration check:
  - Motor load
  - Acceleration and deceleration times (you may need to increase these times with parameters 7 and 8)
  - The manual torque boost setting (parameter 0)

These parameters are described in Chapter 6.




## 5 Operation and Settings

The frequency inverters of the FR-D700, FR-E700/E700SC, FR-F700 and FR-A700 series have integrated control units.



These control units allow you to monitor and display status data and alarms and to enter and display the inverter's setting parameters (see Chapter 6).

In addition to this you can also use the control unit to operate the inverter and the connected motor. This option is particularly useful for setting up the system, troubleshooting and testing.


## 5.1 Operating FR-D700 and FR-E700/E700SC Inverters



## Keys of the operation panel:


Key	Function	Description
	Digital dial	<p>Used to change the frequency setting and parameter values. Press to display the following.</p> <ul style="list-style-type: none"> <li>● Displays the set frequency in the monitor mode</li> <li>● Currently set value is displayed during calibration</li> <li>● Displays the order in the faults history mode</li> </ul>
	Rotation direction	RUN command for forward/reverse rotation. The rotation direction can be selected by setting Pr. 40.
	Stop operation/ Fault reset	<ul style="list-style-type: none"> <li>● Used to stop RUN command.</li> <li>● Fault can be reset when protective function is activated (fault) (refer to section 7.3).</li> </ul>
	Mode switch over	<p>Used to change each setting mode.</p> <ul style="list-style-type: none"> <li>● Pressing PU/EXT simultaneously changes the operation mode.</li> <li>● Pressing for a while (2s) can lock operation.</li> </ul>
	Write settings	If pressed during operation, monitor changes as below:  <pre> graph LR     A[Running frequency] --&gt; B[Output current]     B --&gt; C[Output voltage]     C --&gt; A     </pre>
	Operation mode switch over	<p>Used to switch between the PU and external operation mode. When using the external operation mode (operation using a separately connected frequency setting potentiometer and start signal), press this key to light up the EXT indication. (Press MODE simultaneously (0.5s) or change Pr. 79 setting to change to combined mode.)</p> <p>PU: PU operation mode EXT: External operation mode ( Cancels PU stop also.)</p>

### Overview of the basic functions of the operation panel (factory setting)





## 5.2 Operating FR-F700 and FR-A700 Inverters


The frequency inverters of the FR-F700 and FR-A700 series come with an integrated FR-DU07 control unit.



## Functions of the FR-DU07 control unit:

Control / Key	Function	Description
	Digital Dial	The Digital Dial is a little like a setting potentiometer. It can be turned in both directions to set frequencies, parameters and other values. It also has a pushbutton function. Pressing the Digital Dial stores the current frequency setting value.
	Forward	Starts the motor forward
	Reverse	Starts the motor in reverse
	Mode	Switches the setting mode
	Parameter Settings	Changes the status values displayed while the drive is running: 
	Operation Mode	PU: Control unit operation mode EXT: External signals operation mode This key switches between control via external signals and operation with the control unit. To switch to external mode (setting signals via external potentiometer and external start signal) press and hold the key until the EXT indicator LED lights up. This combined mode is enabled with parameter 79.
	Stop Motor / Reset Inverter	When you are operating the inverter with the control unit you can stop the motor by pressing this key. It is also used to reset the inverter after an error message (see section 7.3).

## FR-DU07 control unit functions



## 5.3 Operating Mode Selection

Frequency inverters can be operated either with external signals (switches, PLC outputs, external setpoint value sources etc.) or directly via the control unit. The mode is controlled with parameter 79 (see section 6.2.7).

**NOTE**

You can only switch the operating mode when the drive is stopped and no start command is active.

You can switch between external and parameter unit (PU) modes by pressing the PU/EXT key on the parameter unit. The PU indicator lights up when the inverter is in parameter unit mode.



Pressing PU/EXT when the inverter is in control unit mode switches the system to external operation mode and the EXT indicator lights up.

## 5.4 Setting the Frequency and Starting the Motor

When external control signals are not used you can only start, stop and change the speed of the external motor with the control unit.

FR-D700

Procedure on FR-D700 and FR-E700/E700SC inverters

FR-E700

Performing operation at 30Hz

## Operation

Screen at powering on  
The monitor display appears.

Press the PU/EXT key to choose the PU operation mode.

Turn the digital dial to show the frequency you want to set. The frequency flickers for about 5s.

While the value is flickering press the SET key to set the frequency. (If you do not press the SET key, the value flickers for about 5s and the display returns to 0.00 (display) Hz. At this time, set the frequency again as described above.)

After the value flickered for about 3s, the display returns to 0.00 (monitor display). Press the RUN key to start operation.

Press the STOP/RESET key to stop.

Press the digital dial to show the set frequency.

## Inverter display




PU indication is lit.



Flickers for about 5s.



Flicker ... Frequency setting complete!



3s later



**FR-F700****Procedure on FR-F700 and FR-A700 inverters****FR-A700**

Example of drive operation at a 30Hz output frequency.

**Operation**

When you switch on the inverter the standard startup display appears.

Press the PU/EXT key to select PU (control unit) mode.

Turn the digital dial to set the output frequency to 30Hz. The value in the display will blink for around 5 seconds.


Press the SET key while the frequency display is still blinking. (If you don't press SET within 5s the display will reset to 0.00. If this happens just set the output frequency again as described above.)

After 3 seconds the display then switches to 0.00 (Monitor mode). Now press FWD or REV to start the motor.

To stop the motor press STOP/RESET.

**Inverter display**

Flicker ... Frequency setting complete!



While the motor is running you can display the current setting frequency by pressing the Digital Dial.

**NOTES****Troubleshooting tips**

If you cannot set the frequency or if you are unable to start the motor with the integrated or external control unit please go through the following checklist:

- Is the inverter in control unit operation mode? The PU indicator LED should be on.

Check parameter 79 and make sure that it is set to "0". This is the default factory setting, which allows the inverter to be switched between external control and control unit mode with the PU/EXT key on the control unit.

- Are all external start commands inactive?

- Did you press the SET key within 5 seconds of setting the frequency?

If you don't press SET during this time (while the display is blinking) the output frequency setting value will not be stored.

## 5.5 Editing Parameter Settings

All the settings for the operation of frequency inverters are stored in editable parameters. You can find a detailed reference to the most important parameters in Chapter 6. All the parameters are preset to default values when the inverter leaves the factory. You can edit parameters on the integrated control unit or the external control unit to configure the inverter for the connected motor and your application.

Note that editing parameters is only possible when the inverter is in control unit operation mode (PU) or combined mode and when no motor start (FWD or REV) command is active.

### FR-D700

### Procedure on the FR-D700 and FR-E700/E700SC

### FR-E700

Change the Pr. 1 “Maximum frequency” setting from 120Hz to 50Hz (refer to section 6.2.2 for details on Parameter 1).

#### Operation

Screen at powering on  
The monitor display appears.

Press the PU/EXT key to choose the PU operation mode.

Press the MODE key to choose the parameter setting mode.

Turn the digital dial until P.1 (Pr. 1) appears.

Press the SET key to show the currently set value. The initial value “120.0” appears.

Turn the digital dial counter clockwise to change it to the setting value of “50.00”.

Press the SET key to set.

#### Inverter display



The parameter number read previously appears.



Flicker ... Parameter setting complete!

**FR-F700****Procedure on FR-F700 and FR-A700 inverters****FR-A700**

The following example shows how to change the maximum output frequency (refer to section 6.2.2 for details on Parameter 1) from 120Hz to 50Hz.

**Operation**

When you switch on the inverter the standard startup display appears.

**Inverter display**

Press the PU/EXT key to select PU (control unit) mode.



PU indication is lit.

Press MODE to activate the parameter setting mode.



The parameter number read previously appears.

Turn the Digital Dial to select parameter no. 1.



Press SET to display the current setting. The factory default setting is "120".



Turn the Digital Dial to change the value to "50".



Press SET to save the new setting.



Flicker ... Parameter setting complete!

You can then turn the Digital Dial to select other parameters.

You can check the setting by pressing the SET key again once to display the current value.

Pressing the SET key twice selects the next parameter.

# 6 Parameter

For optimum operation you need to configure your frequency inverter for the specific requirements and specifications of the connected drive system and your application. All the necessary settings are stored in numbered **parameters** in the inverter's memory – you only have to set them once because this memory is not cleared when the power is switched off. All the parameters are preset to default values when the inverter leaves the factory so that the unit can be used at once.

There are two main classes of parameters, basic parameters and advanced parameters. The basic parameters should always be checked and configured before using the inverter but many of the more advanced parameters are only needed for special or complex applications.



## WARNING:

***Incorrect parameter settings can damage or (in extreme cases) even destroy the connected motor. Take great care when you are setting the parameters and double-check the electrical and mechanical specifications of the motor, your entire drive system and the connected machine before proceeding.***

## 6.1 Basic Parameters

### The basic parameters of the FR-D700 and FR-E700/E700SC inverters

Parameter	Name	FR-D700		FR-E700/E700SC	
		Setting Range	Initial Value	Setting Range	Initial Value
0	Torque boost	0–30%	3%/4%/6% <sup>①</sup>	0–30%	2%/3%/4%/6% <sup>①</sup>
1	Maximum frequency	0–120Hz	120Hz	0–120Hz	120Hz
2	Minimum frequency	0–120Hz	0Hz	0–120Hz	0Hz
3	Base frequency	0–400Hz	50Hz	0–400Hz	50Hz
4	Multi-speed setting (high speed) - RH	0–400Hz	50Hz	0–400Hz	50Hz
5	Multi-speed setting (medium speed) - RM	0–400Hz	30Hz	0–400Hz	30Hz
6	Multi-speed setting (low speed) - RL	0–400Hz	10Hz	0–400Hz	10Hz
7	Acceleration time	0–3600s	5s/10s <sup>①</sup>	0–3600s	5s/10s/15s <sup>①</sup>
8	Deceleration time	0–3600s	5s/10s <sup>①</sup>	0–360s 0–3600s	5s/10s/15s <sup>①</sup>
9	Electronic thermal O/L relay	0–500A	Rated current	0–500A	Rated current
19	Base frequency voltage	0–1000V 8888 <sup>②</sup> 9999 <sup>③</sup>	8888	0–1000V 8888 <sup>②</sup> 9999 <sup>③</sup>	8888
20	Acceleration/ deceleration reference frequency	1–400 Hz	50Hz	1–400Hz	50Hz
79	Operation mode selection	0–4/6/7	0	0–4/6/7	0

<sup>①</sup> The setting depends on the inverter capacity.

<sup>②</sup> With the setting “8888” the maximum output voltage is 95 % of the input voltage.

<sup>③</sup> With the setting “9999” the maximum output voltage equals the input voltage.

**Basic parameters of the FR-F700 and FR-A700 inverters**

Parameter	Name	FR-F700		FR-A700	
		Setting Range	Initial Value	Setting Range	Initial Value
0	Torque boost	0–30%	1%/1.5%/2%/ 3%/4%/6% <sup>①</sup>	0–30%	1%/2%/3%/ 4%/6% <sup>①</sup>
1	Maximum frequency	0–120Hz	60Hz / 120Hz <sup>①</sup>	0–120Hz	60Hz/120Hz <sup>①</sup>
2	Minimum frequency	0–120Hz	0Hz	0–120Hz	0Hz
3	Base frequency	0–400Hz	50Hz	0–400Hz	50Hz
4	Multi-speed setting (high speed) - RH	0–400Hz	50Hz	0–400Hz	50Hz
5	Multi-speed setting (medium speed) - RM	0–400Hz	30Hz	0–400Hz	30Hz
6	Multi-speed setting (low speed) - RL	0–400Hz	10Hz	0–400Hz	10Hz
7	Acceleration time	0–360s 0–3600s	5s or 15s <sup>①</sup>	0–360s 0–3600s	5s or 15s <sup>①</sup>
8	Deceleration time	0–360s 0–3600s	10s or 30s <sup>①</sup>	0–360s 0–3600s	5s or 15s <sup>①</sup>
9	Electronic thermal O/L relay	0–500A 0–3600A	Rated current	0–500A 0–3600A	Rated current
19	Base frequency voltage	0–1000V 8888 <sup>②</sup> 9999 <sup>③</sup>	8888	0–1000V 8888 <sup>②</sup> 9999 <sup>③</sup>	8888
20	Acceleration/ deceleration reference frequency	1–400Hz	50Hz	1–400Hz	50Hz
79	Operation mode selection	0–4/6/7	0	0–4/6/7	0

① The setting depends on the inverter capacity.

② With the setting "8888" the maximum output voltage is 95 % of the input voltage.

③ With the setting "9999" the maximum output voltage equals the input voltage.


**NOTE**

You can find a reference list of all inverter parameters in the Appendix (section A.1).

## 6.2 The Basic Parameters in Detail

### 6.2.1 Torque Boost (Parameter 0)

Parameter 0 enables you to increase the output voltage at low output frequencies, which increases the motor's torque. This function is useful in applications when you need high start-up torque at low speeds.




You can use parameter 0 to achieve better performance for starting the motor under load. The base frequency is set in parameter 3.

### 6.2.2 Minimum/Maximum Output Frequency (Parameters 1 and 2)

The minimum and maximum output frequencies define the range within which the motor speed can be adjusted with the frequency setting value.


You can use these two parameters to adjust the frequency setting range to match the mechanical specifications of the connected system. For example, in many applications it is not desirable or possible to allow the drive to stop completely at the minimum setpoint value (output frequency = 0Hz). At the other end of the scale you will often want to limit the maximum output frequency, and thus the motor speed, so that you don't overstress the machine mechanically or exceed a maximum permitted speed.



### 6.2.3 Base Frequency (Parameter 3)

The setting of parameter 3 is very important because it matches the frequency inverter's output to the requirements of the motor.

Parameter 3 specifies the output frequency at which the output voltage is set to its maximum value. This is normally set to the rated frequency of the motor, which can be found on the motor's rating plate. Be careful with this parameter – incorrect settings can cause overload states and lead to automatic shutdown of the inverter.




Parameter 3 defines the ratio between the output voltage and the output frequency (V/f pattern).

You can set the inverter's maximum output voltage with parameter 19, which should be set to the maximum output voltage allowed for the motor (this can be found on the motor's rating plate).

### 6.2.4 Multi-speed Settings (Parameters 4 to 6)

A limited number of preset speeds is quite adequate for many applications. This can be achieved without the need for analog setpoint signals. Instead, you enter fixed setpoint values in these parameters and activate them with ON/OFF signals applied to the inverter's terminals.

All the inverters described in this guide allow selection of up to 15 frequency setpoint values (corresponding to 15 speeds) via terminals RH, RM, RL and REX. The inverter must be in external operation mode for this to be possible, of course.




Example for connection of the inverter's RH, RM, RL and REX terminals.


The frequency (speed) settings can be selected with relay output signals from a programmable logic controller (PLC).

The first three frequency settings are entered in parameters 4 through 6. Further fixed speed settings (4 – 16) can be stored in additional parameters. See your frequency inverter's documentation for further details.

As the graphic below shows, you can select up to seven frequency setpoint values by applying combinations of signals to terminals RH, RM and RL. The first three values are selected with single terminals, the remaining values with combinations.



Eight additional frequency settings (8 through 15) can be achieved by using the REX terminal as well:



Important information for using preset frequency settings (speeds):


- If only parameters 4, 5 and 6 are used for speed settings the terminals have the following automatic priority if two speeds are accidentally selected at the same time: RL before RM and RM before RH.
- You can also change the parameter values while the inverter is operating.

## 6.2.5

## Acceleration and Deceleration Times (Parameters 7 and 8)

One of the big advantages of frequency inverters is that they can accelerate and slow down the connected motor gradually. Electric motors connected directly to the mains power accelerate up to their maximum speed very rapidly; this is often not desirable, particularly for machines with delicate mechanical parts.

Parameters 7 and 8 allow you to adjust the acceleration and deceleration times. The parameter value defines the acceleration or deceleration period. This means that the speed change per unit of time gets smaller as you increase the value.



Parameter 7 sets the acceleration time for the drive. The value defines the time in seconds in which the drive will be accelerated up from 0 Hz to the frequency preset in parameter 20.

Parameter 8 sets the deceleration time, which is the time in seconds in which the drive will be slowed down to 0 Hz from the frequency preset in parameter 20.

## 6.2.6

## Electronic Thermal Overload Relay (Parameter 9)

Mitsubishi's frequency inverters have an internal electronic thermal overload relay to protect the motor. The motor's frequency and current are monitored in relation to its rated current and if the values rise too high the protection function is activated. This function serves primarily to protect the motor against overheating during operation at low speeds and high torques. The reduced cooling function of the motor's fan at low speeds and other factors are also taken into account.

Enter the motor's rated current in parameter 9. You can find this value on the motor's rating plate.

You can deactivate the thermal overload relay by setting parameter 9 to "0" (for example if you are using an external motor protection device or if multiple motors are connected to the inverter). Deactivating the relay will not turn off the overload protection feature for the frequency inverter's own transistors.

## 6.2.7

**Operation Mode Selection (Parameter 79)**

Parameter 79 sets the operation mode of the frequency inverter. You can set it for operation via external signals, an integrated or external control unit (PU mode), a combination of external signals and PU mode or via a network connection.

- Select external operation mode if you want to control the inverter primarily with signals applied to the control terminals, for example with potentiometers and switches or with a PLC.
- Select PU mode if you want to start the motor and set the speed via the internal or external control unit or via the PU interface.
- Select network mode (NET) for operation via RS-485 communication or an optional communication module (except FR-D700).

Parameter 79	Description		
0	At power on, the inverter is places in the external operation mode. Use the key on the control unit to switch between external control and control from the control unit. (Details of this modes are described in this table for the settings "1" and "2".)		
1	<b>Operation Mode</b>	<b>Setting of the output frequency</b>	<b>Start signal</b>
	Control unit mode	With control unit	RUN (FWD, REV) key of the control unit
2	External control mode	External signal input (e.g. terminals 2 (4)-5, multi-speed setting)	External signal input (terminal STF or STR)
3	Combined mode 1	With control unit or external signal input (e.g. terminals 2 (4)-5, multi-speed setting)	External signal input (terminal STF or STR)
4	Combined mode 2	External signal input (e.g. terminals 2 (4)-5, multi-speed setting)	RUN (FWD, REV) key of the control unit
6	Switch-over mode Switch among parameter unit, external control and control via a network while keeping the same operation status.		
7	External control (Enable/Disable switch-over to the parameter unit mode ) X12 signal ON: Operation mode can be switched to the parameter unit mode (output stop during external control) X12 signal OFF: Operation mode can not be switched to the parameter unit mode		

**HINWEIS**

You must also set the appropriate parameters to assign signal X12 to an input terminal on the inverter. See the documentation of your inverter for details.

**Mode 0 (external operation, switchable to control unit)****Mode 2 (external operation, non-switchable)**

When parameter 79 is set to "0" or "2" external operation mode is activated when the power supply is switched on. It is not generally possible to adjust parameters while the unit is in this mode.

If you do not often need to adjust parameters you can prevent switching to control unit mode by setting parameter 79 to "2".

However, if you often need to change parameter settings you should set parameter 79 to "0" so that you can switch back to control unit mode (PU mode) by pressing PU/EXT on the internal or external control unit. Parameters can be entered and edited in PU mode. When you have finished making your settings you can then press PU/EXT again to switch back to external mode.

When the inverter is in external mode start commands are executed with signals applied to terminals STF (forward) and STR (reverse). The frequency/speed can be set with an analog signal (current or voltage) or by selecting preset speed settings on terminals RH, RM and RL.

**Operation mode 1 (PU – control unit mode)**

When parameter 79 is set to "1" the inverter switches to control unit mode when it is powered up and it can be operated with the keys on the integrated control unit or the external control unit.

When mode 1 is set it is not possible to switch the operating mode by pressing the PU/EXT key.

**Operation mode 3 (combined mode 1)**

Select this combined mode when you want to set the speed frequency with the control unit (Digital Dial) and use the external terminals for the motor start signals.

You cannot switch the operating mode with the PU/EXT key in this mode.

You can also use external signals to set the speed. If an external speed setting signal is used it has higher priority than the frequency setting on the control unit.

**Mode 4 (combined mode 2)**

Select this combined mode when you want to activate the start signals with the control unit and set the speed frequency with an external potentiometer or the speed setting parameters.

Here too, you cannot switch modes with the PU/EXT key.

# 7 Protective and Diagnostics Functions

The Mitsubishi Electric inverters of the FR-D700, FR-E700/E700SC, FR-F700 and FR-A700 series have many functions that protect both the inverter itself and the connected motor against damage when errors occur. If a serious error triggers a protective function the inverter output is turned off, the motor coasts to a stop and an error code is displayed on the control unit. It is then usually easy to localise the cause of the problem with the help of the error code and the troubleshooting information in the inverter documentation. Further assistance is always available from Mitsubishi Electric service if necessary.

Please note the following important points for dealing with error codes:

- Power is needed to store error codes

Error codes can only be output after an error occurs if the inverter's power supply remains on. For example, if the power is switched on by a contactor that trips when a protective function activates the error codes cannot be stored and will be lost.

- Error code display

When a protective function activates the appropriate error code is automatically displayed on the control unit.

- Resetting after activation of protective functions

When a critical protective function activates the inverter's power output is disabled, cutting off the power to the connected motor, which then coasts to a halt. The inverter cannot be restarted until the protective functions have been reset with a RESET command.

When an error occurs you should always first localise and correct the cause. Only reset the inverter and continue normal operation when you are sure that the problem has been resolved.

The error codes that can be displayed can be divided into four basic categories:

- Error messages

Error messages are normally caused by operator or configuration errors. These codes do **not** disable the inverter's power output.

- Warnings

Warnings also do not disable inverter's power output – here too, the motor continues to run. However, if you ignore a warning and fail to correct the cause it can lead to a critical error.

- Minor errors

Minor errors do **not** disable the inverter output.

- Critical errors

Critical errors are errors that activate the inverter's protective functions, which include disabling the power output and switching off the connected motor.

## 7.1 Troubleshooting

When an error occurs or you experience some other problem with operation you can often diagnose the cause from the behaviour of the motor and/or the inverter.

Error	Possible cause	Check points / Remedy
Motor does not rotate as commanded.	Main circuit or motor are not connected properly.	Are the terminals L1 and N (or L1, L3 and L3) connected properly? Is the proper power supply voltage applied? Are the terminals U, V and W wired properly? Check that the jumper across P1 and P/+ resp. P1 and + is connected.
	Missing or wrong input signals	Check that the start signal is input. Check that both the forward and reverse rotation start signals are not input simultaneously. Check that the frequency setting signal is not zero. Check that the AU signal is on when the frequency setting signal is 4 to 20mA. Check that the output stop signal (MRS) or reset signal (RES) is not on.
		Check that the sink or source jumper connector is fitted securely.
		Check that the setting of Pr. 79 is correct. Check that frequency settings of each running frequency (such as multi-speed operation or Pr. 1) are not zero.
		Check that the load is not too heavy. Check that the shaft is not locked.
	Other	Is a error message displayed (e. g. OC1)?
	Motor rotates in opposite direction	Wrong phase sequence Check that the phase sequence of output terminals U, V and W is correct.
		Start signal Check that the start signals (forward rotation, reverse rotation) are connected properly.
		Incorrect rotation signal
Speed greatly differs from the setting	Frequency setting signal	Check that the frequency setting signal is correct. (Measure the input signal level.)
	Incorrect parameter settings	Check the setting of the parameters 1, 2, and 19.
	External noise	Check that the input signal lines are not affected by external noise. (Use shielded cables)
	Load	Check that the load is not too heavy.
Acceleration/deceleration is not smooth	Incorrect settings for acceleration/deceleration time	Check that the acceleration and deceleration time settings are not too short (Pr. 7 and 8). Increase this values.
	Load	Check that the load is not too heavy.
	Torque boost	Check that the torque boost setting is not too large to activate the stall function.
Motor current is large	Load	Check that the load is not too heavy.
	Torque boost	Check that the Pr. 0 Torque boost setting is appropriate.
Speed does not increase	Maximum frequency	Check that the maximum frequency (Pr. 1) setting is correct.
	Load	Check that the load is not too heavy.
	Torque boost	Check that the torque boost setting is not too large to activate the stall function.

Error	Possible cause	Check points / Remedy
Speed varies during operation	Load	Check that the load is not varying.
	Input signals	Check that the frequency setting signal is not varying.
		Check that the frequency setting signal is not affected by noise.
	Other	Check for a malfunction due to undesirable currents when the transistor output unit is connected.
Operation mode is not changed properly	Start signal is ON	Check that the STF or STR signal is OFF. When it is on, the operation mode cannot be changed.
	Parameter setting	Check the Pr. 79 setting. When the Pr. 79 setting is "0" (initial value), the inverter is placed in the external operation mode at input power-on. Use the PU/EXT key to switch to the control unit mode. For a description of the operation mode selection please refer to 6.2.7.
Operation panel display is not operating	Connection between terminals PC and SD	The terminals PC and SD must not be connected.
	Jumper across P1 and P/+ resp. +	Check that the jumper across P1 and P/+ resp. P1 and + is connected.
Parameter write cannot be performed	Start signal is ON	Make sure that operation is not being performed (signal STF or STR is not ON).
	SET key (WRITE key)	Press the SET key (parameter unit FR-DU07) respectively the WRITE key (parameter unit FR-PU04/FR-PU07) to save the parameter settings.
	Parameter setting	Check that the parameter settings are inside the setting ranges.
		Make sure that you are not attempting to set the parameter in the external operation mode (Pr. 79, section 6.2.7).
Motor generates abnormal noise	Parameter setting	Check that the deceleration time is not too short (Pr. 8).

## 7.2 List of Alarm Displays

Classification	Inverter Display					Meaning
	FR-D700	FR-E700/ E700SC	FR-F700	FR-A700	Plaintext	
Error messages	<i>E---</i>	<i>E---</i>	<i>E---</i>	<i>E---</i>	E---	Faults history
	<i>HOLD</i>	<i>HOLD</i>	<i>HOLD</i>	<i>HOLD</i>	HOLD	Operation panel lock
	<i>LOCd</i>	—	—	—	LOCd	Password locked
	<i>Er 1</i>	<i>Er 1</i>	<i>Er 1</i>	<i>Er 1</i>	ER1 ER2 ER3 ER4	Parameter write error
	<i>Er 2</i>	<i>Er 2</i>	<i>Er 2</i>	<i>Er 2</i>		
	<i>Er 3</i>	<i>Er 3</i>	<i>Er 3</i>	<i>Er 3</i>		
	<i>Er 4</i>	<i>Er 4</i>	<i>Er 4</i>	<i>Er 4</i>		
	—	—	<i>rE 1</i>	<i>rE 1</i>	rE1 rE2 rE3 rE2	Copy operation error
	—	—	<i>rE 2</i>	<i>rE 2</i>		
	—	—	<i>rE 3</i>	<i>rE 3</i>		
	—	—	<i>rE 4</i>	<i>rE 4</i>		
	<i>Err.</i>	<i>Err.</i>	<i>Err.</i>	<i>Err.</i>	Err.	Error (e. g. incorrect parameter)
Warnings	<i>OL</i>	<i>OL</i>	<i>OL</i>	<i>OL</i>	OL	Stall prevention (overcurrent)
	<i>oL</i>	<i>oL</i>	<i>oL</i>	<i>oL</i>	oL	Stall prevention (overvoltage)
	<i>rb</i>	<i>rb</i>	<i>rb</i>	<i>rb</i>	RB	Regenerative brake prealarm
	<i>TH</i>	<i>TH</i>	<i>TH</i>	<i>TH</i>	TH	Electronic thermal relay function prealarm
	<i>PS</i>	<i>PS</i>	<i>PS</i>	<i>PS</i>	PS	Inverter has been stopped from PU
	<i>MT</i>	<i>MT</i>	<i>MT</i>	<i>MT</i>	MT	Maintenance signal output
	—	—	<i>CP</i>	<i>CP</i>	CP	Parameter copy
	—	—	—	<i>SL</i>	SL	Speed limit indication (Output during speed limit)
	<i>SA</i>	<i>SA</i> <sup>①</sup>	—	—	SA	Safety stop
	<i>Fn</i>	<i>Fn</i>	<i>Fn</i>	<i>Fn</i>	FN	Fan fault

Classification	Inverter Display					Meaning
	FR-D700	FR-E700/ E700SC	FR-F700	FR-A700	Plaintext	
Critical error	<i>E.OC 1</i>	<i>E.OC 1</i>	<i>E.OC 1</i>	<i>E.OC 1</i>	E.OC1	Overcurrent shut-off during acceleration
	<i>E.OC 2</i>	<i>E.OC 2</i>	<i>E.OC 2</i>	<i>E.OC 2</i>	E.OC2	Overcurrent shut-off during constant speed
	<i>E.OC 3</i>	<i>E.OC 3</i>	<i>E.OC 3</i>	<i>E.OC 3</i>	E.OC3	Overcurrent shut-off during deceleration or stop
	<i>E.Ov 1</i>	<i>E.Ov 1</i>	<i>E.Ov 1</i>	<i>E.Ov 1</i>	E.OV1	Regenerative overvoltage shut-off during acceleration
	<i>E.Ov 2</i>	<i>E.Ov 2</i>	<i>E.Ov 2</i>	<i>E.Ov 2</i>	E.OV2	Regenerative overvoltage shut-off during constant speed
	<i>E.Ov 3</i>	<i>E.Ov 3</i>	<i>E.Ov 3</i>	<i>E.Ov 3</i>	E.OV3	Regenerative overvoltage shut-off during deceleration or stop
	<i>E.THR</i>	<i>E.THR</i>	<i>E.THR</i>	<i>E.THR</i>	E.THT	Inverter overload shut-off (electronic thermal relay function)
	<i>E.THO</i>	<i>E.THO</i>	<i>E.THO</i>	<i>E.THO</i>	E.THM	Motor overload shut-off (electronic thermal relay function)
	<i>E.FI n</i>	<i>E.FI n</i>	<i>E.FI n</i>	<i>E.FI n</i>	E.FIN	Fin overheat
	—	—	<i>E.I PF</i>	<i>E.I PF</i>	E.IPF	Instantaneous power failure
	<i>E.I LF</i>	<i>E.I LF</i>	<i>E.I LF</i>	<i>E.I LF</i>	E.ILF	Input phase failure
	<i>E.OLF</i>	<i>E.OLF</i>	<i>E.OLF</i>	<i>E.OLF</i>	E.OLT	Stall prevention
	<i>E. bE</i>	<i>E. bE</i>	<i>E. bE</i>	<i>E. bE</i>	E.BE	Brake transistor alarm detection
	<i>Uu</i>	<i>Uu</i>	<i>E.UuF</i>	<i>E.UuF</i>	E.UVT	Undervoltage
	<i>E. GF</i>	<i>E. GF</i>	<i>E. GF</i>	<i>E. GF</i>	E.GF	Output side earth (ground) fault overcurrent
	<i>E. LF</i>	<i>E. LF</i>	<i>E. LF</i>	<i>E. LF</i>	E.LF	Output phase failure
	<i>E.OHT</i>	<i>E.OHT</i>	<i>E.OHT</i>	<i>E.OHT</i>	E.OHT	External thermal relay operation
	<i>E.PTC</i>	—	<i>E.PTC</i>	<i>E.PTC</i>	E.PTC	PTC thermistor operation
	—	—	<i>E.OPr</i>	<i>E.OPr</i>	E.OPT	Option alarm
	—	<i>E.OP 1</i>	<i>E.OP 1</i>	—	E.OP1	Communication option alarm
	—	—	—	<i>E.OP 3</i>	E.OP3	
CPU error	—	<i>E. 1</i>	<i>E. 1</i>	<i>E. 1</i>	E.1	Option alarm (e. g. connection error)
	—	<i>E. 2</i>	<i>E. 2</i>	<i>E. 2</i>	E.2	
	—	<i>E. 3</i>	<i>E. 3</i>	<i>E. 3</i>	E.3	
	<i>E.CPU</i>	<i>E. 5</i>	<i>E. 5</i>	<i>E. 5</i>	E.5	CPU error
	<i>E.CPU</i>	<i>E. 6</i>	<i>E. 6</i>	<i>E. 6</i>	E.6	
CPU error	<i>E.CPU</i>	<i>E. 7</i>	<i>E. 7</i>	<i>E. 7</i>	E.7	
	<i>E.CPU</i>	<i>E.CPU</i>	<i>E.CPU</i>	<i>E.CPU</i>	E.CPU	
	—	—	—	<i>E. 11</i>	E.11	Opposite rotation deceleration error
Parameter storage device alarm	—	<i>E. 13</i>	<i>E. 13</i>	<i>E. 13</i>	E.13	Internal circuit error
	<i>E. PE</i>	<i>E. PE</i>	<i>E. PE</i>	<i>E. PE</i>	E.PE	Parameter storage device alarm

Classification	Inverter Display					Meaning
	FR-D700	FR-E700/ E700SC	FR-F700	FR-A700	Plaintext	
Critical error	—	E.PE2	E.PE2	E.PE2	E.PE2	Parameter storage device alarm
	E.PUE	E.PUE	E.PUE	E.PUE	E.PUE	PU disconnection
	—	—	E.CTE	E.CTE	E.CTE	<ul style="list-style-type: none"> <li>Operation panel power supply short circuit</li> <li>RS-485 terminal power supply short circuit</li> </ul>
	E.RET	E.RET	E.RET	E.RET	E.RET	Retry count excess
	—	—	E.P24	E.P24	E.P24	24 V DC power output short circuit
	E.Cd0	—	E.Cd0	E.Cd0	E.CDO	Output current detection value exceeded
	E.I.OH	E.I.OH	E.I.OH	E.I.OH	E.IOH	Inrush current limit circuit alarm
	—	—	E.SEr	E.SEr	E.SER	Communication error (inverter)
	E.AIE	E.AIE	E.AIE	E.AIE	E.AIE	Analog input error
	E.SAF	—	—	—	E.SAF	Safety circuit fault
	—	—	E.PId	—	E.PID	PID signal fault
	—	—	—	E.05	E.OS	Overspeed occurrence
	—	—	—	E.05d	E.OSD	Speed deviation excess detection
	—	—	—	E.ECT	E.ECT	Signal loss detection
	—	—	—	E.0d	E.OD	Excessive position error
	—	E.0b4 to E.0b7	—	E.0b1 to E.0b7	E.MB1/4 to E.MB7	Brake sequence error
	—	—	—	E.EP	E.EP	Encoder phase error
	—	E.USb	—	E.USb	E.USB	USB communication error

① For FR-E700SC only, not available for standard control circuit terminal model FR-E700.

## 7.3 Resetting the Inverter (Reset)

After you have located and corrected the cause of a shutdown you need to reset the inverter so that normal operation can continue. In addition to clearing the error history, executing a RESET also clears the stored record of the number of restart attempts and the stored values registered for the electronic thermal overload relay.


Up to three different ways to reset the inverter are available:

- Reset by pressing a key on the integrated or external control unit.

After a serious error or triggering of a protective function you can reset the inverter by pressing the STOP/RESET key.

- Reset by switching the power supply to the inverter off and on again.
- Reset with an external RESET-Signal

You can reset by **briefly** (but at least 0.1s) connecting terminals RES and SD (negative switching logic) or RES and PC (positive logic). Never make a permanent connection between the RES terminal and the SD or PC terminal!



This example shows how to wire the RES terminal for positive logic.

Instead of a pushbutton you can also use a contactor controlled by PLC (programmable logic controller).



# A Appendix

## A.1 Parameter List

This reference section lists all the parameters supported in each series of Mitsubishi Electric inverters. Please see the documentation of your inverter for more detailed descriptions of each parameter.

### A.1.1 FR-D700

Parameter	Name	Setting Range	Initial Value	Parameter	Name	Setting Range	Initial Value
0	Torque boost	0–30%	6/4/3% <sup>①</sup>	24-27	Multi-speed setting (speed 4 to speed 7)	0–400Hz/9999	9999
1	Maximum frequency	0–120Hz	120Hz	29	Acceleration/deceleration pattern selection	0/1/2	0
2	Minimum frequency	0–120Hz	0Hz	30	Regenerative function selection	0/1/2	0
3	Base frequency	0–400Hz	50Hz	31	Frequency jump 1A	0–400Hz/9999	9999
4	Multi-speed setting (high speed) - RH	0–400Hz	50Hz	32	Frequency jump 1B	0–400Hz/9999	9999
5	Multi-speed setting (middle speed) - RM	0–400Hz	30Hz	33	Frequency jump 2A	0–400Hz/9999	9999
6	Multi-speed setting (low speed) - RL	0–400Hz	10Hz	34	Frequency jump 2B	0–400Hz/9999	9999
7	Acceleration time	0–3600s	5s/10s <sup>①</sup>	35	Frequency jump 3A	0–400Hz/9999	9999
8	Deceleration time	0–3600s	5s/10s <sup>①</sup>	36	Frequency jump 3B	0–400Hz/9999	9999
9	Electronic thermal O/L relay	0–500A	Rated current	37	Speed display	0/0.01–9998	0
10	DC injection brake operation frequency	0–120Hz	3Hz	40	RUN key rotation direction selection	0/1	0
11	DC injection brake operation time	0–10s	0.5s	41	Up-to-frequency sensitivity	0–100%	10%
12	DC injection brake operation voltage	0–30%	6/4% <sup>①</sup>	42	Output frequency detection	0–400Hz	6Hz
13	Starting frequency	0–60Hz	0.5Hz	43	Output frequency detection for reverse rotation	0–400Hz/9999	9999
14	Load pattern selection	0/1/2/3	0	44	Second acceleration/deceleration time	0–3600s	5s/10s <sup>①</sup>
15	Jog frequency	0–400Hz	5Hz	45	Second deceleration time	0–3600s/9999	9999
16	Jog acceleration/deceleration time	0–3600s	0.5s	46	Second torque boost	0–30%/9999	9999
17	MRS input selection	0/2/4	0	47	Second V/F (base frequency)	0–400Hz/9999	9999
18	High speed maximum frequency	120–400Hz	120Hz	48	Second stall prevention operation current	0.1–200%/9999	9999
19	Base frequency voltage	0–1000V/8888 <sup>②</sup> /9999 <sup>③</sup>	8888	51	Second electronic thermal O/L relay	0–500A, 9999	9999
20	Acceleration/deceleration reference frequency	1–400Hz	50Hz	52	DU/PU main display data selection	0/5/8–12/14/20/23–25/52–55/61/62/64/100	0
22	Stall prevention operation level	0–200%	150%	55	Frequency monitoring reference	0–400Hz	50Hz
23	Stall prevention operation level compensation factor at double speed	0–200%/9999	9999	56	Current monitoring reference	0–500A	Rated current

Parameter	Name	Setting Range	Initial Value
57	Restart coasting time	0, 0.1–5s/9999 <sup>①</sup>	9999
58	Restart cushion time	0–60s	1s
59	Remote function selection	0/1/2/3	0
60	Energy saving control selection	0/9	0
65	Retry selection	0–5	0
66	Stall prevention operation reduction starting frequency	0–400Hz	50Hz
67	Number of retries at fault occurrence	0–10/101–110	0
68	Retry waiting time	0.1–600s	1s
69	Retry count display erase	0	0
70	Special regenerative brake duty	0–30%	0%
71	Applied motor	0/1/3/13/23/40/43/50/53	0
72	PWM frequency selection	0–15	1
73	Analog input selection	0/1/10/11	1
74	Input filter time constant	0–8	1
75	Reset selection/disconnected PU detection/PU stop selection	0–3/14–17	14
77	Parameter write selection	0/1/2	0
78	Reverse rotation prevention selection	0/1/2	0
79	Operation mode selection	0/1/2/3/4/6/7	0
80	Motor capacity	0.1–7.5kW/9999	9999
82	Motor excitation current	0–500A/9999	9999
83	Motor rated voltage	0–1000V	200V/ 400V <sup>④</sup>
84	Rated motor frequency	10–120Hz	50Hz
90	Motor constant (R1)	0–50Ω/9999	9999
96	Auto tuning setting/status	0/11/21	0
117	PU communication station number	0–31 (0–247)	0
118	PU communication speed	48/96/192/384	192
119	PU communication stop bit length	0/1/10/11	1
120	PU communication parity check	0/1/2	2
121	Number of PU communication retries	0–10/9999	1
122	PU communication check time interval	0/0.1–999.8s/ 9999	9999

Parameter	Name	Setting Range	Initial Value
123	PU communication waiting time setting	0–150ms/9999	9999
124	PU communication CR/LF selection	0/1/2	1
125	Terminal 2 frequency setting gain frequency	0–400Hz	50Hz
126	Terminal 4 frequency setting gain frequency	0–400Hz	50Hz
127	PID control automatic switchover frequency	0–400Hz/9999	9999
128	PID action selection	0/20/21/40–43	0
129	PID proportional band	0.1–1000%/9999	100%
130	PID integral time	0.1–3600s/9999	1s
131	PID upper limit	0–100%/9999	9999
132	PID lower limit	0–100%/9999	9999
133	PID action set point	0–100%/9999	9999
134	PID differential time	0.01–10s/9999	9999
145	PU display language selection	0–7	1
146	Parameter for manufacturer setting. Do not set.		
150	Output current detection level	0–200%	150%
151	Output current detection signal delay time	0–10s	0s
152	Zero current detection level	0–200%	5%
153	Zero current detection time	0–1s	0.5s
156	Stall prevention operation selection	0–31/100/101	0
157	OL signal output timer	0–25s/ 9999	0s
158	AM terminal function selection	1–3/5/8–12/14/21/ 24/52/53/61/62	1
160	Extended function display selection	0/9999	0
161	Frequency setting/key lock operation selection	0/1/10/11	0
162	Automatic restart after instantaneous power failure selection	0/1/10/11	1
165	Stall prevention operation level for restart	0–200%	150%
166	Output current detection signal retention time	0–10s/9999	0.1s
167	Output current detection operation selection	0/1	0

Parameter	Name	Setting Range	Initial Value
168	Parameter for manufacturer setting. Do not set.		
169			
170	Watt-hour meter clear	0/10/9999	9999
171	Operation hour meter clear	0/9999	9999
178	STF terminal function selection	0~5/7/8/10/12/14/ 16/18/24/25/37/ 60/62/65~67/9999	60
179	STR terminal function selection	0~5/7/8/10/12/14/ 16/18/24/25/37/ 61/62/65~67/9999	61
180	RL terminal function selection		0
181	RM terminal function selection	0~5/7/8/10/12/14/ 16/18/24/25/37/ 62/65~67/9999	1
182	RH terminal function selection		2
190	RUN terminal function selection	0/1/3/4/7/8/11~16/ 25/26/46/47/64/ 70/80/81/90/91/ 93/95/96/98/99/ 100/101/103/104/ 107/108/111~116/ 125/126/146/147/ 164/170/180/181/ 190/191/193/195/ 196/198/199/9999	0
192	ABC terminal function selection	0/1/3/4/7/8/11~16/ 25/26/46/47/64/ 70/80/81/90/91/ 95/96/98/99/100/ 101/103/104/107/ 108/111~116/125/ 126/146/147/164/ 170/180/181/190/ 191/195/196/198/ 199/9999	99
232~239	Multi-speed setting (speed 8 to speed 15)	0~400Hz/9999	9999
240	Soft-PWM operation selection	0/1	1
241	Analog input display unit switchover	0/1	0
244	Cooling fan operation selection	0/1	1
245	Rated slip	0~50%/9999	9999
246	Slip compensation time constant	0.01~10s	0.5s
247	Constant-power range slip compensation selection	0/9999	9999
249	Earth (ground) fault detection at start	0/1	0
250	Stop selection	0~100s/ 1000~1100s/ 8888/9999	9999
251	Output phase loss protection selection	0/1	1

Parameter	Name	Setting Range	Initial Value
255	Life alarm status display	(0~15)	0
256	Inrush current limit circuit life display	(0~100%)	100%
257	Control circuit capacitor life display	(0~100%)	100%
258	Main circuit capacitor life display	(0~100%)	100%
259	Main circuit capacitor life measuring	0/1 (2/3/8/9)	0
260	PWM frequency automatic switchover	0/1	0
261	Power failure stop selection	0/1/2	0
267	Terminal 4 input selection	0/1/2	0
268	Monitor decimal digits selection	0/1/9999	9999
269	Parameter for manufacturer setting. Do not set.		
295	Magnitude of frequency change setting	0/0.01/0.10/ 1.00/10.00	0
296	Password lock level	1~6/101~106/ 9999	9999
297	Password lock/unlock	1000~9998/ (0~5)/(9999)	9999
298	Frequency search gain	0~32767/9999	9999
299	Rotation direction detection selection at restarting	0/1/9999	9999
338	Communication operation command source	0/1	0
339	Communication speed command source	0/1/2	0
340	Communication startup mode selection	0/1/10	0
342	Communication EEPROM write selection	0/1	0
343	Communication error count	—	0
450	Second applied motor	0/1/9999	9999
495	Remote output selection	0/1/10/11	0
496	Remote output data 1	0~4095	0
502	Stop mode selection at communication error	0/1/2	0
503	Maintenance timer	0 (1~9998)	0
504	Maintenance timer alarm output set time	0~9998/9999	9999
549	Protocol selection	0/1	0
551	PU mode operation command source selection	2/4/9999	9999
555	Current average time	0.1~1.0s	1s
556	Data output mask time	0~20s	0s

Parameter	Name	Setting Range	Initial Value	Parameter	Name	Setting Range	Initial Value
557	Current average value monitor signal output reference current	0–500A	Rated current	885	Regeneration avoidance compensation frequency limit value	0–10Hz/9999	6Hz
561	PTC thermistor protection level	0.5–30kΩ/9999	9999	886	Regeneration avoidance voltage gain	0–200%	100%
563	Energization time carrying-over times	(0–65535)	0	888	Free parameter 1	0–9999	9999
564	Operating time carrying-over times	(0–65535)	0	889	Free parameter 2	0–9999	9999
571	Holding time at a start	0.0–10s/9999	9999	891	Cumulative power monitor digit shifted times	0–4/9999	9999
575	Output interruption detection time	0–3600s/9999	1s	C1 (901)	AM terminal calibration	—	—
576	Output interruption detection level	0–400Hz	0Hz	C2 (902)	Terminal 2 frequency setting bias frequency	0–400Hz	0Hz
577	Output interruption cancel level	900–1100%	1000%	C3 (902)	Terminal 2 frequency setting bias	0–300%	0%
592	Traverse function selection	0/1/2	0	125 (903)	Terminal 2 frequency setting gain frequency	0–400Hz	50Hz
593	Maximum amplitude amount	0–25%	10%	C4 (903)	Terminal 2 frequency setting gain	0–300%	100%
594	Amplitude compensation amount during deceleration	0–50%	10%	C5 (904)	Terminal 4 frequency setting bias frequency	0–400Hz	0Hz
595	Amplitude compensation amount during acceleration	0–50%	10%	C6 (904)	Terminal 4 frequency setting bias	0–300%	20%
596	Amplitude acceleration time	0.1–3600s	5s	126 (905)	Terminal 4 frequency setting gain frequency	0–400Hz	50Hz
597	Amplitude deceleration time	0.1–3600s	5s	C7 (905)	Terminal 4 frequency setting gain	0–300%	100%
611	Acceleration time at a restart	0–3600s/9999	9999	C22 (922) — C25 (923)	Parameter for manufacturer setting. Do not set.		
653	Speed smoothing control	0–200%	0	990	PU buzzer control	0/1	1
665	Regeneration avoidance frequency gain	0–200%	100%	991	PU contrast adjustment	0–63	58
872	Input phase loss protection selection ⑤	0/1	1	Pr.CL	Parameter clear	0/1	0
882	Regeneration avoidance operation selection	0/1/2	0	ALLC	All parameter clear	0/1	0
883	Regeneration avoidance operation level	300–800V	400V DC/ 780V DC ④	Er.CL	Faults history clear	0/1	0
				PR.CH	Initial value change list	0	0

## Remarks:

- ① Differ according to capacities.
- ③ When the value “8888” is set, the maximum output voltage is 95% of the input voltage.
- ③ When the value “9999” is set, the maximum output voltage equals the input voltage.
- ④ The initial value differs according to the voltage class.
- ⑤ Available only for the three-phase power input specification model.

**A.1.2 FR-E700/E700SC**

Parameter	Name	Setting Range	Initial Value
0	Torque boost	0–30%	6/4/3/2% <sup>①</sup>
1	Maximum frequency	0–120Hz	120Hz
2	Minimum frequency	0–120Hz	0Hz
3	Base frequency	0–400Hz	50Hz
4	Multi-speed setting (high speed) - RH	0–400Hz	50Hz
5	Multi-speed setting (middle speed) - RM	0–400Hz	30Hz
6	Multi-speed setting (low speed) - RL	0–400Hz	10Hz
7	Acceleration time	0–3600s/360s	5/10/15s <sup>①</sup>
8	Deceleration time	0–3600s/360s	5/10/15s <sup>①</sup>
9	Electronic thermal O/L relay	0–500A	Rated current d
10	DC injection brake operation frequency	0–120Hz	3Hz
11	DC injection brake operation time	0–10s	0.5s
12	DC injection brake operation voltage	0–30%	6/4/2% a
13	Starting frequency	0–60Hz	0.5Hz
14	Load pattern selection	0/1/2/3	1
15	Jog frequency	0–400Hz	5Hz
16	Jog acceleration/ deceleration time	0–3600s/360s	0.5s
17	MRS input selection	0/2/4	0
18	High speed maximum frequency	120–400Hz	120Hz
19	Base frequency voltage	0–1000V/ 8888 <sup>②</sup> /9999 <sup>③</sup>	8888
20	Acceleration/deceleration reference frequency	1–400Hz	50Hz
21	Acceleration/deceleration time increments	0/1	0
22	Stall prevention operation level	0–200%	150%
23	Stall prevention operation level compensation factor at double speed	0–200%/9999	9999
24-27	Multi-speed setting (speed 4 to speed 7)	0–400Hz/9999	9999
29	Acceleration/deceleration pattern selection	0/1/2	0
30	Regenerative function selection	0/1/2	0
31	Frequency jump 1A	0–400Hz/9999	9999
32	Frequency jump 1B	0–400Hz/9999	9999

Parameter	Name	Setting Range	Initial Value
33	Frequency jump 2A	0–400Hz/9999	9999
34	Frequency jump 2B	0–400Hz/9999	9999
35	Frequency jump 3A	0–400Hz/9999	9999
36	Frequency jump 3B	0–400Hz/9999	9999
37	Speed display	0/0.01–9998	0
40	RUN key rotation direction selection	0/1	0
41	Up-to-frequency sensitivity	0–100%	10%
42	Output frequency detection	0–400Hz	6Hz
43	Output frequency detection for reverse rotation	0–400Hz/9999	9999
44	Second acceleration/ deceleration time	0–3600s/360s	5/10/15s <sup>①</sup>
45	Second deceleration time	0–3600s/360s/ 9999	9999
46	Second torque boost	0–30%/9999	9999
47	Second V/F (base frequency)	0–400Hz/9999	9999
48	Second stall prevention operation current	0–120%/9999	110%
51	Second electronic thermal O/L relay	0–500A/9999	9999
52	DU/PU main display data selection	0/5/7–12/14/20/ 23–25/52–57/61/ 62/100	0
55	Frequency monitoring reference	0–400Hz	50Hz
56	Current monitoring reference	0–500A	Rated current
57	Restart coasting time	0/0.1–5s/9999 <sup>①</sup>	9999
58	Restart cushion time	0–60s	1s
59	Remote function selection	0/1/2/3	0
60	Energy saving control selection	0/9	0
61	Reference current	0–500A/9999	9999
62	Reference value at acceleration	0–200%/9999	9999
63	Reference value at deceleration	0–200%/9999	9999
65	Retry selection	0–5	0
66	Stall prevention operation reduction starting frequency	0–400Hz	50Hz
67	Number of retries at alarm occurrence	0–10/101–110	0
68	Retry waiting time	0.1–360s	1s

Parameter	Name	Setting Range	Initial Value
69	Retry count display erase	0	0
70	Special regenerative brake duty	0–30%	0%
71	Applied motor	0/1–3–6/13–16/ 23/24/40/43/44/ 50/53/54	0
72	PWM frequency selection	0–15	1
73	Analog input selection	0/1/10/11	1
74	Input filter time constant	0–8	1
75	Reset selection/disconnected PU detection/PU stop selection	0–3/14–17	14
77	Parameter write selection	0/1/2	0
78	Reverse rotation prevention selection	0/1/2	0
79	Operation mode selection	0/1/2/3/4/6/7	0
80	Motor capacity	0.1–15kW/9999	9999
81	Number of motor poles	2/4/6/8/10/12/ 14/16/18/20/9999	9999
82	Motor excitation current	0–500A/9999 <sup>⑤</sup>	9999
83	Motor rated voltage	0–1000V	200V/400V
84	Rated motor frequency	10–120Hz	50Hz
89	Speed control gain (advanced magnetic flux vector)	0–200%/9999	9999
90	Motor constant (R1)	0–50Ω/9999 <sup>⑤</sup>	9999
91	Motor constant (R2)	0–50Ω/9999 <sup>⑤</sup>	9999
92	Motor constant (L1)	0–1000mH/ 9999 <sup>⑤</sup>	9999
93	Motor constant (L2)	0–1000mH/ 9999 <sup>⑤</sup>	9999
94	Motor constant (X)	0–100%/9999 e	9999
96	Auto tuning setting/status	0/1/11/21	0
117	PU communication station number	0–31 (0–247)	0
118	PU communication speed	48/96/192/384	192
119	PU communication stop bit length	0/1/10/11	1
120	PU communication parity check	0/1/2	2
121	Number of PU communication retries	0–10/9999	1
122	PU communication check time interval	0/0.1–999.8 s/ 9999	9999
123	PU communication waiting time setting	0–150ms/9999	9999

Parameter	Name	Setting Range	Initial Value
124	PU communication CR/LF selection	0/1/2	1
125	Terminal 2 frequency setting gain frequency	0–400Hz	50Hz
126	Terminal 4 frequency setting gain frequency	0–400Hz	50Hz
127	PID control automatic switchover frequency	0–400Hz/9999	9999
128	PID action selection	0/20/21/40–43/ 50/51/60/61	0
129	PID proportional band	0.1–1000%/9999	100%
130	PID integral time	0.1–3600s/9999	1s
131	PID upper limit	0–100%/9999	9999
132	PID lower limit	0–100%/9999	9999
133	PID action set point	0–100%/9999	9999
134	PID differential time	0.01–10.00s/9999	9999
145	PU display language selection	0–7	1
146	Parameter for manufacturer setting. Do not set.		
147	Acceleration/deceleration switching frequency	0–400Hz/9999	9999
150	Output current detection level	0–200%	150%
151	Output current detection signal delay time	0–10s	0s
152	Zero current detection level	0–200%	5%
153	Zero current detection time	0–1s	0.5s
156	Stall prevention operation selection	0–31/100/101	0
157	OL signal output timer	0–25s/ 9999	0s
158	AM terminal function selection	1–3/5/7–12/14/21/ 24/52/53/61/62	1
160	User group read selection	0/1/9999	0
161	Frequency setting/key lock operation selection	0/1/10/11	0
162	Automatic restart after instantaneous power failure selection	0/1/10/11	1
165	Stall prevention operation level for restart	0–200%	150%
168	Parameter for manufacturer setting. Do not set.		
169			
170	Watt-hour meter clear	0/10/9999	9999
171	Operation hour meter clear	0/9999	9999
172	User group registered display/batch clear	(0–16)/9999	9999

Parameter	Name	Setting Range	Initial Value	Parameter	Name	Setting Range	Initial Value
173	User group registration	0–999/9999	9999	249	Earth (ground) fault detection at start	0/1	0
174	User group clear	0–999/9999	9999	250	Stop selection	0–100s/1000–1100s/8888/9999	9999
178	STF terminal function selection	0–5/7/8/10/12/14–16/18/24/25/60/62/65–67/9999	60	251	Output phase loss failure protection selection	0/1	1
179	STR terminal function selection	0–5/7/8/10/12/14–16/18/24/25/61/62/65–67/9999	61	255	Life alarm status display	(0–15)	0
180	RL terminal function selection	0–5/7/8/10/12/14–16/18/24/25/62/65–67/9999	0	256	Inrush current limit circuit life display	(0–100%)	100%
181	RM terminal function selection		1	257	Control circuit capacitor life display	(0–100%)	100%
182	RH terminal function selection		2	258	Main circuit capacitor life display	(0–100%)	100%
183	MRS terminal function selection (FR-E700) ⑥			259	Main circuit capacitor life measuring	0/1	0
	MRS bit function selection (FR-E700SC) ⑥			261	Power failure stop selection	0/1/2	0
184	RES terminal function selection	0/1/3/4/7/8/11–16/20/25/26/46/47/64/90/91/93/95/96/98/99/100/101/103/104/107/108/111–116/120/125/126/146/147/164/193/195/196/198/199/9999	0	267	Terminal 4 input selection	0/1/2	0
190	RUN terminal function selection		0	268	Monitor decimal digits selection	0/1/9999	9999
191	FU terminal function selection	0/1/3/4/7/8/11–16/20/25/26/46/47/64/90/91/95/96/98/99/100/101/103/104/107/108/111–116/120/125/126/146/147/164/190/191/195/196/198/199/9999	1	269	Parameter for manufacturer setting. Do not make setting.		
				270	Stop-on contact control selection	0/1	0
				275	Stop-on contact excitation current low-speed multiplying factor	0–300%/9999	9999
				276	PWM carrier frequency at stop-on contact	0–9/9999	9999
				277	Stall prevention operation current switchover	0/1	0
				278	Brake opening frequency	0–30Hz	3Hz
				279	Brake opening current	0–200%	130%
				280	Brake opening current detection time	0–2s	0.3s
				281	Brake operation time at start	0–5s	0.3s
				282	Brake operation frequency	0–30Hz	6Hz
192	ABC terminal function selection		2	283	Brake operation time at stop	0–5s	0.3s
232–239	Multi-speed setting (speed 8 to speed 15)	0–400Hz/9999	9999	286	Droop gain	0–100%	0%
240	Soft-PWM operation selection	0/1	1	287	Droop filter time constant	0–1s	0.3s
241	Analog input display unit switch over	0/1	0	292	Automatic acceleration/deceleration	0/1/7/8/11	0
244	Cooling fan operation selection	0/1	1	293	Acceleration/deceleration separate selection	0/1/2	0
245	Rated slip	0–50%/9999	9999	295	Magnitude of frequency change setting	0/0.01/0.1/1/10	0
246	Slip compensation time constant	0.01–10s	0.5s				
247	Constant-output region slip compensation selection	0/9999	9999				

Parameter	Name	Setting Range	Initial Value	Parameter	Name	Setting Range	Initial Value
298	Frequency search gain	0–32767/9999	9999	338	Communication operation command source	0/1	0
299	Rotation direction detection selection at restarting	0/1/9999	9999	339	Communication speed command source	0/1/2	0
300	BCD input bias			340	Communication start-up mode selection	0/1/10	0
301	BCD input gain			342	Communication E <sup>2</sup> PROM write selection	0/1	0
302	BIN input bias			343	Communication error count	—	0
303	BIN input gain			345	DeviceNet address		
304	Digital input and analog input compensation enable/disable selection			346	DeviceNet baud rate		
305	Read timing operation selection			349	Communication reset selection		
306	Analog output signal selection			387	Initial communication delay time		
307	Setting for zero analog output			388	Send time interval at heart beat		
308	Setting for maximum analog output			389	Minimum sending time at heart beat		
309	Analog output signal voltage/current switch over			390	% setting reference frequency		
310	Analog meter voltage output selection			391	Receive time interval at heart beat		
311	Setting for zero analog meter voltage output			392	Event driven detection width		
312	Setting for maximum analog meter voltage output			450	Second applied motor	0/1/9999	9999
313	Y0 terminal function selection			495	Remote output selection	0/1/10/11	0
314	Y1 terminal function selection			496	Remote output data 1	0–4095	0
315	Y2 terminal function selection			497	Remote output data 2	0–4095	0
316	Y3 terminal function selection			500	Communication error execution waiting time		
317	Y4 terminal function selection			501	Communication error occurrence count display		
318	Y5 terminal function selection			502	Stop mode selection at communication error	0/1/2/3	0
319	Y6 terminal function selection			503	Maintenance timer	0 (1–9998)	0
320	RA1 terminal function selection			504	Maintenance timer alarm output set time	0–9998/9999	9999
321	RA2 terminal function selection			541	Frequency command sign selection		
322	RA3 terminal function selection			542	Communication station number		
323	AM0 0V adjustment			543	Baud rate		
324	AM1 0mA adjustment			544	CC-Link extended setting		
329	Digital input unit selection			547	USB communication station number	0–31	0

Parameter	Name	Setting Range	Initial Value	Parameter	Name	Setting Range	Initial Value
548	USB communication check time interval	0/0.1–999.8s/9999	9999	886	Regeneration avoidance voltage gain	0–200%	100%
549	Protocol selection	0/1	0	888	Free parameter 1	0–9999	9999
550	NET mode operation command source selection	0/2/9999	9999	889	Free parameter 2	0–9999	9999
551	PU mode operation command source selection	2/3/4/9999	9999	C1 (901)	AM terminal calibration	—	—
555	Current average time	0.1–1.0s	1s	C2 (902)	Terminal 2 frequency setting bias frequency	0–400Hz	0Hz
556	Data output mask time	0–20s	0s	C3 (902)	Terminal 2 frequency setting bias	0–300%	0%
557	Current average value monitor signal output reference current	0–500A	Rated current	125 (903)	Terminal 2 frequency setting gain frequency	0–400Hz	50Hz
563	Energizing time carrying-over times	(0–65535)		C4 (903)	Terminal 2 frequency setting gain	0–300%	100%
564	Operating time carrying-over times	(0–65535)	0	C5 (904)	Terminal 4 frequency setting bias frequency	0–400Hz	0Hz
571	Holding time at a start	0.0–10.0s/9999	9999	C6 (904)	Terminal 4 frequency setting bias	0–300%	20%
611	Acceleration time at a restart	0–3600s/9999	9999	126 (905)	Terminal 4 frequency setting gain frequency	0–400Hz	50Hz
645	AM 0V adjustment	970–1200	1000	C7 (905)	Terminal 4 frequency setting gain	0–300%	100%
653	Speed smoothing control	0–200%	0	C22 (922) – C25 (923)	Parameter for manufacturer setting. Do not set.		
665	Regeneration avoidance frequency gain	0–200%	100%	990	PU buzzer control	0/1	1
800	Control method selection	20/30	20	991	PU contrast adjustment	0–63	58
859	Torque current	0–500A/9999 <sup>⑤</sup>	9999	Pr.CL	Parameter clear	0/1	0
872	Input phase loss protection selection	0/1	0	ALLC	All parameter clear	0/1	0
882	Regeneration avoidance operation selection	0/1/2	0	Er.CL	Faults history clear	0/1	0
883	Regeneration avoidance operation level	300–800V	400V/780V DC				
885	Regeneration avoidance compensation frequency limit value	0–10Hz/9999	6Hz				

**Remarks:**

- ① Differ according to capacities.
- ③ When the value “8888” is set, the maximum output voltage is 95% of the input voltage.
- ② When the value “9999” is set, the maximum output voltage equals the input voltage.
- ④ The initial value of the FR-E740-026 or less is set to 85% of the rated inverter current.
- ⑤ The range differs according to the Pr. 71 setting.
- ⑥ This setting is active only during the communication operation.

### A.1.3 FR-F700

Parameter	Name	Setting Range	Initial Value
0	Torque boost	0~30%	6/4/3/ 2/1.5/1% <sup>①</sup>
1	Maximum frequency	0~120Hz	120/60Hz <sup>①</sup>
2	Minimum frequency	0~120Hz	0Hz
3	Base frequency	0~400Hz	50Hz
4	Multi-speed setting (high speed) - RH	0~400Hz	50Hz
5	Multi-speed setting (medium speed) - RM	0~400Hz	30Hz
6	Multi-speed setting (low speed) - RL	0~400Hz	10Hz
7	Acceleration time	0~3600/360s	5s/15s <sup>①</sup>
8	Deceleration time	0~3600/360s	10s/30s <sup>①</sup>
9	Electronic thermal O/L relay	0~500/ 0~3600A <sup>①</sup>	Rated current
10	DC injection brake operation frequency	0~120Hz/9999	3Hz
11	DC injection brake operation time	0~10s/8888	0.5s
12	DC injection brake operation voltage	0~30%	4/2/1% <sup>①</sup>
13	Starting frequency	0~60Hz	0.5Hz
14	Load pattern selection	0/1	1
15	Jog frequency	0~400Hz	5Hz
16	Jog acceleration/deceleration time	0~3600/360s	0.5s
17	MRS input selection	0/2	0
18	High speed maximum frequency	120~400Hz	120/60Hz <sup>①</sup>
19	Base frequency voltage	0~1000V/ 8888 <sup>②</sup> /9999 <sup>③</sup>	8888
20	Acceleration/deceleration reference frequency	1~400Hz	50Hz
21	Acceleration/deceleration time increments	0/1	0
22	Stall prevention operation level	0~120%/9999	110%
23	Stall prevention operation level compensation factor at double speed	0~150%/9999	9999
24-27	Multi-speed setting 4th speed to 7th speed	0~400Hz/9999	9999
28	Multi-speed input compensation selection	0/1	0
29	Acceleration/deceleration pattern selection	0~3/6	0
30	Regenerative function selection	0/10/20/ 1/11/21/ 2	0
31	Frequency jump 1A	0~400Hz/9999	9999

Parameter	Name	Setting Range	Initial Value
32	Frequency jump 1B	0~400Hz/9999	9999
33	Frequency jump 2A	0~400Hz/9999	9999
34	Frequency jump 2B	0~400Hz/9999	9999
35	Frequency jump 3A	0~400Hz/9999	9999
36	Frequency jump 3B	0~400Hz/9999	9999
37	Speed display	0/1~9998	0
41	Up-to-frequency sensitivity	0~100%	10%
42	Output frequency detection	0~400Hz	6Hz
43	Output frequency detection for reverse rotation	0~400Hz/9999	9999
44	Second acceleration/deceleration time	0~3600/360s	5s
45	Second deceleration time	0~3600/360s/ 9999	9999
46	Second torque boost	0~30%/9999	9999
47	Second V/F (base frequency)	0~400Hz/9999	9999
48	Second stall prevention operation current	0~120%	110%
49	Second stall prevention operation frequency	0~400Hz/9999	0Hz
50	Second output frequency detection	0~400Hz	30Hz
51	Second electronic thermal O/L relay	0~500A, 9999/ 0~3600A, 9999 <sup>①</sup>	9999
52	DU/PU main display data selection	0/5/6/8~14/17/20/ 23~25/50~57/100	0
54	CA terminal function selection	1~3/5/6/8~14/17/ 21/24/50/52/53,	1
55	Frequency monitoring reference	0~400Hz	50Hz
56	Current monitoring reference	0~500A/ 0~3600A <sup>①</sup>	Rated current
57	Restart coasting time	0, 0.1~5s, 9999/ 0, 0.1~30s, 9999 <sup>①</sup>	9999
58	Restart cushion time	0~60s	1s
59	Remote function selection	0/1/2/3/11/12/13	0
60	Energy saving control selection	0/4/9	0
65	Retry selection	0~5	0
66	Stall prevention operation reduction starting frequency	0~400Hz	50Hz
67	Number of retries at alarm occurrence	0~10/101~110	0
68	Retry waiting time	0~10s	1s
69	Retry count display erase	0	0

Parameter	Name	Setting Range	Initial Value
70	Special regenerative brake duty	0–10%	0%
71	Applied motor	0/1/2/20	0
72	PWM frequency selection	0–15/0–6/25 <sup>①</sup>	2
73	Analog input selection	0–7/10–17	1
74	Input filter time constant	0–8	1
75	Reset selection/disconnected PU detection/PU stop selection	0–3/14–17/ 100–103/114–117	14
76	Alarm code output selection	0/1/2	0
77	Parameter write selection	0/1/2	0
78	Reverse rotation prevention selection	0/1/2	0
79	Operation mode selection	0/1/2/3/4/6/7	0
80	Motor capacity (simple magnetic flux vector control)	0.4–55kW, 9999/ 0–3600kW, 9999 <sup>①</sup>	9999
90	Motor constant (R1)	0–50Ω, 9999/ 0–400mΩ, 9999 <sup>①</sup>	9999
100	V/f1 (frequency)	0–400Hz/9999	9999
101	V/f1 (voltage)	0–1000V	0V
102	V/f2 (frequency)	0–400Hz/9999	9999
103	V/f2 (voltage)	0–1000V	0V
104	V/f3 (frequency)	0–400Hz/9999	9999
105	V/f3 (voltage)	0–1000V	0V
106	V/f4 (frequency)	0–400Hz/9999	9999
107	V/f4 (voltage)	0–1000V	0V
108	V/f5 (frequency)	0–400Hz/9999	9999
109	V/f5 (voltage)	0–1000V	0V
117	PU communication station number	0–31	0
118	PU communication speed	48/96/192/384	192
119	PU communication stop bit length	0/1/10/11	1
120	PU communication parity check	0/1/2	2
121	Number of PU communication retries	0–10/9999	1
122	PU communication check time interval	0/0.1–999.8s/ 9999	9999
123	PU communication waiting time setting	0–150ms/9999	9999
124	PU communication CR/LF presence/absence selection	0/1/2	1
125	Terminal 2 frequency setting gain frequency	0–400Hz	50Hz
126	Terminal 4 frequency setting gain frequency	0–400Hz	50Hz
127	PID control automatic switchover frequency	0–400Hz/9999	9999

Parameter	Name	Setting Range	Initial Value
128	PID action selection	10/110/111/20/ 120/21/121/50/ 51/60/61	10
129	PID proportional band	0.1–1000%/9999	100%
130	PID integral time	0.1–3600s/9999	1s
131	PID upper limit	0–100%/9999	9999
132	PID lower limit	0–100%/9999	9999
133	PID action set point	0–100%/9999	9999
134	PID differential time	0.01–10.00s/9999	9999
135	Commercial power-supply switchover sequence output terminal selection	0/1	0
136	MC switchover interlock time	0–100s	1s
137	Start waiting time	0–100s	0.5s
138	Commercial power-supply operation switchover selection at an alarm	0/1	0
139	Automatic switchover frequency between inverter and commercial power-supply operation	0–60Hz/9999	9999
140	Backlash acceleration stopping frequency	0–400Hz	1Hz
141	Backlash acceleration stopping time	0–360s	0.5s
142	Backlash deceleration stopping frequency	0–400Hz	1Hz
143	Backlash deceleration stopping time	0–360s	0.5s
144	Speed setting switchover	0/2/4/6/8/10/102/ 104/106/108/110	4
145	PU display language selection	0–7	1
148	Stall prevention level at 0 V input	0–120%	110%
149	Stall prevention level at 10 V input	0–120%	120%
150	Output current detection level	0–120%	110%
151	Output current detection signal delay time	0–10s	0s
152	Zero current detection level	0–150%	5%
153	Zero current detection time	0–10s	0.5s
154	Voltage reduction selection during stall prevention operation	0/1	1
155	RT signal reflection time selection	0/10	0
156	Stall prevention operation selection	0–31/100/101	0
157	OL signal output timer	0–25s/ 9999	0s

Parameter	Name	Setting Range	Initial Value	Parameter	Name	Setting Range	Initial Value
158	AM terminal function selection	1–3/5/6/7/8–14/17/21/24/50/52/53	1	184	AU terminal function selection	0–8/10–14/16/24/25/37/62–67/70–72/9999	4
159	Automatic switchover ON range between commercial power-supply and inverter operation	0–10Hz/9999	9999	185	JOG terminal function selection		5
160	User group read selection	0/1/9999	9999	186	CS terminal function selection		6
161	Frequency setting/key lock operation selection	0/1/10/11	0	187	MRS terminal function selection	0–8/10–14/16/24/25/37/62/64–67/70–72/9999	24
162	Automatic restart after instantaneous power failure selection	0/1/2/10/11	0	188	STOP terminal function selection		25
163	First cushion time for restart	0–20s	0s	189	RES terminal function selection		62
164	First cushion voltage for restart	0–100%	0%	190	RUN terminal function selection		0
165	Stall prevention operation level for restart	0–120%	110%	191	SU terminal function selection	0–5/7/8/10–19/25/26/45–48/64/70–79/85/90–96/98/99/100–105/107/108/110–116/125/126/145–148/164/170/179/185/190–196/198/199/9999	1
166	Output current detection signal retention time	0–10s/9999	0.1s	192	IPF terminal function selection		2
167	Output current detection operation selection	0/1/10/11	0	193	OL terminal function selection		3
168	Parameter for manufacturer setting. Do not set.			194	FU terminal function selection		4
169				195	ABC1 terminal function selection	0–5/7/8/10–19/25/26/45–48/64/70–79/85/90/91/94–96/98/99/100–105/107/108/110–116/125/126/145–148/164/170/179/185/190–196/198/199/9999	99
170	Cumulative power meter clear	0/10/9999	9999	196	ABC2 terminal function selection		9999
171	Operation hour meter clear	0/9999	9999	232–239	Multi-speed setting (speeds 8 to 15)	0–400Hz/9999	9999
172	User group registered display/batch clear	9999/(0–16)	0	240	Soft-PWM operation selection	0/1	1
173	User group registration	0–999/9999	9999	241	Analog input display unit switchover	0/1	0
174	User group clear	0–999/9999	9999	242	Terminal 1 added compensation amount (terminal 2)	0–100%	100%
178	STF terminal function selection	0–8/10–14/16/24/25/37/60/62/64–67/70–72/9999	60	243	Terminal 1 added compensation amount (terminal 4)	0–100%	75%
179	STR terminal function selection	0–8/10–14/16/24/25/37/61/62/64–67/70–72/9999	61	244	Cooling fan operation selection	0/1	1
180	RL terminal function selection		0	245	Rated slip	0–50%/9999	9999
181	RM terminal function selection		1	246	Slip compensation time constant	0.01–10s	0.5s
182	RH terminal function selection		2	247	Constant-output region slip compensation selection	0/9999	9999
183	RT terminal function selection		3				

Parameter	Name	Setting Range	Initial Value	Parameter	Name	Setting Range	Initial Value
250	Stop selection	0–100s/ 1000–1100s/ 8888/9999	9999	Parameter for option FR-A7AX (16 bit digital input)	300	BCD input bias	
251	Output phase failure protection selection	0/1	1		301	BCD input gain	
252	Override bias	0–200%	50%		302	BIN input bias	
253	Override gain	0–200%	150%		303	BIN input gain	
255	Life alarm status display	(0–15)	0		304	Digital input and analog input compensation enable/ disable selection	
256	Inrush current suppression circuit life display	(0–100%)	100%		305	Read timing operation selection	
257	Control circuit capacitor life display	(0–100%)	100%		306	Analog output signal selection	
258	Main circuit capacitor life display	(0–100%)	100%		307	Setting for zero analog output	
259	Main circuit capacitor life measuring	0/1	0		308	Setting for maximum analog output	
260	PWM frequency automatic switchover	0/1	1		309	Analog output signal voltage/current switchover	
261	Power failure stop selection	0/1/2/21/22	0		310	Analog meter voltage output selection	
262	Subtracted frequency at deceleration start	0–20Hz	3Hz		311	Setting for zero analog meter voltage output	
263	Subtraction starting frequency	0–120Hz/9999	50Hz		312	Setting for maximum analog meter voltage output	
264	Power-failure deceleration time 1	0–3600/360s	5s		313	D00 output selection	
265	Power-failure deceleration time 2	0–3600/360s/ 9999	9999		314	D01 output selection	
266	Power failure deceleration time switchover frequency	0–400Hz	50Hz		315	D02 output selection	
267	Terminal 4 input selection	0/1/2	0		316	D03 output selection	
268	Monitor decimal digits selection	0/1/9999	9999		317	D04 output selection	
269	Parameter for manufacturer setting. Do not set.				318	D05 output selection	
299	Rotation direction detection selection at restarting	0/1/9999	9999		319	D06 output selection	
					320	RA1 output selection	
					321	RA2 output selection	
					322	RA3 output selection	
					323	AM0 0V adjustment	
					324	AM1 0mA adjustment	
					329	Digital input unit selection	
					331	RS-485 communication station	0–31 (0–247)
					332	RS-485 communication speed	96

Parameter	Name	Setting Range	Initial Value	Parameter	Name	Setting Range	Initial Value
333	RS-485 communication stop bit length	0/1/10/11	1	504	Maintenance timer alarm output set time	0–9998/9999	9999
334	RS-485 communication parity check selection	0/1/2	2	522	Output stop frequency	0–400Hz/9999	9999
335	RS-485 communication number of retries	0–10/ 9999	1	539	Modbus-RTU communication check time interval	0/0.1–999.8 s/ 9999	9999
336	RS-485 communication check time interval	0–999.8s/ 9999	0s	542	Communication station number (CC-Link)	Parameter for option FR-A7NC (CC-Link communication)	
337	RS-485 communication waiting time setting	0–150ms/ 9999	9999	543	Baud rate (CC-Link)		
338	Communication operation command source	0/1	0	544	CC-Link extended setting		
339	Communication speed command source	0/1/2	0	549	Protocol selection	0/1	0
340	Communication startup mode selection	0/1/2/10/12	0	550	NET mode operation command source selection	0/1/9999	9999
341	RS-485 communication CR/LF selection	0/1/2	1	551	PU mode operation command source selection	1/2	2
342	Communication EEPROM write selection	0/1	0	553	PID deviation limit	0–1000%/9999	9999
343	Communication error count	—	0	554	PID signal operation selection	0–3/10–13	0
345	DeviceNet address	Parameter for option FR-A7ND (DeviceNet communication)		555	Current average time	0.1–1.0s	1s
346	DeviceNet baud rate			556	Data output mask time	0.0–20.0s	0s
349	Communication reset selection			557	Current average value monitor signal output reference current	0–500A/ 0–3600A <sup>②</sup>	Rated current
387	Initial communication delay time			563	Energization time carrying-over times	(0–65535)	0
388	Send time interval at hart beat			564	Operating time carrying-over times	(0–65535)	0
389	Minimum sending time at hart beat			570	Multiple rating setting	0/1	0
390	% setting reference frequency			571	Holding time at a start	0.0–10.0s/9999	9999
391	Receive time interval at hart beat			573	4 mA Input check selection	1/9999	9999
392	Event driven detection width			575	Output interruption detection time	0–3600s, 9999	1s
495	Remote output selection	0/1/10/11	0	576	Output interruption detection level	0–400Hz	0Hz
496	Remote output data 1	0–4095	0	577	Output interruption release level	900–1100%	1000%
497	Remote output data 2	0–4095	0	578	Auxiliary motor operation selection	0–3	0
500	Communication error execution waiting time	Parameter for networks options		579	Motor swichover selection	0–3	0
501	Communication error occurrence count display			580	MC switching interlock time	0–100s	1s
502	Stop mode selection at communication error			581	Start waiting time	0–100s	1s
503	Maintenance timer	0 (1–9998)	0	582	Auxiliary motor connection-time deceleration time	0–3600/360s/ 9999	1s
				583	Auxiliary motor disconnection-time acceleration time	0–3600/360s/ 9999	1s
				584	Auxiliary motor 1 starting frequency	0–400Hz	50Hz
				585	Auxiliary motor 2 starting frequency	0–400Hz	50Hz

Parameter	Name	Setting Range	Initial Value	Parameter	Name	Setting Range	Initial Value
586	Auxiliary motor 3 starting frequency	0–400Hz	50Hz	889	Free parameter 2	0–9999	9999
587	Auxiliary motor 1 stopping frequency	0–400Hz	0Hz	891	Cumulative power monitor digit shifted times	0–4/9999	9999
588	Auxiliary motor 2 stopping frequency	0–400Hz	0Hz	892	Load factor	30–150%	100%
589	Auxiliary motor 3 stopping frequency	0–400Hz	0Hz	893	Energy saving monitor reference (motor capacity)	0.1–55kW/ 0–3600kW <sup>②</sup>	LD/SLD value of applied motor capacity
590	Auxiliary motor start detection time	0–3600s	5s	894	Control selection during commercial power-supply operation	0/1/2/3	0
591	Auxiliary motor stop detection time	0–3600s	5s	895	Power saving rate reference value	0/1/9999	9999
592	Traverse function selection	0/1/2	0	896	Power unit cost	0–500/9999	9999
593	Maximum amplitude amount	0–25%	10%	897	Power saving monitor average time	0/1–1000h/9999	9999
594	Amplitude compensation amount during deceleration	0–50%	10%	898	Power saving cumulative monitor clear	0/1/10/9999	9999
595	Amplitude compensation amount during acceleration	0–50%	10%	899	Operation time rate (estimated value)	0–100%/9999	9999
596	Amplitude acceleration time	0.1–3600s	5s	C0 (900)	CA terminal calibration	—	—
597	Amplitude deceleration time	0.1–3600s	5s	C1 (901)	AM terminal calibration	—	—
611	Acceleration time at a restart	0–3600s/9999	5/15s <sup>①</sup>	C2 (902)	Terminal 2 frequency setting bias frequency	0–400Hz	0Hz
653	Speed smoothing control	0–200%	0	C3 (902)	Terminal 2 frequency setting bias	0–300%	0%
654	Speed smoothing cutoff frequency	0–120Hz	20 Hz	125 (903)	Terminal 2 frequency setting gain frequency	0–400Hz	50Hz
799	Pulse increment setting for output power	0.1/10/100/ 1000 kWh	1 kWh	C4 (903)	Terminal 2 frequency setting gain	0–300%	100%
867	AM output filter	0–5s	0.01s	C5 (904)	Terminal 4 frequency setting bias frequency	0–400Hz	0Hz
869	Current output filter	0–5s	0.02s	C6 (904)	Terminal 4 frequency setting bias	0–300%	20%
872	Input phase failure protection selection	0/1	0	126 (905)	Terminal 4 frequency setting gain frequency	0–400Hz	50Hz
882	Regeneration avoidance operation selection	0/1	0	C7 (905)	Terminal 4 frequency setting gain	0–300%	100%
883	Regeneration avoidance operation level	300–800V	760 V/ 785 V DC	C8 (930)	Current output bias signal	0–100%	0%
884	Regeneration avoidance at deceleration detection sensitivity	0–5	0	C9 (930)	Current output bias current	0–100%	0%
885	Regeneration avoidance compensation frequency limit value	0–10Hz/9999	6Hz	C10 (931)	Current output gain signal	0–100%	100%
886	Regeneration avoidance voltage gain	0–200%	100%				
888	Free parameter 1	0–9999	9999				

Parameter	Name	Setting Range	Initial Value
C11 (931)	Current output gain current	0–100%	100%
C42 (934)	PID display bias coefficient	0–500.00/9999	9999
C43 (934)	PID display bias analog value	0–300.0%	20%
C44 (935)	PID display gain coefficient	0–500.00/9999	9999
C45 (935)	PID display gain analog value	0–300.0%	100%

Parameter	Name	Setting Range	Initial Value
989	Parameter copy alarm release	10/100	10/100 <sup>②</sup>
990	PU buzzer control	0/1	1
991	PU contrast adjustment	0–63	58
Pr.CL	Parameter clear	0/1	0
ALLC	All parameter clear	0/1	0
Er.CL	Alarm history clear	0/1	0
PCPY	Parameter copy	0/1/2/3	0

**Remarks:**

- ① The setting depends on the inverter capacity.
- ② When the value “8888” is set, the maximum output voltage is 95% of the input voltage.
- ③ When the value “9999” is set, the maximum output voltage equals the input voltage.

## A.1.4 FR-A700

Parameter	Name	Setting Range	Initial Value
0	Torque boost	0 to 30%	6/4/3/ 2/1% <sup>①</sup>
1	Maximum frequency	0–120Hz	120/60Hz <sup>①</sup>
2	Minimum frequency	0–120Hz	0Hz
3	Base frequency	0–400Hz	50Hz
4	Multi-speed setting (high speed) - RH	0–400Hz	50Hz
5	Multi-speed setting (medium speed) - RM	0–400Hz	30Hz
6	Multi-speed setting (low speed) - RL	0–400Hz	10Hz
7	Acceleration time	0–3600/360s	5 s/15s <sup>①</sup>
8	Deceleration time	0–3600/360s	5 s/15s <sup>①</sup>
9	Electronic thermal O/L relay	0–500/ 0–3600A <sup>②</sup>	0
10	DC injection brake operation frequency	0–120Hz/9999	3Hz
11	DC injection brake operation time	0–10s/8888	0.5s
12	DC injection brake operation voltage	0–30%	4/2/1% <sup>①</sup>
13	Starting frequency	0–60Hz	0.5Hz
14	Load pattern selection	0–5	0
15	Jog frequency	0–400Hz	5Hz
16	Jog acceleration/deceleration time	0–3600/360s	0.5s
17	MRS input selection	0/2/4	0
18	High speed maximum frequency	120–400Hz	120/60Hz <sup>①</sup>
19	Base frequency voltage	0–1000V/ 8888 <sup>②</sup> /9999 <sup>③</sup>	8888
20	Acceleration/deceleration reference frequency	1–400Hz	50Hz
21	Acceleration/deceleration time increments	0/1	0
22	Stall prevention operation level	0–400%	150%
23	Stall prevention operation level compensation factor at double speed	0–200%/9999	9999
24-27	Multi-speed setting 4th speed to 7th speed	0–400Hz/9999	9999
28	Multi-speed input compensation selection	0/1	0
29	Acceleration/deceleration pattern selection	0–5	0
30	Regenerative function selection	0/1/2/10/11/20/21	0
31	Frequency jump 1A	0–400Hz/9999	9999
32	Frequency jump 1B	0–400Hz/9999	9999

Parameter	Name	Setting Range	Initial Value
33	Frequency jump 2A	0–400Hz/9999	9999
34	Frequency jump 2B	0–400Hz/9999	9999
35	Frequency jump 3A	0–400Hz/9999	9999
36	Frequency jump 3B	0–400Hz/9999	9999
37	Speed display	0/1–9998	0
41	Up-to-frequency sensitivity	0–100%	10%
42	Output frequency detection	0–400Hz	6Hz
43	Output frequency detection for reverse rotation	0–400Hz/9999	9999
44	Second acceleration/deceleration time	0–3600/360s	5s
45	Second deceleration time	0–3600/360s/ 9999	9999
46	Second torque boost	0–30%/9999	9999
47	Second V/F (base frequency)	0–400Hz/9999	9999
48	Second stall prevention operation current	0–220%	150%
49	Second stall prevention operation frequency	0–400Hz/9999	0Hz
50	Second output frequency detection	0–400Hz	30Hz
51	Second electronic thermal O/L relay	0–500A, 9999/ 0–3600A, 9999 <sup>①</sup>	9999
52	DU/PU main display data selection	0/5–14/17–20/22– 25/32–35/50–57/ 100	0
54	CA terminal function selection	1–3/5–14/17/18/ 21/24/32–34/50/ 52/53/70	1
55	Frequency monitoring reference	0–400Hz	50Hz
56	Current monitoring reference	0–500A/ 0–3600A <sup>①</sup>	Rated current
57	Restart coasting time	0/ 0.1–5s, 9999/ 0/ 0.1–30s/ 9999 <sup>①</sup>	9999
58	Restart cushion time	0–60s	1s
59	Remote function selection	0/1/2/3	0
60	Energy saving control selection	0/4	0
61	Automatic acceleration/deceleration: Reference current	0–500A, 9999/ 0–3600A, 9999 <sup>①</sup>	9999
62	Automatic acceleration/deceleration: Reference value at acceleration	0–220%/9999	9999
63	Automatic acceleration/deceleration: Reference value at deceleration	0–220%/9999	9999

Parameter	Name	Setting Range	Initial Value
64	Automatic acceleration/deceleration: Starting frequency for elevator mode	0–10Hz/9999	9999
65	Retry selection	0–5	0
66	Stall prevention operation reduction starting frequency	0–400Hz	50Hz
67	Number of retries at alarm occurrence	0–10/101–110	0
68	Retry waiting time	0–10s	1s
69	Retry count display erase	0	0
70	Special regenerative brake duty	0–30%/0–10% <sup>①</sup>	0%
71	Applied motor	0–8/13–18/20/23/24/30/33/34/40/43/44/50/53/54	0
72	PWM frequency selection	0–15/0–6/25 <sup>①</sup>	2
73	Analog input selection	0–7/10–17	1
74	Input filter time constant	0–8	1
75	Reset selection/disconnected PU detection/PU stop selection	0–3/14–17/100–103/114–117	14
76	Alarm code output selection	0/1/2	0
77	Parameter write selection	0/1/2	0
78	Reverse rotation prevention selection	0/1/2	0
79	Operation mode selection	0/1/2/3/4/6/7	0
80	Motor capacity (simple magnetic flux vector control)	0.4–55kW, 9999/0–3600kW, 9999 <sup>①</sup>	9999
81	Number of motor poles (simple magnetic flux vector control)	2/4/6/8/10/12/14/16/18/20/9999	9999
82	Motor excitation current	0–500A, 9999/0–3600A, 9999 <sup>①</sup>	9999
83	Motor rated voltage	0–1000V	400V
84	Rated motor frequency	10–120Hz	50Hz
89	Speed control gain (magnetic flux vector)	0–200%/9999	9999
90	Motor constant (R1)	0–50Ω, 9999/0–400mΩ, 9999 <sup>①</sup>	9999
91	Motor constant (R2)	0–50Ω, 9999/0–400mΩ, 9999 <sup>①</sup>	9999
92	Motor constant (L1)	0–50Ω, (0–1000mH), 9999/0–3600mΩ, (0–400mH), 9999 <sup>①</sup>	9999

Parameter	Name	Setting Range	Initial Value
93	Motor constant (L2)	0–50Ω, (0–1000mH), 9999/0–3600mΩ, (0–400mH), 9999 <sup>①</sup>	9999
94	Motor constant (X)	0–500Ω, (0–100%), 9999/0–100Ω, (0–100%), 9999 <sup>①</sup>	9999
95	Online auto tuning selection	0–2	0
96	Auto tuning setting/status	0/1/101	0
100	V/f1 (frequency)	0–400Hz/9999	9999
101	V/f1 (voltage)	0–1000V	0V
102	V/f2 (frequency)	0–400Hz/9999	9999
103	V/f2 (voltage)	0–1000V	0V
104	V/f3 (frequency)	0–400Hz/9999	9999
105	V/f3 (voltage)	0–1000V	0V
106	V/f4 (frequency)	0–400Hz/9999	9999
107	V/f4 (voltage)	0–1000V	0V
108	V/f5 (frequency)	0–400Hz/9999	9999
109	V/f5 (voltage)	0–1000V	0V
110	Third acceleration/deceleration time	0–3600/360s/9999	9999
111	Third deceleration time	0–3600/360s/9999	9999
112	Third torque boost	0–30%/9999	9999
113	Third V/F (base frequency)	0–400Hz/9999	9999
114	Third stall prevention operation current	0–220%	150%
115	Third stall prevention operation frequency	0–400Hz	0
116	Third output frequency detection	0–400Hz	50Hz
117	PU communication station number	0–31	0
118	PU communication speed	48/96/192/384	192
119	PU communication stop bit length	0/1/10/11	1
120	PU communication parity check	0/1/2	2
121	Number of PU communication retries	0–10/9999	1
122	PU communication check time interval	0/0.1–999.8s/9999	9999
123	PU communication waiting time setting	0–150ms/9999	9999
124	PU communication CR/LF presence/absence selection	0/1/2	1

Parameter	Name	Setting Range	Initial Value
125	Terminal 2 frequency setting gain frequency	0–400Hz	50Hz
126	Terminal 4 frequency setting gain frequency	0–400 Hz	50 Hz
127	PID control automatic switchover frequency	0–400Hz/9999	9999
128	PID action selection	10/11/20/21/50/51/60/61/70/71/80/81/90/91/100/101	10
129	PID proportional band	0.1–1000%/9999	100%
130	PID integral time	0.1–3600s/9999	1s
131	PID upper limit	0–100%/9999	9999
132	PID lower limit	0–100%/9999	9999
133	PID action set point	0–100%/9999	9999
134	PID differential time	0.01–10.00s/9999	9999
135	Commercial power-supply switchover sequence output terminal selection	0/1	0
136	MC switchover interlock time	0–100s	1s
137	Start waiting time	0–100s	0.5s
138	Commercial power-supply operation switchover selection at an alarm	0/1	0
139	Automatic switchover frequency between inverter and commercial power-supply operation	0–60Hz/9999	9999
140	Backlash acceleration stopping frequency	0–400Hz	1Hz
141	Backlash acceleration stopping time	0–360s	0.5s
142	Backlash deceleration stopping frequency	0–400Hz	1Hz
143	Backlash deceleration stopping time	0–360s	0.5s
144	Speed setting switchover	0/2/4/6/8/10/102/104/106/108/110	4
145	PU display language selection	0–7	1
148	Stall prevention level at 0 V input	0–220%	150%
149	Stall prevention level at 10 V input	0–220%	200%
150	Output current detection level	0–220%	150%
151	Output current detection signal delay time	0–10s	0s
152	Zero current detection level	0–220%	5%
153	Zero current detection time	0–1s	0.5s
154	Voltage reduction selection during stall prevention operation	0/1	1
155	RT signal reflection time selection	0/10	0

Parameter	Name	Setting Range	Initial Value
156	Stall prevention operation selection	0–31/100/101	0
157	OL signal output timer	0–25s/9999	0s
158	AM terminal function selection	1–3/5–14/17/18/21/24/32–34/50/52/53	1
159	Automatic switchover ON range between commercial power-supply and inverter operation	0–10Hz/9999	9999
160	User group read selection	0/1/9999	0
161	Frequency setting/key lock operation selection	0/1/10/11	0
162	Automatic restart after instantaneous power failure selection	0/1/2/10/11/12	0
163	First cushion time for restart	0–20s	0s
164	First cushion voltage for restart	0–100%	0%
165	Stall prevention operation level for restart	0–220%	150%
166	Output current detection signal retention time	0–10s/9999	0.1s
167	Output current detection operation selection	0/1	0
168	Parameter for manufacturer setting. Do not set.		
169			
170	Cumulative power meter clear	0/10/9999	9999
171	Operation hour meter clear	0/9999	9999
172	User group registered display/batch clear	9999/(0–16)	0
173	User group registration	0–999/9999	9999
174	User group clear	0–999/9999	9999
178	STF terminal function selection	0–20/22–28/37/42–44/50/60/62/64–71/9999	60
179	STR terminal function selection	0–20/22–28/37/42–44/50/61/62/64–71/9999	61
180	RL terminal function selection	0–20/22–28/37/42–44/50/62/64–71/9999	0
181	RM terminal function selection		1
182	RH terminal function selection		2
183	RT terminal function selection		3
184	AU terminal function selection	0–20/22–28/37/42–44/50/62–71/9999	4

Parameter	Name	Setting Range	Initial Value	Parameter	Name	Setting Range	Initial Value
185	JOG terminal function selection	0-20/22-28/37/ 42-44/50/62/ 64-71/9999	5	256	Inrush current suppression circuit life display	(0-100%)	100%
186	CS terminal function selection		6	257	Control circuit capacitor life display	(0-100%)	100%
187	MRS terminal function selection		24	258	Main circuit capacitor life display	(0-100%)	100%
188	STOP terminal function selection		25	259	Main circuit capacitor life measuring	0/1	0
189	RES terminal function selection		62	260	PWM frequency automatic switchover	0/1	1
190	RUN terminal function selection		0	261	Power failure stop selection	0/1/2/11/12	0
191	SU terminal function selection		1	262	Subtracted frequency at deceleration start	0-20Hz	3Hz
192	IPF terminal function selection		2	263	Subtraction starting frequency	0-120Hz/9999	50Hz
193	OL terminal function selection		3	264	Power-failure deceleration time 1	0-3600/360s	5s
194	FU terminal function selection		4	265	Power-failure deceleration time 2	0-3600/ 360s/9999	9999
195	ABC1 terminal function selection	0-8/10-20/25-28/ 30-36/39/41-47/ 64/70/84/85/ 90-99/100-108/ 110-116/120/ 125-128/130-136 /139/141-147/164 /170/184/185/ 190-199/9999	99	266	Power failure deceleration time switchover frequency	0-400Hz	50Hz
196	ABC2 terminal function selection		9999	267	Terminal 4 input selection	0/1/2	0
232-239	Multi-speed setting (speeds 8 to 15)	0-400Hz/9999	9999	268	Monitor decimal digits selection	0/1/9999	9999
240	Soft-PWM operation selection	0/1	1	269	Parameter for manufacturer setting. Do not set.		
241	Analog input display unit switchover	0/1	0	270	Stop-on contact/load torque high-speed frequency control selection	0/1/2/3	0
242	Terminal 1 added compensation amount (terminal 2)	0-100%	100%	271	High-speed setting maximum current	0-220%	50%
243	Terminal 1 added compensation amount (terminal 4)	0-100%	75%	272	Medium-speed setting minimum current	0-220%	100%
244	Cooling fan operation selection	0/1	1	273	Current averaging range	0-400Hz/9999	9999
245	Rated slip	0-50%/9999	9999	274	Current averaging filter time constant	1-4000	16
246	Slip compensation time constant	0.01-10s	0.5s	275	Stop-on contact excitation current low-speed multiplying factor	0-1000%/9999	9999
247	Constant-output region slip compensation selection	0/9999	9999	276	PWM carrier frequency at stop-on contact	0-9, 9999/ 0-4, 9999 <sup>①</sup>	9999
250	Stop selection	0-100s/ 1000-1100s/ 8888/9999	9999	278	Brake opening frequency	0-30Hz	3Hz
251	Output phase failure protection selection	0/1	1	279	Brake opening current	0-220%	130%
252	Override bias	0-200%	50%	280	Brake opening current detection time	0-2s	0.3s
253	Override gain	0-200%	150%	281	Brake operation time at start	0-5s	0.3s
255	Life alarm status display	(0-15)	0	282	Brake operation frequency	0-30Hz	6Hz
				283	Brake operation time at stop	0-5s	0.3s
				284	Deceleration detection function selection	0/1	0

Parameter	Name	Setting Range	Initial Value	Parameter	Name	Setting Range	Initial Value
285	Overspeed detection frequency (Excessive speed deviation detection frequency)	0–30Hz/9999	9999	323	AM0 0V adjustment	Parameter for option FR-A7AY (Analog/digital output)	
286	Droop gain	0–100%	0%	324	AM1 0mA adjustment		
287	Droop filter time constant	0–1s	0.3s	329	Digital input unit selection	Parameter for option FR-A7AX (16 bit digital input)	
288	Droop function activation selection	0/1/2/10/11	0	331	RS-485 communication station	0–31 (0–247)	0
291	Pulse train input selection	0/1/10/11/20/21/100	0	332	RS-485 communication speed	3/6/12/24/48/96/192/384	96
292	Automatic acceleration/deceleration	0/1/3/5–8/11	0	333	RS-485 communication stop bit length	0/1/10/11	1
293	Acceleration/deceleration separate selection	0–2	0	334	RS-485 communication parity check selection	0/1/2	2
294	UV avoidance voltage gain	0–200%	100%	335	RS-485 communication number of retries	0–10/9999	1
299	Rotation direction detection selection at restarting	0/1/9999	9999	336	RS-485 communication check time interval	0–999.8s/9999	0s
300	BCD input bias	Parameter for option FR-A7AX (16 bit digital input)		337	RS-485 communication waiting time setting	0–150ms/9999	9999
301	BCD input gain			338	Communication operation command source	0/1	0
302	BIN input bias			339	Communication speed command source	0/1/2	0
303	BIN input gain			340	Communication startup mode selection	0/1/2/10/12	0
304	Digital input and analog input compensation enable/ disable selection			341	RS-485 communication CR/LF selection	0/1/2	1
305	Read timing operation selection			342	Communication EEPROM write selection	0/1	0
306	Analog output signal selection			343	Communication error count	—	0
307	Setting for zero analog output	Parameter for option FR-A7AY (Analog/digital output)		345	DeviceNet address	Parameter for option FR-A7ND (DeviceNet communication)	
308	Setting for maximum analog output			346	DeviceNet baud rate		
309	Analog output signal voltage/current switchover			349	Communication reset selection	Parameter for communication options FR-A7N□□	
310	Analog meter voltage output selection			350 <sup>④</sup>	Stop position command selection	0/1/9999	9999
311	Setting for zero analog meter voltage output			351 <sup>④</sup>	Orientation speed	0–30Hz	2Hz
312	Setting for maximum analog meter voltage output			352 <sup>④</sup>	Creep speed	0–10Hz	0.5Hz
313	D00 output selection			353 <sup>④</sup>	Creep switchover position	0–16383	511
314	D01 output selection	Parameter for option FR-A7AR (Relay outputs)		354 <sup>④</sup>	Position loop switchover position	0–8191	96
315	D02 output selection			355 <sup>④</sup>	DC injection brake start position	0–255	5
316	D03 output selection			356 <sup>④</sup>	Internal stop position command	0–16383	0
317	D04 output selection			357 <sup>④</sup>	Orientation in-position zone	0–255	5
318	D05 output selection			358 <sup>④</sup>	Servo torque selection	0–13	1
319	D06 output selection			359 <sup>④</sup>	Encoder rotation direction	0/1	1
320	RA1 output selection			360 <sup>④</sup>	16 bit data selection	0–127	0
321	RA2 output selection						
322	RA3 output selection						

Parameter	Name	Setting Range	Initial Value	Parameter	Name	Setting Range	Initial Value
361 <sup>④</sup>	Position shift	0–16383	0	416	Pre-scale function selection	0–5	0
362 <sup>④</sup>	Orientation position loop gain	0.1–100	1	417	Pre-scale setting value	0–32767	1
363 <sup>④</sup>	Completion signal output delay time	0–5s	0.5s	419 <sup>④</sup>	Position command source selection	0/2	0
364 <sup>④</sup>	Encoder stop check time	0–5s	0.5s	420 <sup>④</sup>	Command pulse scaling factor numerator	0–32767	1
365 <sup>④</sup>	Orientation limit	0–60s/9999	9999	421 <sup>④</sup>	Command pulse scaling factor denominator	0–32767	1
366 <sup>④</sup>	Recheck time	0–5s/9999	9999	422 <sup>④</sup>	Position loop gain	0–150 [1/s]	25 [1/s]
367 <sup>④</sup>	Speed feedback range	0–400Hz/9999	9999	423 <sup>④</sup>	Position feed forward gain	0–100%	0
368 <sup>④</sup>	Feedback gain	0–100	1	424 <sup>④</sup>	Position command acceleration/deceleration time constant	0–50s	0s
369 <sup>④</sup>	Number of encoder pulses	0–4096	1024	425 <sup>④</sup>	Position feed forward command filter	0–5s	0s
374	Overspeed detection level	0–400Hz	115Hz	426 <sup>④</sup>	In-position width	0–32767 pulse	100
376 <sup>④</sup>	Encoder signal loss detection enable/disable selection	0/1	0	427 <sup>④</sup>	Excessive level error	0–400k/9999	40k
380	Acceleration S-pattern 1	0–50%	0	428 <sup>④</sup>	Command pulse selection	0–5	0
381	Deceleration S-pattern 1	0–50%	0	429 <sup>④</sup>	Clear signal selection	0/1	1
382	Acceleration S-pattern 2	0–50%	0	430 <sup>④</sup>	Pulse monitor selection	0–5/9999	9999
383	Deceleration S-pattern 2	0–50%	0	447	Digital torque command bias	Parameter for option FR-A7AX (16 bit digital input)	
384	Input pulse division scaling factor	0–250	0	448	Digital torque command gain		
385	Frequency for 0 input pulse	0–400Hz	0	450	Second applied motor	0–8/13–18/20/23/24/30/33/34/40/43/44/50/53/54/9999	9999
386	Frequency for maximum input pulse	0–400Hz	50Hz	451	Second motor control method selection	10/11/12/20/9999	9999
387	Initial communication delay time	Parameter for option FR-A7NL (LONWORKS communication)		453	Second motor capacity	0.4–55kW, 9999/0–3600kW, 9999 <sup>④</sup>	9999
388	Send time interval at hart beat			454	Number of second motor poles	2/4/6/8/10/9999	9999
389	Minimum sending time at hart beat			455	Second motor excitation current	0–500A, 9999/0–3600A, 9999 <sup>②</sup>	9999
390	% setting reference frequency			456	Rated second motor voltage	0–1000V	400V
391	Receive time interval at hart beat			457	Rated second motor frequency	10–120Hz	50Hz
392	Event driven detection width			458	Second motor constant A	0–50Ω, 9999/0–400mΩ, 9999 <sup>①</sup>	9999
393 <sup>④</sup>	Orientation selection	0/1/2	0	459	Second motor constant B	0–50Ω, 9999/0–400mΩ, 9999 <sup>①</sup>	9999
396 <sup>④</sup>	Orientation speed gain (P term)	0–1000	60				
397 <sup>④</sup>	Orientation speed integral time	0–20s	0.333s				
398 <sup>④</sup>	Orientation speed gain (D term)	0–100	1				
399 <sup>④</sup>	Orientation deceleration ratio	0–1000	20				
414	PLC function operation selection	0/1	0				
415	Inverter operation lock mode setting	0/1	0				

Parameter	Name	Setting Range	Initial Value	Parameter	Name	Setting Range	Initial Value
460	Second motor constant C	0–50Ω, (0–1000mH), 9999/ 0–3600mΩ, (0–400mH), 9999 <sup>④</sup>	9999	483 <sup>④</sup>	10th position feed amount lower 4 digits	0–9999	0
461	Second motor constant D	0–50Ω, (0–1000mH), 9999/ 0–3600mΩ, (0–400mH), 9999 <sup>④</sup>	9999	484 <sup>④</sup>	10th position feed amount upper 4 digits	0–9999	0
462	Second motor constant E	0–500Ω, (0–100%), 9999/ 0–100Ω, (0–100%), 9999 <sup>④</sup>	9999	485 <sup>④</sup>	11th position feed amount lower 4 digits	0–9999	0
463	Second motor auto tuning setting/status	0/1/101	0	486 <sup>④</sup>	11h position feed amount upper 4 digits	0–9999	0
464 <sup>④</sup>	Digital position control sudden stop deceleration time	0–360.0s	0	487 <sup>④</sup>	12th position feed amount lower 4 digits	0–9999	0
465 <sup>④</sup>	1st position feed amount lower 4 digits	0–9999	0	488 <sup>④</sup>	12th position feed amount upper 4 digits	0–9999	0
466 <sup>④</sup>	1st position feed amount upper 4 digits	0–9999	0	489 <sup>④</sup>	13th position feed amount lower 4 digits	0–9999	0
467 <sup>④</sup>	2nd position feed amount lower 4 digits	0–9999	0	490 <sup>④</sup>	13th position feed amount upper 4 digits	0–9999	0
468 <sup>④</sup>	2nd position feed amount upper 4 digits	0–9999	0	491 <sup>④</sup>	14th position feed amount lower 4 digits	0–9999	0
469 <sup>④</sup>	3rd position feed amount lower 4 digits	0–9999	0	492 <sup>④</sup>	14th position feed amount upper 4 digits	0–9999	0
470 <sup>④</sup>	3rd position feed amount upper 4 digits	0–9999	0	493 <sup>④</sup>	15th position feed amount lower 4 digits	0–9999	0
471 <sup>④</sup>	4th position feed amount lower 4 digits	0–9999	0	494 <sup>④</sup>	15th position feed amount upper 4 digits	0–9999	0
472 <sup>④</sup>	4th position feed amount upper 4 digits	0–9999	0	495	Remote output selection	0/1/10/11	0
473 <sup>④</sup>	5th position feed amount lower 4 digits	0–9999	0	496	Remote output data 1	0–4095	0
474 <sup>④</sup>	5th position feed amount upper 4 digits	0–9999	0	497	Remote output data 2	0–4095	0
475 <sup>④</sup>	6th position feed amount lower 4 digits	0–9999	0	498	PLC function flash memory clear	0–9999	0
476 <sup>④</sup>	6th position feed amount upper 4 digits	0–9999	0	500	Communication error execution waiting time		
477 <sup>④</sup>	7th position feed amount lower 4 digits	0–9999	0	501	Communication error occurrence count display		
478 <sup>④</sup>	7th position feed amount upper 4 digits	0–9999	0	502	Stop mode selection at communication error		
479 <sup>④</sup>	8th position feed amount lower 4 digits	0–9999	0	503	Maintenance timer	0 (1–9998)	0
480 <sup>④</sup>	8th position feed amount upper 4 digits	0–9999	0	504	Maintenance timer alarm output set time	0–9998/9999	9999
481 <sup>④</sup>	9th position feed amount lower 4 digits	0–9999	0	505	Speed setting reference	0–120Hz	50Hz
482 <sup>④</sup>	9th position feed amount upper 4 digits	0–9999	0	506	Parameter 1 for user	0–65535	0
				507	Parameter 2 for user	0–65535	0
				508	Parameter 3 for user	0–65535	0
				509	Parameter 4 for user	0–65535	0
				510	Parameter 5 for user	0–65535	0
				511	Parameter 6 for user	0–65535	0
				512	Parameter 7 for user	0–65535	0
				513	Parameter 8 for user	0–65535	0
				514	Parameter 9 for user	0–65535	0
				515	Parameter 10 for user	0–65535	0
				516	S-pattern time at a start of acceleration	0.1–2.5s	0.1s

Parameter	Name	Setting Range	Initial Value	Parameter	Name	Setting Range	Initial Value
517	S-pattern time at a completion of acceleration	0.1–2.5s	0.1s	595	Amplitude compensation amount during acceleration	0–50%	10%
518	S-pattern time at a start of deceleration	0.1–2.5s	0.1s	596	Amplitude acceleration time	0.1–3600s	5s
519	S-pattern time at a completion of deceleration	0.1–2.5s	0.1s	597	Amplitude deceleration time	0.1–3600s	5s
539	Modbus-RTU communication check time interval	0–999.8s/ 9999	9999	611	Acceleration time at a restart	0–3600s/9999	5/15s <sup>①</sup>
542	Communication station number (CC-Link)	Parameter for option FR-A7NC (CC-Link communication)		665	Regeneration avoidance frequency gain	0–200%	100
543	Baud rate (CC-Link)			684	Tuning data unit switchover	0/1	0
544	CC-Link extended setting			800	Control method selection	0–5/9–12/20	20
547	USB communication station number	0–31	0	802 <sup>④</sup>	Pre-excitation selection	0/1	0
548	USB communication check time interval	0–999.8s/ 9999	9999	803	Constant power range torque characteristic selection	0/1	0
549	Protocol selection	0/1	0	804	Torque command source selection	0/1/3–6	0
550	NET mode operation command source selection	0/1/9999	9999	805	Torque command value (RAM)	600–1400%	1000%
551	PU mode operation command source selection	1/2/3	2	806	Torque command value (RAM, EEPROM)	600–1400%	1000%
555	Current average time	0.1–1.0s	1s	807	Speed limit selection	0/1/2	0
556	Data output mask time	0.0–2.0s	0s	808	Forward rotation speed limit	0–120Hz	50Hz
557	Current average value monitor signal output reference current	0–500A/ 0–3600A <sup>①</sup>	Rated current	809	Reverse rotation speed limit	0–120Hz/9999	9999
563	Energization time carrying-over times	(0–65535)	0	810	Torque limit input method selection	0/1	0
564	Operating time carrying-over times	(0–65535)	0	811	Set resolution switchover	0/1/10/11	0
569	Second motor speed control gain	0–200%/9999	9999	812	Torque limit level (regeneration)	0–400%/9999	9999
570	Multiple rating setting	0–3	2	813	Torque limit level (3rd quadrant)	0–400%/9999	9999
571	Holding time at a start	0.0–10.0s/9999	9999	814	Torque limit level (4th quadrant)	0–400%/9999	9999
573	4 mA Input check selection	1/9999	9999	815	Torque limit level 2	0–400%/9999	9999
574	Second motor online auto tuning	0/1	0	816	Torque limit level during acceleration	0–400%/9999	9999
575	Output interruption detection time	0–3600s/ 9999	1s	817	Torque limit level during Deceleration	0–400%/9999	9999
576	Output interruption detection level	0–400Hz	0Hz	818	Easy gain tuning response level setting	1–15	2
577	Output interruption release level	900–1100%	1000%	819	Easy gain tuning selection	0–2	0
592	Traverse function selection	0/1/2	0	820	Speed control P gain 1	0–1000%	60%
593	Maximum amplitude amount	0–25%	10%	821	Speed control integral time 1	0–20s	0.33s
594	Amplitude compensation amount during deceleration	0–50%	10%	822	Speed setting filter 1	0–5s/9999	9999

Parameter	Name	Setting Range	Initial Value	Parameter	Name	Setting Range	Initial Value
823 <sup>④</sup>	Speed detection filter 1	0–0.1s	0.001s	862	Notch filter time constant	0–60	0
824	Torque control P gain 1	0–200%	100%	863	Notch filter depth	0/1/2/3	0
825	Torque control integral time 1	0–500ms	5ms	864	Torque detection	0–400%	150%
826	Torque setting filter 1	0–5s/ 9999	9999	865	Low speed detection	0–400Hz	1.5Hz
827	Torque detection filter 1	0–0.1s	0s	866	Torque monitoring reference	0–400%	150%
828	Model speed control gain	0–1000%	60%	867	AM output filter	0–5s	0.01s
830	Speed control P gain 2	0–1000%/ 9999	9999	868	Terminal 1 function assignment	0–6/9999	0
831	Speed control integral time 2	0–20s/ 9999	9999	869	Current output filter	0–5s	0.02s
832	Speed setting filter2	0–5s/ 9999	9999	872	Input phase failure protection selection	0/1	0
833 <sup>④</sup>	Speed detection filter 2	0–0.1s/ 9999	9999	873	Speed limit	0–120Hz	20Hz
834	Torque control P gain 2	0–200%/ 9999	9999	874	OLT level setting	0–200%	150%
835	Torque control integral time 2	0–500ms/ 9999	9999	875	Fault definition	0/1	0
836	Torque setting filter 2	0–5s/ 9999	9999	877	Speed feed forward control/model adaptive speed control selection	0/1/2	0
837	Torque detection filter 2	0–0.1s/ 9999	9999	878	Speed feed forward filter	0–1s	0s
840 <sup>④</sup>	Torque bias selection	0–3/ 9999	9999	879	Speed feed forward torque limit	0–400%	150%
841 <sup>④</sup>	Torque bias 1	600–1400%/ 9999	9999	880	Load inertia ratio	0–200	7
842 <sup>④</sup>	Torque bias 2	600–1400%/ 9999	9999	881	Speed feed forward gain	0–1000%	0%
843 <sup>④</sup>	Torque bias 3	600–1400%/ 9999	9999	882	Regeneration avoidance operation selection	0/1/2	0
844 <sup>④</sup>	Torque bias filter	0–5s/ 9999	9999	883	Regeneration avoidance operation level	300–800V	760/785V DC <sup>①</sup>
845 <sup>④</sup>	Torque bias operation time	0–5s/ 9999	9999	884	Regeneration avoidance at deceleration detection sensitivity	0–5	0
846 <sup>④</sup>	Torque bias balance compensation	0–10V/ 9999	9999	885	Regeneration avoidance compensation frequency limit value	0–10Hz/9999	6Hz
847 <sup>④</sup>	Fall-time torque bias terminal 1 bias	0–400%/ 9999	9999	886	Regeneration avoidance voltage gain	0–200%	100%
848 <sup>④</sup>	Fall-time torque bias terminal 1 gain	0–400%/ 9999	9999	888	Free parameter 1	0–9999	9999
849	Analog input off set adjustment	0–200%	100%	889	Free parameter 2	0–9999	9999
850	Control operation selection	0/1	0	891	Cumulative power monitor digit shifted times	0–4/9999	9999
853	Speed deviation time	0–100s	1s	892	Load factor	30–150%	100%
854	Excitation ratio	0–100%	100%	893	Energy saving monitor reference (motor capacity)	0.1–55kW/ 0–3600kW <sup>①</sup>	SLD/LD/ND/ HD value of applied motor capacity
858	Terminal 4 function assignment	0/1/4/ 9999	0	894	Control selection during commercial power-supply operation	0/1/2/3	0
859	Torque current	0–500A, 9999/ 0–3600A, 9999 <sup>①</sup>	9999	895	Power saving rate reference value	0/1/9999	9999
860	Second motor torque current	0–500A, 9999/ 0–3600A, 9999 <sup>①</sup>	9999				

Parameter	Name	Setting Range	Initial Value	Parameter	Name	Setting Range	Initial Value
896	Power unit cost	0–500/9999	9999	C12 (917)	Terminal 1 bias frequency (speed)	0–400Hz	0Hz
897	Power saving monitor average time	0/1–1000h/9999	9999	C13 (917)	Terminal 1 bias (speed)	0–300%	0%
898	Power saving cumulative monitor clear	0/1/10/9999	9999	C14 (918)	Terminal 1 gain frequency (speed)	0–400Hz	50Hz
899	Operation time rate (estimated value)	0–100%/9999	9999	C15 (918)	Terminal 1 gain (speed)	0–300%	100%
C0 (900)	FM terminal calibration	—	—	C16 (919)	Terminal 1 bias command (torque/magnetic flux)	0–400%	0%
C1 (901)	AM terminal calibration	—	—	C17 (919)	Terminal 1 bias (torque/magnetic flux)	0–300%	0%
C2 (902)	Terminal 2 frequency setting bias frequency	0–400Hz	0Hz	C18 (920)	Terminal 1 gain command (torque/magnetic flux)	0–400%	150%
C3 (902)	Terminal 2 frequency setting bias	0–300%	0%	C19 (920)	Terminal 1 gain (torque/magnetic flux)	0–300%	100%
125 (903)	Terminal 2 frequency setting gain frequency	0–400Hz	50Hz	C38 (932)	Terminal 4 bias command (torque/magnetic flux)	0–400%	0%
C4 (903)	Terminal 2 frequency setting gain	0–300%	100%	C39 (932)	Terminal 4 bias (torque/magnetic flux)	0–300%	20%
C5 (904)	Terminal 4 frequency setting bias frequency	0–400Hz	0Hz	C40 (933)	Terminal 4 gain command (torque/magnetic flux)	0–400%	150%
C6 (904)	Terminal 4 frequency setting bias	0–300%	20%	C41 (933)	Terminal 4 gain (torque/magnetic flux)	0–300%	100%
126 (905)	Terminal 4 frequency setting gain frequency	0–400Hz	50Hz	989	Parameter copy alarm release	10/100	10/100 <sup>②</sup>
C7 (905)	Terminal 4 frequency setting gain	0–300%	100%	990	PU buzzer control	0/1	1
C8 (930)	Current output bias signal	0–100%	0%	991	PU contrast adjustment	0–63	58
C9 (930)	Current output bias current	0–100%	0%	Pr.CL	Parameter clear	0/1	0
C10 (931)	Current output gain signal	0–100%	100%	ALLC	All parameter clear	0/1	0
C11 (931)	Current output gain current	0–100%	100%	Er.CL	Alarm history clear	0/1	0
				PCPY	Parameter copy	0/1/2/3	0

## Remarks:

- ① The setting depends on the inverter capacity.
- ② When the value “8888” is set, the maximum output voltage is 95% of the input voltage.
- ③ When the value “9999” is set, the maximum output voltage equals the input voltage.
- ④ Setting can be made only when the FR-A7AP is mounted.

## A.2 Sample Applications


The applications in this section have been chosen to demonstrate some of the things that you can do with frequency inverters.

### NOTE


The wiring diagrams and the parameter settings are only provided to illustrate these specific examples. They should not be copied directly – you will need to wire and configure your inverter for the specific requirements of your own application. When you are planning and installing your system please also be sure to observe all the relevant regulations and standards for electrical systems applicable in your location, particularly the safety regulations.

### A.2.1 Conveyor Belt


Frequency inverters are often used to control conveyor belts to feed parts and material to processing stations because they are able to accelerate and decelerate the drive gently.



In this example we are going to use an FR-D700 series inverter to power and control the belt using the speed/time pattern shown in the graph above. The configuration is as follows:




The belt is started and stopped by an external controller (for example a PLC). The speed of the motor and thus of the conveyor belt can be adjusted with a setpoint potentiometer.



If the material on the belt still shifts when stopping and starting even with a gentle acceleration curve you can solve the problem by programming an S-curve for acceleration and deceleration, as shown in the graph on the left.

You can change the curve with parameter 29. A value of "0" sets a linear acceleration/deceleration curve, a value of "1" sets an S-curve.


### Wiring




## A.2.2 Lifting Drive

The illustration below shows the basic configuration of an inverter for powering a drive for lifting applications like hoists or roll-up gates. A motor with a mechanical brake is used to ensure that the load cannot not slip down when the motor is off.

When the end position is reached the motor is turned off by a limit switch. After this it can only be activated in the other direction.



In the wiring diagram on the next page the mechanical brake is controlled via the RUN terminal. The frequency at which the brake is released can be set with parameter 13.

**Wiring**

### A.2.3 PID Controller

The FR-D700, FR-E700/E700SC, FR-F700 and FR-A700 series have integrated PID controllers, which makes it possible to use these inverters for applications in the process industry like flow and pressure regulation.

The setpoint value is stored internally in an inverter parameter or input as an external signal via input terminals 2 and 5. The actual value is input as an analog current signal (4-20mA) via input terminals 4 and 5.


The inverter automatically adjusts its output frequency (the *control variable*) in response to the difference between the setpoint and actual values (the *control deviation*). This increases or decreases the speed of the motor to bring the actual value closer to the setpoint value.

The PID control action direction (forward/reverse) can be set with a parameter.


Control Direction	Controller Behaviour	Application (temperature control)
Forward	Actual > Setpoint: Increase control variable Actual < Setpoint: Decrease control variable	Cooling/refrigeration system
Reverse	Actual > Setpoint: Decrease control variable Actual < Setpoint: Increase control variable	Heating system

The illustration below shows a typical configuration for maintaining a constant pressure in the controlled system. The example shows the setup for this application for the FR-F700 inverter.

Schematic diagrams for two versions are included. In the first version an external setpoint signal is provided by a potentiometer connected to the input terminals, in the second the setpoint is set with the control unit and the value is stored in an inverter parameter.



### External setpoint signal




For the PID controller application using the configuration shown above you must also set the inverter parameters shown in the table below, in addition to the basic parameters.

Parameters	Function	Setting
180	RL terminal function assignment	"14" (enable PID control)
128	PID action direction	"20" (reverse action)

\* In a pressure control application you increase pump speed when the actual value is smaller than the setpoint value.

**Setpoint value set with parameters**

In the configuration shown in the circuit diagram below the setpoint is entered via the control unit and stored in a parameter.



In addition to the basic parameters you must also set the following parameters for this configuration:

Parameter	Function	Setting
180	RL terminal function assignment	"14" (enable PID control)
128	PID action direction	"20" (reverse action)
133	Setpoint	0 –100%



# Index

## A

Acceleration time . . . . . 6-6  
Ambient conditions . . . . . 1-2  
Asynchronous three-phase motor . . . . . 1-1

## B

Basic Parameters . . . . . 6-1  
Braking time  
    see deceleration time

## C

Control deviation (PID controller) . . . . . A-31  
Control unit  
    FR-DU07 . . . . . 5-5  
Control unit FR-DU07  
    Description . . . . . 5-5  
    Functions . . . . . 5-7  
Control variable (PID controller) . . . . . A-31

## D

Deceleration time . . . . . 6-6  
Delay time  
    see deceleration time  
Digital dial . . . . . 5-3  
Direction of rotation (motor) . . . . . 1-3

## E

EMC filter  
    connection . . . . . 3-7  
    switching ON/OFF on FR-F700/FR-A700 . . 3-8  
Error codes . . . . . 7-4

## F

Forward operation  
    Start signal (STF) . . . . . 3-3  
    direction of rotation . . . . . 1-3

## I

Input voltages . . . . . 3-1

## M

MRS (control signal) . . . . . 3-3  
Mains RFI suppression filters  
    see EMC Filters

## O

Operation Mode  
    Selection with parameter 79 . . . . . 6-7  
Output frequency  
    parameter . . . . . 6-3  
    setting with control unit . . . . . 5-9

## P

PID Controller . . . . . A-31  
PU operation mode  
    configuration . . . . . 5-8  
    defined . . . . . 1-3  
    display on FR-D700 and FR-E700/E700SC . 5-2  
    display on FR-F700 and FR-A700 . . . . . 5-5  
Parameter  
    0 . . . . . 6-3  
    1 and 2 . . . . . 6-3  
    20 . . . . . 6-6  
    3 . . . . . 6-4  
    4, 5 and 6 . . . . . 6-4  
    7 and 8 . . . . . 6-6  
    79 . . . . . 6-7  
    9 . . . . . 6-6  
    Basic parameters . . . . . 6-1  
    Reference . . . . . A-1  
    defined . . . . . 6-1  
    editing . . . . . 5-11

## R

RES (control signal) . . . . . 3-3  
Reverse operation  
    Start signal (STR) . . . . . 3-3  
    direction of rotation . . . . . 1-3

## S

S-curve for acceleration/deceleration . . . . . A-28  
STF (control signal) . . . . . 3-3  
STR (control signal) . . . . . 3-3  
Specifications  
    Ambient conditions . . . . . 1-2  
    Power supply . . . . . 3-1



AbN  
automation

HEADQUARTERS		EUROPEAN REPRESENTATIVES		EUROPEAN REPRESENTATIVES		EURASIAN REPRESENTATIVES	
MITSUBISHI ELECTRIC EUROPE B.V. German Branch Gothaer Straße 8 <b>D-40880 Ratingen</b> Phone: +49 (0)2102 / 486-0 Fax: +49 (0)2102 / 486-1120	EUROPE	GEVA Wiener Straße 89 <b>AT-2500 Baden</b> Phone: +43 (0)2252 / 85 55 20 Fax: +43 (0)2252 / 488 60	AUSTRIA	ALFATRADE Ltd. 99, Paola Hill <b>Malta- Paola PLA 1702</b> Phone: +356 (0)21 / 697 816 Fax: +356 (0)21 / 697 817	MALTA	TOO Kazpromavtomatika Ul. Zhambyla 28 <b>KAZ-00017 Karaganda</b> Phone: +7 7212 / 50 10 00 Fax: +7 7212 / 50 11 50	KAZAKHSTAN
MITSUBISHI ELECTRIC EUROPE B.V.-org.sl. <b>CZECH REP.</b> Czech Branch Avenir Business Park, Radlická 714/113a <b>CZ-158 00 Praha 5</b> Phone: +420 - 251 551 470 Fax: +420 - 251-551-471		TEHNIKON Oktyabrskaya 16/5, Off. 703-711 <b>BY-220030 Minsk</b> Phone: +375 (0)17 / 210 46 26 Fax: +375 (0)17 / 210 46 26	BELARUS	INTEHSIS srl bld. Traian 23/1 <b>MD-2060 Kishinev</b> Phone: +373 (0)22 / 66 4242 Fax: +373 (0)22 / 66 4280	MOLDOVA		
MITSUBISHI ELECTRIC EUROPE B.V. French Branch 25, Boulevard des Bouvets <b>F-92741 Nanterre Cedex</b> Phone: +33 (0)1 / 55 68 55 68 Fax: +33 (0)1 / 55 68 57 57	FRANCE	ESCO DRIVES & AUTOMATION Culliganlaan 3 <b>BE-1831 Diegem</b> Phone: +32 (0)2 / 717 64 30 Fax: +32 (0)2 / 717 64 31	BELGIUM	HIFLEX AUTOM.TECHNIK B.V. Wolvestraat 22 <b>NL-2984 CD Ridderkerk</b> Phone: +31 (0)180 - 46 60 04 Fax: +31 (0)180 - 44 23 55	NETHERLANDS	SHERF Motion Techn. Ltd. Rehov Hamerkava 19 <b>IL-58851 Holon</b> Phone: +972 (0)3 / 559 54 62 Fax: +972 (0)3 / 556 01 82	ISRAEL
MITSUBISHI ELECTRIC EUROPE B.V. Irish Branch Westgate Business Park, Ballymount <b>IRL-Dublin 24</b> Phone: +353 (0)1 4198800 Fax: +353 (0)1 4198890	IRELAND	Koning & Hartman b.v. Woluweelaan 31 <b>BE-1800 Vilvoorde</b> Phone: +32 (0)2 / 257 02 40 Fax: +32 (0)2 / 257 02 49	BELGIUM	Koning & Hartman b.v. Haarlerbergweg 21-23 <b>NL-1101 CH Amsterdam</b> Phone: +31 (0)20 / 587 76 00 Fax: +31 (0)20 / 587 76 05	NETHERLANDS	CEG INTERNATIONAL Cebaco Center/Block A Autostrade DORA <b>Lebanon - Beirut</b> Phone: +961 (0)1 / 240 430 Fax: +961 (0)1 / 240 438	LEBANON
MITSUBISHI ELECTRIC EUROPE B.V. Italian Branch Viale Colleoni 7 <b>I-20041 Agrate Brianza (MB)</b> Phone: +39 039 / 60 53 1 Fax: +39 039 / 60 53 312	ITALY	INEA BH d.o.o. Aleja Lipa 56 <b>BA-7100 Sarajevo</b> Phone: +387 (0)33 / 921 164 Fax: +387 (0)33 / 524 539	BOSNIA AND HERZEGOVINA	Beijer Electronics AS Postboks 487 <b>NO-3002 Drammen</b> Phone: +47 (0)32 / 24 30 00 Fax: +47 (0)32 / 84 85 77	NORWAY		
MITSUBISHI ELECTRIC EUROPE B.V. Poland Branch Krakowska 50 <b>PL-32-083 Balice</b> Phone: +48 (0)12 / 630 47 00 Fax: +48 (0)12 / 630 47 01	POLAND	AKHNATON 4 Andrej Ljapchev Blvd. Pb 21 <b>BG-1756 Sofia</b> Phone: +359 (0)2 / 817 6044 Fax: +359 (0)2 / 97 44 06 1	BULGARIA	Fonseca S.A. R. João Francisco do Casal 87/89 <b>PT-3801-997 Aveiro, Esqueira</b> Phone: +351 (0)234 / 303 900 Fax: +351 (0)234 / 303 910	PORTUGAL		
MITSUBISHI ELECTRIC EUROPE B.V. 52, bld. 3 Kosmodamianskaya nab 8 floor <b>RU-115054 Moscow</b> Phone: +7 495 721-2070 Fax: +7 495 721-2071	RUSSIA	INEA CR d.o.o. Losijska 4 a <b>HR-10000 Zagreb</b> Phone: +385 (01 / 36 940 - 01/-02/-03 Fax: +385 (01 / 36 940 - 03	CROATIA	Sirius Trading & Services srl Aleea Lacul Morii Nr. 3 <b>RO-060841 Bucuresti, Sector 6</b> Phone: +40 (0)21 / 430 40 06 Fax: +40 (0)21 / 430 40 02	ROMANIA		
MITSUBISHI ELECTRIC EUROPE B.V. Spanish Branch Carretera de Rubí 76-80 <b>E-08190 Sant Cugat del Vallés (Barcelona)</b> Phone: 902 131121 // +34 935653131 Fax: +34 935891579	SPAIN	AutoCont C.S. s.r.o. Technologická 374/6 <b>CZ-708 00 Ostrava-Pustkovec</b> Phone: +420 595 691 150 Fax: +420 595 691 199	CZECH REPUBLIC	Craft Con. & Engineering d.o.o. Bulevar Svetog Cara Konstantina 80-86 <b>SER-18106 Niš</b> Phone: +381 (0)18 / 292-24-4/5 Fax: +381 (0)18 / 292-24-4/5	SERBIA		
MITSUBISHI ELECTRIC EUROPE B.V. UK Branch Travellers Lane <b>UK-Hatfield, Herts. AL10 8XB</b> Phone: +44 (0)1707 / 27 61 00 Fax: +44 (0)1707 / 27 86 95	UK	Beijer Electronics A/S Lykkegårdsvæj 17 <b>DK-4000 Roskilde</b> Phone: +45 (0)46 / 75 76 66 Fax: +45 (0)46 / 75 56 26	DENMARK	INEA SR d.o.o. Izletnicka 10 <b>SER-113000 Smederevo</b> Phone: +381 (0)26 / 617 163 Fax: +381 (0)26 / 617 163	SERBIA		
MITSUBISHI ELECTRIC CORPORATION Office Tower "Z" 14 F 8-12, 1 chome, Harumi Chuo-Ku <b>Tokyo 104-6212</b> Phone: +81 3 622 160 60 Fax: +81 3 622 160 75	JAPAN	Beijer Electronics Eesti OÜ Pärnu mnt.160i <b>EE-11317 Tallinn</b> Phone: +372 (0)6 / 51 81 40 Fax: +372 (0)6 / 51 81 49	ESTONIA	SIMAP s.r.o. Jána Derku 1671 <b>SK-911 01 Trenčín</b> Phone: +421 (0)32 743 04 72 Fax: +421 (0)32 743 75 20	SLOVAKIA		
MITSUBISHI ELECTRIC AUTOMATION, Inc. 500 Corporate Woods Parkway <b>Vernon Hills, IL 60061</b> Phone: +1 847 478 21 00 Fax: +1 847 478 22 53	USA	Beijer Electronics OY Peltioja 37 <b>FIN-28400 Ulvila</b> Phone: +358 (0)207 / 463 540 Fax: +358 (0)207 / 463 541	FINLAND	PROCONT, spol. s.r.o. Prešov Kúpelňa 1/A <b>SK-080 01 Prešov</b> Phone: +421 (0)51 7580 611 Fax: +421 (0)51 7580 650	SLOVAKIA		
		UTECO 5, Mavrogenous Str. <b>GR-18542 Pireaus</b> Phone: +358 (0)207 / 463 540 Fax: +358 (0)207 / 463 541	GREECE	INEA d.o.o. Stegne 11 <b>SI-1000 Ljubljana</b> Phone: +386 (0)1 / 513 8100 Fax: +386 (0)1 / 513 8170	SLOVENIA		
		MELTRADE Kft. Fertő utca 14. <b>HU-1107 Budapest</b> Phone: +36 (0)1 / 431-9726 Fax: +36 (0)1 / 431-9727	HUNGARY	Beijer Electronics AB Box 426 <b>SE-20124 Malmö</b> Phone: +46 (0)40 / 35 86 00 Fax: +46 (0)40 / 93 23 01	SWEDEN		
		Beijer Electronics SIA Ritausmas iela 23 <b>LV-1058 Riga</b> Phone: +371 (0)784 / 2280 Fax: +371 (0)784 / 2281	LATVIA	Omni Ray AG Im Schörli 5 <b>CH-8600 Dübendorf</b> Phone: +41 (0)44 / 802 28 80 Fax: +41 (0)44 / 802 28 28	SWITZERLAND		
		Beijer Electronics UAB Savanoriu Pr. 187 <b>LT-02300 Vilnius</b> Phone: +370 (0)5 / 232 3101 Fax: +370 (0)5 / 232 2980	LITHUANIA	GTS Bayraktar Bulvarı Nutuk Sok. No:5 <b>TR-34775 Yukarı Dardullu-Ümraniye-İSTANBUL</b> Phone: +90 (0)216 526 39 90 Fax: +90 (0)216 526 3995	TURKEY		
				CSC Automation Ltd. 4-B, M. Raskovoy St. <b>UA-02660 Kiev</b> Phone: +380 (0)44 / 494 33 55 Fax: +380 (0)44 / 494-33-66	UKRAINE		