


Programmable Controller

MELSEC **Q**_{series} MELSEC **L**_{series}

MELSEC-Q/L AnyWire DB A20 Master Module User's Manual

-QJ51AW12D2
-LJ51AW12D2



Powered by

Anywire

This product was jointly developed and manufactured by Mitsubishi and Anywire Corporation.

*Note that the warranty on this product differs from that on other programmable controller products.
(Refer to "WARRANTY" in this manual.)

AnyWire DB A20

COPYRIGHT

This document is protected by the law of copyright, whereby all rights established therein remain with the company Mitsubishi Electric Corporation. Reproduction of this document or parts of this document is only permissible within the limits of the legal determination of Copyright Law. Alteration or abridgement of the document is not permitted without the explicit written approval of the company Mitsubishi Electric Corporation.

PRECAUTIONS REGARDING WARRANTY AND SPECIFICATIONS

The QJ51AW12D2 and LJ51AW12D2 were jointly developed and manufactured by Mitsubishi and Anywire Corporation.

Note that there are some precautions regarding warranty and specifications of this product.

<Warranty>

Item	QJ51AW12D2, LJ51AW12D2	Other programmable controller products (e.g. MELSEC-Q series)
Repair term after discontinuation of production	1 years	7 years

<Specifications>

The general specifications of the QJ51AW12D2 are the same as those of other MELSEC-Q series except under the following condition.

When setting the transmission clock at 125kHz by using the master module whose serial number (sixth digit) is 5 or earlier, apply within the following specified range:

Voltage range of external power supply: 21.6 to 25.2VDC

Operating ambient temperature: 0 to 50°C

The general specifications of the LJ51AW12D2 are the same as those of other MELSEC-L series.

<Application of the EMC Directive>

Item	QJ51AW12D2	LJ51AW12D2	Other programmable controller products (e.g. MELSEC-Q series)
Applicable EMC standard	EN61131-2 ^{*1}	EN61131-2	EN61131-2

*1 The master module with a serial number where the sixth digit is "3" or later complies with this standard.

<Application of the UL/cUL standards>

Item	QJ51AW12D2	LJ51AW12D2	Other programmable controller products (e.g. MELSEC-Q series)
Applicable UL standard/cUL standard	UL508 ^{*2} CSA22.2 ^{*2}	UL508 ^{*3} CSA22.2 ^{*3}	UL508 CSA22.2

*2 The master module with a serial number where the sixth digit is "4" or later complies with this standard.

*3 The master module with a serial number where the sixth digit is "2" or later complies with this standard.

●SAFETY PRECAUTIONS●

(Read these precautions before using this product.)

Before using this product, please read this manual and the relevant manuals carefully and pay full attention to safety to handle the product correctly.

The precautions given in this manual are concerned with this product only. For the safety precautions of the programmable controller system, refer to the user's manual for the CPU module used.

In this manual, the safety precautions are classified into two levels: " WARNING" and " CAUTION".

 **WARNING**

Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.

 **CAUTION**

Indicates that incorrect handling may cause hazardous conditions, resulting in minor or moderate injury or property damage.

Under some circumstances, failure to observe the precautions given under " CAUTION" may lead to serious consequences.

Observe the precautions of both levels because they are important for personal and system safety.

Make sure that the end users read this manual and then keep the manual in a safe place for future reference.

When the QJ51AW12D2 is used

[Design Precautions]

WARNING

- An AnyWire DB A20 system has no control function for ensuring safety.
- When connecting a peripheral with the CPU module or a personal computer with an intelligent function module to modify data of a running programmable controller, configure an interlock circuit in the sequence program to ensure that the entire system will always operate safely. For other forms of control (such as program modification or operating status change) of a running programmable controller, read the relevant manuals carefully and ensure that the operation is safe before proceeding. Especially, when a remote programmable controller is controlled by an external device, immediate action cannot be taken if a problem occurs in the programmable controller due to a communication failure. To prevent this, configure an interlock circuit in the sequence program, and determine corrective actions to be taken between the external device and CPU module in case of a communication failure.
- Do not write any data to the "system area" of the buffer memory in the intelligent function module. Also, do not use any "use prohibited" signals as an output signal from the CPU module to each module. Doing so may cause malfunction of the programmable controller system.

[Design Precautions]

CAUTION

- Although an AnyWire DB A20 system features high noise immunity, keep a distance of 100mm or more between the transmission cables or I/O cables and the high-voltage cables or power cables. Failure to do so may cause malfunction.
- Configure safety circuits, such as an emergency stop circuit and interlock circuit, external to the AnyWire DB A20 system.

[Installation Precautions]

WARNING

- Use the programmable controller in an environment that meets the general specifications in the user's manual for the CPU module used.
Failure to do so may result in electric shock, fire, malfunction, or damage to or deterioration of the product.
- To mount the module, while pressing the module mounting lever located in the lower part of the module, fully insert the module fixing projection(s) into the hole(s) in the base unit and press the module until it snaps into place.
Incorrect interconnection may cause malfunction, failure, or drop of the module.
When using the programmable controller in an environment of frequent vibrations, fix the module with a screw.
Tighten the screw within the specified torque range.
Undertightening can cause drop of the screw, short circuit, or malfunction.
Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.
- Shut off the external power supply (all phases) used in the system before mounting or removing a module.
Failure to do so may result in damage to the product.
- Do not directly touch any conductive parts and electronic components of the module.
Doing so can cause malfunction or failure of the module.

[Wiring Precautions]

CAUTION

- Tighten the terminal block screws within the specified torque range.
Undertightening can cause short circuit, fire, or malfunction.
Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.
- Prevent foreign matter such as dust or wire chips from entering the module.
Such foreign matter can cause a fire, failure, or malfunction.
- A protective film is attached to the top of the module to prevent foreign matter, such as wire chips, from entering the module during wiring.
Do not remove the film during wiring.
Remove it for heat dissipation before system operation.
- Incorrect wiring may damage modules and external devices.
Adjust a cable length and a module position to prevent disconnection of a connector type terminal block or a cable.
- Do not solder stranded wires of a cable when connecting them to the terminal block. Doing so may cause poor contact.
- The power supply voltage of remote slave modules may be insufficient due to a voltage drop in the power supply line. Connect an external power supply so that the voltage of remote slave modules is ensured.
- Do not apply the 24VDC power before wiring the entire AnyWire DB A20 system. If the power is applied before wiring, normal data transmission is not guaranteed.
- Use 24VDC stabilized power supplies for devices in the AnyWire DB A20 system.
- Do not install the control lines or communication cables together with the main circuit lines or power cables.
Failure to do so may result in malfunction due to noise.
- Place the cables in a duct or clamp them.
If not, dangling cable may swing or inadvertently be pulled, resulting in damage to the module or cables or malfunction due to poor contact.
- When disconnecting the cable from the module, do not pull the cable by the cable part.
For the cable connected to the terminal block, loosen the terminal screw.
Pulling the cable connected to the module may result in malfunction or damage to the module or cable.

[Startup and Maintenance Precautions]

WARNING

- Do not touch any terminal while power is on. Doing so will cause electric shock or malfunction.
- Shut off the external power supply (all phases) used in the system before cleaning the module or retightening the terminal screws or module fixing screws.
Failure to do so may result in electric shock.
Undertightening the terminal screws can cause short circuit or malfunction.
Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.

[Startup and Maintenance Precautions]

CAUTION

- Do not disassemble or modify the modules. Doing so may cause failure, malfunction, injury, or a fire.
- Shut off the external power supply (all phases) used in the system before mounting or removing a module.
Failure to do so may cause the module to fail or malfunction.
- After the first use of the product, do not mount/remove the module to/from the base unit, and the terminal block to/from the module more than 50 times (IEC 61131-2 compliant) respectively.
Exceeding the limit of 50 times may cause malfunction.
- Before handling the module, touch a grounded metal object to discharge the static electricity from the human body.
Failure to do so may cause the module to fail or malfunction.

[Disposal Precautions]

CAUTION

- When disposing of this product, treat it as industrial waste.

When the LJ51AW12D2 is used

[Design Precautions]

WARNING

- An AnyWire DB A20 system has no control function for ensuring safety.
- When connecting a peripheral with the CPU module or a personal computer with an intelligent function module to modify data of a running programmable controller, configure an interlock circuit in the sequence program to ensure that the entire system will always operate safely. For other forms of control (such as program modification or operating status change) of a running programmable controller, read the relevant manuals carefully and ensure that the operation is safe before proceeding. Especially, when a remote programmable controller is controlled by an external device, immediate action cannot be taken if a problem occurs in the programmable controller due to a communication failure. To prevent this, configure an interlock circuit in the sequence program, and determine corrective actions to be taken between the external device and CPU module in case of a communication failure.
- Do not write any data to the "system area" of the buffer memory in the intelligent function module. Also, do not use any "use prohibited" signals as an output signal from the CPU module to each module. Doing so may cause malfunction of the programmable controller system.

[Design Precautions]

CAUTION

- Do not install the control lines or communication cables together with the main circuit lines or power cables.
Keep a distance of 100mm or more between them. Failure to do so may result in malfunction due to noise.
- Configure safety circuits, such as an emergency stop circuit and interlock circuit, external to the AnyWire DB A20 system.

[Installation Precautions]

WARNING

- Shut off the external power supply (all phases) used in the system before mounting or removing the module.
Failure to do so may result in electric shock or cause the module to fail or malfunction.

[Installation Precautions]

CAUTION

- Use the programmable controller in an environment that meets the general specifications in the Safety Guidelines provided with the CPU module or head module. Failure to do so may result in electric shock, fire, malfunction, or damage to or deterioration of the product.
- To interconnect modules, engage the respective connectors and securely lock the module joint levers. Incorrect interconnection may cause malfunction, failure, or drop of the module.
- Tighten the screws within the specified torque range. Undertightening can cause drop of the screw, short circuit, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.
- Do not directly touch any conductive parts and electronic components of the module.
Doing so can cause malfunction or failure of the module.

[Wiring Precautions]

CAUTION

- Tighten the terminal block screws within the specified torque range.
Undertightening can cause short circuit, fire, or malfunction.
Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.
- Prevent foreign matter such as dust or wire chips from entering the module.
Such foreign matter can cause a fire, failure, or malfunction.
- A protective film is attached to the top of the module to prevent foreign matter, such as wire chips, from entering the module during wiring.
Do not remove the film during wiring.
Remove it for heat dissipation before system operation.
- Incorrect wiring may damage modules and external devices.
Adjust a cable length and a module position to prevent disconnection of a connector type terminal block or a cable.
- Do not solder stranded wires of a cable when connecting them to the terminal block. Doing so may cause poor contact.
- The power supply voltage of remote slave modules may be insufficient due to a voltage drop in the power supply line. Connect an external power supply so that the voltage of remote slave modules is ensured.
- Do not apply the 24VDC power before wiring the entire AnyWire DB A20 system. If the power is applied before wiring, normal data transmission is not guaranteed.
- Use 24VDC stabilized power supplies for devices in the AnyWire DB A20 system.
- Do not install the control lines or communication cables together with the main circuit lines or power cables.
Failure to do so may result in malfunction due to noise.
- Place the cables in a duct or clamp them.
If not, dangling cable may swing or inadvertently be pulled, resulting in damage to the module or cables or malfunction due to poor contact.
- When disconnecting the cable from the module, do not pull the cable by the cable part.
For the cable connected to the terminal block, loosen the terminal screw.
Pulling the cable connected to the module may result in malfunction or damage to the module or cable.

[Startup and Maintenance Precautions]

⚠ WARNING

- Do not touch any terminal while power is on. Doing so will cause electric shock or malfunction.
- Shut off the external power supply (all phases) used in the system before cleaning the module or retightening the terminal block screws. Failure to do so may result in electric shock.

[Startup and Maintenance Precautions]

⚠ CAUTION

- Do not disassemble or modify the module.
Doing so may cause failure, malfunction, injury, or a fire.
- Shut off the external power supply (all phases) used in the system before mounting or removing a module.
Failure to do so may cause the module to fail or malfunction.
- Tighten the terminal block screws within the specified torque range. Undertightening can cause drop of the component or wire, short circuit, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.
- After the first use of the product (module, display unit, and terminal block), the number of connections/disconnections is limited to 50 times (in accordance with IEC 61131-2).
Exceeding the limit may cause malfunction.
- Before handling the module, touch a conducting object such as a grounded metal to discharge the static electricity from the human body.
Failure to do so may cause the module to fail or malfunction.

[Disposal Precautions]

⚠ CAUTION

- When disposing of this product, treat it as industrial waste.

● CONDITIONS OF USE FOR THE PRODUCT ●

(1) Mitsubishi programmable controller ("the PRODUCT") shall be used in conditions;

- i) where any problem, fault or failure occurring in the PRODUCT, if any, shall not lead to any major or serious accident; and
- ii) where the backup and fail-safe function are systematically or automatically provided outside of the PRODUCT for the case of any problem, fault or failure occurring in the PRODUCT.

(2) The PRODUCT has been designed and manufactured for the purpose of being used in general industries.

mitsubishi shall have no responsibility or liability (including, but not limited to any and all responsibility or liability based on contract, warranty, tort, product liability) for any injury or death to persons or loss or damage to property caused by the PRODUCT that are operated or used in application not intended or excluded by instructions, precautions, or warning contained in mitsubishi's user, instruction and/or safety manuals, technical bulletins and guidelines for the PRODUCT.

("Prohibited Application")

Prohibited Applications include, but not limited to, the use of the PRODUCT in;

- Nuclear Power Plants and any other power plants operated by Power companies, and/or any other cases in which the public could be affected if any problem or fault occurs in the PRODUCT.
- Railway companies or Public service purposes, and/or any other cases in which establishment of a special quality assurance system is required by the Purchaser or End User.
- Aircraft or Aerospace, Medical applications, Train equipment, transport equipment such as Elevator and Escalator, Incineration and Fuel devices, Vehicles, Manned transportation, Equipment for Recreation and Amusement, and Safety devices, handling of Nuclear or Hazardous Materials or Chemicals, Mining and Drilling, and/or other applications where there is a significant risk of injury to the public or property.

Notwithstanding the above, restrictions Mitsubishi may in its sole discretion, authorize use of the PRODUCT in one or more of the Prohibited Applications, provided that the usage of the PRODUCT is limited only for the specific applications agreed to by Mitsubishi and provided further that no special quality assurance or fail-safe, redundant or other safety features which exceed the general specifications of the PRODUCTS are required. For details, please contact the Mitsubishi representative in your region.

COMPLIANCE WITH EMC AND LOW VOLTAGE DIRECTIVES

(1) Method of ensuring compliance

To ensure that Mitsubishi programmable controllers maintain EMC and Low Voltage Directives when incorporated into other machinery or equipment, certain measures may be necessary. Please refer to one of the following manuals.

- User's manual for the CPU module or head module used
- Safety Guidelines (This manual is included with the CPU module or base unit.)

The CE mark on the side of the programmable controller indicates compliance with EMC and Low Voltage Directives.

(2) Additional measures

To ensure that this product maintains EMC and Low Voltage Directives, please refer to Page 69, Appendix 1.

CONTENTS

COPYRIGHT	1
PRECAUTIONS REGARDING WARRANTY AND SPECIFICATIONS	1
SAFETY PRECAUTIONS	3
CONDITIONS OF USE FOR THE PRODUCT	12
COMPLIANCE WITH EMC AND LOW VOLTAGE DIRECTIVES	13
TERMS	16
CHAPTER 1 OVERVIEW	17
CHAPTER 2 SPECIFICATIONS	19
2.1 General Specifications	19
2.2 Performance Specifications	20
2.2.1 Performance specifications	20
2.2.2 Power supply sequence and handling of I/O data	21
2.3 Applicable System	22
2.3.1 QJ51AW12D2	22
2.3.2 LJ51AW12D2	22
2.4 External Dimensions	24
2.5 Part Names	25
2.6 Module Mounting	25
2.7 Checking Function Version and Serial Number	25
CHAPTER 3 OPERATION MODE	26
3.1 QJ51AW12D2	26
3.1.1 Transmission speed setting	26
3.1.2 Setting of the number of transmission points, double check mode, and waveform output method	28
3.2 LJ51AW12D2	34
3.2.1 Setting of the number of transmission points	36
3.2.2 Transmission speed setting	37
3.2.3 Double check mode setting	38
3.2.4 Waveform output method setting	40
CHAPTER 4 PROGRAMMING	41
4.1 I/O Signals with CPU Module	41
4.1.1 I/O signal list	41
4.1.2 Details of the input signal	42
4.1.3 Details of the output signal	42
4.2 Buffer Memory Area	43
4.2.1 I/O area	44
4.2.2 Number of error addresses	44
4.2.3 Value of error addresses	44
4.2.4 Number of connection addresses	45
4.2.5 Value of connection addresses	45
4.2.6 Latest error code storage area, latest error ID storage area	45

4.3 Program Example	46
<hr/>	
CHAPTER 5 MONITORING FUNCTION	48
5.1 Automatic Address Detection	48
5.1.1 Executing the automatic address detection function	49
5.2 Monitoring Operation	49
<hr/>	
CHAPTER 6 LED DISPLAY	50
6.1 QJ51AW12D2	50
6.2 LJ51AW12D2	51
<hr/>	
CHAPTER 7 CONNECTIONS	52
7.1 Description of Terminals	52
7.2 Transmission Cable Terminal Block	53
7.3 Cable Processing	54
7.4 Terminating Unit	55
<hr/>	
CHAPTER 8 TRANSMISSION TIME	56
8.1 Transmission Cycle Time	56
8.1.1 Transmission cycle time of the master module	56
8.1.2 Effects of the double check system	57
8.2 Transmission Delay Time	58
8.2.1 Slave module (input) to master module	58
8.2.2 Master module to slave module (output)	59
<hr/>	
CHAPTER 9 TROUBLESHOOTING	60
9.1 Visual Inspection	60
9.2 Check with Input Signals	62
9.3 Troubleshooting of Master Module	63
9.3.1 QJ51AW12D2	63
9.3.2 LJ51AW12D2	64
9.4 Troubleshooting of Slave Module	66
9.5 List of Error Codes	67
<hr/>	
APPENDIX	69
Appendix 1 EMC and Low Voltage Directives	69
Appendix 1.1 Requirements for compliance with the EMC Directive	69
Appendix 1.2 Requirements for compliance with the Low Voltage Directive	71
Appendix 2 Differences between the QJ51AW12D2 and LJ51AW12D2	72
Appendix 3 Functions Added and Modified with Version Upgrade	73
REVISIONS	74
WARRANTY	75
TRADEMARKS	76

TERMS

Unless otherwise specified, this manual uses the following terms.

Term	Description
Address	Parameter set to a slave module to identify each node on the AnyWire DB A20
AnyWire DB A20	An original transmission system provided by Anywire Corporation. The full-duplex transmission mode enables a high-speed and long-distance communication. This system provides a high-speed and highly-reliable sensor network.
Bridge module	A module that serves as a master module in a transmission system such as OpenBus
Buffer memory	A memory in an intelligent function module, where data (such as setting values and monitoring values) exchanged with a CPU module are stored
CPU module	A generic term for the MELSEC-Q series CPU module and MELSEC-L series CPU module
GX Developer	The product name of the software package for the MELSEC programmable controllers
GX Works2	
Head module	The abbreviation for the LJ72GF15-T2 CC-Link IE Field Network head module
ID	Information assigned to a module based on its address to identify whether it is an input module or output module ID of the output slave module: address ID of the input slave module or I/O combined slave module: address + 200 _H
Intelligent function module	A MELSEC-Q/L series module other than CPU modules, power supply modules, and I/O modules, which is mounted on a base unit
LJ51AW12D2	The abbreviation for the AnyWire DB A20 master module, LJ51AW12D2
Master module	A generic term for the QJ51AW12D2 and LJ51AW12D2
MELSEC-L series	The abbreviation for the Mitsubishi Electric programmable controller MELSEC-L series
MELSEC-Q series	The abbreviation for the Mitsubishi Electric programmable controller MELSEC-Q series
Power cable (24V, 0V)	A cable that connects a 24VDC external power supply to a master module
Programming tool	A generic term for GX Works2 and GX Developer
QJ51AW12D2	The abbreviation for the AnyWire DB A20 master module, QJ51AW12D2
Remote I/O module	A module that communicates I/O data with a master module
Slave module	A generic term for modules that communicate data with a master module
Terminating unit	A waveform shaper
Transmission cable (D, G)	A signal cable that connects between a slave module and a master module
Transmission cycle time	A data sampling interval

CHAPTER 1 OVERVIEW

This manual describes the specifications, part names, and settings of the QJ51AW12D2 AnyWire DB A20 master module (hereafter abbreviated as the QJ51AW12D2) and LJ51AW12D2 AnyWire DB A20 master module (hereafter abbreviated as the LJ51AW12D2).

This module, a product of the joint development project with Anywire Corporation, allows the AnyWire sensor network system to be constructed in a MELSEC-Q series or MELSEC-L series programmable controller system.


The AnyWire DB A20 system is a high-speed and highly reliable sensor network system.

<Features of AnyWire DB A20>

The transmission distance can be selected from 50m/200m/1km/3km using the DIP switch.

Up to 512 remote input points and 512 remote output points can be controlled by one QJ51AW12D2 or LJ51AW12D2 (in the standard setting).

Disconnections can be detected even when the wiring is branched.



<Configuration of the AnyWire DB A20 system>

For the number of connectable slave modules, refer to the following.

☞ Page 20, Section 2.2.1

Memo

CHAPTER 2 SPECIFICATIONS

2.1 General Specifications

Item	Specifications					
Operating ambient temperature	0 to 55°C ⁴					
Storage ambient temperature	-25 to 75°C					
Operating ambient humidity						
Storage ambient humidity	5 to 95%RH, non-condensing					
Vibration resistance	Compliant with JIS B 3502 and IEC 61131-2	—	Frequency	Constant acceleration	Half amplitude	No. of sweeps
		Under intermittent vibration	5 to 8.4Hz	—	3.5mm	10 times each in X, Y, and Z directions
		Under continuous vibration	8.4 to 150Hz	9.8m/s ²	—	
		Under continuous vibration	5 to 8.4Hz	—	1.75mm	—
Shock resistance	Compliant with JIS B 3502 and IEC 61131-2 (147 m/s ² , 3 times each in X, Y, and Z directions)					
Operating atmosphere	No corrosive gas					
Operating altitude ¹	0 to 2000m					
Installation location	Inside the control panel					
Overvoltage category ²	II or less					
Pollution degree ³	2 or less					
Equipment class	Class I					

¹ Do not use or store the programmable controller under pressure higher than the atmospheric pressure at sea level. Doing so may cause malfunction.

When using the programmable controller under pressure, please consult your local Mitsubishi representative.

² This indicates the section of the power supply to which the equipment is assumed to be connected between the public electrical power distribution network and the machinery within premises.

Category II applies to equipment for which electrical power is supplied from fixed facilities.

The surge voltage withstand level for up to the rated voltage of 300 V is 2500 V.

³ This index indicates the degree to which conductive material is generated in terms of the environment in which the equipment is used.

In pollution degree 2, only non-conductive pollution occurs. A temporary conductivity caused by an accidental condensation may also occur occasionally.

⁴ When setting the transmission clock of the QJ51AW12D2 with a serial number whose sixth digit is 5 or earlier to 125kHz, use the module within the following specified range.

- Voltage range of external power supply: 21.6 to 25.2VDC
- Operating ambient temperature: 0 to 50°C

2.2 Performance Specifications

2.2.1 Performance specifications

Item	Specifications											
	QJ51AW12D2				LJ51AW12D2							
Transmission clock	125kHz ³	31.3kHz	7.8kHz	2kHz	125kHz	31.3kHz	7.8kHz	2kHz				
Maximum transmission distance (total length)	50m	200m	1km	3km	50m	200m	1km	3km				
Number of connected slave modules (varies depending on the current consumption of each slave module)	Up to 128	Up to 128	Up to 128	Up to 32 ¹	Up to 128	Up to 128	Up to 128	Up to 32 ¹				
Transmission system	Cyclic transmission with full-duplex mode											
Connection type	Bus topology (Multidrop system, T-branch system, tree branch system)											
Transmission protocol	Dedicated protocol (AnyWire DB A20)											
Error control	Double check system											
Number of connected I/O points	Up to 1024 points (512 input points/512 output points) (However, up to 1024 input points/1024 output points can be set) ²											
RAS function	Disconnected transmission cable location detection function, transmission cable short detection function, transmission cable power supply voltage drop detection function											
Transmission cable (D, G)	<ul style="list-style-type: none"> UL-compliant general-purpose 2-/4-wire cable (VCTF, VCT 0.75 to 1.25mm², temperature rating: 70°C or higher) UL-compliant general-purpose wire (0.75 to 1.25mm², temperature rating: 70°C or higher) FK4-UL075-100 (AnyWire) (0.75mm², temperature rating: 90°C) (UL-compliant item) <p>(Regardless of the type of the transmission cable, when the transmission distance exceeds 200m, use wires with a diameter of 0.9 to 1.25mm².)</p>											
Power cable (24V, 0V)	<ul style="list-style-type: none"> UL-compliant general-purpose 2-wire cable (VCTF, VCT 0.75 to 2.0mm², temperature rating: 70°C or higher) UL-compliant general-purpose wire (0.75 to 2.0mm², temperature rating: 70°C or higher) FK4-UL075-100 (AnyWire) (0.75mm², temperature rating: 90°C) (UL-compliant item) 											
Power supply ³	<p>Circuit: (Supplied from the Q bus side) Voltage +5V±5%, Current 0.5A max.</p> <p>Transmission cable: Voltage 24VDC +15 to -10% (21.6 to 27.6VDC), ripple voltage 0.5Vp-p or lower Current 0.5A (When 128 slave modules are connected and the load current is not included)</p>				<p>Circuit: (Supplied from the L bus side) Voltage +5V±5%, Current 0.2A max.</p> <p>Transmission cable: Voltage 24VDC +15 to -10% (21.6 to 27.6VDC), ripple voltage 0.5Vp-p or lower Current 0.5A (When 128 slave modules are connected and the load current is not included)</p>							
Number of I/O occupied points	32 points (I/O assignment: intelligent 32 points)											
Number of writes to EEPROM	100000 times (maximum)											
External dimensions	98 mm (H) × 27.4 mm (W) × 100 mm (D)				90mm (H) × 28.5mm (W) × 104.5mm (D)							
Weight	0.11kg				0.2kg							

¹ Up to 64 modules can be connected within 2km.

² Used when required in special situations.


³ When setting the transmission clock of the QJ51AW12D2 with a serial number whose sixth digit is 5 or earlier to 125kHz, use the module within the following specified range.

- Voltage range of external power supply: 21.6 to 25.2VDC
- Operating ambient temperature: 0 to 50°C

2.2.2 Power supply sequence and handling of I/O data

An incorrect input/output may occur depending on the supply procedure of the power of the programmable controller, the 24VDC external power supply for transmission lines, and the 24VDC external power supply for slave module. Note the following points.

- Do not make any access related to the master module (X, Y, or FROM/TO) for 2 seconds after the programmable controller is powered on. Doing so can cause a malfunction of the module.
- Power on the programmable controller and 24VDC external power supply in this order.
- Depending on how to supply the 24VDC external power supply, D/G terminal disconnection (Xn4) may turn on (the ALM LED may turn on) during initial processing. Therefore, turn on (500ms or more) and off Disconnection flag reset command output (Yn0) at the start of access.



2.3 Applicable System

2.3.1 QJ51AW12D2

(1) Mountable modules, number of mountable modules, and applicable base unit

(a) When mounted together with the CPU module

For mountable CPU modules, the number of mountable modules, and the applicable base unit, refer to the user's manual for the CPU module used.

When the QJ51AW12D2 is mounted together with the CPU module, note the following.

- Insufficient power capacity may occur depending on the combination of other modules and the number of mountable modules. When mounting the modules, consider the power capacity. If the power capacity is insufficient, reconsider the combination of the mounted modules.
- Mount the module within the range for the number of I/O points of the CPU module. The module can be mounted to any slot only within the range for the number of usable slots.

Remark

When using the module with the C Controller module, refer to the user's manual for the C Controller module used.

(b) When used as the MELSECNET/H remote I/O station

For usable MELSECNET/H remote I/O stations, the number of mountable modules, and the applicable base unit, refer to the Q Corresponding MELSECNET/H Network System Reference Manual (Remote I/O network).

(c) When mounted on the RQ extension base unit

When mounting the module on the RQ extension base unit, refer to the MELSEC iQ-R Module Configuration Manual.

(2) Compatibility with multiple CPU system

The QJ51AW12D2 supports the multiple CPU system from its first product.

When using the QJ51AW12D2 in the multiple CPU system, refer to the following manual.

- QCPU User's Manual (Multiple CPU System)

(3) Online module change

The QJ51AW12D2 cannot be changed online.

2.3.2 LJ51AW12D2

(1) Number of connectable modules

For the number of connectable modules, refer to the following.

 MELSEC-L CPU Module User's Manual (Hardware Design, Maintenance and Inspection)
 MELSEC-L CC-Link IE Field Network Head Module User's Manual

(2) Precautions for system configuration

(a) Rated output current (5VDC)


The total current consumption under the system configuration must not exceed the rated output current (5VDC) of the power supply module of the programmable controller. For the specifications of the power supply module, refer to the following.

 MELSEC-L CPU Module User's Manual (Hardware Design, Maintenance and Inspection)


2.3 Applicable System
2.3.2 LJ51AW12D2

2.4 External Dimensions


(1) QJ51AW12D2



(2) LJ51AW12D2



2.5 Part Names



For details on each part, refer to the following.

- LED indicator: Page 50, CHAPTER 6
- Operation mode selector: Page 26, Section 3.1
- SET switch: Page 48, Section 5.1
- Transmission cable terminal block: Page 52, CHAPTER 7

2.6 Module Mounting

For precautions on the installation environment and the installation position of the modules, refer to the following.

- User's Manual (Hardware Design, Maintenance and Inspection) for the CPU module used
- MELSEC-L CC-Link IE Field Network Head Module User's Manual

2.7 Checking Function Version and Serial Number

For how to check the serial number and the function version, refer to the following.

- User's Manual (Hardware Design, Maintenance and Inspection) for the CPU module used
- MELSEC-L CC-Link IE Field Network Head Module User's Manual

CHAPTER 3 OPERATION MODE

Connect the slave module for the AnyWire DB A20.


3.1 QJ51AW12D2

3.1.1 Transmission speed setting

Select the settings such as the transmission distance using the operation mode selector (4-gang DIP switch).

- SW-1, 2 ... Set the transmission distance using a combination of ON/OFF for 1 and 2.
- SW-3 ... System reserve (Set the switch to OFF. Using the module with this switch set to ON may cause malfunction.)
- SW-4 ... System reserve (Set the switch to OFF. Using the module with this switch set to ON may cause malfunction.)

Switch		Specifications
1	2	
OFF	OFF	2kHz 3km
OFF	ON	7.8kHz 1km
ON	OFF	31.3kHz 200m
ON	ON	125kHz 50m



Point

- Switch off the power supply before setting the operation mode.
- Set the operation mode according to the transmission specifications being used.
- If the transmission specifications of the QJ51AW12D2 do not match those of the connected slave module, transmission cannot be performed correctly, resulting in malfunction.
- The operation mode selector is recessed from the front surface. When setting the switch, use a precision driver and be careful not to damage any of the internal boards.

3


3.1 QJ51AW12D2
3.1.1 Transmission speed setting

3.1.2 Setting of the number of transmission points, double check mode, and waveform output method


Set the number of transmission points, double check mode, and waveform output method using "Switch 1", "Switch 3", and "Switch 4" of "Switch setting for I/O and intelligent function module".

Double-click the "PLC Parameter" in the Project window of the programming tool, and perform the following operations.


- Click the "I/O Assignment" tab.
- Click the "Switch Setting" button.
- Open the "Switch Setting for I/O and Intelligent Function Module" window.
- Set a value to "Switch 1", "Switch 3", and "Switch 4".



"Q Parameter Setting" window



"Switch Setting for I/O and Intelligent Function Module" window



Set "Switch 1", "Switch 3", and "Switch 4" as follows.


- "Switch 1": Setting of the number of transmission points (☞ Page 30, Section 3.1.2 (1))
- "Switch 3": Double check mode setting (☞ Page 31, Section 3.1.2 (2))
- Switch 4: Waveform output method setting (☞ Page 33, Section 3.1.2 (3))

Point

- Be sure to set "Switch 1", "Switch 3", and "Switch 4". Furthermore, set the correct and suitable value for the slot position of the QJ51AW12D2. If the settings are not configured, or if the setting position or the switch selection value is incorrect, AnyWire DB A20 transmission does not operate normally.
- If the switch settings are changed using the programming tool, write the parameters and then reset the CPU module or power off and on the system. Without these operations, switch settings are not configured.

(1) Setting of the number of transmission points

Set the number of transmission points using "Switch 1" of "Switch setting for I/O and intelligent function module".



■ Correspondence between the value from 0 to 9 set for "Switch 1" and the number of connected I/O points

Number of connected I/O points		"Switch 1" ^{*1}
Input	Output	
512	512	0
448	448	1
384	384	2
320	320	3
256	256	4
192	192	5
128	128	6
64	64	7
32	32	8
1024	1024	9 ^{*2}

*1 The value other than 0 to 9 is reserved by the system. Do not change the settings.

*2 Used when required in special situations.

Transmission also can be made for normal use. However, the address after the "Maximum address setting-Number of self occupied points" of the slave module for AnyWire DB A20 becomes unassigned, and the transmission cycle time becomes slower.

Ex. For 32-Point Remote I/O Module

- Maximum address setting: 510
- Number of self occupied points: 32 points


According to the details above, up to 510 to 541 points are used as the maximum address that is occupied by the remote I/O module.

Addresses of 541 to 1023 points become unassigned, and cannot be assigned.

(2) Double check mode setting

Set the double check mode using "Switch 3" of "Switch setting for I/O and intelligent function module".

The QJ51AW12D2 with a serial number where the sixth digit is "6" or later can be set.




■ Correspondence between the value from 0 to 40 set for "Switch 3" and the double check

Double check	"Switch 3" *1
Bit data at all points are double-checked.	0
Word data of the first word are double-checked. At the remaining points, bit data are double-checked.	1
Word data of the first two words are double-checked. At the remaining points, bit data are double-checked.	2
Word data of the first three words are double-checked. At the remaining points, bit data are double-checked.	3
:	:
Word data of the first 63 words are double-checked. At the remaining points, bit data are double-checked.	3F
Word data at all points are double-checked.	40


*1 The value other than 0 to 40 is reserved by the system. Do not change the settings.

A double check is an error control system. In this system, cycle data in AnyWire DB A20 transmission is recognized as valid data if the data matches with the data of the last transmission or is ignored as invalid data if the data does not match with the last transmission data. A double check ensures reliability of communication. A double check is classified into a bit double check and word double check.

Double check of bit data



Double check of word data




Point

- Using the "Switch 3" setting, data (bit or word) to be double-checked within the frame can be selected from the head area of the transmission frame.
- The bit double check is suitable for digital I/O type slave modules, which use information in units of bits. The word double check is suitable for analog I/O type slave modules, which use information in units of words.

(3) Waveform output method setting

Set the waveform output method using "Switch 4" of "Switch setting for I/O and intelligent function module".

The QJ51AW12D2 with a serial number where the sixth digit is "6" or later can be set.



■ Correspondence between the value from 0 to 1 set for "Switch 4" and the waveform output method


Waveform output method	"Switch 4" ^{*1}
When Module READY (Xn0) turns on, the transmission waveform is output.	0
When Module READY (Xn0) and Transmission waveform output command (Yn2) turn on, the transmission waveform is output.	1

*1 The value other than 0 and 1 is reserved by the system. Do not change the settings.


3.2 LJ51AW12D2

Set the operation mode using "Switch setting for I/O and intelligent function module". Double-click "PLC Parameter" in the Project window of the programming tool, and perform the following operations.


- Click the "I/O Assignment" tab.
- Click the "Switch Setting" button.
- Open the "Switch Setting for I/O and Intelligent Function Module" window.
- Set a value to "Switch 1" to "Switch 4".



"L Parameter Setting" window



"Switch Setting for I/O and Intelligent Function Module" window



If you use Intelligent Function Module, able to set each module with pulldown format by following function.
- Switch Setting of Intelligent Function Module in project tree.

End

Cancel

Set "Switch 1" to "Switch 4" as follows.


- "Switch 1": Setting of the number of transmission points (☞ Page 36, Section 3.2.1)
- "Switch 2": Transmission speed setting (☞ Page 37, Section 3.2.2)
- "Switch 3": Double check mode setting (☞ Page 38, Section 3.2.3)
- Switch 4: Waveform output method setting (☞ Page 40, Section 3.2.4)

Point

- Be sure to set "Switch 1" to "Switch 4". Furthermore, set the correct and suitable value for the slot position of the LJ51AW12D2. If the settings are not configured, or if the setting position or the switch selection value is incorrect, the AnyWire DB A20 transmission does not operate normally.
- If the switch settings are changed using the programming tool, write the parameters and then reset the CPU module or power off and on the system. Without these operations, switch settings are not configured.

3.2.1 Setting of the number of transmission points

Set the number of transmission points using "Switch 1" of "Switch setting for I/O and intelligent function module".



If you use Intelligent Function Module, able to set each module with pulldown format by following function.
- Switch Setting of Intelligent Function Module in project tree.

Correspondence between the value from 0 to 9 set for "Switch 1" and the number of connected I/O points

Number of connected I/O points		"Switch 1" ^{*1}
Input	Output	
512	512	0
448	448	1
384	384	2
320	320	3
256	256	4
192	192	5
128	128	6
64	64	7
32	32	8
1024	1024	9 ^{*2}

*1 The value other than 0 to 9 is reserved by the system. Do not change the settings.

*2 Used when required in special situations.

Transmission also can be made for normal use. However, the address after the "Maximum address setting-Number of self occupied points" of the slave module for AnyWire DB A20 becomes unassigned, and the transmission cycle time becomes slower.

Ex. For 32-Point Remote I/O Module


- Maximum set address: 510
- Number of self-occupied points: 32 points

According to the details above, up to 510 to 541 points are used as the maximum address that is occupied by the remote I/O module.

Addresses of 541 to 1023 points become unassigned, and cannot be assigned.

3.2.2 Transmission speed setting

Set the transmission speed using "Switch 2" of "Switch setting for I/O and intelligent function module".




Correspondence between the value from 0 to 3 set for "Switch 2" and the transmission speed

Transmission speed (transmission distance)	"Switch 2" ^{*1}
2kHz 3km	0
7.8kHz 1km	1
31.3kHz 200m	2
125kHz 50m	3

*1 The value other than 0 to 3 is reserved by the system. Do not change the settings.

3.2.3 Double check mode setting

Set the double check mode using "Switch 3" of "Switch setting for I/O and intelligent function module".



If you use Intelligent Function Module, able to set each module with pulldown format by following function.
- Switch Setting of Intelligent Function Module in project tree.

Correspondence between the value from 0 to 40 set for "Switch 3" and the double check


Double check	"Switch 3" ^{*1}
Bit data at all points are double-checked.	0
Word data of the first word are double-checked. At the remaining points, bit data are double-checked.	1
Word data of the first two words are double-checked. At the remaining points, bit data are double-checked.	2
Word data of the first three words are double-checked. At the remaining points, bit data are double-checked.	3
:	:
Word data of the first 63 words are double-checked. At the remaining points, bit data are double-checked.	3F
Word data at all points are double-checked.	40

*1 The value other than 0 to 40 is reserved by the system. Do not change the settings.


A double check is an error control system. In this system, cycle data in AnyWire DB A20 transmission is recognized as valid data if the data matches with the data of the last transmission or is ignored as invalid data if the data does not match with the last transmission data. A double check ensures reliability of communication.

A double check is classified into a bit double check and word double check.

Double check of bit data



Double check of word data




Point

- Using the "Switch 3" setting, data (bit or word) to be double-checked within the frame can be selected from the head area of the transmission frame.
- The bit double check is suitable for digital I/O type slave modules, which use information in units of bits. The word double check is suitable for analog I/O type slave modules, which use information in units of words.

3.2.4 Waveform output method setting

Set the waveform output method using "Switch 4" of "Switch setting for I/O and intelligent function module".



■ Correspondence between the value from 0 to 1 set for "Switch 4" and the waveform output method

Waveform output method	"Switch 4" ^{*1}
When Module READY (Xn0) turns on, the transmission waveform is output.	0
When Module READY (Xn0) and Transmission waveform output command (Yn2) turn on, the transmission waveform is output.	1

*1 The value other than 0 and 1 is reserved by the system. Do not change the settings.

CHAPTER 4 PROGRAMMING

This chapter describes programs of the master module.

When applying the program examples introduced in this chapter to the actual system, ensure the applicability and confirm that it does not cause system control problems.

4.1 I/O Signals with CPU Module

4

The master module is an intelligent function module. Thirty-two input points and 32 output points are used for the data communication with the CPU module.

System status information is stored in this area.

The "buffer memory area" is used to input/output the signal to/from the remote I/O module.

4.1.1 I/O signal list

The n in the table below is the start I/O number of the master module which is determined according to the installation position and modules installed before the master module.

Ex. If the start I/O number of the master module is X/Y10

Xn0 to X(n+1)F → X10 to X2F

Yn0 to Y(n+1)F → Y10 to Y2F

Input number	Signal name	Output number	Signal name
Xn0	Module READY	Yn0	Disconnection flag reset command output
Xn1	Short between D and G terminals	Yn1	Automatic address detection command output
Xn2	Short between D and 24 V terminals	Yn2*4	Transmission waveform output command
Xn3	24 V not applied		
Xn4	D/G line disconnection		
Xn5 to Xn7	Use prohibited		
Xn8 to XnB*1	"Switch Setting for I/O and Intelligent Function Module" Switch 1 setting value*2	Yn3 : YnF	Use prohibited
XnC to XnF	Use prohibited		
X(n+1)0 to X(n+1)3	Use prohibited		
X(n+1)4*3	Automatic address detection flag	Y(n+1)0 to Y(n+1)F	Use prohibited
X(n+1)5 to X(n+1)F	Use prohibited		

*1 Use prohibited for the LJ51AW12D2.

*2 When 8 is set for "Switch 1", the settings are as follows.

Xn8: OFF, Xn9: OFF, XnA: OFF, XnB: ON

*3 Use prohibited for the QJ51AW12D2.

*4 The QJ51AW12D2 with a serial number where the sixth digit is "6" or later can be used.

4.1.2 Details of the input signal

The input signal Xn0 is Module READY flag, and it turns on while the master module is operating normally.

(It does not turn off with errors of Xn1 to Xn4.)

For each of the input signals Xn1 to Xn4, an error flag that shows the condition of the AnyWire DB A20 transmission cable turns on.

If the transmission cable is normal, a corresponding input signal turns off, and if an error occurs, a corresponding input signal turns on.

Xn1 to Xn3 flags turn off when the error is eliminated and then maintain the OFF state.

Xn4 maintains the ON state even when the error is eliminated.

Xn4 turns off by resetting the power or outputting the signal to Yn0. (☞ Page 42, Section 4.1.3)

The ON/OFF state is also indicated depending on whether the ALM LED is on or how the ALM LED flashes.

Input signal No.	Description	Normal	Error
Xn0	Module READY (Turns OFF when a watchdog timer error occurs)	ON	OFF
Xn1	Short between D and G terminals	OFF	ON
Xn2	Short between D and 24 V terminals	OFF	ON
Xn3	24VDC is not being supplied to the master module or the voltage is low.	OFF	ON
Xn4	D/G line disconnection, a slave module error, or power is not being supplied	OFF	ON

For Xn8 to XnB, enter the value set for switch 1 of the "Switch setting for I/O and Intelligent Function Module". Xn8 to XnB are used to check the settings.

X(n+1)4 turns on when the automatic address detection function is being executed. (☞ Page 48, Section 5.1)

4.1.3 Details of the output signal

(1) Disconnection flag reset command output

When Disconnection flag reset command output (Yn0) is turned on from off, provided that the disconnection error has been eliminated, the error address information can be cleared by turning off D/G terminal disconnection (Xn4) and resetting the number of error addresses to 0.

If the error has not been eliminated, the error flag, the number of the error addresses, and error address are set. Abnormal address information can also be cleared by supplying the power again.

(2) Automatic address detection command output

When Automatic address detection command output (Yn1) is turned on from off, the automatic address detection function is executed. (☞ Page 48, CHAPTER 5)

(The automatic address detection function can be also executed using the SET switch.)

(3) Transmission waveform output command

This signal is valid when "Switch 4" of "Switch setting for I/O and intelligent function module" is set to 1.

When Transmission waveform output command (Yn2) is turned on from off, the transmission waveform of the AnyWire DB A20 is output.

4.2 Buffer Memory Area

This area is for data communication between the master module and CPU module.

Buffer memory address	Description
100_H to $13F_H$ ^{*1}	Input (1024 points): The least significant bit of 100_H is the 0th data, and the most significant bit of $13F_H$ is the 1023rd data.
1100_H to $113F_H$ ^{*1}	Output (1024 points): The least significant bit of 1100_H is the 0th data, and the most significant bit of $113F_H$ is the 1023rd data.
2000_H	Number of error IDs (1 word)
2001_H to 2080_H	Error ID information
2400_H ^{*2}	Number of connection IDs (1 word)
2401_H to 2480_H ^{*2}	Connection ID information
2810_H ^{*2}	Latest error code storage area
2811_H ^{*2}	Latest error ID storage area

4

*1 The buffer memory address occupies a 64-word sized area, irrespective of the number of I/O points set in the "Switch 1" setting on Page 28, Section 3.1.2.

*2 The QJ51AW12D2 with a serial number where the sixth digit is "6" or later can be used.

Ex. Correspondence between the buffer memory address and AnyWire DB A20 input address


Buffer memory address	Bit No.															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
100 _H	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
101 _H	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16

4.2 Buffer Memory Area

4.2.1 I/O area

The slave module requires "Address setting" which specifies the start number assigned in the transmission frame. The settings are configured in 2-point unit. The addresses of both an input slave module (e.g. input remote I/O module) and an output slave module (e.g. output remote I/O module) start from "0", and the area later than that number is occupied corresponding to the number of module points.

Ex. Assignment of two 8-point input remote I/O modules



4.2.2 Number of error addresses

The number of error IDs (addresses) is entered in 2000H. (☞ Page 48, CHAPTER 5)

Any value from 0 to 128 is entered.

4.2.3 Value of error addresses

If a disconnection or a slave module error is occurred, the error address is written to 2001H to 2080H in the order from the lowest address up to 128 addresses.

This value is maintained until the disconnection error is reset or until the power is turned off.

Buffer memory address	Description
2001H	Error address 1
2002H	Error address 2
2003H	Error address 3
:	:
:	:
207FH	Error address 127
2080H	Error address 128

The detected error address is classified and displayed in the memory and on the monitor according to the table below.

Hexadecimal display address	Description
000H to 1FFH	Address of the output slave module
200H to 3FFH	Address of the input slave module or I/O combined slave module

The lower 2 digits indicate the address set for the slave module.

The uppermost digit indicates the type of the slave module.

4.2.4 Number of connection addresses

The number of connection IDs (addresses) is entered in 2400_H . (☞ Page 48, CHAPTER 5)

Any value from 0 to 128 is entered.

4.2.5 Value of connection addresses

Up to 128 addresses of all the slave modules connected to the master module are written to 2401_H to 2480_H in the order from the lowest address.

These values are maintained until the power is turned off.

Buffer memory address	Description
2401_H	Connection addresses 1
2402_H	Connection addresses 2
2403_H	Connection addresses 3
:	:
:	:
$247F_H$	Connection addresses 127
2480_H	Connection addresses 128

The detected connection addresses are classified and displayed in the memory and on the monitor according to the table below.

Hexadecimal display address	Description
000_H to $1FF_H$	Address of the output slave module
200_H to $3FF_H$	Address of the input slave module or I/O combined slave module

The lower 2 digits indicate the address set for the slave module.

The uppermost digit indicates the type of the slave module.

4.2.6 Latest error code storage area, latest error ID storage area

The latest error code is stored in 2810_H .

The latest error code is maintained even after the error is cleared.

The ID (address) of the error code stored in 2810_H is stored in 2811_H .

However, for Transmission cable power supply voltage drop error ($00C8_H$), D/G short error ($00C9_H$), D/24V short error ($00CB_H$), Master module hardware error (0064_H to 0067_H), and CPU module stop error (0068_H), $0X0FFF_H$ is entered in 2811_H .

4.3 Program Example

The configuration of the programmable controller is as shown below.

Ex. QJ51AW12D2

I/O address	X0 to XF		X10 to X2F		Y10 to Y2F
	Power supply Q62P	CPU Q06UDHCPU	16-point input module	QJ51 AW12D2	
					Vacant

- Used device


Device No.	Application
SM400	Always ON
X10	Module READY
X11	D/G terminal short
X12	D/24V terminal short
X13	24V not applied
X14	D/G line disconnection
Y10	Disconnection flag reset command output
Y11	Automatic address detection command output
M1	Disconnection flag reset command input
M2	Access start flag
M3	Automatic address detection command input
M10	Display of D/G terminal short
M11	Display of D/24V terminal short
M12	Display of 24V not applied
M13	Display of D/G line disconnection
T1	Disconnection flag output ON time (500 ms)

- Program <Disconnection flag clear>



Input is output by the FROM instruction, and output is output by the TO instruction.

A user program is added between the FROM and TO instructions.



The correspondence between each signal and the device in the program above is as shown below.

Signal type	Corresponding device
Input (1024 points)	X100 to X4FF
Output (1024 points)	Y100 to Y4FF
Error address information	D3000 to D3128

CHAPTER 5 MONITORING FUNCTION

The AnyWire DB A20 slave module has the specific ID (address). When the master module sends the ID (address), disconnection and existence of slave modules are detected by receiving a reply from the slave module having the corresponding ID (address).

The master module uses the automatic address detection function to store the addresses of the currently connected slave modules in the EEPROM.

This information is stored even when the power is turned off.

Then, the master module sends the registered addresses in order. If the corresponding slave module does not reply, the ALM LED indicates that a disconnection has occurred. Then an error flag is returned to the memory area on the host side.

Furthermore, this slave module address can be checked.

5.1 Automatic Address Detection

Automatic address detection is a function to store the ID (address) of the connected slave module in the EEPROM of the master module.

In the initial system startup, the ID is not yet registered in the module. Therefore, when the power is on, the "ALM" LED and the "D/G line disconnection" flag are turned on. (☞ Page 41, CHAPTER 4, Page 50, CHAPTER 6)

I/O data can be transmitted in this state. However, to use the disconnected branch line detection function, execute the automatic address detection function at this point.

Execute the automatic address detection function in the following cases.

- When starting the system operation after confirming that all the slave modules connected to the master modules are operating normally
- When adding a slave module after starting the system operation
- When removing a slave module after starting the system operation
- When changing the address of a slave module after starting the system operation

5.1.1 Executing the automatic address detection function

Use the SET switch or Automatic address detection command output (Yn1) to operate the automatic address detection.

Using the SET switch

Procedure

1. **Check that all of the slave modules are operating normally.**
2. **Keep pressing the SET switch on the master module until the SET LED (green) turns on.**
3. **When the SET LED turns on, flashes, and turns off, the ID (address) has been stored.**

5

Using Automatic address detection command output (Yn1)

Procedure

1. **Check that all of the slave modules are operating normally.**
2. **Turn Automatic address detection command output (Yn1) from OFF to ON. (For details on Automatic address detection command output (Yn1), refer to Page 41, CHAPTER 4.)**
3. **When the SET LED turns on, flashes, and turns off, the ID (address) has been stored.**

Point

When an error such as a short circuit has occurred in the AnyWire DB A20, when the power is turned on, or when the module is reset, the automatic address detection function cannot be executed for approximately 5 seconds.

5.2 Monitoring Operation

Registered IDs (addresses) are sent in order. If the slave module does not reply, a disconnection is notified.

The ALM LED turns on and D/G terminal disconnection (Xn4) turns on when a disconnection occurs.

This error information is maintained until the power is turned off or until Disconnection flag reset command output (Yn0) is turned on.


Point

To reset the on state of the ALM LED and D/G terminal disconnection (Xn4: ON) detected during operation, reset the power supply of the master module or turn on Disconnection flag reset command output (Yn0) after eliminating the cause.

The automatic address detection function also clears the display and the flag. However, if an unresponding module exists, its ID (address) is not registered; therefore, it is not monitored.

CHAPTER 6 LED DISPLAY

6.1 QJ51AW12D2



Name	Color	Meaning	
LINK	Green	Flashing	Module operating status
		Off	Module failure
SET	Green	On	Automatic address detection in progress
		Flashing	Address write in progress
		Off	Before or after automatic address detection
ALM	Red	On	D/G disconnection, no response from the slave module
		Slow flashing (one-second intervals)	D/G short circuit, D/24V short circuit
		Fast flashing (0.2-second intervals)	24VDC is not being supplied, or the voltage is low
		Off	Operating normally
M ERR.	Red	On	Turns on when an error occurs in the QJ51AW12D2 or the programmable controller. In this case, all functions are stopped. The error LED for the applicable CPU flashes. (Excluding EEPROM errors)
		Off	Module normal

For details on the display when M ERR. is on, see the table below.

No.	On/Off status				Main Causes
	M ERR.	ALM	LINK	SET	
1	●	●	●	●	Internal ROM error
2	●	●	●	○	Internal RAM error
3	●	*1	*1	●	EEPROM error
4	●	○	○	○	Module initialization error
5	●	○	●	○	Watchdog timer error
6	●	○	○	●	Programmable controller CPU error (ITWDT)
7	●	○	●	●	Software error (IORSTL)

●:On, ○:Off

*1 These LEDs turn on, turn off, or flash according to the operating status.

No.1 to 4 are checked only at the time of the reset.

Transmission is performed only when an EEPROM error occurs.

6.2 LJ51AW12D2



Name	Color	Meaning	
RUN LED	Green	On	Operating normally
		Off	Master module error, 5VDC power off, CPU module stop error
LINK LED	Green	Flashing	Communication possible
		Off, on	Communication impossible
SET LED	Green	On	Automatic address detection in progress
		Flashing	Address write in progress
		Off	Before or after automatic address detection
ALM LED	Red	On	D/G disconnection, no response from the slave module
		Slow flashing (one-second intervals)	D/G short circuit, D/24V short circuit
		Fast flashing (0.2-second intervals)	24VDC is not being supplied, or the voltage is low
		Off	Operating normally
CLOCK LED	125K LED	On	Transmission speed of 125kHz, operating in the 50m mode
		Off	Transmission speed of 125kHz, not in the 50m mode
	31.3K LED	On	Transmission speed of 31.3kHz, operating in the 200m mode
		Off	Transmission speed of 31.3kHz, not in the 200m mode
	7.8K LED	On	Transmission speed of 7.8kHz, operating in the 1km mode
		Off	Transmission speed of 7.8kHz, not in the 1km mode
	2.0K LED	On	Transmission speed of 2.0kHz, operating in the 3km mode
		Off	Transmission speed of 2.0kHz, not in the 3km mode

CHAPTER 7 CONNECTIONS

The connection terminals (transmission cable terminal block) for the AnyWire DB A20 transmission cable can be connected and disconnected easily.

The transmission cables and power supply cables are connected using the common terminal block.

Point


For compliance with the EMC and Low Voltage Directives, refer to Page 69, Appendix 1.

Even when the compliance with the EMC and Low Voltage Directives is not required, use of an EMC-compliant configuration may reduce the influence from external noise.

7.1 Description of Terminals

Terminal	Description
D	AnyWire DB A20 transmission signal terminal for the master module D: Transmission cable (+), G: Transmission cable (-)
G	Connect to the D and G terminals to those on the slave module and terminating unit.
24V	Power supply terminal for driving the transmission circuit for the master module Connect a 24VDC stabilized power supply to the 24V and 0V terminals.
0V	
LG	Connect the LG terminal to the neutral point of the noise filter inserted between the 24V and 0V terminals. If malfunctions occur due to the power noise in the 24VDC system, ground the LG terminal with the functional ground terminal (FG terminal) on the programmable controller at a single point.

For details on connections to the D and G terminals on the slave module and terminating unit, refer to the relevant manuals of each product.



7.2 Transmission Cable Terminal Block

Manufacturer: PHOENIX CONTACT GmbH & Co. KG (Contact: www.phoenixcontact.com)

Model: MSTB 2,5/5-STF-5.08AU

Tightening torque: 0.2 to 0.3N·m

To tighten the connector, a flathead screwdriver having a tipped size of $0.4 \times 2.5\text{mm}$ is required.

Before removing the transmission cable terminal block, check that the terminal block mounting screws on the both sides are completely loosened (removed from the socket).

Pulling the terminal block with excessive force while the terminal block mounting screws on the both sides are still tightened may damage the devices.

Before tightening the terminal block, check that there are no short circuits due to the disconnected or frayed wires. Then tighten the terminal block mounting screws on the both sides securely. (Tightening torque: 0.2 to 0.3N·m)

7.3 Cable Processing

Bare cables can be connected to the transmission cable terminal block; however, for safety reasons, it is recommended to connect cables using bar solderless terminals.

For wiring, use the connection cables as listed in Page 20, Section 2.2.1 and tighten them with the applicable tightening torque.

Use UL-listed solderless terminals and, for processing, use a tool recommended by their manufacturer.

[Recommended bar solderless terminals (manufactured by PHOENIX CONTACT GmbH & Co. KG)]

- For processing a 0.75mm^2 wire: AI 0,75-8 GY
- For processing a 1.25mm^2 wire: AI 1,5-8 BK
- For processing a 2mm^2 wire: AI 2,5-8 BU or others
- For processing two 0.75mm^2 wires: AI-TWIN 2 \times 0,75-8 GY
- For processing two 1.25mm^2 wires: AI-TWIN 2 \times 1,5-8 BK


When connecting two wires to one terminal, connect the two wires together to the TWIN bar solderless terminal.

When TWIN bar solderless terminals are used for this transmission cable terminal block, the maximum wire diameter is 1.25mm^2 .

For details on sizes other than those listed above and crimping tools, refer to the catalog or website of PHOENIX CONTACT GmbH & Co. KG.

Point

- Do not run multiple transmission cables (D, G) using a multicore cable. Running multiple transmission cables (D, G) together may cause noise, resulting in a malfunction.




- Use the following line diameters for the transmission cables.
 - 200m or shorter: 0.75mm^2 to 1.25mm^2
 - 200m or longer: 0.9mm^2 to 1.25mm^2
- The voltage should not fall below the lower limit of the allowable voltage range due to the voltage drop caused by the cable.
 - If the voltage falls below the lower limit, malfunctions may occur.
 - If the voltage falls substantially, install the external power supply.
For installing the external power supply, refer to the "AnyWire DB A20 Series Technical Manual" (manufactured by Anywire Corporation).
- Do not connect soldered cables directly to the terminals. Doing so may loosen the screws, resulting in a poor contact.
- Use a crimping tool to connect a cable to a bar solderless terminal.
- Before inserting a bar solderless terminal, check the shapes of the wire insertion opening and bar solderless terminal. Then, insert the terminal in the correct orientation. Inserting a bar solderless terminal wider than the wire insertion opening may damage the terminal block.

7.4 Terminating Unit


To ensure more stable transmission quality, connect a terminating unit to the end of a transmission cable (D, G).

■ Terminating unit connection



■ Branch of transmission cables (transmission distance: 1km)


【Example】



7

7.4 Terminating Unit

■ Total length



CHAPTER 8 TRANSMISSION TIME

This section describes the transmission cycle time and transmission delay time of AnyWire DB A20.

8.1 Transmission Cycle Time

The transmission cycle time is the time required for the master module and all the slave modules to update I/O data.

8.1.1 Transmission cycle time of the master module

The transmission cycle time of the master module is listed in the table below.

Transmission clock		125kHz	31.3kHz	7.8kHz	2kHz
Maximum transmission distance (total length)		50m	200m	1km	3km
Number of transmission points setting	64 points (32 input points/32 output points)	0.42ms	1.7ms	6.8ms	24.8ms
	128 points (64 input points/64 output points)	0.7ms	2.7ms	10.9ms	40.7ms
	256 points (128 input points/128 output points)	1.2ms	4.8ms	19.1ms	72.4ms
	384 points (192 input points/192 output points)	1.7ms	6.8ms	27.3ms	104.2ms
	512 points (256 input points/256 output points)	2.2ms	8.9ms	35.5ms	135.9ms
	640 points (320 input points/320 output points)	2.7ms	10.9ms	43.6ms	167.6ms
	768 points (384 input points/384 output points)	3.2ms	13.0ms	51.8ms	199.4ms
	896 points (448 input points/448 output points)	3.8ms	15.0ms	60.0ms	231.1ms
	1024 points (512 input points/512 output points)	4.3ms	17.1ms	68.2ms	262.9ms
	2048 points (1024 input points/1024 output points)	8.4ms	33.4ms	133.8ms	516.8ms

8.1.2 Effects of the double check system


(1) Input

Unless the master module receives the same data twice successively, data in the input area is not updated.

A minimum of one-transmission cycle time and a maximum of two-transmission cycle time are required as data response time.

Therefore, when input data is shorter than two-transmission cycle time, the input data may not be captured depending on the timing.

To ensure the response, provide an input signal that is longer than two-transmission cycle time.



(2) Output


As the double check is performed on the slave module side, the time required is the same as that for input, namely a minimum of one-transmission cycle time and a maximum of two-transmission cycle time.

8.2 Transmission Delay Time

This section describes the transmission delay time (time until data is transmitted).

8.2.1 Slave module (input) to master module

The figure below shows the time between a signal input to the slave module and the CPU module device (X) turning on/off.



[Calculation formula]

1) Signal delay time of the slave module + 2) Transmission cycle time \times 2 + 3) Processing time on the master module side + 4) Sequence program scan time \times 2 [ms]

[Calculation example]

1) Signal delay time of the slave module

Signal delay time of the slave module is 0.17ms: 0.17 [ms]

2) Transmission cycle time \times 2

When the transmission point is set to 1024 and the transmission speed is set to 31.3kHz: $17.1 \times 2 = 34.2$ [ms]

3) Processing time on the master module side

Processing time on the master module side = Transmission speed clock width \times 16

When the transmission speed is set to 31.3kHz: $(1 \div 31.3k) \times 16 = 0.511$ [ms]


4) Sequence program scan time \times 2

Set the sequence program scan time to 5ms: $5 \times 2 = 10$ [ms]

Therefore, the transmission delay time is $0.17 + 34.2 + 0.511 + 10 = 44.88$ [ms].

8.2.2 Master module to slave module (output)

The figure below shows the time between the CPU module device (Y) turning on/off and a signal output from the slave module turning on/off.



[Calculation formula]

1) Sequence program scan time + 2) Processing time on the master module side + 3) Transmission cycle time \times 2 + 4) Signal delay time of the slave module [ms]

8

[Calculation example]

1) Sequence program scan time

Set the sequence program scan time to 5ms: : 5 [ms]

2) Processing time on the master module side

Processing time on the master module side = Transmission speed clock width \times 16

When the transmission speed is set to 31.3kHz: $(1 \div 31.3k) \times 16 = 0.511$ [ms]

3) Transmission cycle time \times 2

When the transmission point is set to 1024 and the transmission speed is set to 31.3kHz: $17.1 \times 2 = 34.2$ [ms]

4) Signal delay time of the slave module

Signal delay time of the slave module is 0.01ms : 0.01 [ms]

Therefore, the transmission delay time is $5 + 0.511 + 34.2 + 0.01 = 39.72$ [ms].

CHAPTER 9 TROUBLESHOOTING

If the transmission does not start normally, check the following items and perform the troubleshooting.

- All devices are being supplied with 24VDC power supply.
- The LINK LEDs of all the AnyWire DB A20 slave modules are flashing.
- The address settings are correct and unique.

For details on the entire AnyWire DB A20 system, refer to the "AnyWire DB A20 Series Technical Manual" (manufactured by Anywire Corporation).

9.1 Visual Inspection

Check that the communication cables and wires are not disconnected and check the following items.

(1) Checking the LED status of the master module

Errors regarding the operating status and communications of the master module can be checked with the following LEDs. When the LEDs are in the following status, settings and wiring need to be corrected.

(a) QJ51AW12D2

1. Check the M ERR.LED of the master module.

If the M ERR.LED is on, perform the following troubleshooting.

☞ Page 63, Section 9.3.1 (1)

2. Check the LINK LED of the master module.

If the LINK LED does not flash, perform the following troubleshooting.

☞ Page 63, Section 9.3.1 (2)

3. Check the ALM LED of the master module.

If the ALM LED is flashing at 0.2-second intervals, perform the following troubleshooting.

☞ Page 63, Section 9.3.1 (3)

If the ALM LED is flashing at 1 second intervals, perform the following troubleshooting.

☞ Page 63, Section 9.3.1 (4)

If the ALM LED is on, perform the following troubleshooting.

☞ Page 64, Section 9.3.1 (5)

(b) LJ51AW12D2**1. Check the LINK LED of the master module.**

If the LINK LED does not turn on or flash even after power-on, perform the following troubleshooting.

☞ Page 64, Section 9.3.2 (1)

If the LINK LED does not flash, perform the following troubleshooting.

☞ Page 64, Section 9.3.2 (2)

2. Check the ALM LED of the master module.

If the ALM LED is flashing at 0.2-second intervals, perform the following troubleshooting.

☞ Page 65, Section 9.3.2 (3)

If the ALM LED is flashing at 1 second intervals, perform the following troubleshooting.

☞ Page 65, Section 9.3.2 (4)

If the ALM LED is on, perform the following troubleshooting.

☞ Page 65, Section 9.3.2 (5)

3. Check the RUN LED of the master module.

If the RUN LED does not turn on, perform the following troubleshooting.

☞ Page 65, Section 9.3.2 (6)

(2) Checking the status of the slave module

Check that there is no error in the slave module.

For the troubleshooting of the slave module, refer to the following.

☞ Page 66, Section 9.4

- When the data (I/O data and parameter data) of the slave module cannot be checked
- When the data (I/O data and parameter data) of the slave module data is unstable

9.2 Check with Input Signals

(1) If D/G terminal short (Xn1) is on

If D/G terminal short (Xn1) is on, perform the following troubleshooting.

- QJ51AW12D2 (☞ Page 63, Section 9.3.1 (4))
- LJ51AW12D2 (☞ Page 65, Section 9.3.2 (4))

(2) If D/24V terminal short (Xn2) is on

If D/24V terminal short (Xn2) is on, perform the following troubleshooting.

- QJ51AW12D2 (☞ Page 63, Section 9.3.1 (4))
- LJ51AW12D2 (☞ Page 65, Section 9.3.2 (4))

(3) If 24V not applied (Xn3) is on

If 24V not applied (Xn3) is on, perform the following troubleshooting.

- QJ51AW12D2 (☞ Page 63, Section 9.3.1 (3))
- LJ51AW12D2 (☞ Page 65, Section 9.3.2 (3))

(4) If D/G terminal disconnection (Xn4) is on

If D/G terminal disconnection (Xn4) is on, perform the following troubleshooting.

- QJ51AW12D2 (☞ Page 64, Section 9.3.1 (5))
- LJ51AW12D2 (☞ Page 65, Section 9.3.2 (5))

9.3 Troubleshooting of Master Module

This section describes the troubleshooting of the master module.

9.3.1 QJ51AW12D2

(1) The M ERR.LED on the master module is on.

Item	Action
Check that the supply power to the programmable controller system is within the specifications.	If the M ERR.LED does not turn off after the master module is powered on, a hardware failure may have occurred.
Check that a hardware failure or a watchdog timer error has not occurred.	Please consult your local Mitsubishi representative.

(2) The LINK LED on the master module does not flash.

Item	Action
Check that the LINK LED is off.	A malfunction has been detected in the master module hardware. Reset the master module. If the error occurs again, the module may be in failure. Please consult your local Mitsubishi representative.

(3) The ALM LED on the master module is flashing at 0.2 second intervals.

Item	Action
Check the power supply voltage of the 24VDC external power supply.	Adjust the power supply voltage of the 24VDC external power supply to be within the rated value (21.6 to 27.6VDC).
Check that the power cables (24V, 0V) are not short-circuited.	<ul style="list-style-type: none">Check that the power cables (24V, 0V) are not disconnected or short-circuited.When crimping the link connector, check that the pin assignment is correct.
Check the wiring of the terminal blocks.	<ul style="list-style-type: none">Check that the 24VDC external power supply is properly connected to the terminal block of the master module or the slave module.Check that there is no short-circuit or incorrect wiring and screws have been tightened sufficiently.

(4) The ALM LED on the master module is flashing at 1 second intervals.

Item	Action
Check that the transmission cables (between D and G, D and 24V) are not short-circuited.	<ul style="list-style-type: none">Check that the transmission cables (between D and G, D and 24V) are not short-circuited.When crimping the link connector, check that the pin assignment is correct.
Check the wiring of the terminal blocks.	Check that the transmission cables (D, G) are not short-circuited and there is no incorrect wiring in the terminal block wiring of the master module and the slave module.

(5) The ALM LED on the master module is on.

Item	Action
Check that the transmission cables (D, G) are not disconnected.	<ul style="list-style-type: none"> Check that the entire transmission cables (D, G) are free from disconnection. Check that the cables have been crimped with proper pin assignment using link connectors appropriate to the wire diameter.
Check the wiring of the terminal blocks.	<ul style="list-style-type: none"> Check that the transmission cables (D, G) and power cables (24V, 0V) are properly connected to the terminal block of the master module. Check that there is no incorrect wiring and screws have been tightened sufficiently.
Execute the automatic address detection function.	When creating a new system, adding or removing a slave module, or changing the address of the slave module, execute the automatic address detection function. After executing the automatic address detection function, check that the number of slave modules and the address are consistent with those of the actual system.
Check the existence of the slave module.	If the LINK LED of the slave module is not flashing, check that there is no disconnection, short-circuit, incorrect wiring, or poor contact in the transmission cables around the slave module.

9.3.2 LJ51AW12D2

(1) When the LINK LED does not turn on or flash after power-on

Item	Action
Check the power supply voltage of the 24VDC external power supply.	Adjust the power supply voltage of the 24VDC external power supply to be within the rated value (21.6 to 27.6VDC).
Check the wiring of the terminal blocks.	<ul style="list-style-type: none"> Check that the 24VDC external power supply is properly connected to the terminal block of the master module. Check that there is no short-circuit or incorrect wiring and screws have been tightened sufficiently.
Check that the power cables (24V, 0V) are not short-circuited.	<ul style="list-style-type: none"> Check that the power cables (24V, 0V) are not disconnected or short-circuited. When crimping the link connector, check that the pin assignment is correct.
Check the total internal current consumption of the entire system.	Review the system configuration so that the total internal current consumption does not exceed the rated output current of the power supply module.

(2) The LINK LED on the master module does not flash.

Item	Action
Check that the LINK LED is turned on.	<p>A malfunction has been detected in the master module hardware.</p> <p>Reset the master module.</p> <p>If the error occurs again, the module may be in failure. Please consult your local Mitsubishi representative.</p>

(3) The ALM LED on the master module is flashing at 0.2 second intervals.

Item	Action
Check the power supply voltage of the 24VDC external power supply.	Adjust the power supply voltage of the 24VDC external power supply connected to the master module to be within the rated value (21.6 to 27.6VDC).
Check that the power cables (24V, 0V) are not short-circuited.	<ul style="list-style-type: none"> Check that the power cables (24V, 0V) are not disconnected or short-circuited. When crimping the link connector, check that the pin assignment is correct.
Check the wiring of the terminal blocks.	<ul style="list-style-type: none"> Check that the 24VDC external power supply is properly connected to the terminal block of the master module or the slave module. Check that there is no short-circuit or incorrect wiring and screws have been tightened sufficiently.

(4) The ALM LED on the master module is flashing at 1 second intervals.

Item	Action
Check that the transmission cables (between D and G, D and 24V) are not short-circuited.	<ul style="list-style-type: none"> Check that the transmission cables (between D and G, D and 24V) are not short-circuited. When crimping the link connector, check that the pin assignment is correct.
Check the wiring of the terminal blocks.	Check that the transmission cables (D, G) are not short-circuited and there is no incorrect wiring in the terminal block wiring of the master module and the slave module.

(5) The ALM LED on the master module is on.

Item	Action
Check that the transmission cables (D, G) are not disconnected.	<ul style="list-style-type: none"> Check that the entire transmission cables (D, G) are free from disconnection. Check that the cables have been crimped with proper pin assignment using link connectors appropriate to the wire diameter.
Check the wiring of the terminal blocks.	<ul style="list-style-type: none"> Check that the transmission cables (D, G) and power cables (24V, 0V) are properly connected to the terminal block of the master module. Check that there is no incorrect wiring and screws have been tightened sufficiently.
Execute the automatic address detection function.	When creating a new system, adding or removing a slave module, or changing the address of the slave module, execute the automatic address detection function. After executing the automatic address detection function, check that the number of slave modules and the address are consistent with those of the actual system.
Check the existence of the slave module.	If the LINK LED of the slave module is not flashing, check that there is no disconnection, short-circuit, incorrect wiring, or poor contact in the transmission cables around the slave module.

(6) The RUN LED on the master module does not turn on.

Item	Action
Check that the supply power to the programmable controller system is within the specifications.	If the RUN LED does not turn on after powering on the master module, hardware failure may have occurred.
Check that a hardware failure or a watchdog timer error has not occurred.	Please consult your local Mitsubishi representative.

9.4 Troubleshooting of Slave Module

This section describes the troubleshooting of the slave module.

(1) When I/O data and parameter data cannot be checked

Item	Action
Check the FROM/TO instruction issued by the program using the programming tool.	<ul style="list-style-type: none">Check that the buffer memory map of the programmable controller device and the master module assigned by the MOV instruction or the FROM/TO instruction is appropriate.Check that the CPU module is in the STOP state. Slave module cannot output data when the CPU module is in the STOP state.
Check that the LINK LED on the slave module is flashing.	If the LINK LED of the slave module is not flashing, check that there is no disconnection, short-circuit, incorrect wiring, or poor contact in the transmission cables around the slave module. In addition, check that the transmission speed setting of the slave module is same as that of the master module.
Check that the RDY LED on the slave module is on.	If the RDY LED on the slave module does not turn on, a power supply error has occurred. Possible causes are disconnection of the power cable, short-circuit, and shortage of the power supply voltage. Check the wiring, installation method, and power supply voltage of the slave module.

(2) When the I/O data and parameter data of the slave module is unstable

Item	Action
Check the connection of the terminating unit.	Pay attention to the polarities of the terminating unit and connect it correctly.
Check the total length of the transmission cables (D, G).	Adjust the total length of the AnyWire DB A20 system to be within the specification range.
Check the specifications of the transmission cables (D, G).	<ul style="list-style-type: none">Check that the transmission cables (D, G) have the specified type, wire diameter, and tightening torque to the terminal block.Do not run multiple transmission cables (D, G) using a multicore cable.
Check the voltage range of the 24VDC external power supply.	Adjust the power supply voltage of the 24VDC external power supply to be within the rated value (21.6 to 27.6VDC).
Check that the slave module does not have the same address as the addresses of other slave modules.	Set a unique address in the slave module.
Check the FROM/TO instruction issued by the program using the programming tool.	Check that the buffer memory map of the programmable controller device and the master module assigned by the MOV instruction or the FROM/TO instruction is appropriate.
Check that two or more master modules are not connected within one AnyWire DB A20 line.	Connect only one master module within one AnyWire DB A20 line.
Check that master modules of different series are not connected within one AnyWire DB A20 line.	Connect only one master module within one AnyWire DB A20 line.
Check that a master module and the AnyWire DB A20 bridge module are not connected within one AnyWire DB A20 line.	Connect either one master module or one AnyWire DB A20 bridge module within one AnyWire DB A20 line.

9.5 List of Error Codes

This section lists the error codes of the master module.

Error code	Error description	Action
0064 _H to 0067 _H	Master module hardware error	A malfunction has been detected in the master module hardware. Reset the CPU module or power off and on the system. If the error occurs again, the master module may be in failure. Please consult your local Mitsubishi representative.
0068 _H	CPU module stop error	A stop error has occurred in the CPU module. Check and correct the error using PLC Diagnostics of the programming tool.
00C8 _H	Transmission cable voltage drop error	The voltage of the 24VDC external power supply may be lacking. Perform the following. <ul style="list-style-type: none"> • Adjust the power supply voltage of the 24VDC external power supply to be within the rated value (21.6 to 27.6VDC). • Check that the power cables (24V, 0V) are not disconnected or short-circuited. • When crimping the link connector, check that the pin assignment is correct. • Check that the 24VDC external power supply is properly connected to the terminal block of the master module or the slave module. • Check that there is no short-circuit or incorrect wiring and screws have been tightened sufficiently.
00C9 _H	Short between D and G terminals	The transmission cables (D, G) may have short-circuited. Perform the following. <ul style="list-style-type: none"> • Check that the transmission cables (D, G) are not short-circuited. • When crimping the link connector, check that the pin assignment is correct. • Check that the transmission cables (D, G) are not short-circuited and there is no incorrect wiring in the terminal block wiring of the master module and the slave module.
00CA _H	D, G disconnection error	The transmission cables (D, G) may be disconnected or there may be no response from the slave module. The slave module may be in failure or the system configuration may have been changed after execution of the automatic address detection function. Check the buffer memory areas "Number of error IDs (1 word)" (2000 _H) and "Error ID information" (2001 _H to 2080 _H) to locate the disconnected cable and perform the following. <ul style="list-style-type: none"> • Check that the transmission cables (entire cables) are free from disconnection. • Check that the cables have been crimped with proper pin assignment using link connectors appropriate to the wire diameter. • Check that the transmission cables (D, G) and power cables (24V, 0V) are properly connected to the terminal block of the master module. • Check that there is no incorrect wiring and screws have been tightened sufficiently. • When creating a new system, adding or removing a slave module, or changing the address of the slave module, execute the automatic address detection function. After executing the automatic address detection function, check that the number of slave modules and the address are consistent with those of the actual system. • If the LINK LED on the slave module is not flashing, check that there is no disconnection, short-circuit, incorrect wiring, or poor contact in the transmission cables (D, G) around the module.
00CB _H	D-24 V short error	The transmission cables (between D and 24V) may be short-circuited. Perform the following. <ul style="list-style-type: none"> • Check that the transmission cables (between D and 24V) are not short-circuited. • When crimping the link connector, check that the pin assignment is correct. • Check that the transmission cables (between D and 24V) are not short-circuited and there is no incorrect wiring in the terminal block wiring of the master module and the slave module.

Point

Check the error information with Latest error code storage area (2810_H) and Latest error ID storage area (2811_H) of the buffer memory.

APPENDIX

Appendix 1 EMC and Low Voltage Directives

Compliance with the EMC Directive, which is one of the EU directives, has been mandatory for the products sold within EU member states since 1996 as well as compliance with the Low Voltage Directive since 1997.

To prove the compliance with these Directives, manufacturers must issue an EC Declaration of Conformity and the products must bear a CE marking.

(1) Sales representative in EU member states

The authorized representative in EU member states will be:

Company name: MITSUBISHI ELECTRIC EUROPE B.V.

Address: Mitsubishi-Electric-Platz 1, 40882 Ratingen, Germany

Appendix 1.1 Requirements for compliance with the EMC Directive

The EMC Directive sets two requirements for compliance: emission (conducted and radiated electromagnetic energy emitted by a product) and immunity (the ability of a product to function without being influenced by externally generated electromagnetic energy), and all applicable products are required to satisfy these requirements. This section summarizes the precautions for machinery constructed with this product to comply with the EMC Directive. These precautions are based on the requirements of the EMC Directive and the harmonized standards. However, they do not guarantee that the entire machinery constructed according to the descriptions complies with the EMC Directive. The manufacturer of the machinery must determine the testing method for compliance and declare conformity to the EMC Directive.

(1) Installation in control panel

This open-type device is intended to be placed in an industrial control panel or similar type of enclosure. ^{*1}

This ensures safety as well as effective shielding of electromagnetic noise emitted from this product.

*1 Modules on the remote station in each network must be also installed inside the control panel.

However, waterproof modules on the remote station can be installed outside the control panel.

(a) Control panel

- Use a conductive control panel.
- Mask off the area used for grounding when securing the top or bottom plate to the control panel using bolts.
- To ensure electrical contact between the inner plate and the control panel, mask off the bolt installation areas of an inner plate so that conductivity can be ensured in the largest possible area.
- Ground the control panel with a thick ground cable so that low impedance can be ensured even at high frequencies.
- Keep the diameter of the holes in the control panel 10cm or less. If the diameter is larger than 10cm, electromagnetic wave may be emitted. In addition, because electromagnetic wave leaks through a clearance between the control panel and its door, reduce the clearance as much as possible. The leakage of radio waves can be suppressed by the direct application of an EMI gasket on the paint surface.

The tests by Mitsubishi were conducted using a panel having the damping characteristics of 37dB (maximum) and 30db (average) (measured at 3m distance, 30 to 300MHz).

(b) Wiring power and ground cables


Run the ground cable and the power cable of this product as instructed below.

- Provide a ground point to the control panel near the power supply module. Ground the LG (line ground) and FG (frame ground) terminals of the power supply module for the programmable controller and the LG terminal of the transmission cable terminal block to the ground point with the thickest and shortest ground cable possible (about 30cm or shorter). Because the LG and FG terminals serve to dissipate noise generated within the programmable controller to the ground, the impedance of the ground cable must be as low as possible. In addition, the ground cable must be kept as short as possible. The ground cable serves to dissipate noise. Because the ground cable itself bears noise, keeping the cable short means that the cable prevents itself from being an antenna.
- The ground cable run from the contact point must be twisted with the power cable. By twisting the power cable with the ground cable, more noise flowing through the power cable can be dissipated to the ground. However, when a noise filter is attached to the power cable, twisting with the ground cable may be unnecessary.

(2) Cables

(a) Cable connected to the transmission cable terminal block

For the cable connected to the transmission cable terminal block, attach a ferrite core having the attenuation characteristics equivalent to that of ZCAT3035-1330 made by TDK Corporation as close to the transmission cable terminal block of this product as possible. Use a ferrite core with three turns of wire as shown below.



(b) Power cable for the 24VDC power supply terminal

Use a CE-marked DC power supply. The DC power supply must be placed together with the module in the same control panel, and the power cable connected to the power terminal of this product should be 30cm or shorter.

(3) External power supply

Use a CE-marked external power supply and ground the FG terminal.

(External power supply used for the tests conducted by Mitsubishi: PS5R-SF24 made by IDEC Corporation)

(4) Power supply module for the programmable controller

Ground the LG and FG terminals after short-circuiting them.

(5) Installation environment

Use this product in Zone B^{*1}.

*1 Zone means a category determined according to the industrial environment conditions and defined by the harmonized standard EN61131-2 of the EMC and Low Voltage Directives.

Zone C: Main power supply insulated from the public power supply by a special transformer

Zone B: Special power supply with the secondary surge protector from the main power (Rated voltage is assumed to be 300V or less.)

Zone A: Local power supply protected by an AC-DC converter or an insulating transformer from the special power supply (Rated voltage is assumed to be 120V or less.)

Appendix 1.2 Requirements for compliance with the Low Voltage Directive

The Low Voltage Directive does not apply to this product because it operates on 5VDC and 24VDC power supply. For making the PLC system used comply with the Low Voltage Directive, refer to the manual supplied with the CPU module, the base unit, or the head module.

Appendix 2 Differences between the QJ51AW12D2 and LJ51AW12D2

This section describes the differences between the QJ51AW12D2 and LJ51AW12D2.

Item	Difference	
	QJ51AW12D2	LJ51AW12D2
Error diagnostics using system monitor of the programming tool	Disabled	Enabled
Operation at recovery from error (Voltage drop of the 24VDC power supply, short-circuit of transmission cables (D, G) and power cables (24V, 0V))	Error flags are automatically cleared. Error clear is not required after recovery from error.	Error flags are maintained. Error clear is required after recovery from error.

Appendix 3 Functions Added and Modified with Version Upgrade

The master module has some new functions added and specifications modified as a result of a version upgrade. The functions and specifications that can be used in the master module vary depending on the function version and the serial number.

Additional functions	Module	Supported function version	Sixth digit of the serial number
<ul style="list-style-type: none">Double check mode, waveform output method (☞ Page 28, Section 3.1.2)Addition of buffer memory area (☞ Page 43, Section 4.2)	QJ51AW12D2	B	"6" or later

REVISIONS

*The manual number is given on the bottom left of the back cover.

Print date	*Manual number	Revision
February 2011	SH(NA)-080968ENG-A	First edition
May 2011	SH(NA)-080968ENG-B	Revision due to error correction
March 2013	SH(NA)-080968ENG-C	Revision due to compliance with EMC and UL/cUL
October 2014	SH(NA)-080968ENG-D	Revision due to the addition of the LJ51AW12D2 and function for the QJ51AW12D2, and compliance with UL/cUL of the LJ51AW12D2
November 2016	SH(NA)-080968ENG-E	Revision due to changes in the rating plate and grounding mark

Japanese manual version SH-080967-F

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

© 2011 MITSUBISHI ELECTRIC CORPORATION

WARRANTY

Please confirm the following product warranty details before using this product.

1. Gratis Warranty Term and Gratis Warranty Range

If any faults or defects (hereinafter "Failure") found to be the responsibility of Mitsubishi occurs during use of the product within the gratis warranty term, the product shall be repaired at no cost via the sales representative or Mitsubishi Service Company.

However, if repairs are required onsite at domestic or overseas location, expenses to send an engineer will be solely at the customer's discretion. Mitsubishi shall not be held responsible for any re-commissioning, maintenance, or testing on-site that involves replacement of the failed module.

[Gratis Warranty Term]

The gratis warranty term of the product shall be for one year after the date of purchase or delivery to a designated place. Note that after manufacture and shipment from Mitsubishi, the maximum distribution period shall be six (6) months, and the longest gratis warranty term after manufacturing shall be eighteen (18) months. The gratis warranty term of repair parts shall not exceed the gratis warranty term before repairs.

[Gratis Warranty Range]

- (1) The range shall be limited to normal use within the usage state, usage methods and usage environment, etc., which follow the conditions and precautions, etc., given in the instruction manual, user's manual and caution labels on the product.
- (2) Even within the gratis warranty term, repairs shall be charged for in the following cases.
 1. Failure occurring from inappropriate storage or handling, carelessness or negligence by the user. Failure caused by the user's hardware or software design.
 2. Failure caused by unapproved modifications, etc., to the product by the user.
 3. When the Mitsubishi product is assembled into a user's device, Failure that could have been avoided if functions or structures, judged as necessary in the legal safety measures the user's device is subject to or as necessary by industry standards, had been provided.
 4. Failure that could have been avoided if consumable parts (battery, backlight, fuse, etc.) designated in the instruction manual had been correctly serviced or replaced.
 5. Failure caused by external irresistible forces such as fires or abnormal voltages, and Failure caused by force majeure such as earthquakes, lightning, wind and water damage.
 6. Failure caused by reasons unpredictable by scientific technology standards at time of shipment from Mitsubishi.
 7. Any other failure found not to be the responsibility of Mitsubishi or that admitted not to be so by the user.

2. Onerous repair term after discontinuation of production

- (1) Mitsubishi shall accept onerous product repairs for one year after production of the product is discontinued.

Discontinuation of production shall be notified with Mitsubishi Technical Bulletins, etc.

- (2) Product supply (including repair parts) is not available after production is discontinued.

3. Overseas service

Overseas, repairs shall be accepted by Mitsubishi's local overseas FA Center. Note that the repair conditions at each FA Center may differ.

4. Exclusion of loss in opportunity and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to:

- (1) Damages caused by any cause found not to be the responsibility of Mitsubishi.
- (2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products.
- (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products.
- (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

5. Changes in product specifications

The specifications given in the catalogs, manuals or technical documents are subject to change without prior notice.

TRADEMARKS

Anywire and AnyWireASLINK are either registered trademarks or trademarks of Anywire Corporation.

Ethernet is a registered trademark of Fuji Xerox Co., Ltd. in Japan.

The company names, system names and product names mentioned in this manual are either registered trademarks or trademarks of their respective companies.

In some cases, trademark symbols such as TM or [®] are not specified in this manual.

Anywire Anywire Corporation www.anywire.jp

SH(NA)-080968ENG-E(1611)MEE

MODEL: QJ51AW12D2-U-E

MODEL CODE: 13JZ52

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS : 1-14 , YADA-MINAMI 5-CHOME , HIGASHI-KU, NAGOYA , JAPAN

When exported from Japan, this manual does not require application to the
Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.