

Mitsubishi Programmable Controller

**MELSEC iQ-R**  
series

**MELSEC iQ-R High Speed Analog-Digital  
Converter Module  
User's Manual (Application)**

---

-R60ADH4



# SAFETY PRECAUTIONS

(Read these precautions before using this product.)

Before using this product, please read this manual and the relevant manuals carefully and pay full attention to safety to handle the product correctly.

The precautions given in this manual are concerned with this product only. For the safety precautions of the programmable controller system, refer to the MELSEC iQ-R Module Configuration Manual.

In this manual, the safety precautions are classified into two levels: " WARNING" and " CAUTION".

 <b>WARNING</b>	Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.
 <b>CAUTION</b>	Indicates that incorrect handling may cause hazardous conditions, resulting in minor or moderate injury or property damage.

Under some circumstances, failure to observe the precautions given under " CAUTION" may lead to serious consequences.

Observe the precautions of both levels because they are important for personal and system safety.

Make sure that the end users read this manual and then keep the manual in a safe place for future reference.

## [Design Precautions]

---

### **WARNING**

- Configure safety circuits external to the programmable controller to ensure that the entire system operates safely even when a fault occurs in the external power supply or the programmable controller. Failure to do so may result in an accident due to an incorrect output or malfunction.
  - (1) Emergency stop circuits, protection circuits, and protective interlock circuits for conflicting operations (such as forward/reverse rotations or upper/lower limit positioning) must be configured external to the programmable controller.
  - (2) When the programmable controller detects an abnormal condition, it stops the operation and all outputs are:
    - Turned off if the overcurrent or overvoltage protection of the power supply module is activated.
    - Held or turned off according to the parameter setting if the self-diagnostic function of the CPU module detects an error such as a watchdog timer error.
  - (3) All outputs may be turned on if an error occurs in a part, such as an I/O control part, where the CPU module cannot detect any error. To ensure safety operation in such a case, provide a safety mechanism or a fail-safe circuit external to the programmable controller. For a fail-safe circuit example, refer to "General Safety Requirements" in the MELSEC iQ-R Module Configuration Manual.
  - (4) Outputs may remain on or off due to a failure of a component such as a relay and transistor in an output circuit. Configure an external circuit for monitoring output signals that could cause a serious accident.
- In an output circuit, when a load current exceeding the rated current or an overcurrent caused by a load short-circuit flows for a long time, it may cause smoke and fire. To prevent this, configure an external safety circuit, such as a fuse.
- Configure a circuit so that the programmable controller is turned on first and then the external power supply. If the external power supply is turned on first, an accident may occur due to an incorrect output or malfunction.
- For the operating status of each station after a communication failure, refer to manuals relevant to the network. Incorrect output or malfunction due to a communication failure may result in an accident.

---

## [Design Precautions]

### **WARNING**

- When connecting an external device with a CPU module or intelligent function module to modify data of a running programmable controller, configure an interlock circuit in the program to ensure that the entire system will always operate safely. For other forms of control (such as program modification, parameter change, forced output, or operating status change) of a running programmable controller, read the relevant manuals carefully and ensure that the operation is safe before proceeding. Improper operation may damage machines or cause accidents.
- Especially, when a remote programmable controller is controlled by an external device, immediate action cannot be taken if a problem occurs in the programmable controller due to a communication failure. To prevent this, configure an interlock circuit in the program, and determine corrective actions to be taken between the external device and CPU module in case of a communication failure.
- Do not write any data to the "system area" and "write-protect area" of the buffer memory in the module. Also, do not use any "use prohibited" signals as an output signal from the CPU module to each module. Doing so may cause malfunction of the programmable controller system. For the "system area", "write-protect area", and the "use prohibited" signals, refer to the user's manual for the module used.
- If a communication cable is disconnected, the network may be unstable, resulting in a communication failure of multiple stations. Configure an interlock circuit in the program to ensure that the entire system will always operate safely even if communications fail. Failure to do so may result in an accident due to an incorrect output or malfunction.
- To maintain the safety of the programmable controller system against unauthorized access from external devices via the network, take appropriate measures. To maintain the safety against unauthorized access via the Internet, take measures such as installing a firewall.

## [Design Precautions]

---

### **CAUTION**

- Do not install the control lines or communication cables together with the main circuit lines or power cables. Keep a distance of 100mm or more between them. Failure to do so may result in malfunction due to noise.
- During control of an inductive load such as a lamp, heater, or solenoid valve, a large current (approximately ten times greater than normal) may flow when the output is turned from off to on. Therefore, use a module that has a sufficient current rating.
- After the CPU module is powered on or is reset, the time taken to enter the RUN status varies depending on the system configuration, parameter settings, and/or program size. Design circuits so that the entire system will always operate safely, regardless of the time.
- Do not power off the programmable controller or reset the CPU module while the settings are being written. Doing so will make the data in the flash ROM undefined. The values need to be set in the buffer memory and written to the flash ROM again. Doing so also may cause malfunction or failure of the module.
- When changing the operating status of the CPU module from external devices (such as the remote RUN/STOP functions), select "Do Not OPEN in Program" for "Open Method Setting" in the module parameters. If "OPEN in Program" is selected, an execution of the remote STOP function causes the communication line to close. Consequently, the CPU module cannot reopen the line, and external devices cannot execute the remote RUN function.

---

## [Installation Precautions]

---

### **WARNING**

- Shut off the external power supply (all phases) used in the system before mounting or removing the module. Failure to do so may result in electric shock or cause the module to fail or malfunction.

---

## [Installation Precautions]

### **CAUTION**

- Use the programmable controller in an environment that meets the general specifications in the Safety Guidelines included with the base unit. Failure to do so may result in electric shock, fire, malfunction, or damage to or deterioration of the product.
- To mount a module, place the concave part(s) located at the bottom onto the guide(s) of the base unit, and push in the module until the hook(s) located at the top snaps into place. Incorrect interconnection may cause malfunction, failure, or drop of the module.
- When using the programmable controller in an environment of frequent vibrations, fix the module with a screw.
- Tighten the screws within the specified torque range. Undertightening can cause drop of the screw, short circuit, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.
- When using an extension cable, connect it to the extension cable connector of the base unit securely. Check the connection for looseness. Poor contact may cause malfunction.
- When using an SD memory card, fully insert it into the SD memory card slot. Check that it is inserted completely. Poor contact may cause malfunction.
- Securely insert an extended SRAM cassette into the cassette connector of the CPU module. After insertion, close the cassette cover and check that the cassette is inserted completely. Poor contact may cause malfunction.
- Do not directly touch any conductive parts and electronic components of the module, SD memory card, extended SRAM cassette, or connector. Doing so can cause malfunction or failure of the module.

## [Wiring Precautions]

### **WARNING**

- Shut off the external power supply (all phases) used in the system before installation and wiring. Failure to do so may result in electric shock or cause the module to fail or malfunction.
- After installation and wiring, attach the included terminal cover to the module before turning it on for operation. Failure to do so may result in electric shock.

## [Wiring Precautions]

### **CAUTION**

- Individually ground the FG and LG terminals of the programmable controller with a ground resistance of 100 ohms or less. Failure to do so may result in electric shock or malfunction.
- Use applicable solderless terminals and tighten them within the specified torque range. If any spade solderless terminal is used, it may be disconnected when the terminal screw comes loose, resulting in failure.
- Check the rated voltage and signal layout before wiring to the module, and connect the cables correctly. Connecting a power supply with a different voltage rating or incorrect wiring may cause fire or failure.
- Connectors for external devices must be crimped or pressed with the tool specified by the manufacturer, or must be correctly soldered. Incomplete connections may cause short circuit, fire, or malfunction.
- Securely connect the connector to the module. Poor contact may cause malfunction.
- Do not install the control lines or communication cables together with the main circuit lines or power cables. Keep a distance of 100mm or more between them. Failure to do so may result in malfunction due to noise.
- Place the cables in a duct or clamp them. If not, dangling cable may swing or inadvertently be pulled, resulting in damage to the module or cables or malfunction due to poor contact. Do not clamp the extension cables with the jacket stripped.
- Check the interface type and correctly connect the cable. Incorrect wiring (connecting the cable to an incorrect interface) may cause failure of the module and external device.
- Tighten the terminal screws or connector screws within the specified torque range. Undertightening can cause drop of the screw, short circuit, fire, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, fire, or malfunction.
- When disconnecting the cable from the module, do not pull the cable by the cable part. For the cable with connector, hold the connector part of the cable. For the cable connected to the terminal block, loosen the terminal screw. Pulling the cable connected to the module may result in malfunction or damage to the module or cable.
- Prevent foreign matter such as dust or wire chips from entering the module. Such foreign matter can cause a fire, failure, or malfunction.
- A protective film is attached to the top of the module to prevent foreign matter, such as wire chips, from entering the module during wiring. Do not remove the film during wiring. Remove it for heat dissipation before system operation.
- Programmable controllers must be installed in control panels. Connect the main power supply to the power supply module in the control panel through a relay terminal block. Wiring and replacement of a power supply module must be performed by qualified maintenance personnel with knowledge of protection against electric shock. For wiring, refer to the MELSEC iQ-R Module Configuration Manual.
- For Ethernet cables to be used in the system, select the ones that meet the specifications in the user's manual for the module used. If not, normal data transmission is not guaranteed.

## [Startup and Maintenance Precautions]

---

### **WARNING**

- Do not touch any terminal while power is on. Doing so will cause electric shock or malfunction.
- Correctly connect the battery connector. Do not charge, disassemble, heat, short-circuit, solder, or throw the battery into the fire. Also, do not expose it to liquid or strong shock. Doing so will cause the battery to produce heat, explode, ignite, or leak, resulting in injury and fire.
- Shut off the external power supply (all phases) used in the system before cleaning the module or retightening the terminal screws, connector screws, or module fixing screws. Failure to do so may result in electric shock.

---

## [Startup and Maintenance Precautions]

### **CAUTION**

- When connecting an external device with a CPU module or intelligent function module to modify data of a running programmable controller, configure an interlock circuit in the program to ensure that the entire system will always operate safely. For other forms of control (such as program modification, parameter change, forced output, or operating status change) of a running programmable controller, read the relevant manuals carefully and ensure that the operation is safe before proceeding. Improper operation may damage machines or cause accidents.
- Especially, when a remote programmable controller is controlled by an external device, immediate action cannot be taken if a problem occurs in the programmable controller due to a communication failure. To prevent this, configure an interlock circuit in the program, and determine corrective actions to be taken between the external device and CPU module in case of a communication failure.
- Do not disassemble or modify the modules. Doing so may cause failure, malfunction, injury, or a fire.
- Use any radio communication device such as a cellular phone or PHS (Personal Handy-phone System) more than 25cm away in all directions from the programmable controller. Failure to do so may cause malfunction.
- Shut off the external power supply (all phases) used in the system before mounting or removing the module. Failure to do so may cause the module to fail or malfunction.
- Tighten the screws within the specified torque range. Undertightening can cause drop of the component or wire, short circuit, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.
- After the first use of the product, do not mount/remove the module to/from the base unit, and the terminal block to/from the module, and do not insert/remove the extended SRAM cassette to/from the CPU module more than 50 times (IEC 61131-2 compliant) respectively. Exceeding the limit may cause malfunction.
- After the first use of the product, do not insert/remove the SD memory card to/from the CPU module more than 500 times. Exceeding the limit may cause malfunction.
- Do not touch the metal terminals on the back side of the SD memory card. Doing so may cause malfunction or failure.
- Do not touch the integrated circuits on the circuit board of an extended SRAM cassette. Doing so may cause malfunction or failure of the module.
- Do not drop or apply shock to the battery to be installed in the module. Doing so may damage the battery, causing the battery fluid to leak inside the battery. If the battery is dropped or any shock is applied to it, dispose of it without using.
- Startup and maintenance of a control panel must be performed by qualified maintenance personnel with knowledge of protection against electric shock. Lock the control panel so that only qualified maintenance personnel can operate it.
- Before handling the module, touch a conducting object such as a grounded metal to discharge the static electricity from the human body. Failure to do so may cause the module to fail or malfunction.

## [Operating Precautions]

### **CAUTION**

- When changing data and operating status, and modifying program of the running programmable controller from an external device such as a personal computer connected to an intelligent function module, read relevant manuals carefully and ensure the safety before operation. Incorrect change or modification may cause system malfunction, damage to the machines, or accidents.
- Do not power off the programmable controller or reset the CPU module while the setting values in the buffer memory are being written to the flash ROM in the module. Doing so will make the data in the flash ROM undefined. The values need to be set in the buffer memory and written to the flash ROM again. Doing so can cause malfunction or failure of the module.

## [Disposal Precautions]

### **CAUTION**

- When disposing of this product, treat it as industrial waste.
- When disposing of batteries, separate them from other wastes according to the local regulations. For details on battery regulations in EU member states, refer to the MELSEC iQ-R Module Configuration Manual.

## [Transportation Precautions]

### **CAUTION**

- When transporting lithium batteries, follow the transportation regulations. For details on the regulated models, refer to the MELSEC iQ-R Module Configuration Manual.
- The halogens (such as fluorine, chlorine, bromine, and iodine), which are contained in a fumigant used for disinfection and pest control of wood packaging materials, may cause failure of the product. Prevent the entry of fumigant residues into the product or consider other methods (such as heat treatment) instead of fumigation. The disinfection and pest control measures must be applied to unprocessed raw wood.

# CONDITIONS OF USE FOR THE PRODUCT

(1) Mitsubishi programmable controller ("the PRODUCT") shall be used in conditions;

- i) where any problem, fault or failure occurring in the PRODUCT, if any, shall not lead to any major or serious accident; and
- ii) where the backup and fail-safe function are systematically or automatically provided outside of the PRODUCT for the case of any problem, fault or failure occurring in the PRODUCT.

(2) The PRODUCT has been designed and manufactured for the purpose of being used in general industries.

MITSUBISHI SHALL HAVE NO RESPONSIBILITY OR LIABILITY (INCLUDING, BUT NOT LIMITED TO ANY AND ALL RESPONSIBILITY OR LIABILITY BASED ON CONTRACT, WARRANTY, TORT, PRODUCT LIABILITY) FOR ANY INJURY OR DEATH TO PERSONS OR LOSS OR DAMAGE TO PROPERTY CAUSED BY the PRODUCT THAT ARE OPERATED OR USED IN APPLICATION NOT INTENDED OR EXCLUDED BY INSTRUCTIONS, PRECAUTIONS, OR WARNING CONTAINED IN MITSUBISHI'S USER, INSTRUCTION AND/OR SAFETY MANUALS, TECHNICAL BULLETINS AND GUIDELINES FOR the PRODUCT.

("Prohibited Application")

Prohibited Applications include, but not limited to, the use of the PRODUCT in;

- Nuclear Power Plants and any other power plants operated by Power companies, and/or any other cases in which the public could be affected if any problem or fault occurs in the PRODUCT.
- Railway companies or Public service purposes, and/or any other cases in which establishment of a special quality assurance system is required by the Purchaser or End User.
- Aircraft or Aerospace, Medical applications, Train equipment, transport equipment such as Elevator and Escalator, Incineration and Fuel devices, Vehicles, Manned transportation, Equipment for Recreation and Amusement, and Safety devices, handling of Nuclear or Hazardous Materials or Chemicals, Mining and Drilling, and/or other applications where there is a significant risk of injury to the public or property.

Notwithstanding the above, restrictions Mitsubishi may in its sole discretion, authorize use of the PRODUCT in one or more of the Prohibited Applications, provided that the usage of the PRODUCT is limited only for the specific applications agreed to by Mitsubishi and provided further that no special quality assurance or fail-safe, redundant or other safety features which exceed the general specifications of the PRODUCTS are required. For details, please contact the Mitsubishi representative in your region.

## INTRODUCTION

Thank you for purchasing the Mitsubishi MELSEC iQ-R series programmable controllers.

This manual describes the functions, parameter settings, and troubleshooting of the relevant product listed below.

Before using this product, please read this manual and the relevant manuals carefully and develop familiarity with the functions and performance of the MELSEC iQ-R series programmable controller to handle the product correctly.

When applying the program examples provided in this manual to an actual system, ensure the applicability and confirm that it will not cause system control problems.

Please make sure that the end users read this manual.



Unless otherwise specified, this manual provides program examples in which the I/O numbers of X/Y0 to X/YF are assigned to the A/D converter module. Assign I/O numbers when applying the program examples to an actual system. For I/O number assignment, refer to the following.

MELSEC iQ-R Module Configuration Manual

### Relevant product

R60ADH4

# CONTENTS

SAFETY PRECAUTIONS .....	1
CONDITIONS OF USE FOR THE PRODUCT .....	10
INTRODUCTION .....	10
RELEVANT MANUALS .....	13
TERMS .....	14
MANUAL PAGE ORGANIZATION .....	15
<b>CHAPTER 1 FUNCTIONS</b>	<b>16</b>
1.1 Modes .....	16
1.2 Processing of Each Function .....	19
1.3 Range Switching Function .....	21
1.4 A/D Conversion Enable/Disable Setting Function .....	21
1.5 A/D Conversion Method .....	22
Sampling processing .....	23
Averaging processing .....	25
Primary delay filter .....	28
Digital filter .....	30
1.6 Scaling Function .....	38
1.7 Shift Function .....	41
1.8 Digital Clipping Function .....	44
1.9 Difference Conversion Function .....	46
1.10 Maximum Value/Minimum Value Hold Function .....	50
1.11 Warning Output Function .....	51
Process alarm .....	51
Rate alarm .....	54
1.12 Input Signal Error Detection Function .....	59
1.13 Using One of the Logging Functions Depending on the Intended Use .....	66
1.14 Normal Logging Function .....	69
Stopping the logging operation .....	76
Logging hold request .....	79
Level trigger .....	80
Initial settings of the normal logging function .....	85
Logging read function .....	88
Saving to a CSV file .....	93
1.15 Continuous Logging Function .....	94
Transfer of continuous logging data .....	98
Continuous logging when the inter-module synchronization function is used .....	106
1.16 Interrupt Function .....	110
1.17 Inter-Module Synchronization Function .....	114
1.18 Error History Function .....	122
1.19 Event History Function .....	125
1.20 Backing up, Saving, and Restoring Offset/Gain Values .....	126
When a module-specific backup parameters is used .....	126
When the module-specific backup parameter is not used .....	129
<b>CHAPTER 2 PARAMETER SETTINGS</b>	<b>133</b>
2.1 Basic Setting .....	133
2.2 Application Setting .....	134

2.3	Interrupt Setting .....	135
2.4	Refresh Setting .....	136
	Refresh processing time .....	137
<b>CHAPTER 3 TROUBLESHOOTING</b>		<b>138</b>
3.1	Troubleshooting with the LEDs .....	138
3.2	Checking the State of the Module .....	139
3.3	Troubleshooting by Symptom .....	141
	When the RUN LED flashes or turns off .....	141
	When the ERR LED turns on .....	141
	When the ALM LED turns on or flashes .....	142
	When a digital output value cannot be read .....	143
	When the digital output value does not fall within the range of accuracy .....	145
	When the synchronization digital output value does not change .....	145
3.4	List of Error Codes .....	146
3.5	List of Alarm Codes .....	152
<b>APPENDICES</b>		<b>153</b>
<b>Appendix 1 Module Label .....</b>		<b>153</b>
<b>Appendix 2 I/O Signals .....</b>		<b>155</b>
	List of I/O signals .....	155
	Details of input signals .....	156
	Details of output signals .....	163
<b>Appendix 3 Buffer Memory Areas .....</b>		<b>166</b>
	List of buffer memory addresses .....	166
	Details of buffer memory addresses .....	176
<b>Appendix 4 Dedicated Instructions .....</b>		<b>230</b>
	Instruction list .....	230
<b>Appendix 5 Operation Examples of When the Remote Head Module Is Mounted .....</b>		<b>232</b>
	System configuration example .....	232
	Setting in the master station .....	233
	Setting in the intelligent device station .....	236
	Checking the network status .....	239
	Program examples .....	239
<b>INDEX</b>		<b>242</b>
<b>REVISIONS .....</b>		<b>244</b>
<b>WARRANTY .....</b>		<b>245</b>
<b>TRADEMARKS .....</b>		<b>246</b>

# RELEVANT MANUALS

Manual name [manual number]	Description	Available form
MELSEC iQ-R High Speed Analog-Digital Converter Module User's Manual (Application) [SH-081581ENG] (this manual)	Functions, parameter settings, I/O signals, buffer memory, and troubleshooting of the high speed analog-digital converter module	Print book e-Manual PDF
MELSEC iQ-R High Speed Analog-Digital Converter Module User's Manual (Startup) [SH-081580ENG]	System configuration, specifications, procedures before operation, wiring, and operation examples of the high speed analog-digital converter module	Print book e-Manual PDF
MELSEC iQ-R Programming Manual (Instructions, Standard Functions/Function Blocks) [SH-081266ENG]	Instructions for the CPU module, dedicated instructions for the intelligent function modules, and standard functions/function blocks	e-Manual PDF



e-Manual refers to the Mitsubishi FA electronic book manuals that can be browsed using a dedicated tool.

e-Manual has the following features:

- Required information can be cross-searched in multiple manuals.
- Other manuals can be accessed from the links in the manual.
- The hardware specifications of each part can be found from the product figures.
- Pages that users often browse can be bookmarked.

# TERMS

Unless otherwise specified, this manual uses the following terms.

Term	Description
A/D converter module	The abbreviation for MELSEC iQ-R series high speed analog-digital converter module
Buffer memory	A memory in an intelligent function module for storing data (such as setting values and monitored values) to be transferred to the CPU module
Engineering tool	Another term for GX Works3
Factory default setting	A generic term for analog input ranges of 0 to 10V, 0 to 5V, 1 to 5V, -10 to 10V, 0 to 20mA, 4 to 20mA, 1 to 5V (extended mode), and 4 to 20mA (extended mode). In the window on the engineering tool, 4 to 20mA (extended mode) and 1 to 5V (extended mode) are displayed as follows: <ul style="list-style-type: none"><li>• 4 to 20mA (Extension)</li><li>• 1 to 5V (Extension)</li></ul>
Global label	A label that is valid for all the program data when multiple program data are created in the project. The global label has two types: a module specific label (module label), which is generated automatically by GX Works3, and an optional label, which can be created for any specified device.
GX Works3	The product name of the software package for the MELSEC programmable controllers
Module label	A label that represents one of memory areas (I/O signals and buffer memory areas) specific to each module in a given character string. For the module used, GX Works3 automatically generates this label, which can be used as a global label.
Normal mode	The mode for normal A/D conversion. Use one of the two types of modes, the normal mode (medium speed: 10 $\mu$ s/CH) and normal mode (low speed: 20 $\mu$ s/CH).
Offset/gain setting mode	The mode for the offset/gain setting
Remote head module	The abbreviation for the RJ72GF15-T2 CC-Link IE Field Network remote head module
User range	An analog input range where any value can be set. This range can be set in the offset/gain setting.
Watchdog timer error	An error that occurs if the internal processing of the A/D converter module is abnormal. Watchdog timer enables the module to monitor its own internal processing.

# MANUAL PAGE ORGANIZATION

In this manual, pages about functions, I/O signals, and buffer memory areas are organized and the symbols are used as shown below.

The following illustration is for explanation purpose only, and should not be referred to as an actual documentation.

**Averaging processing**

**Common**

The averaging processing is performed to the digital output value for each channel. The value after the averaging processing is performed is stored to the buffer memory area.

The following three types of averaging processing are provided.

- Time average
- Count average
- Moving average

**Time average**

**Medium speed** **Low speed**

The A/D conversion is performed for the setting time and the averaging processing is performed to the total value except the maximum and minimum values. The value after the averaging processing is performed is stored to the buffer memory area.

**Setting time**

The setting range of the time (for averaging) is 1 to 5000ms.

**Processing times**

The number of processing times within the setting time changes depending on the number of channels where the A/D conversion is enabled.

- Number of processing times (times) = Setting time/Sampling cycle

**Ex**

The following table shows the processing times with the setting below.

Item	Setting
Operation mode	Normal mode (medium speed: 10μs/CH)
Number of channels where the A/D conversion is enabled	Four channels (CH1 to CH4)
Setting time	8ms

$8(\text{ms})/(4 (\text{CH})) = 200 (\text{times})$   
Conversion is processed 200 times and the mean value is output.

**Count average**

**Medium speed** **Low speed**

The A/D conversion is performed for the set number of times and the averaging processing is performed to the total value except the maximum and minimum values. The value after the averaging processing is performed is stored to the buffer memory area.

The time taken for the mean value calculated through the average processing to be stored in the buffer memory area changes depending on the number of channels where the A/D conversion is enabled.

- Processing time = Set number of times × Sampling cycle

**Ex**

The following table shows the processing time with the setting below.

Item	Setting
Operation mode	Normal mode (medium speed: 10μs/CH)
Number of channels where the A/D conversion is enabled	Four channels (CH1 to CH4)
Set number of times	Five times

$5 (\text{times}) \times (4 (\text{CH})) \times 10 (\mu\text{s}) = 200 (\mu\text{s})$   
A mean value is output every 200μs.

1 FUNCTIONS  
1.5 A/D Conversion Method

24

① The following table lists the operation modes of the A/D converter module in which the corresponding functions and buffer memory areas can be used. Each icon indicates an operation mode as follows.

Icon	Description
<b>Common</b>	The corresponding functions and buffer memory areas can be used in all the operation modes.
<b>Medium speed</b>	The corresponding functions and buffer memory areas can be used in the normal mode (medium speed: 10μs/CH).
<b>Low speed</b>	The corresponding functions and buffer memory areas can be used in the normal mode (low speed: 20μs/CH).
<b>Simultaneous conversion</b>	The corresponding functions and buffer memory areas can be used in the simultaneous conversion mode (5μs/4CH).
<b>Synchronization</b>	The corresponding functions and buffer memory areas can be used in the inter-module synchronization mode.

For details on each mode, refer to the following.

☞ Page 16 Modes

# 1 FUNCTIONS

This chapter describes the functions of the A/D converter module and the setting procedures for those functions. For details on the I/O signals and the buffer memory, refer to the following.

 Page 155 I/O Signals

 Page 166 Buffer Memory Areas

## Point

- This chapter describes I/O signals and buffer memory addresses for CH1. For details on the I/O signals and buffer memory addresses for CH2 and later, refer to the following.

 Page 155 List of I/O signals

 Page 166 List of buffer memory addresses

- Numerical values come in  $\square$  and  $\triangle$  of the error codes and alarm codes described in this chapter.  $\square$  indicates the channel where an error has occurred and  $\triangle$  indicates details of the error. For details on the numerical values, refer to the following.

 Page 146 List of Error Codes

 Page 152 List of Alarm Codes

## 1.1 Modes

The A/D converter module has the normal mode, simultaneous conversion mode, inter-module synchronization mode, and offset/gain setting mode. Change the mode according to the function used.

### Normal mode

The normal A/D conversion is performed in this mode. Use the normal mode (medium speed: 10 $\mu$ s/CH) or the normal mode (low speed: 20 $\mu$ s/CH) for each sampling cycle. In this manual, the description of "normal mode" indicates the normal mode (medium speed: 10 $\mu$ s/CH) and normal mode (low speed: 20 $\mu$ s/CH).

### Simultaneous conversion mode

The A/D conversion is performed simultaneously in all channels. The sampling cycle is fixed to 5 $\mu$ s/4CH.

### Inter-module synchronization mode

The A/D conversion is performed at the inter-module synchronization cycle in this mode.

### Offset/gain setting mode


The mode for the offset/gain setting.

For details on the offset/gain setting, refer to the following.

 MELSEC iQ-R High Speed Analog-Digital Converter Module User's Manual (Startup)

## Mode transition

The following figure and table describe the transition condition for each mode.



No.	Transition condition	
(1)	Set "Normal mode (medium speed: 10μs/CH" for "Operation mode setting" in "Basic setting" of the engineering tool.	
(2)	Set "Normal mode (low speed: 20μs/CH" for "Operation mode setting" in "Basic setting" of the engineering tool.	
(3)	Set "Offset/gain setting mode" for "Operation mode setting" in "Basic setting" of the engineering tool.	
(4)*1	Set "Simultaneous conversion mode (5μs/4CH)" for "Operation mode setting" in "Basic setting" of the engineering tool.	
(5)*2*3	Change the mode with one of the following methods. Method 1      Execute the G(P).OFFGAN (argument "S": 0: Shifting to the normal mode). Method 2      Set the following values for 'Mode switching setting' (Un\G296, Un\G297) and turn on and off 'Operating condition setting request' (Y9). <ul style="list-style-type: none"><li>• Un\G296: 5260H</li><li>• Un\G297: 4144H</li></ul>	
(6)	Change the mode with one of the following methods. Method 1      Execute the G(P).OFFGAN (argument "S": 1: Shifting to the offset/gain setting mode). Method 2      Set the following values for 'Mode switching setting' (Un\G296, Un\G297) and turn on and off 'Operating condition setting request' (Y9). <ul style="list-style-type: none"><li>• Un\G296: 4144H</li><li>• Un\G297: 5260H</li></ul>	
(7)*1*4	Set "Synchronize" for the A/D converter module in the following parameter of the engineering tool. [System Parameter] ⇒ "Synchronization Setting within the Modules" ⇒ "Inter-module Synchronous Setting" ⇒ "Select Synchronous Target Unit between Unit"	

\*1 The simultaneous conversion mode and the inter-module synchronization mode are independent from the other modes. After the module is started in the simultaneous conversion mode or the inter-module synchronization mode, the mode cannot be changed to the other modes. After the module is started in a mode other than the two modes, the mode cannot be switched to the simultaneous conversion mode and inter-module synchronization mode.

\*2 The mode is shifted to the normal mode before the transition to the offset/gain setting mode.

\*3 The offset/gain setting mode is set at the power-on or at the reset of the CPU module and the mode has never been shifted to the normal mode, the mode shifts to the normal mode (low speed: 20μs/CH).

\*4 When "Synchronize" is set for the A/D converter module in "Select Synchronous Target Unit between Unit", the module operates in the inter-module synchronization mode regardless of "Operation mode setting". To operate the module in the normal mode, simultaneous conversion mode, or offset/gain setting mode, set "Do Not Synchronize" for the A/D converter module in "Select Synchronous Target Unit between Unit".

## Checking method

The current mode can be checked with the following items.


Mode		RUN LED status	Value stored in 'Operation mode monitor' (Un\G60)	'Offset/gain setting mode status flag' (XA)
Normal mode	Normal mode (medium speed: 10μs/CH)	On	1	OFF <sup>*1</sup>
	Normal mode (low speed: 20μs/CH)	On	2	OFF <sup>*1</sup>
Simultaneous conversion mode		On	3	OFF
Inter-module synchronization mode		On	4	OFF
Offset/gain setting mode		Flashing (1s cycle)	5	ON

\*1 Status of when 'User range write request' (YA) is off

## 1.2 Processing of Each Function


The functions are processed in the order shown below. If multiple functions are enabled, the output of the first processed function is used as the input of the next function.

- In the normal mode



No.	Processing details
(1)	Input signal error detection function
(2)	The A/D conversion is executed in one of the following A/D conversion methods. <ul style="list-style-type: none"> <li>• Sampling processing</li> <li>• Count average</li> <li>• Time average</li> <li>• Moving average</li> <li>• Primary delay filter</li> <li>• Low pass filter</li> <li>• High pass filter</li> <li>• Band pass filter</li> </ul>
(3)	Digital clipping function
(4)	Scaling function
(5)	Shift function
(6)	Difference conversion function
(7)	Warning output function (rate alarm)
(8)	Warning output function (process alarm)
(9)	Normal logging function
(10)	Maximum value/minimum value hold function

- In the simultaneous conversion mode or inter-module synchronization mode



No.	Processing details
(1)	Input signal error detection function
(2)	The A/D conversion is executed in one of the following A/D conversion methods. <ul style="list-style-type: none"> <li>• Sampling processing</li> <li>• Moving average</li> </ul>
(3)	Warning output function (process alarm)
(4)	Continuous logging function
(5)	Maximum value/minimum value hold function

## Digital output value

These values are the digital values after the sampling processing, each averaging processing, primary delay filter, or digital filter has been performed.

## Digital operation value

These values are obtained by operating a digital output value using the digital clipping function, scaling function, shift function, or difference conversion function. When each function is not used, the same value as the digital output value is stored.

## Maximum and minimum value

The maximum and minimum values of the following digital values are stored for each mode.

- In the normal mode, the maximum and minimum values of the digital operation values are stored.
- In the simultaneous conversion mode or inter-module synchronization mode, the maximum and minimum values of the digital output values are stored.

## Logging data area

When the normal logging function is used, digital output values or digital operation values are collected. When the continuous logging function is used, digital output values are collected.

## 1.3 Range Switching Function

Common

This function switches the input range of an analog input for each channel.

Switching the range makes it possible to change the I/O conversion characteristics.

### Setting procedure

Set the input range to be used in the "Input range setting".

☞ Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Module Parameter] ⇒ "Basic setting" ⇒ "Range switching function"

Input range setting	Digital output value
4 to 20mA	0 to 32000
0 to 20mA	
1 to 5V	
0 to 5V	
-10 to 10V	-32000 to 32000
0 to 10V	0 to 32000
4 to 20mA (Extension)	-8000 to 32000
1 to 5V (Extension)	
User range	-32000 to 32000

After the data is written, the range is switched when the programmable controller power supply is turned off and on or when the CPU module is reset.



With the following buffer memory areas, the range switching and range setting can be monitored.

'CH1 Range setting' (Un\G598)

'CH1 Range setting monitor' (Un\G430)

For details on the buffer memory addresses, refer to the following.

☞ Page 221 CH1 Range setting

☞ Page 190 CH1 Range setting monitor

## 1.4 A/D Conversion Enable/Disable Setting Function

Common

This function controls whether to enable or disable the A/D conversion for each channel.

### Setting procedure

Set "A/D conversion enable/disable setting" to "A/D conversion enable" or "A/D conversion disable".

☞ Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Module Parameter] ⇒ "Basic setting" ⇒ "A/D conversion enable/disable setting function"

# 1.5 A/D Conversion Method

## Common

An A/D conversion method can be set for each channel. The following lists available conversion methods.

- Sampling processing
- Averaging processing (time average, count average, moving average)
- Primary delay filter
- Digital filter (low pass filter, high pass filter, band pass filter)

## Overview of A/D conversion

The A/D conversion can be executed as follows depending on the mode.

- In the normal mode, the A/D conversion is executed per channel. For example, when the A/D conversion is enabled for CH1, CH2, and CH3, the A/D conversion of CH2 is executed after the A/D conversion of CH1 is completed. The A/D conversion of CH3 is executed after the A/D conversion of CH2 is completed.
- In the simultaneous conversion mode or inter-module synchronization mode, the A/D conversion is executed simultaneously in all channels.

## ■Sampling cycle

Sampling cycle is the internal A/D conversion cycle. In the normal mode, this cycle varies depending on the setting of the number of conversion enabled channels. (  Page 21 A/D Conversion Enable/Disable Setting Function)

The following table lists the sampling cycles for the modes.

Mode	Sampling cycle	
Normal mode	Normal mode (medium speed: 10 $\mu$ s/CH)	10 $\mu$ s × Number of A/D conversion enabled channels
	Normal mode (low speed: 20 $\mu$ s/CH)	20 $\mu$ s × Number of A/D conversion enabled channels
Simultaneous conversion mode		5 $\mu$ s
Inter-module synchronization mode	Oversampling disable	Inter-module synchronization cycle
	Oversampling enable	5 $\mu$ s

## ■Conversion cycle

Digital output values are updated on the conversion cycle of sampling processing, averaging processing, primary delay filter, or digital filter. The following table lists the conversion cycles in each A/D conversion method.

A/D conversion method	Conversion cycle
Sampling processing	Sampling cycle
Time average <sup>*2</sup>	((The time set for Time average/Count average/Moving average/Primary delay filter constant setting) ÷ Sampling cycle) <sup>*1</sup> × Sampling cycle
Count average <sup>*2</sup>	(The count set for Time average/Count average/Moving average/Primary delay filter constant setting) × Sampling cycle
Moving average	Sampling cycle
Primary delay filter <sup>*2</sup>	Sampling cycle
Low pass filter <sup>*2</sup>	Sampling cycle
High pass filter <sup>*2</sup>	Sampling cycle
Band pass filter <sup>*2</sup>	Sampling cycle

\*1 Values after the decimal point are omitted.

\*2 This method cannot be used in the simultaneous conversion mode and inter-module synchronization mode.

# Sampling processing

Common

Analog input values are converted at each sampling cycle and stored in the buffer memory as digital output values. The conversion cycle varies depending on the mode.


## In the normal mode

The conversion cycle in the normal mode is the sampling cycle.

Whether to enable or disable the A/D conversion can be set for each channel. Disabling the A/D conversion for unused channels reduces the A/D conversion cycles.

**Ex.**

When the A/D conversion is enabled for CH1 and CH2 in the normal mode (medium speed: 10μs/CH), the conversion cycle is 20μs (10μs × 2). In this case, digital output values and digital operation values of CH1 and CH2 are updated every 10μs.




## In the simultaneous conversion mode

In the simultaneous conversion mode, the conversion cycle is fixed to 5μs regardless of the number of conversion enabled channels. The A/D conversion is performed simultaneously in all channels.

**Ex.**

When the A/D conversion is enabled for CH1 and CH2 in the simultaneous conversion mode, digital output values of CH1 and CH2 are updated every 5μs.



## Setting procedure

Set "Average processing setting" to "Sampling processing".

☞ Navigation window  $\Rightarrow$  [Parameter]  $\Rightarrow$  [Module Information]  $\Rightarrow$  Module model name  $\Rightarrow$  [Module Parameter]  $\Rightarrow$  "Basic setting"  $\Rightarrow$  "A/D conversion method"

# Averaging processing

Common

The A/D converter module performs the averaging processing on digital output values for each channel. The averaged values are stored in the buffer memory.

The following three types of averaging processing are provided.

- Time average
- Count average
- Moving average

## Time average

Medium speed

Low speed

The A/D conversion is performed for the setting time and the averaging processing is performed on the total value excluding the maximum and the minimum values. The averaged values are stored in the buffer memory.

### ■Setting time

The setting range of the time (for averaging) is 1 to 5000ms.

### ■Number of processing times

The number of processing times within the setting time changes depending on the number of channels where the A/D conversion is enabled.

- Number of processing times (times) = Setting time/Sampling cycle

Ex.

The following shows the number of processing times with the setting below.

Item	Setting
Operation mode	Normal mode (medium speed: 10μs/CH)
Number of channels where the A/D conversion is enabled	Four channels (CH1 to CH4)
Setting time	8ms

$$8 \text{ (ms)} / (4 \text{ (CH)} \times 0.01 \text{ (ms)}) = 200 \text{ (times)}$$

Conversion is processed 200 times and the mean value is output.

## Count average

Medium speed

Low speed

The A/D conversion is performed for the set number of times and the averaging processing is performed on the total value excluding the maximum and the minimum values. The averaged values are stored in the buffer memory.

The time taken for the mean value calculated through the average processing to be stored in the buffer memory changes depending on the number of channels where the A/D conversion is enabled.

- Processing time = Set number of times × Sampling cycle

### Ex.

The following shows the processing time with the setting below.

Item	Setting
Operation mode	Normal mode (medium speed: 10μs/CH)
Number of channels where the A/D conversion is enabled	Four channels (CH1 to CH4)
Set number of times	Five times

$$5 \text{ (times)} \times (4 \text{ (CH)}) \times 10 \text{ (μs)} = 200 \text{ (μs)}$$

A mean value is output every 200μs.

### Point


Because the count average requires a sum of at least two converted values excluding the maximum and the minimum values, set four or more times as the set number of times.

## Moving average

Common

The A/D converter module averages digital output values taken at every sampling cycle for a specified number of times, and stores a mean value in the buffer memory. Since the averaging processing is performed on a moving set of sampling, the latest digital output values can be obtained.

The following figure shows the moving average processing of when the set number of times is five.



digit: Digital output value

t: Time (μs)

## Setting procedure

1. Set "Average processing setting" to "Time average", "Count average", or "Moving average".
2. Navigation window  $\Rightarrow$  [Parameter]  $\Rightarrow$  [Module Information]  $\Rightarrow$  Module model name  $\Rightarrow$  [Module Parameter]  $\Rightarrow$  "Basic setting"  $\Rightarrow$  "A/D conversion method"
2. Set a value for "Time average/Count average/Moving average/Primary delay filter constant setting". The setting range varies depending on the "A/D conversion method".

A/D conversion method	Setting range
Time average	1 to 5000 (ms)
Count average	4 to 62500 (times)
Moving average	2 to 1000 (times)

### Point

In the simultaneous conversion mode or inter-module synchronization mode, set values so that the settings of "Average processing setting" and "Time average/Count average/Moving average/Primary delay filter constant setting" are the same in all channels where the A/D conversion is enabled. When the settings of the channels are different from one another, an across channels average setting error (error code: 19A0H) occurs and the A/D conversion stops in all channels.

To specify different averaging processing settings for each channel, use the normal mode.

# Primary delay filter

Medium speed

Low speed

The A/D converter module smooths transient noise of an analog input according to the set time constant. The smoothed digital output value is stored in the buffer memory.

Time constant is the time taken for the digital output value to reach 63.2% of the steady-state value. The degree of smoothing changes depending on the setting of a time constant. The following shows the calculation formula of a time constant.

- Time constant = (Conversion cycle) × (Value set in 'CH1 Time average/Count average/Moving average/Primary delay filter constant setting' (Un\G502))

The following table shows the relational expressions of a time constant, digital output values, and current number of sampling (n).

Current number of sampling	Relational expression	Element
n = 1	$Y_n = 0$	$Y_n$ : Current digital output value $Y_{n-1}$ : Last digital output value n: Number of sampling $X_n$ : Digital output value before smoothing $X_{n-1}$ : Last digital output value before smoothing $\Delta t$ : Sampling cycle TA: Time constant
n = 2	$Y_n = X_{n-1} + \frac{\Delta t}{\Delta t + TA} (X_n - X_{n-1})$	
$n \geq 3$	$Y_n = Y_{n-1} + \frac{\Delta t}{\Delta t + TA} (X_n - Y_{n-1})$	


'A/D conversion completed flag' (XE) turns on when  $n \geq 2$ .

**Ex.**

The following shows the digital output value of when an analog input value is changed from 0 to 1V.

Item	Setting
Operation mode	Normal mode (low speed: 20 $\mu$ s/CH)
Number of channels where the A/D conversion is enabled	Two channels
Primary delay filter constant setting	100

After 4ms from when the analog input value is changed to 1V, the digital output value reaches 63.2% of the digital output value of when the sampling processing is selected.



V: Analog input value (V)

t: Elapsed time (ms)

digit: Digital output value

— : Change of the analog input value

— : Change of the digital output value

## Setting procedure

1. Set "Average processing setting" to "Primary delay filter".

 Navigation window  $\Rightarrow$  [Parameter]  $\Rightarrow$  [Module Information]  $\Rightarrow$  Module model name  $\Rightarrow$  [Module Parameter]  $\Rightarrow$  "Basic setting"  $\Rightarrow$  "A/D conversion method"

2. Set a value for "Time average/Count average/Moving average/Primary delay filter constant setting".

A/D conversion method	Setting range
Primary delay filter	1 to 500 (times)


# Digital filter

Medium speed

Low speed

When data is obtained from a sensor connected with the A/D converter module, an analog input value may be output with unnecessary noise from the sensor. This function eliminates noise by attenuating unnecessary frequency data to obtain only digital values with target frequency data.




Select the low pass filter, high pass filter, or band pass filter depending on the sensor connected. When the high pass filter or band pass filter is used, direct signals are eliminated.



- (1) Direct current
- (2) Low frequency
- (3) Medium frequency
- (4) High frequency
- (5) Wave including direct current, low frequency, medium frequency, and high frequency
- (6) After filtering with the low pass filter
- (7) After filtering with the band pass filter
- (8) After filtering with the high pass filter

## Characteristics and advantages of the digital filters

The following table lists the characteristics and advantages of the digital filters.

Filter type	Characteristic	Advantage
Low pass filter (low frequency pass filter)		<ul style="list-style-type: none"> <li>Analog input values are processed every conversion cycle.</li> <li>This filter attenuates frequency signals between a pass band edge frequency and the pass band edge frequency + an attenuation band width to cut off frequency signals higher than the attenuation band.</li> <li>The target frequency of the filtering should be the same as, or lower than 1/2 of the sampling frequency*1.</li> </ul>
High pass filter (high frequency pass filter)		<ul style="list-style-type: none"> <li>Analog input values are processed every conversion cycle.</li> <li>This filter attenuates frequency signals between a pass band edge frequency and the pass band edge frequency - an attenuation band width, cutting off frequency signals lower than the attenuation band.</li> <li>The target frequency of the filtering should be the same as, or lower than 1/2 of the sampling frequency*1.</li> </ul>
Band pass filter (band frequency pass filter)		<ul style="list-style-type: none"> <li>Analog input values are processed every conversion cycle.</li> <li>Both the low pass filter and high pass filter are set simultaneously. As a result, only frequency within a specified bandwidth passes this filter.</li> <li>The target frequency of the filtering should be the same as, or lower than 1/2 of the sampling frequency*1.</li> </ul>

G: Attenuation rate (dB)

f: Frequency (Hz)

: Pass band\*2

: Attenuation band\*3

: Stopband\*4

(1) Attenuation band width

(2) Pass band edge frequency

(3) Pass band edge frequency + Attenuation band width

(4) Pass band edge frequency - Attenuation band width

(5) Pass band edge frequency (Low) - Attenuation band width

(6) Pass band edge frequency (Low)

(7) Pass band edge frequency (High)

(8) Pass band edge frequency (High) + Attenuation band width

\*1 Indicates the reciprocal number of the conversion cycle (1/conversion cycle).

\*2 Indicates the frequency band where noise passes through the filter without being attenuated.

\*3 Indicates the frequency band whose attenuation rate of the filter is in a transition state.

\*4 Indicates the frequency band where noise is attenuated by the filter.

## How to use the digital filters

To use the digital filters, configure the setting as shown below.

Filter type	Item	Setting and setting range	
Low pass filter	'CH1 Averaging process specification' (Un\G501)	Set Low pass filter (5).	
	'CH1 LPF Pass band edge frequency' (Un\G560)	Set a pass band edge frequency for the low pass filter. The setting range varies depending on the conversion cycle. The following shows the setting range of the frequency.	
		Conversion cycle	Setting range
		10 $\mu$ s	Pass band edge frequency + Attenuation band width $\leq$ 48000 Attenuation band width $\geq$ 1300 Pass band edge frequency $\geq$ 0
		20 $\mu$ s	Pass band edge frequency + Attenuation band width $\leq$ 24000 Attenuation band width $\geq$ 650 Pass band edge frequency $\geq$ 0
		30 $\mu$ s	Pass band edge frequency + Attenuation band width $\leq$ 16000 Attenuation band width $\geq$ 440 Pass band edge frequency $\geq$ 0
		40 $\mu$ s	Pass band edge frequency + Attenuation band width $\leq$ 12000 Attenuation band width $\geq$ 330 Pass band edge frequency $\geq$ 0
		60 $\mu$ s	Pass band edge frequency + Attenuation band width $\leq$ 8000 Attenuation band width $\geq$ 220 Pass band edge frequency $\geq$ 0
		80 $\mu$ s	Pass band edge frequency + Attenuation band width $\leq$ 6000 Attenuation band width $\geq$ 170 Pass band edge frequency $\geq$ 0
	'CH1 Attenuation band width' (Un\G568)	Set an attenuation band width for each channel. Set an attenuation band width so that the sum of an LPF pass band edge frequency and the attenuation band width becomes the boundary between the attenuation band and a stopband. Frequencies higher than the sum of the LPF pass band edge frequency and the attenuation band width are cut off. For the setting range, refer to 'CH1 LPF Pass band edge frequency' (Un\G560).	

Filter type	Item	Setting and setting range															
High pass filter	'CH1 Averaging process specification' (Un\G501)	Set High pass filter (6).															
	'CH1 HPF Pass band edge frequency' (Un\G562)	<p>Set a pass band edge frequency for the high pass filter. The setting range varies depending on the conversion cycle. The following shows the setting range of the frequency.</p> <table border="1"> <thead> <tr> <th>Conversion cycle</th> <th>Setting range</th> </tr> </thead> <tbody> <tr> <td>10μs</td> <td>Pass band edge frequency - Attenuation band width &gt; 0 Attenuation band width ≥ 1300 Pass band edge frequency ≤ 48000</td> </tr> <tr> <td>20μs</td> <td>Pass band edge frequency - Attenuation band width &gt; 0 Attenuation band width ≥ 650 Pass band edge frequency ≤ 24000</td> </tr> <tr> <td>30μs</td> <td>Pass band edge frequency - Attenuation band width &gt; 0 Attenuation band width ≥ 440 Pass band edge frequency ≤ 16000</td> </tr> <tr> <td>40μs</td> <td>Pass band edge frequency - Attenuation band width &gt; 0 Attenuation band width ≥ 330 Pass band edge frequency ≤ 12000</td> </tr> <tr> <td>60μs</td> <td>Pass band edge frequency - Attenuation band width &gt; 0 Attenuation band width ≥ 220 Pass band edge frequency ≤ 8000</td> </tr> <tr> <td>80μs</td> <td>Pass band edge frequency - Attenuation band width &gt; 0 Attenuation band width ≥ 170 Pass band edge frequency ≤ 6000</td> </tr> </tbody> </table>		Conversion cycle	Setting range	10μs	Pass band edge frequency - Attenuation band width > 0 Attenuation band width ≥ 1300 Pass band edge frequency ≤ 48000	20μs	Pass band edge frequency - Attenuation band width > 0 Attenuation band width ≥ 650 Pass band edge frequency ≤ 24000	30μs	Pass band edge frequency - Attenuation band width > 0 Attenuation band width ≥ 440 Pass band edge frequency ≤ 16000	40μs	Pass band edge frequency - Attenuation band width > 0 Attenuation band width ≥ 330 Pass band edge frequency ≤ 12000	60μs	Pass band edge frequency - Attenuation band width > 0 Attenuation band width ≥ 220 Pass band edge frequency ≤ 8000	80μs	Pass band edge frequency - Attenuation band width > 0 Attenuation band width ≥ 170 Pass band edge frequency ≤ 6000
Conversion cycle	Setting range																
10μs	Pass band edge frequency - Attenuation band width > 0 Attenuation band width ≥ 1300 Pass band edge frequency ≤ 48000																
20μs	Pass band edge frequency - Attenuation band width > 0 Attenuation band width ≥ 650 Pass band edge frequency ≤ 24000																
30μs	Pass band edge frequency - Attenuation band width > 0 Attenuation band width ≥ 440 Pass band edge frequency ≤ 16000																
40μs	Pass band edge frequency - Attenuation band width > 0 Attenuation band width ≥ 330 Pass band edge frequency ≤ 12000																
60μs	Pass band edge frequency - Attenuation band width > 0 Attenuation band width ≥ 220 Pass band edge frequency ≤ 8000																
80μs	Pass band edge frequency - Attenuation band width > 0 Attenuation band width ≥ 170 Pass band edge frequency ≤ 6000																
	'CH1 Attenuation band width' (Un\G568)	<p>Set an attenuation band width for each channel. Set an attenuation band width so that the difference between an HPF pass band edge frequency and the attenuation band width becomes the boundary between the attenuation band and a stopband. Frequencies lower than the difference between the HPF pass band edge frequency and attenuation band width are cut off. For the setting range, refer to 'CH1 HPF Pass band edge frequency' (Un\G562).</p>															

Filter type	Item	Setting and setting range														
Band pass filter	'CH1 Averaging process specification' (Un\G501)	Set Band pass filter (7).														
	'CH1 BPF Pass band edge frequency (Low)' (Un\G564) 'CH1 BPF Pass band edge frequency (High)' (Un\G566)	<p>Set a pass band edge frequency for the band pass filter. Set the frequency that becomes the boundary between the lower pass band and an attenuation band and the one that becomes the boundary between the higher pass band and an attenuation band.</p> <p>The setting range varies depending on the conversion cycle. The following shows the setting range of the frequency.</p> <table border="1"> <thead> <tr> <th>Conversion cycle</th> <th>Setting range</th> </tr> </thead> <tbody> <tr> <td>10μs</td> <td>           Pass band edge frequency (High) + Attenuation band width <math>\leq</math> 48000            Pass band edge frequency (Low) - Attenuation band width <math>&gt;</math> 0            Attenuation band width <math>\geq</math> 1300            Pass band edge frequency (Low) <math>&lt;</math> Pass band edge frequency (High)         </td> </tr> <tr> <td>20μs</td> <td>           Pass band edge frequency (High) + Attenuation band width <math>\leq</math> 24000            Pass band edge frequency (Low) - Attenuation band width <math>&gt;</math> 0            Attenuation band width <math>\geq</math> 650            Pass band edge frequency (Low) <math>&lt;</math> Pass band edge frequency (High)         </td> </tr> <tr> <td>30μs</td> <td>           Pass band edge frequency (High) + Attenuation band width <math>\leq</math> 16000            Pass band edge frequency (Low) - Attenuation band width <math>&gt;</math> 0            Attenuation band width <math>\geq</math> 440            Pass band edge frequency (Low) <math>&lt;</math> Pass band edge frequency (High)         </td> </tr> <tr> <td>40μs</td> <td>           Pass band edge frequency (High) + Attenuation band width <math>\leq</math> 12000            Pass band edge frequency (Low) - Attenuation band width <math>&gt;</math> 0            Attenuation band width <math>\geq</math> 330            Pass band edge frequency (Low) <math>&lt;</math> Pass band edge frequency (High)         </td> </tr> <tr> <td>60μs</td> <td>           Pass band edge frequency (High) + Attenuation band width <math>\leq</math> 8000            Pass band edge frequency (Low) - Attenuation band width <math>&gt;</math> 0            Attenuation band width <math>\geq</math> 220            Pass band edge frequency (Low) <math>&lt;</math> Pass band edge frequency (High)         </td> </tr> <tr> <td>80μs</td> <td>           Pass band edge frequency (High) + Attenuation band width <math>\leq</math> 6000            Pass band edge frequency (Low) - Attenuation band width <math>&gt;</math> 0            Attenuation band width <math>\geq</math> 170            Pass band edge frequency (Low) <math>&lt;</math> Pass band edge frequency (High)         </td> </tr> </tbody> </table>	Conversion cycle	Setting range	10μs	Pass band edge frequency (High) + Attenuation band width $\leq$ 48000 Pass band edge frequency (Low) - Attenuation band width $>$ 0 Attenuation band width $\geq$ 1300 Pass band edge frequency (Low) $<$ Pass band edge frequency (High)	20μs	Pass band edge frequency (High) + Attenuation band width $\leq$ 24000 Pass band edge frequency (Low) - Attenuation band width $>$ 0 Attenuation band width $\geq$ 650 Pass band edge frequency (Low) $<$ Pass band edge frequency (High)	30μs	Pass band edge frequency (High) + Attenuation band width $\leq$ 16000 Pass band edge frequency (Low) - Attenuation band width $>$ 0 Attenuation band width $\geq$ 440 Pass band edge frequency (Low) $<$ Pass band edge frequency (High)	40μs	Pass band edge frequency (High) + Attenuation band width $\leq$ 12000 Pass band edge frequency (Low) - Attenuation band width $>$ 0 Attenuation band width $\geq$ 330 Pass band edge frequency (Low) $<$ Pass band edge frequency (High)	60μs	Pass band edge frequency (High) + Attenuation band width $\leq$ 8000 Pass band edge frequency (Low) - Attenuation band width $>$ 0 Attenuation band width $\geq$ 220 Pass band edge frequency (Low) $<$ Pass band edge frequency (High)	80μs	Pass band edge frequency (High) + Attenuation band width $\leq$ 6000 Pass band edge frequency (Low) - Attenuation band width $>$ 0 Attenuation band width $\geq$ 170 Pass band edge frequency (Low) $<$ Pass band edge frequency (High)
Conversion cycle	Setting range															
10μs	Pass band edge frequency (High) + Attenuation band width $\leq$ 48000 Pass band edge frequency (Low) - Attenuation band width $>$ 0 Attenuation band width $\geq$ 1300 Pass band edge frequency (Low) $<$ Pass band edge frequency (High)															
20μs	Pass band edge frequency (High) + Attenuation band width $\leq$ 24000 Pass band edge frequency (Low) - Attenuation band width $>$ 0 Attenuation band width $\geq$ 650 Pass band edge frequency (Low) $<$ Pass band edge frequency (High)															
30μs	Pass band edge frequency (High) + Attenuation band width $\leq$ 16000 Pass band edge frequency (Low) - Attenuation band width $>$ 0 Attenuation band width $\geq$ 440 Pass band edge frequency (Low) $<$ Pass band edge frequency (High)															
40μs	Pass band edge frequency (High) + Attenuation band width $\leq$ 12000 Pass band edge frequency (Low) - Attenuation band width $>$ 0 Attenuation band width $\geq$ 330 Pass band edge frequency (Low) $<$ Pass band edge frequency (High)															
60μs	Pass band edge frequency (High) + Attenuation band width $\leq$ 8000 Pass band edge frequency (Low) - Attenuation band width $>$ 0 Attenuation band width $\geq$ 220 Pass band edge frequency (Low) $<$ Pass band edge frequency (High)															
80μs	Pass band edge frequency (High) + Attenuation band width $\leq$ 6000 Pass band edge frequency (Low) - Attenuation band width $>$ 0 Attenuation band width $\geq$ 170 Pass band edge frequency (Low) $<$ Pass band edge frequency (High)															
	'CH1 Attenuation band width' (Un\G568)	<p>Set an attenuation band width for each channel. This setting is common to both lower and higher sides.</p> <ul style="list-style-type: none"> <li>The difference between the BPF pass band edge frequency (Low) and the attenuation band width is the boundary between the lower attenuation band and the stopband. Frequencies lower than the difference between the BPF pass band edge frequency (Low) and the attenuation band width are cut off.</li> <li>The sum of the BPF pass band edge frequency (High) and attenuation band width is the boundary between the higher attenuation band and the stopband. Frequencies higher than the sum of the BPF pass band edge frequency (High) and the attenuation band width are cut off.</li> </ul>														

## Attenuation characteristic and response time

The A/D converter module uses FIR filters as the digital filters. An FIR filter has linear phase response, provides system stability, and displays a steep attenuation characteristic, but takes time to respond.


## ■ Attenuation characteristic

For the digital filters of the A/D converter module, the frequency boundary (pass band edge frequency) between a pass band and an attenuation band is set. In addition, the frequency boundary (pass band edge frequency + attenuation band width) between the attenuation band and a stopband is set as well.

An attenuation characteristic is composed of the attenuation band and the attenuation rate (-53(dB)) shown with the pass band edge frequency and the pass band edge frequency + the attenuation band width.

**Ex.**

The following figure shows the attenuation characteristic (attenuation band and attenuation rate) of when the low pass filter is used.



G: Attenuation rate (dB)

f: Frequency (Hz)

: Pass band

: Attenuation

: Stopband


### (1) Attenuation band width

## ■Response time

Response time is the time taken to obtain an attenuation characteristic (-53(dB)) after filter processing is started. The following figure shows the response time.

**Ex.**

The output waveform obtained after an input SIN wave passed through a digital filter.



A: Amplitude

t: Time (ms)

(1) Input waveform

(2) Waveform after the digital filtering

(3) Start of the filter processing

(4) Timing to obtain an attenuation characteristic

(5) Response time (Conversion cycle × Filter degree<sup>\*1</sup>)

\*1 The filter degree is calculated with the following formula.

$$= 3.3 \times \text{Sampling frequency} \div \text{Attenuation band width}$$

$$= 3.3 \times (1000000 \div \text{Sampling cycle}) \div \text{Attenuation band width} \text{ (Value after the decimal point is rounded up.)}$$

When the calculation result of the formula above is an even value, add 1 to the value so that it becomes an odd value.


## Setting example

The following shows the setting example of a digital filter.

### ■Example 1

The following describes an example under the following conditions with a low pass filter.

- Operation mode: Normal mode (medium speed: 10μs/CH)
- Channels to be used: CH1
- Conversion cycle: 10μs (Sampling frequency: 100kHz)
- 'CH1 LPF Pass band edge frequency' (Un\G560): 1400 (Hz)
- 'CH1 Attenuation band width' (Un\G568): 1300 (Hz)
- The frequency of analog inputs is changed from 1000Hz to 4000Hz, and 4000Hz to 10000Hz to input a SIN wave.



digit: Digital output value

t: Time (ms)

(1) Input waveform

(2) Waveform after the digital filtering

(3) Frequency that passes through

(4) Frequency to be attenuated

(5) Response time (Conversion cycle (10μs) × Filter degree (255)<sup>\*1</sup> = 2.55ms)

\*1 The filter degree is calculated with the following formula.

$$= 3.3 \times (1000000 \div 10) \div 1300$$

$$= 253.846\dots$$

= 254 (Value after the decimal point is rounded up.)

Because the calculation result is an even value, add 1 so that the value becomes an odd value.

$$= 254 + 1$$

$$= 255$$

# 1.6 Scaling Function

Medium speed

Low speed

This function performs the scale conversion on digital output values. The values are converted within a specified range between a scaling upper limit value and scaling lower limit value. This function reduces the time and effort to create a program of the scale conversion.

The converted values are stored in 'CH1 Digital operation value' (Un\G402).

## Concept of scaling setting

Ex.

When the input range is set to -10 to 10V:

For the scaling lower limit value, set a value corresponding to the lower limit value of the input range (-32000).

For the scaling upper limit value, set a value corresponding to the upper limit value of the input range (32000).

## Calculating the scaling value

The scale conversion is based on the following formula. (In the scale conversion, values are rounded to the nearest whole number.)

- Current: 0 to 20mA, 4 to 20mA, 4 to 20mA (extended mode)<sup>\*1</sup>, user range setting (current)
- Voltage: 0 to 10V, 0 to 5V, 1 to 5V, 1 to 5V (extended mode)<sup>\*1</sup>, user range setting (voltage)

$$D_Y = \frac{D_X \times (S_H - S_L)}{D_{Max}} + S_L$$

- Voltage: -10 to 10V

$$D_Y = \frac{D_X \times (S_H - S_L)}{D_{Max} - D_{Min}} + \frac{(S_H + S_L)}{2}$$

$D_X$  : Digital output value

$D_Y$  : Scaling value (Digital operation value)

$D_{Max}$  : Maximum digital output value of the input range in use

$D_{Min}$  : Minimum digital output value of the input range in use

$S_H$  : Scaling upper limit value

$S_L$  : Scaling lower limit value

\*1 Although the range of the digital output value in the extended mode is -8000 to 32000, this function performs the scale conversion on digital output values within the range of 0 to 32000.

## Setting procedure

1. Set "Scaling enable/disable setting" to "Enable".

 Navigation window  $\Rightarrow$  [Parameter]  $\Rightarrow$  [Module Information]  $\Rightarrow$  Module model name  $\Rightarrow$  [Module Parameter]  $\Rightarrow$  "Application setting"  $\Rightarrow$  "Scaling function"

2. Set values for "Scaling upper limit value" and "Scaling lower limit value".

Item	Setting range
Scaling upper limit value	-32000 to 32000
Scaling lower limit value	




- Even when the scaling upper limit value and the scaling lower limit value are set so that the change is greater than the resolution, the resolution will not increase.
- If the relation between the values is scaling lower limit value > scaling upper limit value, the scale conversion can be performed according to a negative slope.
- Set the scaling with the condition "Scaling upper limit value  $\neq$  Scaling lower limit value".

## Setting example

Ex.

When 20000 is set for the scaling upper limit value and 4000 is set for the scaling lower limit value for the module with the input range of 0 to 5V



V: Analog input voltage (V)


S<sub>H</sub>: Scaling upper limit value: 20000

S<sub>L</sub>: Scaling lower limit value: 4000

Voltage input (V)	Digital output value	Scaling value (Digital operation value)
0	0	4000
1	6400	7200
2	12800	10400
3	19200	13600
4	25600	16800
5	32000	20000

Ex.

When 20000 is set for the scaling upper limit value and 4000 is set for the scaling lower limit value for the module with the input range of -10 to 10V



V: Analog input voltage (V)


S<sub>H</sub>: Scaling upper limit value: 20000

S<sub>L</sub>: Scaling lower limit value: 4000

Voltage input (V)	Digital output value	Scaling value (Digital operation value)
-10	-32000	4000
-5	-16000	8000
0	0	12000
5	16000	16000
10	32000	20000

**Ex.**

When 20000 is set for the scaling upper limit value and 4000 is set for the scaling lower limit value for the module with the input range of 1 to 5V (extended mode)



V: Analog input voltage (V)

$S_H$ : Scaling upper limit value: 20000

$S_L$ : Scaling lower limit value: 4000

Voltage input (V)	Digital output value	Scaling value (Digital operation value)
0	-8000	0
1	0	4000
2	8000	8000
3	16000	12000
4	24000	16000
5	32000	20000
5.096	32767	20384



When the scaling function is used with the digital clipping function, the scale conversion is performed on the digital operation values after digital clipping.

# 1.7 Shift Function

Medium speed

Low speed

This function adds (shifts) a set conversion value shift amount to a digital output value and stores the result in the buffer memory. The change in the conversion value shift amount is reflected on the digital operation value on a real-time basis. Therefore, fine adjustment can be easily performed when the system starts.

## Operation

A set conversion value shift amount is added to the digital operation value. The digital operation value with shift addition is stored in 'CH1 Digital operation value' (Un\G402). The conversion value shift amount is added in every sampling cycle when sampling processing is performed, or the conversion value shift amount is added in every averaging process cycle when averaging processing is performed. The value after the addition is stored in 'CH1 Digital operation value' (Un\G402). If the conversion value shift amount is set, the value is added regardless of turning on and off of 'Operating condition setting request' (Y9).

## Setting procedure

Set a value for "Conversion value shift amount".


🔗 Navigation window  $\Rightarrow$  [Parameter]  $\Rightarrow$  [Module Information]  $\Rightarrow$  Module model name  $\Rightarrow$  [Module Parameter]  $\Rightarrow$  "Application setting"  $\Rightarrow$  "Shift function"

Item	Setting range
Conversion value shift amount	-32768 to 32767

## Setting example

### Ex.


When the I/O conversion characteristics are adjusted in a channel where the input range of 0 to 5V is set by the shift function



Voltage input (V)	Digital output value	Digital operation value
0	-10	0
5	31990	32000

Ex.

When the I/O conversion characteristics are adjusted in a channel where the input range of -10 to 10V is set by the shift function




Voltage input (V)	Digital output value	Digital operation value
-10	-32000	-12000
-5	-16000	4000
0	0	20000
5	16000	32767 <sup>*1</sup>
10	32000	32767 <sup>*1</sup>

\*1 Because the value exceeds the range of -32768 to 32767, the value is fixed to 32767 (the upper limit value).

## Ex.

When the following values are set for the A/D converter module with the input range of 0 to 5V

- 'CH1 Scaling enable/disable setting' (Un\G504): Enable (0)
- 'CH1 Scaling upper limit value' (Un\G506): 12000
- 'CH1 Scaling lower limit value' (Un\G508): 2000
- 'CH1 Conversion value shift amount' (Un\G472): 2000



- (1) 'CH1 Digital output value' (Un\G400)  
Scaling  
0 to 32000  
↓  
2000 to 12000
- (2) Value after scaling  
'CH1 Conversion value shift amount' (Un\G472) "+2000"  
↓
- (3) 'CH1 Digital operation value' (Un\G402)

Voltage input (V)	Digital output value	Value after scaling	Digital operation value
0	0	2000	4000
1	6400	4000	6000
2	12800	6000	8000
3	19200	8000	10000
4	25600	10000	12000
5	32000	12000	14000

## Point

When the shift function is used with the digital clipping function and scaling function, shift-and-add is performed on the value obtained after digital clipping and scale conversion. Therefore, the range of the digital operation value is determined as -32768 to 32767.

For a setting example of when the digital clipping function, scaling function, and shift function are used together, refer to the following.

☞ Page 45 Setting example

# 1.8 Digital Clipping Function

Medium speed

Low speed

This function fixes the digital operation value with the maximum digital output value and the minimum digital output value when the corresponding current or voltage exceeds the input range.

## List of output ranges

The following table lists the output ranges of the digital operation values when the digital clipping function is enabled for each range.

Input range	Output range of digital operation values	
	Digital clipping function is enabled	Digital clipping function is disabled
4 to 20mA	0 to 32000	-768 to 32767
0 to 20mA		
1 to 5V		
0 to 5V		
0 to 10V		
-10 to 10V	-32000 to 32000	-32768 to 32767
User range setting		
4 to 20mA (extended mode)	-8000 to 32000	-8768 to 32767
1 to 5V (extended mode)		

## Setting procedure

Set "Digital clipping enable/disable setting" to "Enable".


 Navigation window  $\Rightarrow$  [Parameter]  $\Rightarrow$  [Module Information]  $\Rightarrow$  Module model name  $\Rightarrow$  [Module Parameter]  $\Rightarrow$  "Application setting"  $\Rightarrow$  "Digital clipping function"

## Setting example

### Ex.

When the following values are set for the A/D converter module with the input range of 0 to 5V

- 'CH1 Scaling enable/disable setting' (Un\G504): Enable (0)
- 'CH1 Scaling upper limit value' (Un\G506): 12000
- 'CH1 Scaling lower limit value' (Un\G508): 2000
- 'CH1 Conversion value shift amount' (Un\G472): 2000
- 'CH1 Digital clipping enable/disable setting' (Un\G510): Enable (0)



Input voltage (V)	Digital output value	Digital operation value
-0.12	-768	4000
0	0	4000
1	6400	6000
2	12800	8000
3	19200	10000
4	25600	12000
5	32000	14000
5.096	32767	14000

### Point

When the digital clipping function is used with the scaling function, shift function, and difference conversion function, the scale conversion, shift-and-add, and difference conversion are performed on the value obtained after digital clipping.


# 1.9 Difference Conversion Function

Medium speed

Low speed

This function subtracts the difference conversion reference value from a digital operation value and stores the acquired value in the buffer memory.

The digital operation value at the start of this function is treated as 0 (reference value). Thereafter, values that increased or decreased from the reference value are stored in the buffer memory.



## Operation

The digital operation value at the start of the difference conversion (the data stored inside the A/D converter module before the difference conversion starts) is determined as a difference conversion reference value. The value acquired by subtracting the difference conversion reference value from the digital operation value is stored in 'CH1 Digital operation value' (Un\G402). At the start of this function, the digital operation value is 0 (because the digital operation value and the difference conversion reference value have the same value at the start).

- Digital operation value after difference conversion = (Digital operation value) - (Difference conversion reference value)

### ■Starting the difference conversion

1. Change 'CH1 Difference conversion trigger' (Un\G470) from No request (0) to Trigger request (1).

The rise of No request (0) → Trigger request (1) is detected as a trigger. When the trigger is detected, the digital operation value at the start is output to the difference conversion reference value. The value acquired by subtracting the difference conversion reference value from the digital operation value is stored in 'CH1 Digital operation value' (Un\G402). After the value is stored, 'CH1 Difference conversion status flag' (Un\G408) turns to Converting difference (1).


### ■Stopping the difference conversion

1. Change 'CH1 Difference conversion trigger' (Un\G470) from Trigger request (1) to No request (0).

The fall of Trigger request (1) → No request (0) is detected as a trigger. When the trigger is detected, the difference conversion stops, and 'CH1 Difference conversion status flag' (Un\G408) turns to Not converted (0). Thereafter, the digital operation value is stored as it is in 'CH1 Digital operation value' (Un\G402).

## Operations of when an input signal error has occurred


When an input signal error has occurred, even if 'CH1 Difference conversion trigger' (Un\G470) changes from No request (0) to Trigger request (1), the difference conversion does not start, and 'CH1 Difference conversion status flag' (Un\G408) and 'CH1 Difference conversion reference value' (Un\G432) are not updated. After the value in the input signal error range returns to the normal value, change 'CH1 Difference conversion trigger' (Un\G470) from No request (0) to Trigger request (1) again. If an input signal error has occurred in the status of Trigger request (1), the difference conversion starts at the timing when the error value returns to the normal value, treating the digital operation value at that timing as the difference conversion reference value.



(A) Timing when the error value returns to the normal value


## ■Operations of when 'Operating condition setting request' (Y9) is turned on and off

- During the difference conversion, even when 'Operating condition setting request' (Y9) is turned on and off, the difference conversion continues without updating the difference conversion reference value. To update the difference conversion reference value, restart the difference conversion by changing 'CH1 Difference conversion trigger' (Un\G470) from Trigger request (1) to No request (0), and Trigger request (1) again.
- Difference conversion trigger is not enabled even though the trigger changes from No request (0) to Trigger request (1) while 'Operating condition setting request' (Y9) is on. After turning on and off 'Operating condition setting request' (Y9), change 'CH1 Difference conversion trigger' (Un\G470) from No request (0) to Trigger request (1) again.



## ■Operations of Maximum value and Minimum value

Once the difference conversion is started, the maximum value and the minimum value of the values acquired by the difference conversion are stored in 'CH1 Maximum value' (Un\G404) and 'CH1 Minimum value' (Un\G406). By turning on 'Maximum value/minimum value reset request' (YD), the maximum value and the minimum value after the start of the difference conversion can be checked. When 'Maximum value/minimum value reset request' (YD) is not turned on, the maximum values and minimum values before and after the difference conversion are mixed.



## ■Operation of when the averaging processing is set

If the difference conversion starts after the averaging processing is set, the digital operation value at the completion of the averaging processing is determined as 'CH1 Difference conversion reference value' (Un\G432). 'CH1 Difference conversion status flag' (Un\G408) turns to Converting difference (1).

### Point

- The difference conversion function can be started at any timing.
- When the difference conversion function is used with the digital clipping function, scaling function, and shift function, each digital operation value is used as a difference conversion reference value for the difference conversion.
- Even though the digital clipping function, scaling function, and shift function are enabled during the difference conversion, the value in 'CH1 Difference conversion reference value' (Un\G432) is not updated. To update the value in 'CH1 Difference conversion reference value' (Un\G432), stop the difference conversion and restart it again.

# 1.10 Maximum Value/Minimum Value Hold Function

Common

This function stores the maximum and minimum values of digital operation values for each channel in the buffer memory.



In the simultaneous conversion mode or inter-module synchronization mode, the maximum and minimum values of the digital output values are stored.

## Resetting the maximum value and the minimum value

Turn on and off 'Maximum value/minimum value reset request' (YD) or 'Operating condition setting request' (Y9) to replace the maximum value and minimum value with the current values.

Turning on 'Maximum value/minimum value reset request' (YD) turns on 'Maximum value/minimum value reset completed flag' (XD).

## Values to be the maximum value and the minimum value

The maximum and minimum values of digital operation values are stored in the buffer memory.

When the digital clipping function, scaling function, shift function, or difference conversion function is used, the maximum value and minimum value obtained after the operation processing of each function are stored.

# 1.11 Warning Output Function

Common


This function has process alarms and rate alarms. The following sections describe process alarms and rate alarms.

## Process alarm

Common

This function outputs a warning when a digital operation value enters the preset warning output range.

Digital operation value



$P_{UU}$ : Process alarm upper upper limit value

$P_{UL}$ : Process alarm upper lower limit value

$P_{LU}$ : Process alarm lower upper limit value

$P_{LL}$ : Process alarm lower lower limit value

## Operation

### ■Operation performed when a warning is output

When a digital operation value is equal to or greater than 'CH1 Process alarm upper upper limit value' (Un\G514), or the value is equal to or smaller than 'CH1 Process alarm lower lower limit value' (Un\G520) and thus the value enters the warning output range, a warning is output as follows.

- Alarm ON (1) is stored in 'Warning output flag (Process alarm upper limit)' (Un\G36) or 'Warning output flag (Process alarm lower limit)' (Un\G37).
- 'Warning output signal' (X8) turns on.
- The ALM LED turns on.

In addition, an alarm code is stored in 'Latest alarm code' (Un\G2).

For details on the alarm codes, refer to the following.

 [Page 152 List of Alarm Codes](#)

#### Point

- The A/D conversion on a channel where a warning was output continues.
- In the simultaneous conversion mode or inter-module synchronization mode, whether to output a warning is judged with a digital output value.

### ■Operation after a warning was output

After a warning was output, if the digital operation value does not satisfy the warning output condition due to being smaller than 'CH1 Process alarm upper lower limit value' (Un\G516) or being greater than 'CH1 Process alarm lower upper limit value' (Un\G518), Normal (0) is stored in a bit corresponding to the channel number of 'Warning output flag (Process alarm upper limit)' (Un\G36) or 'Warning output flag (Process alarm lower limit)' (Un\G37).

In addition, when all 'Warning output flag (Process alarm upper limit)' (Un\G36) and 'Warning output flag (Process alarm lower limit)' (Un\G37) return to Normal (0), 'Warning output signal' (X8) turns off and the ALM LED turns off. However, the alarm code stored in 'Latest alarm code' (Un\G2) is not cleared. To clear the alarm code, turn on and off 'Error clear request' (YF) after all the bits of 'Warning output flag (Process alarm upper limit)' (Un\G36) and 'Warning output flag (Process alarm lower limit)' (Un\G37) return to Normal (0).

## Detection cycle

When time average is specified, the function works at every interval of the time (for averaging). When count average is specified, the function works at every count (for averaging).

When the sampling processing, moving average, primary delay filter, or digital filter is specified, this function works at every sampling cycle.

## Detection target for outputting a warning

When the digital clipping function, scaling function, shift function, or difference conversion function is used, the digital operation value obtained after digital clipping, scale conversion, shift-and-add, or difference conversion is performed is the detection target for outputting a warning. Set values for 'CH1 Process alarm upper upper limit value' (Un\G514), 'CH1 Process alarm upper lower limit value' (Un\G516), 'CH1 Process alarm lower upper limit value' (Un\G518), and 'CH1 Process alarm lower lower limit value' (Un\G520) while considering the digital clipping, scale conversion, shift-and-add, and difference conversion.

## Setting procedure

1. Set "Warning output setting (Process alarm)" to "Enable".  
 Navigation window  $\Rightarrow$  [Parameter]  $\Rightarrow$  [Module Information]  $\Rightarrow$  Module model name  $\Rightarrow$  [Module Parameter]  $\Rightarrow$  "Application setting"  $\Rightarrow$  "Warning output function (Process alarm)"
2. Set values for "Process alarm upper upper limit value", "Process alarm upper lower limit value", "Process alarm lower upper limit value", and "Process alarm lower lower limit value".

Item	Setting range
Process alarm upper upper limit value	-32768 to 32767
Process alarm upper lower limit value	
Process alarm lower upper limit value	
Process alarm lower lower limit value	

### Point


Set values within the range satisfying the condition "Process alarm upper upper limit value  $\geq$  Process alarm upper lower limit value  $\geq$  Process alarm lower upper limit value  $\geq$  Process alarm lower lower limit value". If a value out of the range is set, a process alarm upper lower limit value setting range error (error code: 1B△□H) occurs.

# Rate alarm

Medium speed

Low speed

This function outputs a warning when the change rate of a digital output value is equal to or greater than the rate alarm upper limit value, or the rate is equal to or smaller than the rate alarm lower limit value.



-----► Performed by the A/D converter module.

(1) The change amount of a digital output value is converted into the change rate at every rate alarm warning detection cycle. When the change amount increases, the change rate is greater than 0. When the change amount decreases, the change rate is smaller than 0.

## Operation

### ■Operation performed when a warning is output

Digital output values are monitored every rate alarm warning detection cycle. When a change rate of a digital output value (from a previous value) is equal to or greater than the rate alarm upper limit value, or the rate is equal to or smaller than the rate alarm lower limit value, a warning is output as follows.

- Alarm ON (1) is stored in 'Warning output flag (Rate alarm upper limit)' (Un\G38) or 'Warning output flag (Rate alarm lower limit)' (Un\G39).
- 'Warning output signal' (X8) turns on.
- The ALM LED turns on.

In addition, an alarm code is stored in 'Latest alarm code' (Un\G2).

For details on the alarm codes, refer to the following.

 Page 152 List of Alarm Codes



The A/D conversion on a channel where a warning was output continues.

### ■Operation after a warning was output

After a warning was output, if the change rate of a digital output value does not satisfy the warning output conditions due to being smaller than the rate alarm upper limit value or being greater than the rate alarm lower limit value, Normal (0) is stored in a bit corresponding to the channel number of 'Warning output flag (Rate alarm upper limit)' (Un\G38) or 'Warning output flag (Rate alarm lower limit)' (Un\G39).

In addition, when all 'Warning output flag (Rate alarm upper limit)' (Un\G38) and 'Warning output flag (Rate alarm lower limit)' (Un\G39) return to Normal (0), 'Warning output signal' (X8) turns off and the ALM LED turns off. However, the alarm code stored in 'Latest alarm code' (Un\G2) is not cleared. To clear the alarm code, turn on and off 'Error clear request' (YF) after all the bits of 'Warning output flag (Rate alarm upper limit)' (Un\G38) and 'Warning output flag (Rate alarm lower limit)' (Un\G39) return to Normal (0).

## Detection cycle

Set the rate alarm warning detection cycle in 'CH1 Rate alarm warning detection cycle setting' (Un\G522).

The rate alarm warning detection cycle is the value calculated by multiplying the set value by the conversion cycle.

**Ex.**

The rate alarm warning detection cycle under the following conditions

- Operation mode: Normal mode (low speed: 20 $\mu$ s/CH)
- A/D conversion-enabled channels: CH1 to CH3
- 'CH1 Rate alarm warning detection cycle setting' (Un\G522): 5 (times)

The rate alarm warning detection cycle is 300 $\mu$ s. (20 $\mu$ s  $\times$  3 (CH)  $\times$  5 (times))

Digital output values are compared in 300 $\mu$ s intervals to check the change rate.

## Judgment of rate alarm

A change rate is judged with digital values per rate alarm warning detection cycle, which are calculated using values in 'CH1 Rate alarm upper limit value' (Un\G524) and 'CH1 Rate alarm lower limit value' (Un\G526).

The following shows the conversion formulas to obtain judgment values (Unit: digit) per rate alarm warning detection cycle.

- $D_H = (R_H/1000) \times D_{Max}$
- $D_L = (R_L/1000) \times D_{Max}$

Item	Description
$D_H^{*1}$	Upper limit value used for judgment on the rate alarm warning detection cycle (Unit: digit)
$D_L^{*1}$	Lower limit value used for judgment on the rate alarm warning detection cycle (Unit: digit)
$R_H$	Rate alarm upper limit value (Unit: 0.1%)
$R_L$	Rate alarm lower limit value (Unit: 0.1%)
$D_{Max}$	Maximum digital output value of the input range (32000)

\*1 Values after the decimal point are omitted.

### Ex.

The judgment value under the following conditions

- Operation mode: Normal mode (low speed: 20 $\mu$ s/CH)
- Input range: 4 to 20mA
- A/D conversion-enabled channel: CH1
- 'CH1 Averaging process specification' (Un\G501): Sampling processing (0)
- 'CH1 Rate alarm warning detection cycle setting' (Un\G522): 5 (times)
- 'CH1 Rate alarm upper limit value' (Un\G524): 250 (25.0%)
- 'CH1 Rate alarm lower limit value' (Un\G526): 50 (5.0%)

$$D_H: \frac{250}{1000} \times 32000 = 8000 \text{ (digit)}$$

$$D_L: \frac{50}{1000} \times 32000 = 1600 \text{ (digit)}$$

The current value is compared with the previous value on the rate alarm warning detection cycle of 100 $\mu$ s (Sampling cycle 20 $\mu$ s  $\times$  5). A digital value is judged if it increases 8000 digits (25.0%) or more, or judged if the increase is 1600 digits (5.0%) or less from the previous value.

Use the following formula to calculate a change rate to be set based on the change amount of voltage and current to detect a warning.

$$RC = \frac{V/I_x}{V/I_G - V/I_O} \times 1000$$

Item	Description
$RC^{*2}$	Change rate to be set (Unit: 0.1%)
$V/I_x$	Change amount of the voltage (current) to detect a warning (V (mA))
$V/I_G$	Gain voltage (current) (V (mA))
$V/I_O$	Offset voltage (current) (V (mA))


\*2 Values after the decimal point are omitted.

## Application examples of rate alarms

A rate alarm serves to monitor that the change rate of a digital output value lies in a limited range as shown below:

**Ex.**

To monitor that a rising rate of a digital output value is within the specified range



$RC_D$ : Change rate of the digital output value (%)


t: Time

(1) Rate alarm upper limit value

(2) Rate alarm lower limit value

**Ex.**

To monitor that a drop rate of a digital output value is within the specified range



$RC_D$ : Change rate of the digital output value (%)


t: Time

(1) Rate alarm upper limit value

(2) Rate alarm lower limit value

**Ex.**

To monitor that a change rate of a digital output value is within the specified range



$RC_D$ : Change rate of the digital output value (%)

t: Time

(1) Rate alarm upper limit value

(2) Rate alarm lower limit value

## Setting procedure

1. Set "Warning output function (Rate alarm)" to "Enable".

 Navigation window  $\Rightarrow$  [Parameter]  $\Rightarrow$  [Module Information]  $\Rightarrow$  Module model name  $\Rightarrow$  [Module Parameter]  $\Rightarrow$  "Application setting"  $\Rightarrow$  "Warning output function (Rate alarm)"

2. Set a warning detection cycle of rate alarms.

Set the cycle in "Rate alarm detection cycle setting".

Item	Setting range
Rate alarm detection cycle setting	1 to 32000 (times)

### Point

In the channel where a value out of the range is set, a rate alarm warning detection cycle setting range error (error code: 1B9□H) occurs.

3. Set values for "Rate alarm upper limit value" and "Rate alarm lower limit value".

Set a value to the maximum value (32000) of the digital output value in increments of 0.1%.

Item	Setting range
Rate alarm upper limit value	-3276.8 to 3276.7 (%)
Rate alarm lower limit value	

### Point


Set values within the range satisfying the condition "Rate alarm upper limit value > Rate alarm lower limit value".

If a value out of the range is set, a rate alarm upper/lower limit setting value inversion error (error code: 1BA□H) occurs.

## 1.12 Input Signal Error Detection Function

### Common

This function outputs an alarm when an analog input value exceeds the preset range.






How to clear the input signal error varies depending on 'Input signal error detection auto-clear enable/disable setting' (Lp/G302). For details, refer to the following.

◀ Page 62 Clearing input signal errors

## Detection method

Select a detection method from the following table.

Detection method	Detection condition	
0: Disable	Input signal errors are not detected.	—
1: Upper and lower limit detection	An input signal error is detected when the analog input value is equal to or greater than the input signal error detection upper limit value, or when the analog input value is equal to or smaller than the input signal error detection lower limit value.	
2: Lower limit detection	An input signal error is detected when the analog input value is equal to or smaller than the input signal error detection lower limit value.	
3: Upper limit detection	An input signal error is detected when the analog input value is equal to or greater than the input signal error detection upper limit value.	
4: Simple disconnection detection	Simple disconnection detection is performed. For details, refer to the following. <a href="#">Page 61 Simple disconnection detection</a>	

V/I: Analog input value

t: Time

In<sub>H</sub>: Input signal error detection upper limit value

In<sub>L</sub>: Input signal error detection lower limit value


## ■Simple disconnection detection

An alarm is output when an analog input value is 0.5V or lower or 2mA or lower.

By combining this function with the extended mode in the input range setting, simple disconnection detection is enabled.

When an analog input value satisfies either of the following conditions, it is regarded as a disconnection and 'Input signal error detection flag' (Un\G40) turns on.

Input range	Disconnection detection value
4 to 20mA (extended mode)	Analog input value $\leq$ 2mA
1 to 5V (extended mode)	Analog input value $\leq$ 0.5V



V/I: Analog input value

t: Time

(1) 0.5V or 2mA

The settings of 'CH1 Input signal error detection lower limit setting value' (Un\G529) and 'CH1 Input signal error detection upper limit setting value' (Un\G530) are ignored.

## Notification

When an input signal error is detected, an error is notified as follows.

- Input signal error (1) is stored in the corresponding bit of 'Input signal error detection flag' (Un\G40).
- 'Input signal error detection signal' (XC) turns on.
- The ALM LED flashes.

In addition, an alarm code is stored in 'Latest alarm code' (Un\G2). Alarm codes are stored whenever the analog input satisfies the condition for the input signal error detection.

For details on the alarm codes, refer to the following.

☞ Page 152 List of Alarm Codes

## Operation

On the channel where an error is detected, the digital output value and digital operation value just before the detection of the error are stored.

When an analog input value falls within the set range, the A/D conversion is restarted regardless of whether 'Input signal error detection flag' (Un\G40) and 'Input signal error detection signal' (XC) are reset or not. (The ALM LED remains flashing.)

### Point

- The values in 'CH1 Digital output value' (Un\G400) and 'CH1 Digital operation value' (Un\G402) are not updated during the occurrence of an input signal error.
- The A/D conversion continues on the channel where no input signal error is detected.
- Whether an input signal error has occurred or not is judged with the value of when the A/D conversion is completed. Thus, the corresponding bit of 'A/D conversion completed flag' (Un\G42) turns on even when an input signal error is detected.

## Detection cycle

This function works at every sampling cycle.

## Clearing input signal errors

How to clear the input signal error can be selected from the following depending on the setting of 'Input signal error detection auto-clear enable/disable setting' (Un\G302).

### ■When 'Input signal error detection auto-clear enable/disable setting' (Un\G302) is Enable (0)

After the analog input value falls within the set range, the A/D converter module automatically arranges the following status.

After the analog input value falls within the set range, turning on and off 'Error clear request' (YF) is not required.

- 'Input signal error detection flag' (Un\G40) is cleared.
- 'Input signal error detection signal' (XC) turns off.
- The ALM LED turns off.



'Latest alarm code' (Un\G2) is not cleared.

To clear 'Latest alarm code' (Un\G2), turn on and off 'Error clear request' (YF) after the analog input value falls within the set range.

### ■When 'Input signal error detection auto-clear enable/disable setting' (Un\G302) is Disable (1)

After the analog input value falls within the set range, turn on and off 'Error clear request' (YF).

The A/D converter module arranges the following status when an input signal error is cleared.

- 'Input signal error detection flag' (Un\G40) is cleared.
- 'Input signal error detection signal' (XC) turns off.
- The ALM LED turns off.
- 'Latest alarm code' (Un\G2) is cleared.

## Setting of the input signal error detection upper/lower limit value

### ■Input signal error detection upper limit value

Set the input signal error detection upper limit value in increments of 1 (0.1%) using the input signal error detection upper limit setting value.

This value is calculated by adding "Analog input range width (Gain value - Offset value) × Input signal error detection upper limit setting value (%)" to the gain value. Only a value that is equal to or greater than the gain value can be set.

To calculate the input signal error detection upper limit setting value based on the input signal error detection upper limit value, use the following formula.

- Input signal error detection upper limit setting value =  $((I_{nH} - V/I_G) \div (V/I_G - V/I_O)) \times 1000$

Item	Description
$I_{nH}$	Input signal error detection upper limit value
$V/I_G$	Gain value of each range
$V/I_O$	Offset value of each range

### ■Input signal error detection lower limit value

Set the input signal error detection lower limit value in increments of 1 (0.1%) using the input signal error detection lower limit setting value.

This value is calculated by subtracting "Analog input range width (Gain value - Offset value) × Input signal error detection lower limit setting value (%)" from the lower limit value of each range. Only the value that is equal to or smaller than the lower limit value of the range can be set.

To calculate the input signal error detection lower limit setting value based on the input signal error detection lower limit value, use the following formula.

- Input signal error detection lower limit setting value =  $((V/I_{L-InL}) \div (V/I_G - V/I_O)) \times 1000$

Item	Description
$V/I_L$	Lower limit value of each range
$I_{nL}$	Input signal error detection lower limit value
$V/I_G$	Gain value of each range
$V/I_O$	Offset value of each range

The following table lists the lower limit value, offset value, and gain value for each range.

Input range		Lower limit value	Offset value	Gain value
Voltage	0 to 10V	0V		10V
	0 to 5V	0V		5V
	1 to 5V	1V		5V
	1 to 5V (extended mode)	1V		5V
	-10 to 10V	-10V	0V	10V
	User range setting	Analog input value equivalent to the digital output value of -32000	Analog input value set as an offset value	Analog input value set as a gain value
Current	0 to 20mA	0mA		20mA
	4 to 20mA	4mA		20mA
	4 to 20mA (extended mode)	4mA		20mA
	User range setting	Analog input value equivalent to the digital output value of -32000	Analog input value set as an offset value	Analog input value set as a gain value

## Setting procedure

1. Select a detection method in "Input signal error detection setting".  
 Navigation window  $\Rightarrow$  [Parameter]  $\Rightarrow$  [Module Information]  $\Rightarrow$  Module model name  $\Rightarrow$  [Module Parameter]  $\Rightarrow$  "Application setting"  $\Rightarrow$  "Input signal error detection function"
2. Set values for "Input signal error detection lower limit setting value" and "Input signal error detection upper limit setting value".

Item	Setting range
Input signal error detection lower limit setting value	0.0 to 25.0 (%)
Input signal error detection upper limit setting value	

3. Set "Input signal error detection auto clear enable/disable setting" to "Enable" or "Disable".

### Point

In the channel where a value out of the range is set, an input signal error detection setting value range error (error code: 1C1□H) occurs.

## Setting example of the input signal error detection

The following shows a setting example for detecting an input signal error when an analog input value is greater than 21.6mA or is smaller than 0.4mA in the channel set as shown below.

Item	Setting value
Input range	4 to 20mA
'Input signal error detection auto-clear enable/disable setting' (Un\G302)	Disable (1)
'CH1 Input signal error detection setting' (Un\G528)	Upper and lower limit detection (1)

Assign the following values in the formula for calculating the input signal error detection lower limit setting value and the input signal error detection upper limit setting value.

- Input signal error detection lower limit value: 0.4mA
- Input signal error detection upper limit value: 21.6mA
- Lower limit value of the range: 4.0mA
- Offset value: 4.0mA
- Gain value: 20.0mA

### ■Input signal error detection lower limit setting value

Input signal error detection lower limit setting value =  $((4.0 - 0.4) \div (20.0 - 4.0)) \times 1000 = 225$  (22.5%)

Thus, set 'CH1 Input signal error detection lower limit setting value' (Un\G529) to 225 (22.5%).


### ■Input signal error detection upper limit setting value

Input signal error detection upper limit setting value =  $((21.6 - 20.0) \div (20.0 - 4.0)) \times 1000 = 100$  (10.0%)

Thus, set 'CH1 Input signal error detection upper limit setting value' (Un\G530) to 100 (10.0%).

### ■Operation

The following graph shows the operation of the input signal error detection.



In<sub>H</sub>: Input signal error detection upper limit value

V/I<sub>G</sub>: Gain value

V/I<sub>O</sub>: Offset value (Lower limit value of the input range)

In<sub>L</sub>: Input signal error detection lower limit value

(1) Error detection

(2) 1.6mA (10.0% of 16mA)

(3) 16mA (Gain value - Offset value)

(4) 3.6mA (22.5% of 16mA)

# 1.13 Using One of the Logging Functions Depending on the Intended Use

Low speed

Simultaneous conversion

Synchronization

As logging functions, the normal logging function that operates in the normal mode (low speed: 20μs/CH) and the continuous logging function that operates in the simultaneous conversion mode or the inter-module synchronization mode are provided. The normal logging function and continuous logging function have different logging methods of data. Check the features of each logging function and select one of the logging functions depending on the intended use.

## Features of the normal logging function

This function operates in the normal mode (low speed: 20μs/CH).

Data can be logged under various conditions with the logging hold processing, level trigger, logging read function, and others. For the normal logging function, refer to the following.

☞ Page 69 Normal Logging Function

## Features of the continuous logging function

This function operates in the simultaneous conversion mode or the inter-module synchronization mode. This function continuously collects the data to which the A/D conversion has been performed simultaneously in four channels at a high speed (5μs cycles at a maximum). Thus, when the module is connected with a sensor that has input characteristics of the high-frequency band, this function can collect data for signal analysis.

For the continuous logging function, refer to the following.

☞ Page 94 Continuous Logging Function

## Differences of each logging function

The following tables list differences between the normal logging function and the continuous logging function.

- Combination with each function

○: Available, △: Restricted use, ×: Not available

Function	Logging function		
	Normal logging function	Continuous logging function (simultaneous conversion mode)	Continuous logging function (inter-module synchronization mode)
Conversion cycle	Depends on the A/D conversion method	5μs/4CH	<ul style="list-style-type: none"> <li>■Oversampling disable</li> <li>Inter-module synchronization cycle/4CH</li> <li>■Oversampling enable</li> <li>5μs/4CH</li> </ul>
A/D conversion method	○	△ (Only sampling processing and moving average)	
Scaling function	○	×	×
Digital clipping function	○	×	×
Shift function	○	×	×
Difference conversion function	○	×	×
Warning output function	○	△ (Only process alarms)	△ (Only process alarms)
Input signal error detection function	○	○	○
Logging read function	○	×	×
Interrupt function	○	○	×


- Specifications of each logging function

Specifications of a logging function	Logging function		
	Normal logging function	Continuous logging function (simultaneous conversion mode)	Continuous logging function (inter-module synchronization mode)
Logging start timing	When 'Operating condition setting request' (Y9) is turned on and off after 'CH1 Logging enable/disable setting' (UnlG535) is set to Enable (0) When 'CH1 Logging hold request' (Y1) is turned off (when the logging is stopped due to a hold trigger generation)	When the next conversion cycle has come after 'Continuous logging start/stop request' (UnlG100) is changed from Stop (0) to Start (1)	When the second inter-module synchronization cycle has come after 'Continuous logging start/stop request' (UnlG100) is changed from Stop (0) to Start (1)
Logging stop timing	<ul style="list-style-type: none"> <li>When data collection for the preset number of logging data points is completed after a hold trigger generation</li> <li>When 'Operating condition setting request' (Y9) is turned on</li> </ul>	When the next conversion cycle has come after 'Continuous logging start/stop request' (UnlG100) is changed from Start (1) to Stop (0)	<ul style="list-style-type: none"> <li>When the second inter-module synchronization cycle has come after 'Continuous logging start/stop request' (UnlG100) is changed from Start (1) to Stop (0)</li> <li>When the state of CPU module is changed from RUN to STOP</li> </ul>
Number of logging data points	Collects data of 0 to 90000 points for each channel	Collects data of 10000 points for each channel	
Storage of logging data	Stores data of 1 point at every set logging cycle	Stores data of 5000 points collectively in the logging data areas after logging all the data (5000 points)	Stores data at every inter-module synchronization cycle from the next cycle after data logging is started by a synchronous signal
Reading of logging data	Reads data into a CSV file or file registers after logging is stopped	Reads data by 5000 points into file registers without stopping the logging	
Logging hold flag	Turns on after logging of data for the number of post-trigger logging points is completed	No logging hold flag	
Logging pointer	Updates the pointer at every conversion cycle	No pointer	
Number of logging data	90000 points in total in all channels	Depends on the capacity of file registers in the CPU module	
Trigger generation time	Stores the generation time of a logging hold request	Stores the start time of continuous logging	

Specifications of a logging function	Logging function		
	Normal logging function	Continuous logging function (simultaneous conversion mode)	Continuous logging function (inter-module synchronization mode)
Updating the digital value during logging	Updates the value at every conversion cycle	Updates the value every time data of 5000 points are logged	Updates the value at every inter-module synchronization cycle

## Procedure for selecting logging functions

The following figure shows an example of how to select a logging function to be used. Select a suitable function considering intended applications of the A/D converter module and features of each logging function.



# 1.14 Normal Logging Function

Low speed

This function logs (records) digital output values or digital operation values for up to 90000 points. Logged data are stored in the buffer memory. In addition, the data collection can be stopped by using the status change of the data as a trigger. This function also helps the error analysis since the data before and after the occurrence of an error is held.

Using function blocks (FBs) enables saving the data stored in the buffer memory as a CSV file.


## Normal logging function

### ■Collecting logging data

Logging data is collected as follows.

- The latest digital output values or digital operation values can be always collected for each channel. The number of logging data points to be collected can be set for each channel. (☞ Page 71 Logging data)
- The data can be collected at intervals of 20μs at a minimum and of 3600s at a maximum.

An address where the latest/oldest data is stored can be checked with the latest/head pointer.



(1) Head pointer  
The address of the oldest data in logging data can be checked.

(2) Latest pointer  
The address of the latest data in logging data can be checked.

Logging data is stored in the buffer memory. After the number of stored data points reaches the maximum point, data is sequentially overwritten from address 0 with new data.


## ■Stopping the logging operation

Logging data is updated at a high speed during the logging. Stop logging when the logging data needs to be referred to without paying attention to the updating cycle.

Logging can be stopped by the hold trigger.

- A hold trigger allows two options: Logging hold request or Level trigger.
- The number of data points to be collected after a hold trigger occurs can be set.

Logging data are stored in buffer memory areas.




(1) Logging hold request

A hold trigger is generated from a program at any timing.

(2) Level trigger

A hold trigger is generated when a stored value in a buffer memory area is monitored and the set condition is satisfied as follows.

Example: When the stored value exceeds or falls below the set value, a hold trigger is generated.




(3) Post-trigger logging points

When data for the set number of data points are collected after a hold trigger is generated, the logging operation is stopped.

## Operation of logging

### ■Starting logging data collection

Logging data collection starts when 'CH1 Logging enable/disable setting' (Un\G535) is set to Enable (0) and 'Operating condition setting request' (Y9) is turned on and off. Collecting is performed at the preset logging cycle.



(1) Logging is started.

## ■Logging data

The areas of 90000 points for logging data storage are prepared in all channels.

To distribute the areas to each channel, set a value in Logging data points setting in increments of 100 points.


**Ex.**

When setting the number of points for logging data areas to be used by each channel as follows

Item	Setting value <sup>*1</sup>
'CH1 Logging data points setting' (Un\G536)	200 (20000 points)
'CH2 Logging data points setting' (Un\G736)	100 (10000 points)
'CH3 Logging data points setting' (Un\G936)	50 (5000 points)
'CH4 Logging data points setting' (Un\G1136)	400 (40000 points)

\*1 Set a value in increments of 1 (100 points).

Logging data area (Un\G10000 to Un\G99999) is distributed to each channel as follows.



After the number of stored data points reaches the maximum point, data is overwritten with new data from the start address of Logging data area of the corresponding channel.

If logging has been performed even once, all the logging data areas are cleared to 0 at the timing when 'Operating condition setting request' (Y9) is turned on.



- Because the logging data areas are reserved automatically by the setting, refer to 'CH1 Logging start address monitor' (Un\G434, Un\G435) to find the logging start position.
- Setting 0 in Logging data points setting of the channel that is not used for logging allows users to set wide logging areas of the channel used for logging.

## Logging data setting

Select a type of the data to be collected with 'CH1 Logging data setting' (Un\G537).

- Digital output value (0)
- Digital operation value (1)

## Logging cycle

### ■Logging cycle setting

Set the logging cycle with 'CH1 Logging cycle setting value' (Un\G538) and 'CH1 Logging cycle unit setting' (Un\G539).

The following table lists the setting range for each cycle unit.

Setting value of CH1 Logging cycle unit setting	Setting range of CH1 Logging cycle setting value
μs(0)	20 to 32767
ms(1)	1 to 32767
s(2)	1 to 3600

The logging cycle must be an integral multiple of the conversion cycle. Even if the setting is not an integral multiple, the actual logging cycle is adjusted to an integral multiple of the conversion cycle within a limit of the set logging cycle.

For the conversion cycle of each A/D conversion method, refer to the following.

☞ Page 22 Conversion cycle

#### Ex.

With the following settings, the conversion cycle is 80μs and the actual logging is performed every 6960μs (integral multiple of 80μs).

- Operation mode: Normal mode (low speed: 20μs/CH)
- A/D Conversion enabled channels: CH1 to CH4
- A/D conversion method: Sampling processing
- 'CH1 Logging cycle setting value' (Un\G538): 7000
- 'CH1 Logging cycle unit setting' (Un\G539): μs (0)

The following values are stored in 'CH1 Logging cycle monitor value' (Un\G450 to Un\G452).

Address	Item	Stored value
450	CH1 Logging cycle monitor value	s 0
451		ms 6
452		μs 960

### ■When the normal logging function becomes disabled

The logging is not performed when even one of the following errors occurs after the normal logging function is enabled and 'Operating condition setting request' (Y9) is turned on and off.

- Error code (190□H to 198□H): Setting errors related to the range setting and A/D conversion method
- Error code (1D0□H to 1D6□H, 1DA□H to 1DD□H): Setting errors of the logging functions
- Error code (1D8□H and 1D9□H): Setting errors of the logging read function

#### Point

When 'Operating condition setting request' (Y9) is turned on and off under the condition in which the logging cycle determined by 'CH1 Logging cycle setting value' (Un\G538) and 'CH1 Logging cycle unit setting' (Un\G539) is shorter than the conversion cycle, a logging cycle setting disable error (error code: 1D2□H) occurs.


## Number of logging data

With 'CH1 Number of logging data' (Un\G440, Un\G441), the number of valid data points in Logging data area (Un\G10000 to Un\G99999) can be checked.

**When the number of collected data points is less than the number of points (N) set in 'CH1 Logging data points setting' (Un\G536)**



**When the number of collected data points reaches the number of points (N) set in 'CH1 Logging data points setting' (Un\G536)**



(1) Valid data (CH1 Number of logging data = 5)

(2) Invalid data (The content of the data is not guaranteed.)

(3) Valid data (CH1 Number of logging data = N)

The number of logging data points increases by one every time new data is stored.


When the logging data area distributed to each channel is filled, the next data is stored in the start address of Logging data area. The logging operation continues overwriting the existing data. In this case, the number of logging data points is fixed to the number of points set in 'CH1 Logging data points setting' (Un\G536).

## Head pointer and latest pointer

The storage locations of the oldest data and the latest data of each channel in Logging data area (Un\G10000 to Un\G99999) can be checked with the following buffer memory areas.


Buffer memory area	Description
'CH1 Head pointer' (Un\G436, Un\G437)	Out of the logging data area distributed to each channel, the buffer memory address of the oldest data can be checked with this buffer memory area. The offset value counted from the start address of each channel is stored.
'CH1 Latest pointer' (Un\G438, Un\G439)	Out of the logging data area distributed to each channel, the buffer memory address of the latest data can be checked with this buffer memory area. The offset value counted from the start address of each channel is stored.

**When the number of collected data points is less than the number of points (N) set in 'CH1 Logging data points setting' (Un\G536)**



- (1) Storage location of the oldest data CH1 Head pointer = 0
- (2) Storage location of the latest data CH1 Latest pointer = 4
- (3) Storage location of the oldest data CH1 Head pointer = 5

**When the number of collected data points reaches the number of points (N) set in 'CH1 Logging data points setting' (Un\G536)**



'CH1 Head pointer' (Un\G436, Un\G437) does not change (fixed to 0) until logging data for the number of the points set in 'CH1 Logging data points setting' (Un\G536) is completed after the logging start.

'CH1 Head pointer' (Un\G436, Un\G437) changes by one point when logging data for the number of the points set in 'CH1 Logging data points setting' (Un\G536) is completed and overwriting the data starts from the start address of Logging data area (Un\G10000 to Un\G99999).

## Logging status monitor value

The execution status of logging can be checked with 'CH1 Logging status monitor value' (Un\G458).

Stored value of 'CH1 Logging status monitor value' (Un\G458)	Execution status of logging
FH	Stop (disabled)
0H	Logging hold request waiting (during logging)
1H	Level trigger waiting (during logging)
2H	Trigger existing (during logging)
3H	Logging hold completed (stop)

## Checking logging data without stopping the logging operation

Logging data can be checked during the logging operation with 'CH1 Head pointer' (Un\G436, Un\G437), 'CH1 Latest pointer' (Un\G438, Un\G439), and 'CH1 Number of logging data' (Un\G440, Un\G441).

To check logging data during the logging operation, follow the precautions below because logging data may be updated while data is being read.

- Set the cycle to 'CH1 Logging cycle setting value' (Un\G538) so that checking and reading of data surely is completed before logging data is updated. If the logging cycle is short, logging data may be updated during checking and reading of data.
- After obtaining the logging data which needs to be checked, monitor the change of 'CH1 Head pointer' (Un\G436, Un\G437) or 'CH1 Number of logging data' (Un\G440, Un\G441), and obtain logging data just after the stored value has changed.
- If the updated data and the data being checked do not synchronize due to the relationship between the logging cycle and the scan time of the CPU module, adjust the logging cycle.

Stop the logging operation when the logging data needs to be checked without paying attention to the logging cycle. (☞

Page 76 Stopping the logging operation)

# Stopping the logging operation

Logging operation stops (holds) when the preset trigger condition is satisfied and data is collected for the set number of data points.


A trigger that is generated when the condition is satisfied is called a hold trigger.

To generate a hold trigger, the following two methods are available.

☛ Page 79 Logging hold request

☛ Page 80 Level trigger

When a hold trigger is detected during data collection, the logging operation stops after data is collected for the number of data points set in 'CH1 Post-trigger logging points' (Un\G540, Un\G541).



(1) Data is collected for the number of the points set in 'CH1 Post-trigger logging points' (Un\G540, Un\G541).

## Post-trigger logging points

Set the number of points of data to be collected in the period from the detection of a hold trigger to when the logging operation stops in 'CH1 Post-trigger logging points' (Un\G540, Un\G541).

## Checking that the logging has stopped

Check that 'CH1 Logging hold flag' (Un\G409) has changed to ON (1).

## Checking data when a hold trigger has occurred


The storage location of the data of when a hold trigger has occurred can be checked with 'CH1 Trigger pointer' (Un\G442, Un\G443).

The offset value counted from the start address is stored in 'CH1 Trigger pointer' (Un\G442, Un\G443).

### Ex.

The value to be stored in 'CH1 Trigger pointer' (Un\G442, Un\G443) when the logging operation stops under the following conditions

- 'CH1 Logging data points setting' (Un\G536): 10000 points
- 'CH1 Post-trigger logging points' (Un\G540, Un\G541): 6505 points
- The data location where a hold trigger has occurred: 3500th data



(1) Storage location of the latest data CH1 Latest pointer = 4

(2) Storage location of the oldest data CH1 Head pointer = 5

(3) CH1 Trigger pointer = 3500

## ■Checking the trigger generation time

The trigger generation time can be checked with 'CH1 Trigger generation time' (Un\G453 to Un\G457).

### Ex.

For 'CH1 Trigger generation time' (Un\G453 to Un\G457)


b15	...	b8 b7	...	b0
Un\G453		First two digits of the year	Last two digits of the year	
Un\G454		Month	Day	
Un\G455		Hour	Minute	
Un\G456		Second	Day of the week	
Un\G457		Millisecond (higher-order digits)	Millisecond (lower-order digits)	

Item	Storage contents
First two digits of the year	Last two digits of the year
Month	Day
Hour	Minute
Second	
Day of the week	One of the following values is stored in BCD code. Sunday: 0, Monday: 1, Tuesday: 2, Wednesday: 3 Thursday: 4, Friday: 5, Saturday: 6
Millisecond (upper)	Stored in BCD code.
Millisecond (lower)	


## Restarting the logging

To restart logging, check that ON (1) is stored in 'CH1 Logging hold flag' (Un\G409) and turn off 'CH1 Logging hold request' (Y1). After logging is restarted, a value is stored from the start buffer memory area of Logging data area (Un\G10000 to Un\G99999). In addition, OFF (0) is stored in 'CH1 Logging hold flag' (Un\G409).

It may take time until ON (1) is stored in 'CH1 Logging hold flag' (Un)G409 after 'CH1 Logging hold request' (Y1) is turned on.



Logging does not stop when 'CH1 Logging hold request' (Y1) is turned off before ON (1) is stored in 'CH1 Logging hold flag' (Un\G409).



→ Performed by

## ■ Buffer memory area status when logging is restarted


## **Buffer memory area status when logging is restarted**

Buffer memory area	Value status
'CH1 Head pointer' (Un\G436, Un\G437)	Values are initialized.
'CH1 Latest pointer' (Un\G438, Un\G439)	
'CH1 Number of logging data' (Un\G440, Un\G441)	
'CH1 Trigger pointer' (Un\G442, Un\G443)	
'CH1 Trigger generation time' (Un\G453 to Un\G457)	
Logging data area (Un\G10000 to Un\G99999)	The values before logging is restarted are not initialized. After logging is restarted, values are stored in the start address and later of each channel. To refer to the logging data, check for valid data with 'CH1 Number of logging data' (Un\G440, Un\G441).

## Logging hold request

A hold trigger is generated from a program at any timing.

Logging stops when data collection for the preset number of data points is completed after 'CH1 Logging hold request' (Y1) is turned on.



-----► Performed by the A/D converter module.

(1) The data before the setting value of 'CH1 Logging data points setting' (Un\G536) is discarded.

(2) Generation of a hold trigger

(3) Logging is held

### Point

- The following delay time occurs until the A/D converter module receives a hold trigger after 'CH1 Logging hold request' (Y1) is turned on.  
Trigger delay = Logging cycle (Cycle at which logging is actually performed) + Scan time of the CPU module
- When 'CH1 Logging hold request' (Y1) is turned off before 'CH1 Logging hold flag' (Un\G409) is set to ON (1), the logging is not held when the data collection for the number of data points set in 'CH1 Post-trigger logging points' (Un\G540, Un\G541) is completed, and logging is restarted soon.

### Checking that the logging has stopped

Check that 'CH1 Logging hold flag' (Un\G409) has changed to ON (1).

# Level trigger

When a value in the monitored buffer memory area of the A/D converter module satisfies a preset condition, a hold trigger is generated.

A level trigger is monitored on the updating cycle of a digital output value or a digital operation value.

## Initial setting of a level trigger

### ■Setting a target to be monitored

As a condition to generate a hold trigger, set the buffer memory address to be monitored in 'CH1 Trigger data' (Un\G543).

Item	Setting range
'CH1 Trigger data' (Un\G543)	0 to 9999

To monitor a device value of a module other than the A/D converter module such as a device of the CPU module, set as follows.

- Set a value between 90 and 99 (Level data□ (Un\G90 to Un\G99)) in 'CH1 Trigger data' (Un\G543).
- Write a value of the device to be monitored in Level data□ (Un\G90 to Un\G99) with the MOV instruction.

Item	Setting range
Level data□ (Un\G90 to Un\G99)	-32768 to 32767

### Ex.

Application example of Level data□ (Un\G90 to Un\G99)

To monitor the data register D100 in the CPU module and operate the level trigger in CH1, create a program as follows.

1. Set 91 (buffer memory address of Level data 1) in 'CH1 Trigger data' (Un\G543) (when Level data 1 is used).
2. Store the storage data of D100 in 'Level data 1' (Un\G91) with a program continuously.

### Point

- Specify appropriate monitor data such as 'CH1 Digital output value' (Un\G400), 'CH1 Digital operation value' (Un\G402), or Level data□ (Un\G90 to Un\G99) in 'CH1 Trigger data' (Un\G543). When a setting area or a system area is specified, the normal operation is not guaranteed.
- When Process alarm (upper limit warning) (4), Process alarm (lower limit warning) (5), or Process alarm (upper limit warning/lower limit warning) (6) is set in 'CH1 Level trigger condition setting' (Un\G542), setting 'CH1 Trigger data' (Un\G543) and Level data□ (Un\G90 to Un\G99) is not required.

## ■Setting the condition to be monitored

- Set a condition to generate a hold trigger in 'CH1 Level trigger condition setting' (Un\G542).

Setting value	Description	
Level trigger (Rise) (1)		A hold trigger is generated under the condition (a).
Level trigger (Fall) (2)		A hold trigger is generated under the condition (b).
Level trigger (Rise and fall) (3)	<p>Y: Stored value of a device to be monitored t: Time Tx: Trigger setting value (a) A hold trigger is generated when the relation between the values changes from "Stored value of a buffer memory area to be monitored <math>\leq</math> Trigger setting value" to "Stored value of a buffer memory area to be monitored <math>&gt;</math> Trigger setting value". (b) A hold trigger is generated when the relation between the values changes from "Stored value of a buffer memory area to be monitored <math>\geq</math> Trigger setting value" to "Stored value of a buffer memory area to be monitored <math>&lt;</math> Trigger setting value".</p>	A hold trigger is generated under the condition (a) or (b).
Process alarm (upper limit warning) (4)		A hold trigger is generated under the condition (d).
Process alarm (lower limit warning) (5)		A hold trigger is generated under the condition (c).
Process alarm (upper limit warning/lower limit warning) (6)	<p>digit t: Time P<sub>UU</sub>: Process alarm upper upper limit value P<sub>LL</sub>: Process alarm lower lower limit value (c) A hold trigger is generated when the lower limit warning of the process alarm is issued. (d) A hold trigger is generated when the upper limit warning of the process alarm is issued.</p>	A hold trigger is generated under the condition (c) or (d).

- Set a value to generate a hold trigger in 'CH1 Trigger setting value' (Un\G544). When Process alarm (upper limit warning) (4), Process alarm (lower limit warning) (5), or Process alarm (upper limit warning/lower limit warning) (6) is set in 'CH1 Level trigger condition setting' (Un\G542), setting this area is not required.


Item	Setting range
'CH1 Trigger setting value' (Un\G544)	-32768 to 32767

## ■Setting of the hold trigger generation timing

Set the timing of detecting a hold trigger after the number of the generated level triggers is counted in 'CH1 Trigger judgment count setting value' (Un\G545). When level triggers are generated for the set number of level triggers, a hold trigger is generated.

### Ex.

When 'CH1 Level trigger condition setting' (Un\G542) is set to Level trigger (Rise) (1) and 'CH1 Trigger judgment count setting value' (Un\G545) is set to 3 (times), the following operation is performed.



Y: Stored value of a device to be monitored

t: Time

Tx: Trigger setting value


(1) Trigger generation (first time)

(2) Trigger generation (second time)

(3) Generation of a hold trigger

### Ex.

When 'CH1 Level trigger condition setting' (Un\G542) is set to Process alarm (upper limit warning/lower limit warning) (6) and 'CH1 Trigger judgment count setting value' (Un\G545) is set to 3 (times), the following operation is performed.



digit: Digital operation value

t: Time

P<sub>UU</sub>: Process alarm upper upper limit value

P<sub>UL</sub>: Process alarm upper lower limit value

P<sub>LU</sub>: Process alarm lower upper limit value

P<sub>LL</sub>: Process alarm lower lower limit value


(1) Trigger generation (first time)

(2) Trigger generation (second time)

(3) Generation of a hold trigger

## ■ Relation between items

The following figure shows the relation between items to be set in the initial setting of a level trigger.



- (1) Set a condition.
- (2) Set a buffer memory address to be monitored.
- (3) Set a standard value of the trigger generation.
- (4) When the condition is satisfied, a trigger is generated.

### Ex.


To generate a hold trigger when a value in 'CH1 Digital output value' (Un\G400) is greater than 10000, set as follows.

- 'CH1 Level trigger condition setting' (Un\G542): Level trigger (Rise) (1)
- 'CH1 Trigger data' (Un\G543): 400
- 'CH1 Trigger setting value' (Un\G544): 10000

## Operation of a level trigger

To use a level trigger, turn on 'CH1 Logging hold request' (Y1) in advance. At the point where 'CH1 Logging hold request' (Y1) is turned on, the module becomes the trigger condition wait status.

The logging stops when data collection for the set number of data points is completed after the trigger condition is satisfied.



→ Performed by the A/D converter module.


(1) The data before the setting value of 'CH1 Logging data points setting' (Un\G536) is discarded.

(2) Generation of a hold trigger

(3) Logging is held

## ■Precautions

A level trigger is detected on the updating cycle of a digital output value or digital operation value. Therefore, the data when a hold trigger is generated may not be stored in Logging data area (Un\G10000 to Un\G99999) depending on the setting of the logging cycle. To store the data at the timing when a hold trigger is generated in Logging data area (Un\G10000 to Un\G99999), arrange related settings so that the conversion cycle of the target value to be monitored (a trigger data) and the logging cycle (actual logging cycle) have the same time period.



Y: Stored value of a device to be monitored

t: Time

Tx: Trigger setting value

(1) Although a trigger is generated, the data at the timing when a trigger is generated is not stored in the buffer memory area.

## ■Checking that the logging has stopped

Check that 'CH1 Logging hold flag' (Un\G409) has changed to ON (1).

# Initial settings of the normal logging function

The following describes the initial setting procedure to use the normal logging function.

## Setting procedure

Select one of the following setting procedures depending on the setting of "Level trigger condition setting".

### ■When setting "Level trigger (Condition: Rise)", "Level trigger (Condition: Fall)", or "Level trigger (Condition: Rise and fall)" for "Level trigger condition setting"

1. Set "A/D conversion enable/disable setting" to "A/D conversion enable".  
☞ Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Module Parameter] ⇒ "Basic setting" ⇒ "A/D conversion enable/disable setting function"
2. Set "Logging enable/disable setting" to "Enable".  
☞ Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Module Parameter] ⇒ "Application setting" ⇒ "Normal logging function"
3. Set the number of points of the logging data areas to be used by each channel in "Logging data points setting".
4. Set the target data to be logged in "Logging data setting". Set either of "Digital output value" or "Digital operation value" for each channel.
5. Set the cycle to store the logging data in "Logging cycle setting value".
6. Select a unit of the logging cycle setting value in "Logging cycle unit setting".
7. Set a condition to generate a hold trigger in "Level trigger condition setting". Set "Level trigger (Condition: Rise)", "Level trigger (Condition: Fall)", or "Level trigger (Condition: Rise and fall)".
8. Set the judgment count of a level trigger in "Trigger judgment count setting value".
9. Set the number of points of data to be collected in the time period from the occurrence of a hold trigger to when logging stops in "Logging points after trigger".
10. Set a buffer memory address to be monitored for a level trigger in "Trigger data".
11. Set whether to enable or disable the logging read function in "Logging loading enable/disable setting".
12. Set a level where a level trigger operates in "Trigger setting value".

■When setting "Process alarm (Upper limit warning)", "Process alarm (Lower limit warning)", or "Process alarm (Upper limit warning and lower limit warning)" in "Level trigger condition setting"

1. Set "A/D conversion enable/disable setting" to "A/D conversion enable".  
     Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Module Parameter] ⇒ "Basic setting" ⇒ "A/D conversion enable/disable setting function"
2. Set "Warning output setting (Process alarm)" to "Enable".  
     Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Module Parameter] ⇒ "Application setting" ⇒ "Warning output function (Process alarm)"
3. Set values for "Process alarm upper upper limit value", "Process alarm upper lower limit value", "Process alarm lower upper limit value", and "Process alarm lower lower limit value".

Item	Setting range
Process alarm upper upper limit value	-32768 to 32767
Process alarm upper lower limit value	
Process alarm lower upper limit value	
Process alarm lower lower limit value	

4. Set "Logging enable/disable setting" to "Enable".  
     Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Module Parameter] ⇒ "Application setting" ⇒ "Normal logging function"
5. Set the number of points of the logging data areas to be used by each channel in "Logging data points setting".
6. Set the target data to be logged in "Logging data setting". Set either of "Digital output value" or "Digital operation value" for each channel.
7. Set the cycle to store the logging data in "Logging cycle setting value".
8. Select a unit of the logging cycle setting value in "Logging cycle unit setting".
9. Set a condition to generate a hold trigger in "Level trigger condition setting". Set "Process alarm (Upper limit warning)", "Process alarm (Lower limit warning)", or "Process alarm (Upper limit warning and lower limit warning)".
10. Set the judgment count of a level trigger in "Trigger judgment count setting value".
11. Set the number of points of data to be collected in the time period from the occurrence of a hold trigger to when logging stops in "Logging points after trigger".
12. Set whether to enable or disable the logging read function in "Logging loading enable/disable setting".

**■When setting "Disable" for "Level trigger condition setting"**

1. Set "A/D conversion enable/disable setting" to "A/D conversion enable".  
☞ Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Module Parameter] ⇒ "Basic setting" ⇒ "A/D conversion enable/disable setting function"
2. Set "Logging enable/disable setting" to "Enable".  
☞ Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Module Parameter] ⇒ "Application setting" ⇒ "Normal logging function"
3. Set the number of points of the logging data areas to be used by each channel in "Logging data points setting".
4. Set the target data to be logged in "Logging data setting". Set either of "Digital output value" or "Digital operation value" for each channel.
5. Set the cycle to store the logging data in "Logging cycle setting value".
6. Select a unit of the logging cycle setting value in "Logging cycle unit setting".
7. Set "Level trigger condition setting" to "Disable".
8. Set the number of points of data to be collected in the time period from the occurrence of a hold trigger to when logging stops in "Logging points after trigger".
9. Set whether to enable or disable the logging read function in "Logging loading enable/disable setting".

# Logging read function

More than 90000 points of logging data can be stored by transferring the device data to the file register of the CPU module without stopping logging. This function reduces the takt time in a test demanding high-speed sampling.

## Overview of the logging read function

After logging starts, an interrupt request is sent to the CPU module and an interrupt program is executed every time data is logged for the preset number of logging read points.

The A/D converter module has 16 points of interrupt factors (SI) corresponding to the logging reading of each channel.

## Setting interrupt pointers

Assign the interrupt factors (SI) of the A/D converter module and interrupt pointers of the CPU module in the interrupt pointer setting of the engineering tool.

The interrupt function must be set when the logging read function is used.

## Starting the logging read function

To use the logging read function, set 'CH1 Loading interrupt enable/disable setting' (Un\G546) to Enable (0) and set the number of logging points to generate an interrupt in 'CH1 Logging read points setting value' (Un\G547). This function starts when 'Operating condition setting request' (Y9) is turned on and off.

### ■The number of logging read points

Set a value that satisfies the following condition in 'CH1 Logging read points setting value' (Un\G547). (The following N shows an integer value.)

- 'CH1 Logging data points setting' (Un\G536) = 'CH1 Logging read points setting value' (Un\G547)  $\times$  N

When the condition above is not satisfied, the set value is regarded as the value closest to 'CH1 Logging read points setting value' (Un\G547) (but smaller than 'CH1 Logging read points setting value' (Un\G547)) among divisors of the setting value of 'CH1 Logging data points setting' (Un\G536).

### Ex.

Relation of the number of logging read points when 'CH1 Logging data points setting' (Un\G536) is set to 800 (80000 points)

Logging read points setting value	Actual number of logging read points	Logging read points monitor value
10 (1000 points)	1000 points	1000
9 (900 points)	800 points	800
11 (1100 points)	1000 points	1000
65 (6500 points)	5000 points	5000
600 (60000 points)	40000 points	40000

## Data checking method

### ■ Current logging read pointer

- The head pointer read from Logging data area (Un\G10000 to Un\G99999) with the interrupt processing is stored in 'CH1 Current logging read pointer' (Un\G444, Un\G445).
- The default value of 'CH1 Current logging read pointer' (Un\G444, Un\G445) is -1.
- Every time data is logged for the number of data points set in 'CH1 Logging read points monitor value' (Un\G448, Un\G449), a value calculated by the following formula is stored in 'CH1 Current logging read pointer' (Un\G444, Un\G445).

CH1 Current logging read pointer = CH1 Latest pointer - CH1 Logging read points monitor value + 1

### ■ Previous logging read pointer

- The value of 'CH1 Current logging read pointer' (Un\G444, Un\G445) at the timing when the previous read pointer detection interrupt occurs is stored in 'CH1 Previous logging read pointer' (Un\G446, Un\G447).
- The default value of 'CH1 Previous logging read pointer' (Un\G446, Un\G447) is -1.
- 'CH1 Previous logging read pointer' (Un\G446, Un\G447) is used to detect the overlap of the logging read pointer detection interrupt processing.

#### Ex.

The values to be stored in each pointer at every detection interrupt when the logging read detection starts with the setting below

- 'CH1 Logging data points setting' (Un\G536): 100 (10000 points)
- 'CH1 Logging read points setting value' (Un\G547): 10 (1000 points)

Occurrence of read pointer detection interrupts	Buffer memory area		
	Previous logging read pointer	Current logging read pointer	Latest pointer
When an interrupt has not occurred	-1 (default value)	-1 (default value)	0 (default value)
First time	-1	0	999
Second time	0	1000	1999
Third time	1000	2000	2999
:	:	:	:
10th time	8000	9000	9999
11th time	9000	0	999
12th time	0	1000	1999


## Operation

The logging read function starts after interrupt pointers are set and 'Operating condition setting request' (Y9) is turned on and off. This function repeats its operation every time data is logged for the amount equivalent to the logging read points monitor value.

### Ex.

The following figure shows the operation when the logging read function is used under the following conditions.

- A/D conversion-enabled channel: CH1
- 'CH1 Logging read points setting value' (Un\G547): 1 (100 points)



- (1) The timing when the first interrupt processing occurs
- (2) The timing when the second interrupt processing occurs
- (3) The timing when the third interrupt processing occurs
- (4) The CPU module receives a logging read interrupt and read logging data from the logging read start address for the amount equivalent to the logging read points setting value.

## Setting procedure

To use the logging read function, both the logging read function and the interrupt setting must be set.

**1.** Set "Condition target setting" to "Logging read".

→ Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Module Parameter] ⇒ "Interrupt setting"

**2.** Set "A/D conversion enable/disable setting" to "A/D conversion enable".

→ Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Module Parameter] ⇒ "Basic setting" ⇒ "A/D conversion enable/disable setting"

**3.** Set "Logging enable/disable setting" to "Enable".

→ Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Module Parameter] ⇒ "Application setting" ⇒ "Normal logging function"

**4.** Set the target data to be logged in "Logging data setting".

**5.** Set the cycle to store the logging data in "Logging cycle setting value".

**6.** Select a unit of the logging cycle setting value in "Logging cycle unit setting".

**7.** Set "Logging loading enable/disable setting" to "Enable".

**8.** Set the number of logging points to generate a read interrupt in "Logging read points setting value".

## Setting example


**Ex.**

When an interrupt program that is executed when data is logged for 'CH1 Logging read points monitor value' (Un\G448, Un\G449) is assigned to the interrupt pointer I50

- Label settings

Classification	Label name	Description	Device																																				
Module label	RCPU.stSM.bAfter_RUN1_Scan_ON	Turning on for one scan after RUN	SM402																																				
	R60ADH_1.ulnInterruptFactorMask_D[0].0	Interrupt factor mask [1]	U0\G124																																				
	R60ADH_1.ulnInterruptFactorDetectionFlag_D[0].0	Interrupt factor detection flag [1]	U0\G4																																				
	R60ADH_1.ulnInterruptFactorResetRequest_D[0].0	Interrupt factor reset request [1]	U0\G156																																				
	R60ADH_1.stnMonitor_D[0].dThisLoggingLoadPointer_D	CH1 Current logging read pointer	U0\G444, U0\G445																																				
	R60ADH_1.stnMonitor_D[0].udLoggingLoadPointsMonitorValue_D	CH1 Logging read points monitor value	U0\G448, U0\G449																																				
Labels to be defined	Define global labels as shown below:																																						
	<table border="1"> <thead> <tr> <th>Label Name</th> <th>Data Type</th> <th>Class</th> <th>Assign (Device/Label)</th> </tr> </thead> <tbody> <tr> <td>G_udLoggingReadPoints</td> <td>Double Word [Unsigned]/Bit String [32-bit]</td> <td>VAR_GLOBAL</td> <td>D10</td> </tr> <tr> <td>G_udWritePosition</td> <td>Double Word [Unsigned]/Bit String [32-bit]</td> <td>VAR_GLOBAL</td> <td>D20</td> </tr> <tr> <td>G_udSaveFileRegisterMaxValue</td> <td>Double Word [Signed]</td> <td>VAR_GLOBAL</td> <td>D30</td> </tr> <tr> <td>G_dFirstTimeLoggingReadPointIndex</td> <td>Double Word [Unsigned]/Bit String [32-bit]</td> <td>VAR_GLOBAL</td> <td>Z0</td> </tr> <tr> <td>G_udWritePositionIndex</td> <td>Double Word [Unsigned]/Bit String [32-bit]</td> <td>VAR_GLOBAL</td> <td>Z4</td> </tr> <tr> <td>G_wLoggingReadMonitorValuePlusIndex</td> <td>Word [Signed]</td> <td>VAR_GLOBAL</td> <td>U0\G10000Z0</td> </tr> <tr> <td>G_wSaveFileRegisterPlusIndex</td> <td>Word [Signed]</td> <td>VAR_GLOBAL</td> <td>ZROZZ4</td> </tr> <tr> <td>G_udLoggingReadPointsTemporary</td> <td>Double Word [Unsigned]/Bit String [32-bit]</td> <td>VAR_GLOBAL</td> <td>D12</td> </tr> </tbody> </table>	Label Name	Data Type	Class	Assign (Device/Label)	G_udLoggingReadPoints	Double Word [Unsigned]/Bit String [32-bit]	VAR_GLOBAL	D10	G_udWritePosition	Double Word [Unsigned]/Bit String [32-bit]	VAR_GLOBAL	D20	G_udSaveFileRegisterMaxValue	Double Word [Signed]	VAR_GLOBAL	D30	G_dFirstTimeLoggingReadPointIndex	Double Word [Unsigned]/Bit String [32-bit]	VAR_GLOBAL	Z0	G_udWritePositionIndex	Double Word [Unsigned]/Bit String [32-bit]	VAR_GLOBAL	Z4	G_wLoggingReadMonitorValuePlusIndex	Word [Signed]	VAR_GLOBAL	U0\G10000Z0	G_wSaveFileRegisterPlusIndex	Word [Signed]	VAR_GLOBAL	ZROZZ4	G_udLoggingReadPointsTemporary	Double Word [Unsigned]/Bit String [32-bit]	VAR_GLOBAL	D12		
Label Name	Data Type	Class	Assign (Device/Label)																																				
G_udLoggingReadPoints	Double Word [Unsigned]/Bit String [32-bit]	VAR_GLOBAL	D10																																				
G_udWritePosition	Double Word [Unsigned]/Bit String [32-bit]	VAR_GLOBAL	D20																																				
G_udSaveFileRegisterMaxValue	Double Word [Signed]	VAR_GLOBAL	D30																																				
G_dFirstTimeLoggingReadPointIndex	Double Word [Unsigned]/Bit String [32-bit]	VAR_GLOBAL	Z0																																				
G_udWritePositionIndex	Double Word [Unsigned]/Bit String [32-bit]	VAR_GLOBAL	Z4																																				
G_wLoggingReadMonitorValuePlusIndex	Word [Signed]	VAR_GLOBAL	U0\G10000Z0																																				
G_wSaveFileRegisterPlusIndex	Word [Signed]	VAR_GLOBAL	ZROZZ4																																				
G_udLoggingReadPointsTemporary	Double Word [Unsigned]/Bit String [32-bit]	VAR_GLOBAL	D12																																				

- Program example



(0) Enable only the interrupt pointer I50.  
 Initialize 'CH1 Logging read points monitor value' (U0\G448, U0\G449) and the write position of the save destination file register.  
 Set the maximum number of storage data points of the save destination file register.  
 Clear 'Interrupt factor mask [1]' (U0\G124).

(151) Store the value in 'CH1 Current logging read pointer' (U0\G444, U0\G445) in an index register.  
 Store the value in 'CH1 Logging read points monitor value' (U0\G448, U0\G449) in a register.  
 Store the write position of the save destination file register in an index register.  
 Store data for the amount equivalent to the logging read points monitor value from Logging data area (U0\G10000 to U0\G99999) in the save destination file register.  
 Add the points of the logging read points monitor value to the write position of the save destination file register and store the obtained value as the write position for the next logging.

(393) Turn off 'Interrupt factor detection flag [1]' (U0\G4) when Interrupt factor detection flag turns on.  
 Turn on 'Interrupt factor reset request [1]' (U0\G156).

## Saving to a CSV file

The logging data stored in the buffer memory areas can be saved to a CSV file by using function blocks (FBs). The save data is sorted in a time series, where the logging data can be easily checked.

However, function blocks (FBs) can be executed only when the logging operation is stopped. During the logging operation, the execution of function blocks (FBs) is disabled.

### Saving a CSV file

To save a CSV file, an SD memory card is required.

CSV files are saved in an SD memory card installed in the CPU module. CSV files cannot be saved in the built-in memory of the CPU module.

### Saving procedure

1. Check that ON (1) is stored in 'CH1 Logging hold flag' (Un\G409).
2. Execute the function block (FB).



If the execution state of the function block (FB) is maintained, logging data can be saved in the CSV file every time logging stops.

### Data to be saved in a CSV file

The logging data stored in the buffer memory areas is saved.

For how to check the logging data, refer to the following.

☞ Page 77 Checking data when a hold trigger has occurred

### CSV file name

CSV files where data was saved with the function block (FB) are named as follows.

- AD□□△○○○.CSV

□□: First two digits of the start I/O number of the A/D converter module (when the number is displayed in four digits in hexadecimal)

△: Target channel

○○○: Consecutive number\*1

\*1 The maximum number of the consecutive numbers can be set with the input label i\_Max\_Number (maximum number of saving files) of the function block (FB).

#### Ex.

The file name under the following condition is AD453006.CSV.

- Start I/O number of the A/D converter module: 0450H
- Target channel: 3
- Saving to a CSV file: 6th time.

# 1.15 Continuous Logging Function

Simultaneous conversion

Synchronization

This function simultaneously logs digital output values in four channels and continuously transfers logging data to the CPU module without stopping logging. This function continuously collects the data to which the A/D conversion have been performed simultaneously in four channels at a high speed (5 $\mu$ s cycles at a maximum). Thus, when the module is connected with a sensor that has input characteristics of the high-frequency band, this function can collect data for signal analysis.


## Collecting logging data

Logging data is stored in CH1 Logging data area (Un\G10000 to Un\G19999). Each channel has buffer memory areas of 10000 points for storing logging data.

### ■Timing to store data in the buffer memory areas

Logging data is temporarily stored in the module, and when the number of temporarily-stored logging data reaches 5000 points, the data is stored into buffer memory areas. At this time, the buffer memory addresses for the first 5000 points (logging data storage areas (A side)) of CH1 Logging data area (Un\G10000 to Un\G19999) are used. When the number of temporarily-stored logging data reaches 5000 points again after logging data is stored in the logging data storage areas (A side), the buffer memory addresses for the last 5000 points (logging data storage areas (B side)) of CH1 Logging data area (Un\G10000 to Un\G19999) are used.

After that, logging data areas are overwritten with new data by 5000 points as follows.



- (1) Logging data storage areas (A side)
- (2) Logging data storage areas (B side)
- (3) The A-side areas and B-side areas are alternately overwritten with new logging data by 5000 points.

### ■Notification of logging data storage

- After logging data is stored into the logging data storage areas (A side), the value in 'CH1 Continuous logging data A side storage flag' (Un\G474) is changed from Logging data storage in A side not completed (0) to Logging data storage in A side completed (1).
- After logging data is stored into the logging data storage areas (B side), the value in 'CH1 Continuous logging data B side storage flag' (Un\G475) is changed from Logging data storage in B side not completed (0) to Logging data storage in B side completed (1).

### ■Transfer of logging data

Old logging data are overwritten when data more than 10000 points are stored. The data can be transferred into file registers (ZR) of the CPU module with function blocks (FBs). (☞ Page 98 Stopping continuous logging)

## Check items before the start of continuous logging

### ■Operation modes and functions

Before starting continuous logging, check the operation mode and the settings of each function.

Item	Description
Operation mode	Check that the simultaneous conversion mode or inter-module synchronization mode is set.
A/D conversion enable/disable setting function	Check that the A/D conversion is enabled for the channel to be used.
Averaging processing function	Check that the sampling processing or moving average processing is set.
Warning output function (process alarm)	When using the warning output function (process alarm), check that each parameter has been correctly set.
Input signal error detection function	When using the input signal error detection function, check that each parameter has been correctly set.
Interrupt function	When using the interrupt function, check that the continuous logging data storage has been set as the condition target.

When the above functions have been set and an error has occurred, continuous logging cannot be started. In addition, settings cannot be changed during continuous logging. Thus, configure the above settings before starting the continuous logging.

### ■Continuous logging status monitor

Check whether the A/D converter module can start continuous logging or not with 'Continuous logging status monitor' (Un\G61). Check that Continuous logging start request waiting (1) is stored.


### ■Continuous logging cycle setting value

The logging cycle of the continuous logging function is obtained by the following formula: Conversion cycle (5μs) × (Value set in 'Continuous logging cycle setting value' (Un\G280)). Set a desired logging cycle with 'Continuous logging cycle setting value' (Un\G280). Check the set logging cycle with 'CH1 Logging cycle monitor value (μs)' (Un\G452).

## Starting continuous logging

Changing the value of 'Continuous logging start/stop request' (Un\G100) from Stop (0) to Start (1) starts the continuous logging on the set continuous logging cycle. After the continuous logging is started, the update of 'CH1 Digital output value' (Un\G400) performed at every 5 $\mu$ s stops.

At the point when data of 5000 points has been logged, the logging data storage in the continuous logging data storage areas (A side) starts. Subsequently, Logging data storage in A side completed (1) is stored in 'CH1 Continuous logging data A side storage flag' (Un\G474) and the latest value is stored in 'CH1 Digital output value' (Un\G400).



When data of 5000 points has been logged again after logging data of 5000 points was stored in the continuous logging data storage areas (A side), the new data is stored in the continuous logging data storage areas (B side). Subsequently, Logging data storage in B side completed (1) is stored in 'CH1 Continuous logging data B side storage flag' (Un\G475). After that, new logging data is alternately logged into A-side areas → B-side areas → A-side areas ... by 5000 points.



- The time when continuous logging was started is stored in 'CH1 Trigger generation time' (Un\G453 to Un\G457).
- Refer to the value of 'CH1 Digital output value' (Un\G400), which is updated after data storage in the logging data areas is completed, as an indication to check that external devices (such as sensors) are operating.
- When the status of the CPU module is changed from RUN to STOP during continuous logging in the simultaneous conversion mode, the continuous logging continues without being stopped.

## ■Counting the number of logging data points

The value of 'CH1 Number of logging data' (Un\G440, Un\G441) increases by 5000 every time data of 5000 points has been logged.

After the number of data points reaches 720000000, the counter is reset to 0.

**Ex.**

When the value of 'CH1 Number of logging data' (Un\G440, Un\G441) is 719995000 and then data of 5000 points is continuously logged, the value changes as follows: 719995000 → 720000000 → 5000 ...



To calculate the elapsed time of continuous logging, refer to the values of 'CH1 Logging cycle monitor value (μs)' (Un\G452) and 'CH1 Number of logging data' (Un\G440, Un\G441).

- Elapsed time (μs) = Logging cycle monitor value (μs) × Number of logging data

When 'CH1 Logging cycle monitor value (μs)' (Un\G452) is 5 and 'CH1 Number of logging data' (Un\G440, Un\G441) is 720000000 (maximum value), logging for 3600 seconds (1 hour) has been completed.


## Stopping continuous logging

Changing the value of 'Continuous logging start/stop request' (Un\G100) from Start (1) to Stop (0) stops continuous logging.

After continuous logging is stopped, the data that was partially logged is stored in buffer memory areas and the value of 'CH1 Number of logging data' (Un\G440, Un\G441) is updated to the number of points of when the stop request was accepted. In addition, 0 is stored in the data area and later of when the stop request was accepted.

**Ex.**

When a stop request is accepted at the timing of when 3000th data is logged under the condition in which 100000 is already stored in 'CH1 Number of logging data' (Un\G440, Un\G441), 103000 is stored in 'CH1 Number of logging data' (Un\G440, Un\G441). Subsequently, 0 is stored in the 3001th to 5000th logging data areas.



(1) A stop request is accepted.

## ■Restarting continuous logging

To restart continuous logging, change the value of 'Continuous logging start/stop request' (Un\G100) from Stop (0) to Start (1).

Continuous logging is restarted from the beginning of the logging data storage areas. In this case, the values in the following buffer memory areas are initialized to 0.

- 'CH1 Number of logging data' (Un\G440, Un\G441)
- 'CH1 Continuous logging data A side storage flag' (Un\G474)
- 'CH1 Continuous logging data B side storage flag' (Un\G475)

After continuous logging is restarted, values are stored in the logging data storage areas (starting from A side).

The values before the restart of continuous logging remain in CH1 Logging data area (Un\G10000 to Un\G19999). Thus, before referring to the logging data, check that Logging data storage in A side completed (1) has been stored in 'CH1 Continuous logging data A side storage flag' (Un\G474) again.



The value of 'CH1 Trigger generation time' (Un\G453 to Un\G457) is updated to the time when continuous logging was restarted.


# Transfer of continuous logging data

Logging data can be transferred into file registers (ZR) of the CPU module by using following items.

- Function block for continuous logging data transfer (M+R60ADH\_ReadContinuousLogging)
- Interrupt function

## Transfer of data with the function block

The function block for continuous logging data transfer continuously transfers logging data into file registers (ZR) of the CPU module in the storage order of logging data (A side → B side → A side …). Set the number of data sets to be transferred into the CPU module considering the capacity of file registers of the CPU module in use.



(1) A/D converter module (buffer memory areas)

(2) CPU module (file registers (ZR))

(3) The function block transfers data into file registers in the order of ①→②→③→④….



- For the file register capacity setting, refer to the MELSEC iQ-R CPU Module User's Manual (Application).
- For details on the function block for continuous logging data transfer, refer to the MELSEC iQ-R Analog-Digital Converter Module/Digital-Analog Converter Module Function Block Reference.

## ■Program example to transfer data with the function block


Ex.

To start the continuous logging and copy logging data (CH1) for 100000 points and register them in file registers (ZR0 to ZR99999) of the CPU module continuously

- Label settings

Classification	Label name	Description	Device																																								
Module label	R60ADH_1.uContinuousLoggingStartStopRequest_D	Continuous logging start/stop request	U0/G100																																								
Labels to be defined	Define global labels as shown below:																																										
	<table border="1"> <thead> <tr> <th></th> <th>Label Name</th> <th>Data Type</th> <th>Class</th> <th>Assign (Device/Label)</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>G_bContinuousLoggingStartStop</td> <td>Bit</td> <td>VAR_GLOBAL</td> <td>M10</td> </tr> <tr> <td>2</td> <td>G_bReadFbEn</td> <td>Bit</td> <td>VAR_GLOBAL</td> <td>M20</td> </tr> <tr> <td>3</td> <td>G_bReadReady</td> <td>Bit</td> <td>VAR_GLOBAL</td> <td>M21</td> </tr> <tr> <td>4</td> <td>G_bCompleteReadLogging</td> <td>Bit</td> <td>VAR_GLOBAL</td> <td>M22</td> </tr> <tr> <td>5</td> <td>G_udCompleteLogPoints</td> <td>Double Word [Unsigned]/Bit String [32-bit]</td> <td>VAR_GLOBAL</td> <td>D0</td> </tr> <tr> <td>6</td> <td>G_bErrReadLogging</td> <td>Bit</td> <td>VAR_GLOBAL</td> <td>F0</td> </tr> <tr> <td>7</td> <td>G_uContinuousLoggingFbErrCode</td> <td>Word [Unsigned]/Bit String [16-bit]</td> <td>VAR_GLOBAL</td> <td>D2</td> </tr> </tbody> </table>				Label Name	Data Type	Class	Assign (Device/Label)	1	G_bContinuousLoggingStartStop	Bit	VAR_GLOBAL	M10	2	G_bReadFbEn	Bit	VAR_GLOBAL	M20	3	G_bReadReady	Bit	VAR_GLOBAL	M21	4	G_bCompleteReadLogging	Bit	VAR_GLOBAL	M22	5	G_udCompleteLogPoints	Double Word [Unsigned]/Bit String [32-bit]	VAR_GLOBAL	D0	6	G_bErrReadLogging	Bit	VAR_GLOBAL	F0	7	G_uContinuousLoggingFbErrCode	Word [Unsigned]/Bit String [16-bit]	VAR_GLOBAL	D2
	Label Name	Data Type	Class	Assign (Device/Label)																																							
1	G_bContinuousLoggingStartStop	Bit	VAR_GLOBAL	M10																																							
2	G_bReadFbEn	Bit	VAR_GLOBAL	M20																																							
3	G_bReadReady	Bit	VAR_GLOBAL	M21																																							
4	G_bCompleteReadLogging	Bit	VAR_GLOBAL	M22																																							
5	G_udCompleteLogPoints	Double Word [Unsigned]/Bit String [32-bit]	VAR_GLOBAL	D0																																							
6	G_bErrReadLogging	Bit	VAR_GLOBAL	F0																																							
7	G_uContinuousLoggingFbErrCode	Word [Unsigned]/Bit String [16-bit]	VAR_GLOBAL	D2																																							

- Program example



- (0) After the function block for continuous logging data transfer becomes in start status, the continuous logging is started.
- (17) 'G\_bReadFbEn' (M20) is turned on and the function block for continuous logging data transfer is started.  
If data omission occurs during continuous logging because of the processing time of the other scan program or interrupt program, the function block turns on 'G\_bErrReadLogging' (F0), and this stops the read of logging data.
- (297) After the transfer of the logging data for 100000 points is completed, the continuous logging and the function block for continuous logging data transfer are stopped.

## ■Precautions for creating the program

- The function block for continuous logging data transfer reads out the data to the file registers each time 5000 point data sets are stored in the A/D converter module. The approximate processing time of the function block is obtained by adding up the required time of following instruction operations used in the function block: five times of the FROM instruction (1000 points)<sup>\*1</sup>, nine times of the FROM instruction (1 point)<sup>\*1</sup>. If the exact processing time is required, add up the processing time of all instructions used in the function block. For details on the processing time of each instruction used in the function block, refer to MELSEC iQ-R Programming Manual (Instructions, Standard Functions/Function Blocks).
- To prevent logging data omission, create the program where the function block is executed once or more times in 20ms<sup>\*2</sup>. (The processing time of this program must be 20ms<sup>\*2</sup> or shorter including the processing time of the function block.)
- The following table (at the bottom row) shows the formula to calculate the approximate number of channels available for data transfer to the file registers with the function block. Note that this applies to the case when a user do not create any program.

Item	Calculation formula
Processing time (as a guide) of the function block for continuous logging data transfer	$  \begin{aligned}  &= (\text{Processing time of the FROM instruction (1000 points)}) \times (5 \text{ times}) + (\text{Processing time of the FROM instruction (1 point)}) \times (9 \text{ times}) \\  &= 55.6\mu\text{s}^{-1} \times 5 + 4.3\mu\text{s}^{-1} \times 9 \\  &= 316.7\mu\text{s}  \end{aligned}  $
Number of channels (as a guide) available for data read	$  \begin{aligned}  &= 20\text{ms}^{-2} \div (\text{Processing time (as a guide) of the function block for continuous logging data transfer}) \\  &= 20\text{ms} \div 316.7\mu\text{s} \\  &= \text{Approx. 63 channels}  \end{aligned}  $

\*1 Maximum processing time of each instruction is used for the calculation. (MELSEC iQ-R Programming Manual (Instructions, Standard Functions/Function Blocks))

\*2 This value is for when the continuous logging is executed every 5 $\mu$ s cycle. When using the continuous logging cycle different from 5 $\mu$ s, apply the value obtained from T(ms) below for the calculation of the number of channels.

$$T(\text{ms}) = (\text{Continuous logging cycle } (\mu\text{s}) \times 5000 \text{ (points)}) \div 1000 - 5 \text{ (ms)}$$

The calculation result of 63 channels, which is the number of channels available for data read, is a value for the case when the program consists of only the function block for continuous logging data transfer. If the other processing is added to the program, or another program is added, the number of channels available for the continuous logging decreases. Please consider an actual application and configure the system.

## Transfer of data with the interrupt function

ON of Continuous logging data storage can be set as an interrupt factor of the interrupt function.

When the above item is set, the interrupt program is executed on the timing when the logging data for 5000 points are stored in a buffer memory area. Thus, logging data can be transferred into file registers (ZR) without depending on the scan time.

For the interrupt program, do not use the function block for continuous logging data transfer because the function block does not operate properly by doing so.

### ■Program example to transfer data with the interrupt function

#### Ex.

To start the continuous logging and copy logging data (CH1) for 100000 points and register them in file registers (ZR0 to ZR99999) of the CPU module continuously

- Label settings

Classification	Label name	Description	Device																																																							
Module label	RCPU.stSM.bAfter_RUN1_Scan_ON	Turning on for one scan after RUN	SM402																																																							
	R60ADH_1.ulnInterruptFactorDetectionFlag_D[0].0	Interrupt factor detection flag [1]	U0\G4.0																																																							
	R60ADH_1.uContinuousLoggingStartStopRequest_D.0	Continuous logging start/stop request	U0\G100.0																																																							
	R60ADH_1.ulnInterruptFactorMask_D[0].0	Interrupt factor mask [1]	U0\G124.0																																																							
	R60ADH_1.ulnInterruptFactorResetRequest_D[0].0	Interrupt factor reset request [1]	U0\G156.0																																																							
	R60ADH_1.stnControl_D[0].wContinuousLoggingASideStorageFlag_D.0	CH1 Continuous logging data A side storage flag	U0\G474.0																																																							
	R60ADH_1.stnControl_D[0].wContinuousLoggingBSideStorageFlag_D.0	CH1 Continuous logging data B side storage flag	U0\G475.0																																																							
Labels to be defined	Define global labels as shown below:	<table border="1"> <thead> <tr> <th></th> <th>Label Name</th> <th>Data Type</th> <th>Class</th> <th>Assign (Device/Label)</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>G_bErrorDetection</td> <td>Bit</td> <td>VAR.GLOBAL</td> <td>▼ F0</td> </tr> <tr> <td>2</td> <td>G_udWritePosition</td> <td>Double Word [Unsigned]/Bit String [32-bit]</td> <td>VAR.GLOBAL</td> <td>▼ D20</td> </tr> <tr> <td>3</td> <td>G_udSaveFileRegisterMaxValue</td> <td>Double Word [Unsigned]/Bit String [32-bit]</td> <td>VAR.GLOBAL</td> <td>▼ D30</td> </tr> <tr> <td>4</td> <td>G_udWritePositionIndex</td> <td>Double Word [Unsigned]/Bit String [32-bit]</td> <td>VAR.GLOBAL</td> <td>▼ Z4</td> </tr> <tr> <td>5</td> <td>G_wLoggingReadSideA</td> <td>Word [Signed]</td> <td>VAR.GLOBAL</td> <td>▼ U0\G1 0000</td> </tr> <tr> <td>6</td> <td>G_wLoggingReadSideB</td> <td>Word [Signed]</td> <td>VAR.GLOBAL</td> <td>▼ U0\G1 5000</td> </tr> <tr> <td>7</td> <td>G_wSaveFileRegisterPlusIndex</td> <td>Word [Signed]</td> <td>VAR.GLOBAL</td> <td>▼ ZR0ZZ4</td> </tr> <tr> <td>8</td> <td>G_bContinuousLoggingStartStop</td> <td>Bit</td> <td>VAR.GLOBAL</td> <td>▼ M0</td> </tr> <tr> <td>9</td> <td>G_udWriteEndPosition</td> <td>Double Word [Signed]</td> <td>VAR.GLOBAL</td> <td>▼ D40</td> </tr> <tr> <td>10</td> <td>G_udWriteStartPosition</td> <td>Double Word [Signed]</td> <td>VAR.GLOBAL</td> <td>▼ D10</td> </tr> </tbody> </table>			Label Name	Data Type	Class	Assign (Device/Label)	1	G_bErrorDetection	Bit	VAR.GLOBAL	▼ F0	2	G_udWritePosition	Double Word [Unsigned]/Bit String [32-bit]	VAR.GLOBAL	▼ D20	3	G_udSaveFileRegisterMaxValue	Double Word [Unsigned]/Bit String [32-bit]	VAR.GLOBAL	▼ D30	4	G_udWritePositionIndex	Double Word [Unsigned]/Bit String [32-bit]	VAR.GLOBAL	▼ Z4	5	G_wLoggingReadSideA	Word [Signed]	VAR.GLOBAL	▼ U0\G1 0000	6	G_wLoggingReadSideB	Word [Signed]	VAR.GLOBAL	▼ U0\G1 5000	7	G_wSaveFileRegisterPlusIndex	Word [Signed]	VAR.GLOBAL	▼ ZR0ZZ4	8	G_bContinuousLoggingStartStop	Bit	VAR.GLOBAL	▼ M0	9	G_udWriteEndPosition	Double Word [Signed]	VAR.GLOBAL	▼ D40	10	G_udWriteStartPosition	Double Word [Signed]	VAR.GLOBAL	▼ D10
	Label Name	Data Type	Class	Assign (Device/Label)																																																						
1	G_bErrorDetection	Bit	VAR.GLOBAL	▼ F0																																																						
2	G_udWritePosition	Double Word [Unsigned]/Bit String [32-bit]	VAR.GLOBAL	▼ D20																																																						
3	G_udSaveFileRegisterMaxValue	Double Word [Unsigned]/Bit String [32-bit]	VAR.GLOBAL	▼ D30																																																						
4	G_udWritePositionIndex	Double Word [Unsigned]/Bit String [32-bit]	VAR.GLOBAL	▼ Z4																																																						
5	G_wLoggingReadSideA	Word [Signed]	VAR.GLOBAL	▼ U0\G1 0000																																																						
6	G_wLoggingReadSideB	Word [Signed]	VAR.GLOBAL	▼ U0\G1 5000																																																						
7	G_wSaveFileRegisterPlusIndex	Word [Signed]	VAR.GLOBAL	▼ ZR0ZZ4																																																						
8	G_bContinuousLoggingStartStop	Bit	VAR.GLOBAL	▼ M0																																																						
9	G_udWriteEndPosition	Double Word [Signed]	VAR.GLOBAL	▼ D40																																																						
10	G_udWriteStartPosition	Double Word [Signed]	VAR.GLOBAL	▼ D10																																																						

- Interrupt setting

Setting Item				
No.	Condition target setting	Condition target channel setting	Interrupt factor transaction setting	Interrupt pointer
1	Continuous logging data storage	CH1	Interrupt reissue requests	I50
2	Disable	All CH specification	Interrupt reissue requests	
3	Disable	All CH specification	Interrupt reissue requests	
4	Disable	All CH specification	Interrupt reissue requests	
5	Disable	All CH specification	Interrupt reissue requests	
6	Disable	All CH specification	Interrupt reissue requests	
7	Disable	All CH specification	Interrupt reissue requests	
8	Disable	All CH specification	Interrupt reissue requests	
9	Disable	All CH specification	Interrupt reissue requests	
10	Disable	All CH specification	Interrupt reissue requests	
11	Disable	All CH specification	Interrupt reissue requests	
12	Disable	All CH specification	Interrupt reissue requests	
13	Disable	All CH specification	Interrupt reissue requests	
14	Disable	All CH specification	Interrupt reissue requests	
15	Disable	All CH specification	Interrupt reissue requests	
16	Disable	All CH specification	Interrupt reissue requests	

- Scan program



(0) The settings are configured as follows by the contact turning on for one scan after RUN.


- 'G\_udWriteStartPosition' (D10) is set to 0 so that ZR0 is set as the start position of the save destination file register.
- 'G\_udWritePosition' (D20) is set to a value in 'G\_udWriteStartPosition' (D10) so that the write position of the file register is initialized.
- The maximum number of storage data points of the save destination file register is set to 100000.

(147) 'G\_bContinuousLoggingStartStop' (M0) is turned on at the desired timing to start the continuous logging, and the continuous logging is started. In addition, 'G\_bContinuousLoggingStartStop' (M0) is turned off at the desired timing to stop the continuous logging, and the continuous logging is stopped.

(165) After the continuous logging is stopped, the operations are performed as follows.

- The write position of the file register where the continuous logging is stopped is stored in 'G\_udWriteEndPosition' (D40).
- 'G\_udWritePosition' (D20) is set to a value in 'G\_udWriteStartPosition' (D10) so that the write position of the file register is initialized.

- Interrupt program



(210) An interrupt occurs each time logging data for 5000 points are stored in a buffer memory area. In addition, if both 'CH1 Continuous logging data A side storage flag' (Un\G474) and 'CH1 Continuous logging data B side storage flag' (Un\G475) are on, it is regarded as a logging data omission and 'G\_bErrorDetection' (F0) is turned on. In such a case, the logging data transfer is stopped.

(269) The logging data are transferred to the file registers. The 5000 point logging data sets are transferred per interrupt. The transfer is repeated until the data are transferred to ZR99999.

(506) When the transfer of 100000 point logging data sets (ZR0 to ZR99999) is completed, 'G\_udWritePosition' (D20) is set to a value in 'G\_udWriteStartPosition' (D10).

(533) 'Interrupt factor detection flag [1]' (Un\G4) is turned off and 'Interrupt factor reset request [1]' (Un\G156) is turned on so that an interrupt functions properly when an interrupt condition is satisfied next time.

## ■Precautions for creating the program

- Each time 5000 point logging data sets are stored in the A/D converter module, an interrupt program is executed and the data are transferred to the file registers. The approximate instruction processing time of the interrupt program is obtained by adding up the processing time of instructions accessing to the buffer memory areas in the interrupt program (equivalent to a value of "five times of FROM instruction (1000 points)<sup>\*1</sup> + eight times of FROM instruction (1 point)<sup>\*1</sup> + three times of TO instruction (1 point)<sup>\*1</sup>") and the processing time of the IRET instruction. If the exact instruction processing time is required, add up the processing time of all instructions used in the interrupt program. For details on the processing time of each instruction used in the interrupt program, refer to MELSEC iQ-R Programming Manual (Instructions, Standard Functions/Function Blocks).
- The approximate processing time of the interrupt program is obtained by adding both the interrupt overhead time and the refresh processing time (when the refresh processing is set) at the interrupt execution to the instruction processing time of the interrupt program. The interrupt overhead time and the refresh processing time at the interrupt execution vary depending on the parameter settings of the CPU module. For details, refer to MELSEC iQ-R CPU Module User's Manual (Application).
- To prevent logging data omission, create the program so that a series of processing of the interrupt program (from the start to the completion) takes 20ms<sup>\*2</sup> or shorter after an interrupt factor (storage of 5000 point continuous logging data sets) occurs.
- The following table (at the bottom row) shows the formula to calculate the approximate number of channels available for data transfer to the file registers with the interrupt program. Note that this applies to the case when a user do not create any program. (The calculation is for when the interrupt overhead time is 20.6μs and the refresh processing time at the interrupt execution is 0μs.)

Item	Calculation formula
Instruction processing time (as a guide) of the interrupt program	$  \begin{aligned}  &= (\text{Processing time of the FROM instruction (1000 points)}) \times (5 \text{ times}) + (\text{Processing time of the FROM instruction (1 point)}) \times (8 \text{ times}) + (\text{Processing time of the TO instruction (1 point)}) \times (3 \text{ times}) \\  &\quad + (\text{Processing time of the IRET instruction}) \times (1 \text{ time}) \\  &= 55.6\mu\text{s}^{-1} \times 5 + 4.3\mu\text{s}^{-1} \times 8 + 2.7\mu\text{s}^{-1} \times 3 + 2.2\mu\text{s}^{-1} \times 1 \\  &= 322.7\mu\text{s}  \end{aligned}  $
Processing time (as a guide) of the interrupt program	$  \begin{aligned}  &= (\text{Instruction processing time (as a guide) of the interrupt program}) + (\text{Interrupt overhead time}) \\  &\quad + (\text{Refresh processing time at the interrupt execution}) \\  &= 322.7\mu\text{s} + 20.6\mu\text{s} + 0\mu\text{s} \\  &= 343.3\mu\text{s}  \end{aligned}  $
Number of channels (as a guide) available for data read	$  \begin{aligned}  &= 20\text{ms}^{-2} \div (\text{Processing time (as a guide) of the interrupt program}) \\  &= 20\text{ms} \div 343.3\mu\text{s} \\  &= \text{Approx. 58 channels}  \end{aligned}  $

\*1 This value indicates the maximum processing time of each instruction. (Refer to MELSEC iQ-R Programming Manual (Instructions, Standard Functions/Function Blocks))

\*2 This value is for when the continuous logging is executed every 5μs cycle. When using the continuous logging cycle different from 5μs, apply the value obtained from T(ms) below for the calculation of the number of channels.

$$T(\text{ms}) = (\text{Continuous logging cycle } (\mu\text{s}) \times 5000 \text{ (points)}) \div 1000 - 5 \text{ (ms)}$$

The calculation result of 58 channels, which is the number of channels available for data read, is a value for the case when the program consists of only the interrupt program to transfer logging data. If a program or processing other than the interrupt program to transfer logging data is added, the number of channels available for the continuous logging decreases. Please consider an actual application and configure the system.

## Saving continuous logging data

The logging data stored in the file registers (ZR) can be written into an SD memory card as a CSV file and checked with spreadsheet software.

Use the SP.FWRITE instruction to write the data into the SD memory card. For details on the SP.FWRITE instruction, refer to the following.

 MELSEC iQ-R Programming Manual (Instructions, Standard Functions/Function Blocks)

# Continuous logging when the inter-module synchronization function is used

When the inter-module synchronization function is used, continuous logging can be used. The conversion cycle of continuous logging of when the inter-module synchronization function is used depends on the oversampling mode enable/disable setting.

## Oversampling

Oversampling is to take multiple samples using one inter-module synchronization cycle as a trigger. When the oversampling mode is enabled, data can be logged on a constant conversion cycle ( $5\mu\text{s}/4\text{CH}$ ) without being affected by the longer inter-module synchronization cycle if the cycle is set to match with other slower modules.


When the conversion cycle same with the inter-module synchronization cycle is adequate, disable the oversampling mode.

When a fast conversion cycle is required for data analysis, enable the oversampling mode.

### When oversampling is disabled

The inter-module synchronization cycle is used as a trigger to take a sample of an analog input value. The conversion cycle becomes equal to the inter-module synchronization cycle and an A/D conversion value is logged by 1 point at every inter-module synchronization cycle.

Because the inter-module synchronization cycle is used as trigger to execute the A/D conversion in all channels, the logging timing of each A/D converter module is uniform.




### Point

During inter-module synchronization, the continuous logging starts at the second inter-module synchronization cycle after the continuous logging start request is set.

## ■When oversampling is enabled

An inter-module synchronization cycle is used as a trigger to sample an analog value at 5μs cycle. The conversion cycle is fixed to 5μs and A/D conversion values are logged by (Inter-module synchronization cycle/5μs) points.



### Ex.

When the inter-module synchronization cycle is 1ms, data of 200 points is logged in an inter-module synchronization cycle.

### Point

When the oversampling mode is enabled, the inter-module synchronization cycle is used as a trigger to start the conversion in all channels in the same way as when the oversampling mode is disabled. However, after the trigger of the inter-module synchronization cycle, A/D conversion is executed according to the cycle based on the clock of each A/D converter module. Thus, a time lag in the nanosecond range is generated in every conversion cycle due to the differences of modules (crystal frequency deviation) or the ambient temperature. But this does not affect the conversion cycle because the conversion cycle timing is corrected by using the inter-module synchronization cycle as a trigger.

## ■Setting procedure

The oversampling mode can be set only with an engineering tool. The default value is "Disable".

### 1. Set "Oversampling mode".


Navigation window  $\Rightarrow$  [Parameter]  $\Rightarrow$  [Module Information]  $\Rightarrow$  Module model name  $\Rightarrow$  [Module Parameter]  $\Rightarrow$  "Application setting"  $\Rightarrow$  "Oversampling mode"

## Operation

The following shows the operation of the continuous logging function of when the inter-module synchronization function is used. The operation described in this section is the one of when oversampling is enabled.

### ■Starting continuous logging

A continuous logging start request is sent at every inter-module synchronization cycle. Thus, when the value in 'Continuous logging start/stop request' (Un\G100) is changed in the inter-module synchronous interrupt program, the continuous logging is started or stopped at the timing of the next inter-module synchronization cycle. To check whether the module is executing continuous logging or not, check that 'Continuous logging status monitor' (Un\G61) is set to Continuous logging in process (2).



### ■Operation of continuous logging in process

Once continuous logging is started, in the channel where A/D conversion is enabled, A/D conversion values are logged at every conversion cycle of the oversampling mode. The logged values are not immediately reflected into the buffer memory, but stored in the buffer memory in the next inter-module synchronization cycle. The latest A/D conversion value, which was converted in the inter-module synchronization cycle, is stored in 'CH1 Synchronization digital output value' (Un\G9500) regardless of whether continuous logging has stopped or is in process.


In addition, the values of 'CH1 Continuous logging data A side storage flag' (Un\G474) and 'CH1 Continuous logging data B side storage flag' (Un\G475) are changed from 0 to 1 every time data of 5000 points are stored in the buffer memory in the same way as the continuous logging executed when the inter-module synchronization processing is asynchronous.



When the status of the CPU module is changed from RUN to STOP while continuous logging is in progress in the inter-module synchronization processing, the inter-module synchronization stops and continuous logging also automatically stops. After that, if the status of the CPU module is changed from STOP to RUN, the A/D conversion is restarted but continuous logging is not restarted. To execute continuous logging again, change the value of 'Continuous logging start/stop request' (Un\G100) from Stop (0) to Start (1).

## ■Stopping continuous logging

A continuous logging stop request is sent at every inter-module synchronization cycle in the same way as when continuous logging is started. Thus, logged data is stored in the buffer memory in the next inter-module synchronization cycle after the continuous logging stop request is accepted. After the data has been stored, 'Continuous logging status monitor' (Un\G61) is set to Continuous logging start request waiting (1).



# 1.16 Interrupt Function

Low speed

Simultaneous conversion

Synchronization

This function executes interrupt programs of the CPU module when an interrupt factor such as a warning output or an input signal error is detected.

For the A/D converter module, the maximum number of available interrupt pointers is 16 per module.

## Operation

### ■ Detecting an interrupt factor

An interrupt factor can be detected by setting "Interrupt setting" of the module parameter and by setting 'Interrupt factor mask [n]' (Un\G124 to Un\G139) to Mask clear (Interrupt used) (1) in advance. When an interrupt factor occurs, an interrupt request is sent to the CPU module at the same time as 'Interrupt factor detection flag [n]' (Un\G4 to Un\G19) is turned to Interrupt factor (1).

### ■ How to reset an interrupt factor

When Reset request (1) is set in 'Interrupt factor reset request [n]' (Un\G156 to Un\G171) corresponding to the interrupt factor, the specified interrupt factor is reset and the value of 'Interrupt factor detection flag [n]' (Un\G4 to Un\G19) changes to No interrupt factor (0).

## Setting procedure

To use the interrupt function, set "Condition target setting", "Condition target channel setting", "Interrupt factor transaction setting", and "Interrupt pointer" with the engineering tool. After completing the settings, write the project to enable the settings.

 Navigation window  $\Rightarrow$  [Parameter]  $\Rightarrow$  [Module Information]  $\Rightarrow$  Module model name  $\Rightarrow$  [Module Parameter]  $\Rightarrow$  "Interrupt setting"

Item	Description
Condition target setting	Select a factor of the target for the interrupt detection.
Condition target channel setting	Select a target channel when the condition target setting for the interrupt detection is channel specification.
Interrupt factor transaction setting	Set an interrupt request for when an interrupt factor occurs while the same interrupt factor has been detected.
Interrupt pointer	Specify the number of an interrupt pointer that is started at the detection of an interrupt factor.

### ■ Condition target setting

Select a factor of the condition target setting for the interrupt detection.

Setting value	Description	Available operation mode
Disable	No interrupt is detected.	<p>Low speed</p> <p>Simultaneous conversion</p> <p>Synchronization</p>

Setting value	Description	Available operation mode
Error flag	An interrupt is detected at the timing of when 'Error flag' (XF) turns on.	Low speed
Warning output flag (Process alarm)	An interrupt is detected at the timing of when Warning output flag (Process alarm) turns on (A channel is specified.).	Synchronization
Warning output flag (Rate alarm)	An interrupt is detected at the timing of when Warning output flag (Rate alarm) turns on (A channel is specified.).	
Input signal error detection flag	An interrupt is detected at the timing of when Input signal error detection flag turns on (A channel is specified.).	
A/D conversion completed	An interrupt is detected every time A/D conversion is completed (A channel is specified.).	
Logging hold flag	An interrupt is detected at the timing of when Logging hold flag turns on (A channel is specified.).	
Logging read	The fact that data for the number of logging read points has been logged is detected (A channel is specified.).	
Continuous logging data storage	An interrupt is detected every time data of 5000 points is stored during continuous logging.	Simultaneous conversion

When a value out of the setting range for each operation mode is set, a condition target setting range error (error code: 181△H) occurs.

### ■Condition target channel setting

Select a target channel when the condition target setting for the interrupt detection is channel specification.

## ■Interrupt factor transaction setting

Set an interrupt request for when an interrupt factor occurs while the same interrupt factor has been detected.

- When "Interrupt reissue requests" has been set and the same interrupt factor occurs while the interrupt factor has been detected, an interrupt request is sent to the CPU module again.
- When "No interrupt reissue requests" has been set and the same interrupt factor occurs while the interrupt factor has been detected, an interrupt request is not sent to the CPU module.

## ■Interrupt pointer

Specify the number of an interrupt pointer that is started when an interrupt factor is detected. For details on the interrupt pointers, refer to the following.

 MELSEC iQ-R CPU Module User's Manual (Application)

## Precautions

- When 'Condition target setting [n]' (Un\G232 to Un\G247) is Disable (0), an interrupt request is not sent to the CPU module.
- If an interrupt factor occurs when 'Interrupt factor mask [n]' (Un\G124 to Un\G139) is Mask (Interrupt unused) (0), an interrupt request is not sent to the CPU module though 'Interrupt factor detection flag [n]' (Un\G4 to Un\G19) is turned to Interrupt factor (1).
- To reset the interrupt factor, set Reset request (1) until 'Interrupt factor detection flag [n]' (Un\G4 to Un\G19) changes to No interrupt factor (0).
- Resetting interrupt factors is executed only when 'Interrupt factor reset request [n]' (Un\G156 to Un\G171) changes from No reset request (0) to Reset request (1).
- Multiple interrupt pointers can share the same setting of 'Condition target setting [n]' (Un\G232 to Un\G247). When multiple interrupt pointers have shared the same setting of 'Condition target setting [n]' (Un\G232 to Un\G247) and interrupts occur, interrupt programs are executed in order of priority of the interrupt pointers. For the priority of the interrupt pointers, refer to the following.

 MELSEC iQ-R CPU Module User's Manual (Application)

- When All channels (0) is set for 'Condition target channel setting [n]' (Un\G264 to Un\G279) and an interrupt detection target is set for 'Condition target setting [n]' (Un\G232 to Un\G247) of each channel, the interrupt requests that have the same interrupt factor are sent to the CPU module if warnings are issued in multiple channels. In this case, the CPU module executes multiple interrupt programs and judges that the programs cannot be normally completed with the scan monitoring function, and a CPU module error may occur. When a CPU error occurs, refer to the following.

 MELSEC iQ-R CPU Module User's Manual (Application)

## Setting example

### Ex.

To execute the interrupt program (I51) when an error occurs in any channel


- Parameter setting

Set "Interrupt setting" of Module Parameter as follows.

No.	Condition target setting	Condition target channel setting	Interrupt pointer
2	Error flag	All CH specification	I51

- Label settings

Classification	Label name	Description	Device										
Module label	RCPU.stSM.bAlways_ON	Always ON	SM400										
	RCPU.stSM.bAfter_RUN1_Scan_ON	Turning on for one scan after RUN	SM402										
	R60ADH_1.unInterruptFactorMask_D[1].0	Interrupt factor mask	U0\G125.0										
	R60ADH_1.unInterruptFactorResetRequest_D[1].0	Interrupt factor reset request	U0\G157.0										
Labels to be defined	Define global labels as shown below:												
	<table border="1"> <thead> <tr> <th></th> <th>Label Name</th> <th>Data Type</th> <th>Class</th> <th>Assign (Device/Label)</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>G_bErrorDetection</td> <td>Bit</td> <td>... \VAR_GLOBAL</td> <td>F0</td> </tr> </tbody> </table>		Label Name	Data Type	Class	Assign (Device/Label)	1	G_bErrorDetection	Bit	... \VAR_GLOBAL	F0		
	Label Name	Data Type	Class	Assign (Device/Label)									
1	G_bErrorDetection	Bit	... \VAR_GLOBAL	F0									



(0) Only the interrupt pointer I51 is enabled.  
 (78) 'Interrupt factor reset request [2]' (U0\G157) is turned on.  
 The processing of when an error is detected is performed.

# 1.17 Inter-Module Synchronization Function

## Synchronization

The operations of multiple A/D converter modules and the timing of A/D conversion of all channels can be synchronized. An A/D converter module uses the inter-module synchronization signal as a trigger to simultaneously execute the A/D conversion of all channels. The A/D conversion value stored in the buffer memory before the execution of the inter-module synchronous interrupt program allows users to refer to the A/D conversion value of the latest synchronization cycle.

## Setting procedure

### ■Setting the system parameter

To use the inter-module synchronization function, configure the setting of the inter-module synchronization function in "System Parameter" to set the A/D converter module as the target module of the inter-module synchronization.

The following shows a setting procedure example.

 Navigation window  $\Rightarrow$  [Parameter]  $\Rightarrow$  [System Parameter]  $\Rightarrow$  "Inter-module Synchronous Setting"

"I/O Assignment" window

Slot	Module Name	Module Status Setting	Points	Start XY

"Inter-module Synchronous Setting" window

Item	Setting
Inter-module Synchronous Setting	
Use Inter-module Synchronization Function in System	Use

"Select the Synchronous Target Unit" window

Slot	Module Name	Management	Master/Local	Setting

"Inter-module Synchronous Setting" window

Item	Setting
Inter-module Synchronous Setting	
Use Inter-module Synchronization Function in System	Use
Select Synchronous Target Unit between Unit	<Detailed Setting>
Fixed Scan Interval Setting of Inter-module Synchronization	
0.05ms Unit Setting	Set
Fixed Scan Interval Setting (Not set in 0.05ms unit)	0.888ms
Fixed Scan Interval Setting (Set in 0.05ms unit)	0.50 ms

1. Set the I/O assignment appropriate to the system in use.

2. Select "Use" for "Use Inter-module Synchronization Function in System".

3. Double-click "Detailed Setting" of "Select Synchronous Target Unit between Unit".

4. Set "Synchronize" for the A/D converter module.

5. Set the inter-module synchronization cycle in "Fixed Scan Interval Setting of Inter-module Synchronization".

6. Write the system parameter into the CPU module and change the status of the CPU module from RESET to RUN. When the inter-module synchronization function is enabled, whether the synchronization is in process or the synchronization is stopped can be monitored with 'Synchronization status monitor' (Un\G9600).

## ■Setting the module parameter

Set the module parameter to use the inter-module synchronization function.

The following shows a setting procedure example.

Navigation window  $\Rightarrow$  [Parameter]  $\Rightarrow$  [Module Information]  $\Rightarrow$  Module model name  $\Rightarrow$  [Module Parameter]  $\Rightarrow$  "Basic setting"

"Module Parameter" window

Item	CH1	CH2	CH3	CH4
Range switching function				
Input range setting	4 to 20mA	4 to 20mA	4 to 20mA	4 to 2
Operation mode setting function				
Operation mode setting	Normal mode(low speed:20μs/CH)			

1. The setting of "Input range setting" is the same as the one for the normal mode. Select an appropriate input range.
2. Select "Normal mode (low speed: 20μs/CH)" or "Normal mode (medium speed: 10μs/CH" for "Operation mode setting".
3. Write the module parameter into the CPU module and change the status of the CPU module from RESET to RUN.

## ■Interrupt program setting

When the inter-module synchronization function is used, the A/D conversion values acquired on the inter-module synchronization cycle are stored in "CH1 Synchronization digital output value" (Un\G9500).

Read the value of 'CH1 Synchronization digital output value' (Un\G9500) with an interrupt program.

The interrupt program contains the interrupt pointer (I) to the IRET instruction set with the program, and the program is executed on the cycle set by a customer. The A/D converter module refreshes 'CH1 Synchronization digital output value' (Un\G9500) at the timing when the interrupt program is executed.

The following shows how to set an interrupt program.

Navigation window  $\Rightarrow$  [Parameter]  $\Rightarrow$  Model name of the CPU module  $\Rightarrow$  [CPU Parameter]  $\Rightarrow$  "Program Setting" "CPU Parameter" window

Item	Setting
Program Setting	<a href="#">Detailed Setting</a>

"Program Setting" window

Execute Order	Program Name	Execution Type		Refresh Group Setting
		Type	Detailed Setting Information	
1	MAIN	Scan	(Do not Set)	
2	DOUKI	Event	Bit ON:Do Not Clear:	(Do not Set)

"Event Execution Type Detailed Setting" window

Item	Setting
Trigger Type	Interrupt Occurrence
	I44

1. Double-click "Detailed Setting" of "Program Setting".
2. Set an interrupt program name for "Program Name".
3. Set "Event" for "Type" of "Execution Type".
4. Double-click "Detailed Setting Information" of "Execution Type".
5. Set "Interruption Occurrence" for "Trigger Type".
6. Set "I44" for "Interruption Occurrence".
7. Create an interrupt program.

The interrupt program is executed at every inter-module synchronization cycle set by a customer. For details on interrupt programs, refer to the following.

 MELSEC iQ-R CPU Module User's Manual (Application)

## ■Changing the module setting

- To write the default values with a program without using the module parameter or to change the parameter setting during module operation, the program that writes setting values and turns on and off Operating condition setting request (Y9) is required to enable the setting.
- When Operating condition setting request (Y9) is turned on and off to enable the setting, 0 is stored in 'CH1 Synchronization digital output value' (Un\G9500) of the channel where A/D conversion disable is set.

### Point

When the A/D converter module is set as the synchronization target, the I/O setting is refreshed before and after the execution of the synchronous interrupt program. Thus, use the direct access (DY) to immediately reflect the setting into the A/D converter module by turning on and off Operating condition setting request (Y9).

## Operation example

When the inter-module synchronization function is used, control is basically performed with the inter-module synchronous interrupt program (I44).

To improve the synchronization performance of the entire system, the dedicated refresh target data is used when the inter-module synchronous interrupt program is executed. The following shows the refresh target data.

- 'CH1 Synchronization digital output value' (Un\G9500)
- 'Synchronization status monitor' (Un\G9600)

### Point

When the inter-module synchronization function is used, the buffer memory areas dedicated for reading, such as 'CH1 Maximum value' (Un\G404), are updated based on 'CH1 Synchronization digital output value' (Un\G9500).


However, when the inter-module synchronous interrupt program is executed, only 'CH1 Synchronization digital output value' (Un\G9500) and 'Synchronization status monitor' (Un\G9600) are updated. Thus, when 'CH1 Synchronization digital output value' (Un\G9500) is compared with 'CH1 Maximum value' (Un\G404) in the inter-module synchronous interrupt program, the values of them do not match.

When creating the program that refers to the data other than 'CH1 Synchronization digital output value' (Un\G9500) and 'Synchronization status monitor' (Un\G9600) in the inter-module synchronous interrupt program, note the descriptions above.

## ■Basic operation


The following shows the basic operation of when the settings have been correctly configured and two A/D converter modules operate in synchronization with each other.

- Synchronized operation flow of when the status of the CPU module is changed from STOP to RUN




- (1) The synchronization of the modules is started at the timing of the next inter-module synchronization cycle after the status of the CPU module is changed from STOP to RUN.
- (2) When the CPU module is synchronized, A/D conversion is executed in all channels at the start timing of the inter-module synchronization cycle.
- (3) The digital output value that was converted from an analog value immediately before the next timing of the inter-module synchronization cycle is stored in 'CH1 Synchronization digital output value' (Un\G500).
- (4) The synchronous interrupt program is not executed in the first inter-module synchronization cycle after the CPU module is set to RUN.
- (5) The program is executed at the start timing of the second inter-module synchronization cycle.

- Synchronized operation flow of when the CPU module is in the RUN state



- Synchronized operation flow of when the status of the CPU module is changed from RUN to STOP




(1) When the CPU module is in the STOP state, the value of 'CH1 Synchronization digital output value' (Un\G9500) is not updated.  
(2) When the CPU module is in the STOP state, the synchronous interrupt program is not executed.

## ■Synchronous conversion processing in the A/D converter module

The A/D converter module stores the latest A/D conversion value into 'CH1 Synchronization digital output value' (Un\G9500) within 5μs between the start timing of an inter-module synchronization cycle and the execution timing of the inter-module synchronous interrupt program.

The following shows the A/D conversion processing example of when A/D conversion is enabled in all channels.




(1) Time between the start timing of an inter-module synchronization cycle and the execution timing of the interrupt program (5μs)  
(2) The A/D converter module simultaneously executes A/D conversion in all channels using the timing of the inter-module synchronization cycle as a trigger and stores results in the following buffer memory areas.  
• 'CH1 Synchronization digital output value' (Un\G9500)  
• 'CH2 Synchronization digital output value' (Un\G9502)  
• 'CH3 Synchronization digital output value' (Un\G9504)  
• 'CH4 Synchronization digital output value' (Un\G9506)  
(3) The A/D converter module simultaneously executes A/D conversion in all channels at the timing of the synchronization cycle. Because the conversion results are stored in the above buffer memory areas before the interrupt program is executed, all A/D converter modules can simultaneously refer to the data converted from analog to digital.

## ■Abnormal operation during synchronization

The phenomenon that the A/D converter module cannot receive inter-module synchronization signals at a normal cycle is called "synchronization loss". When a synchronization loss has occurred, an inter-module synchronization signal error (error code: 2610H) occurs. When this error has occurred, the synchronization of the A/D converter modules stops and 'CH1 Synchronization digital output value' (Un\G9500) keeps the previously stored value.

The following shows the operation of the A/D converter modules of when a synchronization loss has occurred.



- (1) When the A/D converter module cannot accept the inter-module synchronization cycle, a synchronization loss has occurred.
- (2) When the A/D converter module did not accept the synchronization cycle at the timing where the synchronization cycle was supposed to be accepted, an inter-module synchronization signal error (error code: 2610H) occurs and 'CH1 Synchronization digital output value' (Un\G9500) keeps the previously stored value.
- (3) Once an inter-module synchronization signal error (error code: 2610H) is detected, Inter-module synchronization target (synchronization stopped) (1) is stored in 'Synchronization status monitor' (Un\G9600).

### Point

When a synchronization loss has occurred, the module may be affected by noise. Check and adjust the cable wiring and the installation environment of the programmable controllers, and restart the system. If the error reoccurs even after the adjustment, the possible cause is a failure of the module. Please consult your local Mitsubishi representative.

## Monitor

When the inter-module synchronization function is used, the inter-module synchronization status can be monitored.

For details, refer to the following.

☞ Page 228 Synchronization status monitor

## Precautions

- The following table shows the availability of other functions of when the inter-module synchronization function is enabled.

Function	Availability	Remarks	
A/D conversion enable/disable setting function	○	—	
Range switching function	○	—	
A/D conversion method	Sampling processing	○	
	Averaging processing	Count average	×
		Time average	×
		Moving average	○
	Primary delay filter	×	
	Digital filter	Low pass filter	×
		High pass filter	×
		Band pass filter	×
Scaling function	×	The scaling function cannot be used. When the function is set to be enabled, the setting is ignored.	
Shift function	×	The value set for 'CH1 Conversion value shift amount' (Un\G472) is disabled.	
Digital clipping function	×	The digital clipping function cannot be used. When the function is set to be enabled, the setting is ignored.	
Difference conversion function	×	When 'CH1 Difference conversion trigger' (Un\G470) is set, the setting is ignored.	
Maximum value/minimum value hold function	○	—	
Warning output function	Process alarm	○	
	Rate alarm	×	
Input signal error detection function	○	—	
Logging function	Normal logging function	×	
	Logging read function	×	
	Continuous logging function	○	
Interrupt function	△	When continuous logging is executed, no interrupt is detected.	
Error history function	○	—	
Event history function	○	—	
Offset/gain setting	×	—	
Backing up, saving, and restoring offset/gain values	×	—	
Online module change	×	<p>During inter-module synchronization, the online module change is disabled.</p> <p>If the online module change is attempted during the inter-module synchronization, an online module change error (error code: 4206H) is stored in Online module change error cause (SD1618) and the module cannot be changed.</p> <p>If the module is changed, a module verification error (error code: 2400H) occurs in the CPU module.</p>	

- To execute the continuous logging function during inter-module synchronization, arrange the modules on the same base unit. If the modules were not arranged on the same base unit, the conversion timing of the modules may differ depending on the inter-module synchronization accuracy. (📖 MELSEC iQ-R Inter-Module Synchronization Function Reference Manual)
- In the normal mode, 'CH1 Synchronization digital output value' (Un\G9500) is fixed to 0.
- When the offset/gain setting mode is set in the operation mode setting, an inter-module synchronization selection offset/gain setting error (error code: 1EA1H) occurs and the module does not operate.
- When a mode switching setting value is set for 'Mode switching setting' (Un\G296, Un\G297) and 'Operating condition setting request (Y9)' is turned on, a mode switching request error (alarm code: 0D00H) occurs and the ALM LED turns on. In this case, the mode is not switched and the synchronization processing continues. Turn on and off 'Error clear request' (YF) to clear the alarm that occurred.
- When performing the offset/gain setting, set the module as a synchronization non-target, and switch the mode to the normal mode, and then switch the mode again to the offset/gain setting mode.
- Dedicated instructions cannot be used. The following shows the operation when a dedicated instruction has been executed.

Dedicated instruction*1	Operation
G(P).OFFGAN	If the G(P).OFFGAN instruction is executed, a mode switching request error (alarm code: 0D00H) occurs.
G(P).OGLOAD	The G(P).OGLOAD instruction is disabled.
G(P).OGSTOR	If the G(P).OGSTOR instruction is executed, a G(P).OGSTOR instruction execution error in offset/gain setting mode (error code: 1860H) is stored in the dedicated instruction completion status.

\*1 For details on the dedicated instructions, refer to the following.

📖 MELSEC iQ-R Programming Manual (Instructions, Standard Functions/Function Blocks)

# 1.18 Error History Function

## Common

This function stores up to the latest 16 errors and alarms that occurred in the A/D converter module to the buffer memory area.

## Operation

When an error occurs, the error code and the error time are stored from Error history 1 (Un\G3600 to Un\G3609) in order. When an alarm occurs, the alarm code and the alarm time are stored from Alarm history 1 (Un\G3760 to Un\G3769) in order. Error time and alarm time are stored as follows:

### Ex.

The following shows Error history 1 and Alarm history 1.

- Details of the error history

b15	...	b8 b7	...	b0		
Error code						
Un\G3601		First two digits of the year		Last two digits of the year		
Un\G3602		Month		Day		
Un\G3603		Hour		Minute		
Un\G3604		Second		Day of the week		
Un\G3605		Millisecond (higher-order digits)		Millisecond (lower-order digits)		
System area						
Un\G3609						

- Details of the alarm history

b15	...	b8 b7	...	b0		
Alarm code						
Un\G3760		First two digits of the year		Last two digits of the year		
Un\G3761		Month		Day		
Un\G3762		Hour		Minute		
Un\G3763		Second		Day of the week		
Un\G3764		Millisecond (higher-order digits)		Millisecond (lower-order digits)		
System area						
Un\G3769						

Item	Storage contents	Storage example <sup>*1</sup>
Error code or alarm code	An error code or alarm code is stored.	3030H
First two digits of the year	Stored in BCD code.	2015H
Month		1224H
Hour		1234H
Second		56H
Day of the week	One of the following values is stored in BCD code. Sunday: 0, Monday: 1, Tuesday: 2, Wednesday: 3 Thursday: 4, Friday: 5, Saturday: 6	4H
Millisecond (upper)	Stored in BCD code.	7H
Millisecond (lower)		89H
System area	—	—

\*1 Values stored when a flash memory error (error code: 3030H) occurs at 12:34:56.789 on Thursday, December 24th, 2015.


## Checking method

The start address of Error history where the latest error is stored can be checked in 'Latest address of error history' (Un\G1).

The start address of Alarm history where the latest alarm is stored can be checked in 'Latest address of alarm history' (Un\G3).


### Ex.

The following shows an example of when the 3rd error occurs. The 3rd error is stored in Error history 3, and the value 3620 (start address of Error history 3) is stored in 'Latest address of error history' (Un\G1).



**Ex.**

The following shows an example of when the 17th error occurs. The 17th error is stored in Error history 1, and 'Latest address of error history' (Un\G1) is overwritten with the value 3600 (start address of Error history 1).

**Point**

- Once the error history storage area becomes full, subsequent error information will overwrite the existing data, starting from Error history 1 (Un\G3600 to Un\G3609), and the overwriting continues sequentially thereafter. The overwritten history is deleted.
- The same processing is performed for Alarm history when an alarm occurs.
- The stored error history is cleared when the A/D converter module is powered off, or when the CPU module is reset.

# 1.19 Event History Function

## Common

This function collects generated errors, alarms or executed operations in the A/D converter module as event information in the CPU module.

The CPU module collects the event information of the A/D converter module and keeps them in the data memory inside of the CPU module or an SD memory card.

The event information collected by the CPU module can be displayed on an engineering tool to check the occurrence history in a time series.

Event type	Classification	Description
System	Error	An error detected by the self diagnostics in each module.
	Warning	A warning (alarm) detected in each module.
	Information	The operation by the normal detection of the system that is not classified as Error or Warning, or the operation performed automatically by the system.
Security	Warning	Operation that is judged as an unauthorized access to each module.
	Information	Operation that is hard to be judged as the success of unlocking passwords or an unauthorized access.
Operation	Warning	Deleting (data clear) operations that may change the action. (These operations are not judged as errors by the self diagnostics.)
	Information	Operations performed by users to change the system operation or configuration in the offset/gain setting.

## Setting procedure

The event history function can be set from the event history setting window of the engineering tool. For the setting method, refer to the following.

 MELSEC iQ-R CPU Module User's Manual (Application)

## Displaying event history

Access the menu window of the engineering tool. For details on the operating procedure and how to view the contents, refer to the following.

 GX Works3 Operating Manual

## List of event history data

The following table lists the events that would occur in the A/D converter module when the event type is set to "Operation"

Event code	Classification	Event name	Event detail	Additional information
20010	Information	Offset/gain setting execution	In the user range setting, offset/gain values has been set.	Total number of writes
20100	Information	Error clear	Error clear request has been issued.	—

# 1.20 Backing up, Saving, and Restoring Offset/Gain Values

Medium speed

Low speed

The A/D converter module can back up, save, and restore offset/gain values in the user range.

- **Backup:** Creates a module-specific backup parameter and saves offset/gain values.
- **Save:** Saves the offset/gain information, registered in this module by making the offset/gain setting, in the CPU module.
- **Restoration:** Writes the information backed up and saved in the CPU module to this module.

In the event that the A/D converter module fails and needs to be replaced, the offset/gain values of the failed A/D converter module can be restored onto the new A/D converter module.

However, if the offset/gain values are saved and restored, the accuracy after the restoration decreases to approximately the one-third compared to that before the restoration. Reconfigure the offset/gain setting when required.

Only when the model where the offset/gain values are to be saved and the model where the offset/gain values are to be restored are the same, the offset/gain values can be saved and restored. Each procedure differs depending on whether a module-specific backup parameter is used or not.

## When a module-specific backup parameters is used

Medium speed

Low speed

At the time of replacement by means of the online module change, the offset/gain values are automatically restored.

For details on the online module change, refer to the following.

 MELSEC iQ-R Online Module Change Manual

### Details of the module-specific backup parameter

A module-specific backup parameter is a file created in an SD memory card or the data memory of the control CPU. The contents of the parameter are the offset/gain values of the user range stored in the non-volatile memory of the A/D converter module.

The file name of a module-specific backup parameter is determined as follows based on the start I/O number of the A/D converter module.

UBPmmmn.BPR

- mmm indicates a value calculated by dividing the module I/O No. by 10H (3 digits in hexadecimal).
- nn indicates a consecutive number of the module-specific backup parameters for each module and fixed to 00.

## Creating and updating a module-specific backup parameter

A module-specific backup parameter is created or updated when the offset/gain values stored in the non-volatile memory of the A/D converter module are updated.

Timing when backup data is created or updated	Description
When the offset/gain setting is completed with "Offset/gain setting" of the engineering tool	A module-specific backup parameter is created or updated when the offset/gain setting is completed with "Offset/gain setting" of the engineering tool.
When 'User range write request' (YA) is turned on in the offset/gain setting mode	A module-specific backup parameter is created or updated when the offset/gain values of the user range are changed in the offset/gain setting mode.
When 'User range write request' (YA) is turned on in the normal mode	When 'User range write request' (YA) is turned on in the normal mode, the offset/gain values of the user range are restored based on the settings of the buffer memory areas (Save data type, CH1 Factory default setting offset value (L) to CH4 User range setting gain value (H)). At this timing, module-specific backup parameters are updated.
When the G(P).OGSTOR instruction is executed in the normal mode	When the G(P).OGSTOR instruction is executed in the normal mode, the offset/gain values of the user range are restored. At this timing, module-specific backup parameters are updated.
When a new module is recognized in the process of online module change	When a new module is mounted and recognized in the process of online module change, the offset/gain values of the user range are restored. At this timing, module-specific backup parameters are updated.

When no module-specific backup parameter exists in the data memory of the control CPU and a module-specific backup parameter needs to be created with the current setting, change the mode of the A/D converter module to the offset/gain setting mode and turn on 'User range write request' (YA). A module-specific backup parameter is created with the current setting of the flash memory.

### ■Precautions

If the creation of a module-specific backup parameter fails because the data memory of the control CPU does not have sufficient free space or the module-specific backup parameter is being used, a module-specific backup parameter creation error (error code: 17E1H) occurs.

## Reading of module-specific backup parameters

To read a module-specific backup parameter and restore offset/gain values, set "Auto restore of Offset/gain setting with the module change" of the module parameter to "Enable" in advance.

 Navigation window  $\Rightarrow$  [Parameter]  $\Rightarrow$  [Module Information]  $\Rightarrow$  Module model name  $\Rightarrow$  [Module Parameter]  $\Rightarrow$  "Application setting"  $\Rightarrow$  "Online module change"

### ■Reading timing

Module-specific backup parameters are read when a new module is mounted and recognized in the process of online module change. If the module is replaced with the programmable controller powered off, module-specific backup parameters are not read.

### ■Precautions

When the module-specific backup parameter for the target slot does not exist in an SD memory card or the data memory of the control CPU, the subsequent restoration of the offset/gain values is not performed. If the offset/gain values cannot be restored even though the module-specific backup parameter exists, a module-specific backup parameter restore error (error code: 17E0H) occurs.

## Restoring the offset/gain values of the user range

Upon the successful completion of reading module-specific backup parameters, the values are converted (restored) into the offset/gain values of the user range for the new module, and stored in the non-volatile memory. At the same time, the module-specific backup parameter in the data memory of the control CPU is updated with the setting of the new module.

## Restrictions on the module-specific backup parameter

The backup and restoration by means of module-specific backup parameters fails in the following cases.

- When the control CPU is not the process CPU
- When replacing the A/D converter module with the programmable controller powered off
- When "Auto restore of Offset/gain setting with the module change" of the module parameter is set to "Disable"

In any of the cases above, back up and restore offset/gain values by referring to the following.

☞ Page 129 When the module-specific backup parameter is not used

## When the module-specific backup parameter is not used

Medium speed


Low speed

When the module-specific backup parameter is not used, back up and restore offset/gain values by one of the following methods.


- Saving and restoring with dedicated instructions
- Saving and restoring by reading from and writing to the buffer memory

With the methods above, offset/gain values can be restored to a new module, or the offset/gain values set in one module can be applied to the other modules in the same system.


- To restore offset/gain values onto a new replaced module:




1. Save the offset/gain values.



2. Replace the A/D converter module.



3. Restore the offset/gain values.




- To apply the offset/gain values set in one module to the other modules in the same system:


**Ex.**

When the offset/gain values in module No.1 are applied to modules No.2 to No.4

1. Save the offset/gain values of module No.1.



2. Apply the offset/gain values to modules No.2 to No.4.



### Saving and restoring with dedicated instructions

Use the dedicated instruction G(P).OGLOAD to temporarily save the offset/gain values of the source A/D converter module to the internal device of the CPU module, and use the G(P).OGSTOR to write the values to the destination A/D converter module.

Prevent the saved offset/gain setting data from being deleted, by one of the following methods before replacing the modules:

- Use latch settings for the internal device of the destination module.
- Save the data onto an SD memory card. (To write data: use the SP.FWRITE instruction. To read data: use the SP.FREAD instruction.)
- Store the saved data.

For how to use dedicated instructions, refer to the following.

 MELSEC iQ-R Programming Manual (Instructions, Standard Functions/Function Blocks)

## Saving and restoring by reading from and writing to the buffer memory

Use Save data type setting (Un\G4002), CH1 Factory default setting offset value (L) (Un\G4004) to CH4 User range setting gain value (H) (Un\G4035), and 'User range write request' (YA) to read the offset/gain values from the source A/D converter module. Use the buffer memory again to write the values to the destination A/D converter module.

The following describes the procedure for using the buffer memory.

### ■To restore offset/gain values onto a new replaced module:

Performing operations to the source A/D converter module

1. Set Save data type setting (Un\G4002).
2. Turn on and off 'Operating condition setting request' (Y9).
3. Save the stored values of Save data type setting (Un\G4002) and CH1 Factory default setting offset value (L) (Un\G4004) to CH4 User range setting gain value (H) (Un\G4035).
4. Replace the A/D converter module.

Performing the operation when the power of the module is off

Performing operations to the destination A/D converter module

5. Write the data saved in Save data type setting (Un\G4002) and CH1 Factory default setting offset value (L) (Un\G4004) to CH4 User range setting gain value (H) (Un\G4035).
6. Turn on 'User range write request' (YA).
7. Check that 'Offset/gain setting mode status flag' (XA) is on.
8. Turn off 'User range write request' (YA).
9. Check that the destination A/D converter module operates with the offset/gain values that are restored.



When replacing modules, prevent the saved offset/gain setting data from being deleted, by one of the following methods before powering off the module.

- Use latch settings for the internal device of the destination module.
- Save the data onto an SD memory card. (To write data: use the SP.FWRITE instruction. To read data: use the SP.FREAD instruction.)
- Store the saved data.

### ■To apply the offset/gain values set in one module to the other modules in the same system:

Performing operations to the source A/D converter module

1. Set Save data type setting (Un\G4002).
2. Turn on and off 'Operating condition setting request' (Y9).
3. Save the stored values of Save data type setting (Un\G4002) and CH1 Factory default setting offset value (L) (Un\G4004) to CH4 User range setting gain value (H) (Un\G4035).

Performing operations to the destination A/D converter module

4. Write the data saved in Save data type setting (Un\G4002) and CH1 Factory default setting offset value (L) (Un\G4004) to CH4 User range setting gain value (H) (Un\G4035).
5. Turn on 'User range write request' (YA).
6. Check that 'Offset/gain setting mode status flag' (XA) is on.
7. Turn off 'User range write request' (YA).
8. Check that the destination A/D converter module operates with the offset/gain values that are restored.

## Range reference table

The following shows the range reference tables to be used for saving and restoring offset/gain values.

### ■Range reference table of Factory default setting offset/gain value

Address (decimal)				Description	Save data type setting <sup>*1</sup>	Analog value	Reference value (hexadecimal)
CH1	CH2	CH3	CH4				
4004	4008	4012	4016	Factory default setting offset value	Voltage specification	0V	00000H
4005	4009	4013	4017		Current specification	0mA	00000H
4006	4010	4014	4018	Factory default setting gain value	Voltage specification	10V	179C3H
4007	4011	4015	4019		Current specification	20mA	0BCE2H

\*1 The reference values differ depending on the setting of Save data type setting (Un\G4002) (voltage or current).

### ■Range reference table of User range setting offset/gain value

The following values are stored as the user range setting by default.

Address (decimal)				Description	Range type	Setting details	Reference value (hexadecimal)
CH1	CH2	CH3	CH4				
4020	4024	4028	4032	User range setting offset value	Current	4mA	025C7H
4021	4025	4029	4033				
4022	4026	4030	4034	User range setting gain value	Current	20mA	0BCE2H
4023	4027	4031	4035				

The following shows the range reference table of User range setting offset/gain value.

Offset/gain value		Reference value (hexadecimal)	
Voltage	0V	00000H	
	1V	025C7H	
	5V	0BCE2H	
	10V	179C3H	
Current	0mA	00000H	
	4mA	025C7H	
	20mA	0BCE2H	

# 2 PARAMETER SETTINGS

Set the parameters of each channel.

Setting parameters here eliminates the need to program them.

2


## 2.1 Basic Setting

### Setting procedure

Open "Basic setting" of the engineering tool.

#### 1. Start Module Parameter.

Navigation window  $\Rightarrow$  [Parameter]  $\Rightarrow$  [Module Information]  $\Rightarrow$  Module model name  $\Rightarrow$  [Module Parameter]  $\Rightarrow$  "Basic setting"



#### 2. Click the item to be changed to enter the setting value.

- Item where a value is selected from the drop-down list

Click the [▼] button of the item to be set, and from the drop-down list that appears, select the value.

- Item where a value is entered into the text box

Double-click the item to be set to enter the numeric value.


## 2.2 Application Setting

### Setting procedure

Open "Application setting" of the engineering tool.

#### 1. Start Module Parameter.

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Module Parameter] ⇒ "Application setting"



#### 2. Click the item to be changed to enter the setting value.

- Item where a value is selected from the drop-down list

Click the [▼] button of the item to be set, and from the drop-down list that appears, select the value.

- Item where a value is entered into the text box

Double-click the item to be set to enter the numeric value.


## 2.3 Interrupt Setting

### Setting procedure

Open "Interrupt setting" of the engineering tool.

#### 1. Start Module Parameter.

Navigation window  $\Rightarrow$  [Parameter]  $\Rightarrow$  [Module Information]  $\Rightarrow$  Module model name  $\Rightarrow$  [Module Parameter]  $\Rightarrow$  "Interrupt setting"



#### 2. Click the item of interrupt setting number (No.1 to 16) to be changed to enter the setting value.

- Item where a value is selected from the drop-down list

Click the  $\downarrow$  button of the item to be set, and from the drop-down list that appears, select the value.

- Item where a value is entered into the text box

Double-click the item to be set to enter the numeric value.

## 2.4 Refresh Setting


### Setting procedure

Set the buffer memory area of the A/D converter module to be refreshed.

This refresh setting eliminates the need for reading/writing data by programming.

#### 1. Start Module Parameter.

Navigation window  $\Rightarrow$  [Parameter]  $\Rightarrow$  [Module Information]  $\Rightarrow$  Module model name  $\Rightarrow$  [Module Parameter]  $\Rightarrow$  "Refresh settings"



#### 2. Click "Target", and set the auto refresh destination.

- When "Target" is "Module Label"

Set whether to enable or disable the refresh by setting "Level data 0" to Enable or Disable.

- When "Target" is "Refresh Data Register (RD)"

The transfer destinations of all items are automatically set by setting the start device to "Start Device Name".

- When "Target" is "Device"

Double-click the item to be set to enter the refresh destination device.

#### 3. Click "Refresh Group" to set the timing to refresh.

Set "Refresh Group" to "At the Execution Time of END Instruction" or "At the Execution Time of Specified Program".

When "At the Execution Time of Specified Program" is set, double-click "Group [n] (n: 1-64)" and set a value of 1 to 64.



When the refresh is enabled, the values of the refresh destination are enabled at the refresh timing set with the engineering tool. At this time, the buffer memory areas are overwritten with the values of the refresh destination. To change the values of the refresh target buffer memory areas, create a program so that the values of module labels or devices of the refresh source are changed.

## Refresh processing time

A refresh processing time [ $\mu\text{s}$ ] is a constituent of the scan time of the CPU module. For details on the scan time, refer to the following.

 MELSEC iQ-R CPU Module User's Manual (Application)

The refresh processing time [ $\mu\text{s}$ ], which is taken for refresh, is given by:

- Refresh processing time [ $\mu\text{s}$ ] = Refresh read time (time for transferring refresh data to the CPU module) + Refresh write time (time for transferring refresh data to the intelligent function module)

The refresh read time and refresh write time vary depending on the settings of "Target".

### When "Target" is "Module Label" or "Refresh Data Register (RD)"

The following table shows the refresh read time and refresh write time with an R□CPU used.

Model	Classification	When using the refresh settings	When using the inter-module synchronization function
R60ADH4	Refresh read time	20.56 $\mu\text{s}$	12.94 $\mu\text{s}$
	Refresh write time	12.35 $\mu\text{s}$	0 $\mu\text{s}$

### When "Target" is "Device"

Calculate the refresh read time and refresh write time according to the number of items and the number of their transfer data (in units of word) that are set to be refreshed. For the calculation method, refer to the following.

 MELSEC iQ-R CPU Module User's Manual (Application)

# 3 TROUBLESHOOTING

This chapter describes errors that may occur in the use of the A/D converter module and those troubleshooting.

## 3.1 Troubleshooting with the LEDs

Check the state of the LEDs to narrow down the possible causes of the trouble. This step is the first diagnostics before using the engineering tool.

A state of the A/D converter module can be checked with the RUN LED, ERR LED, and ALM LED. The following table shows the correspondence of these LEDs and a state of the A/D converter module.

Name	Description
RUN LED	Indicates the operating status of the module. On: Normal operation Flashing (1s cycles): In offset/gain setting mode Flashing (400ms cycles): Selected as a module for the online module change Off: 5V power supply interrupted, watchdog timer error occurred, or module replacement allowed in the process of the online module change
ERR LED	Indicates the error status of the module.*1 On: Error occurred Off: Normal operation
ALM LED	Indicates the alarm status of the module.*2 On: Warning (process alarm or rate alarm) issued Flashing: Input signal error detected Off: Normal operation

\*1 For details, refer to the following.

 Page 146 List of Error Codes

\*2 For details, refer to the following.

 Page 152 List of Alarm Codes

## 3.2 Checking the State of the Module


The following functions can be used on the "Module Diagnostics" window of the A/D converter module.

Function	Application
Error Information	Indicates the errors that have occurred. Click the [Event History] button to check not only the errors and alarms that occurred in the A/D converter module, but also the errors detected by each module and the operation history.
Module Information List	Indicates each status information of the A/D converter module.

### Error Information

Check the details and actions for the errors that have occurred.


☞ [Diagnostics] ⇒ [System Monitor] ⇒ Right-click the module to be checked. ⇒ "Module Diagnostics"



Item	Description
Cause	Indicates detailed causes of the error.
Corrective Action	Indicates the actions for the error.


Check alarm codes, error history, and alarm history on the Event History window of the engineering tool.

→ [Diagnostics] → [System Monitor] → [Event History] button



## Module Information List

Switch the tab to the "Module Information List" tab and check each status information of the A/D converter module.



Item	Description
LED information	Indicates the LED status of the A/D converter module.
Input signal error detection	Indicates the input signal error detection status of the A/D converter module for each channel.

## 3.3 Troubleshooting by Symptom

### When the RUN LED flashes or turns off

#### When flashing

Check item	Cause	Action
Check whether the module is in the offset/gain setting mode.	The programmable controller power supply has been turned off and on, or the CPU module has been reset with "Operation mode setting" set to "Offset/gain setting mode" in the module parameter setting of the engineering tool.	In the module parameter setting of the engineering tool, set "Operation mode setting" to other than "Offset/gain setting mode", and turn off and on the programmable controller power supply or reset the CPU module.
	The G(P).OFFGAN instruction has been executed with the mode being set to be switched to the offset/gain setting mode.	Review the program that uses the G(P).OFFGAN instruction to check whether the mode has been switched erroneously.
	The value in 'Mode switching setting' (Un\G296, Un\G297) has been changed and the mode has been switched to the offset/gain setting mode.	Review the program that uses 'Mode switching setting' (Un\G296, Un\G297) to check whether the mode has been switched erroneously.
Check whether the module is selected as the target module for the online module change.	The base number and slot number of the A/D converter module have been set in Module selection specification (Base No.) (SD1600) and Module selection specification (Slot No.) (SD1601).	Turn on Module selection cancel request flag (SM1615).

#### When turning off

Check item	Action
Check whether the power is supplied.	Check that the supply voltage of the power supply module is within the rated range.
Check whether the capacity of the power supply module is enough.	Calculate the current consumption of mounted modules, such as the CPU module, I/O modules, and intelligent function modules to check that the power capacity is enough.
Check whether the module is mounted properly.	Check the mounting state of the module.
Check whether the module replacement is allowed in the process of the online module change.	Perform the online module change. For details, refer to the following.  MELSEC iQ-R Online Module Change Manual
Cases other than the above	Reset the CPU module, and check if the RUN LED turns on. If the RUN LED still remains off, the possible cause is a failure of the module. Please consult your local Mitsubishi representative.

### When the ERR LED turns on

#### When turning on

Check item	Action
Check whether any error has occurred.	Check 'Latest error code' (Un\G0) and take actions described in the list of error codes.  Page 146 List of Error Codes

# When the ALM LED turns on or flashes

## When turning on

Check item	Action
Check whether any warning has been issued.	<p>Check 'Warning output flag (Process alarm upper limit)' (Un\G36), 'Warning output flag (Process alarm lower limit)' (Un\G37), 'Warning output flag (Rate alarm upper limit)' (Un\G38), and 'Warning output flag (Rate alarm lower limit)' (Un\G39).</p> <p>Take actions described in the list of alarm codes.</p> <p> <a href="#">Page 152 List of Alarm Codes</a></p>

## When flashing

Check item	Action
Check whether any input signal error has occurred.	<p>Check 'Input signal error detection signal' (XC) or 'Input signal error detection flag' (Un\G40).</p> <p>Take actions described in the list of alarm codes.</p> <p> <a href="#">Page 152 List of Alarm Codes</a></p>

## When a digital output value cannot be read

Follow the steps in the table below to find the cause of the trouble.

Description	Procedure
<p>■Step 1: Checking the digital output value</p> <p>Check the following.</p> <ul style="list-style-type: none"> <li>• Check whether digital output values have been stored in the buffer memory.</li> <li>• Check whether the program for reading digital output values has an error.</li> </ul>	<pre> graph TD     A([When digital output values cannot be read]) --&gt; B[Check the stored value in 'CH1 Digital output value' (Un\G400).]     B -.-&gt; C[Monitor the buffer memory area with the monitor function*1 of the engineering tool.]     B --&gt; D{Are the stored digital output values corresponding to the analog input?}     D -- YES --&gt; E["The read program has an error or the CPU module is in STOP status."]     E --&gt; F["Check item 1"]     D -- NO --&gt; G1((1))   </pre>
<p>■Step 2: Checking the conversion status</p> <p>Check the execution status of the A/D conversion in the module, such as whether the A/D converter module have executed the A/D conversion.</p>	<pre> graph TD     G1((1)) --&gt; H[Check the stored value in 'CH1 A/D conversion status monitor' (Un\G459).]     H -.-&gt; I[Monitor the buffer memory area with the monitor function*1 of the engineering tool.]     H --&gt; J{Is "A/D conversion disable (1)" stored?}     J -- YES --&gt; K["A/D conversion is not enabled."]     K --&gt; L["Check item 2"]     J -- NO --&gt; M2((2))   </pre>
<p>■Step 3: Checking the input range setting</p> <p>Check whether the input range appropriate to the analog input is set.</p>	<pre> graph TD     M2((2)) --&gt; N[Check the stored value in 'CH1 Range setting monitor' (Un\G430).]     N -.-&gt; O[Monitor the buffer memory area with the monitor function*1 of the engineering tool.]     N --&gt; P{Is the set input range matched with the analog input?}     P -- YES --&gt; Q["Check and correct the wiring and offset/gain setting."]     Q --&gt; R["Check item 3"]     P -- NO --&gt; S["The analog input is not matched with the input range setting."]     S --&gt; T["Check item 4"]   </pre>

\*1 Monitor the buffer memory areas using "Device/Buffer Memory Batch Monitor" or "Intelligent Function Module Monitor".



If digital output values cannot be read even after the above actions are taken, the possible cause is a failure of the A/D converter module. Please consult your local Mitsubishi representative.

## Check item 1

The program for reading digital output values has an error or the CPU module is in the STOP state. Check the following items.

Check item	Action
Check whether the program for reading digital output values has an error.	Check 'CH1 Digital output value' (Un\G400) using the monitor functions of the engineering tool ("Device/Buffer Memory Batch Monitor" or "Intelligent Function Module Monitor"). If the digital output value corresponding to the analog input is stored, review and correct the program for reading digital output values.
Check whether the auto refresh setting is correct.	If the value in 'CH1 Digital output value' (Un\G400) is transferred to a device of the CPU module with the auto refresh, review and correct the auto refresh setting.
Check whether the CPU module is in the STOP state.	Change the state of the CPU module to RUN.

## Check item 2

The A/D conversion is not executed. Check the following items.

Check item	Action
Check whether A/D conversion disable (1) is set in 'CH1 A/D conversion enable/disable setting' (Un\G500) of the channel where a value is to be input.	Check 'CH1 A/D conversion enable/disable setting' (Un\G500) using the monitor functions of the engineering tool ("Device/Buffer Memory Batch Monitor" or "Intelligent Function Module Monitor"). When 'CH1 A/D conversion enable/disable setting' (Un\G500) is set to A/D conversion disable (1), change it to A/D conversion enable (0) with the engineering tool or a program.
Check whether 'Operating condition setting request' (Y9) has been executed after parameter changes.	Turn on and off 'Operating condition setting request' (Y9) <sup>*1</sup> with the engineering tool and check that a digital output value is stored in 'CH1 Digital output value' (Un\G400). If the stored value is correct, further check the program to verify the description of 'Operating condition setting request' (Y9).

\*1 If 'Operating condition setting request' (Y9) is on, the A/D conversion does not start. Therefore, first turn on 'Operating condition setting request' (Y9), check the off state of 'Operating condition setting completed flag' (X9), and make sure to turn off 'Operating condition setting request' (Y9).

## Check item 3

Wiring or the offset/gain setting is incorrect. Check the following items.

Check item	Action
Check whether a terminal screw is loosen.	Retighten the terminal screw within the specified torque range.
Check whether an incorrect terminal is not connected.	Refer to the external wiring example and check and correct the wiring.  MELSEC iQ-R High Speed Analog-Digital Converter Module User's Manual (Startup)
Check whether there is any problem with the wiring, such as looseness or disconnection of analog signal wires.	Identify the faulty area of signal wires by a visual check and continuity check.
Check whether the terminals (V+) and (I+) are connected at the current input.	Always connect the terminals (V+) and (I+) at the current input as shown in the external wiring example.  MELSEC iQ-R High Speed Analog-Digital Converter Module User's Manual (Startup)
Check whether there is any potential difference between the AG terminal and the external device GND.	A potential difference may occur between the AG terminal and the external device GND by a cause such as a long wiring distance, resulting in an incorrect A/D conversion. Connect the AG terminal and the external device GND to eliminate the potential difference.
Check whether external devices to be connected at each channel share the same GND.	If the external device GND is shared across channels, noise can sneak in between channels, which may cause some error in A/D conversion. Connect the AG terminal and the external device GND to eliminate the errors.
Check whether the offset/gain setting is correct.	If the input range setting is the user range, turn on and off 'Operating condition setting request' (Y9) and compare CH□ User range setting offset/gain value (Un\G4020 to Un\G4035) with the range reference table. If the stored values are not desired offset/gain values, configure the offset/gain setting again. For the range reference table, refer to the following.  Page 132 Range reference table

## Check item 4

The analog input and input range setting do not match. Check the following items.

Check item	Action
Check whether "Input range setting" of the module parameter is correct.	Check "Input range setting" of the module parameter and configure the setting again if the setting is incorrect.
When an input range is set in 'CH1 Range setting' (Un\G598) with a program, check whether the program has any error.	Check 'CH1 Range setting' (Un\G598) using the monitor functions of the engineering tool ("Device/Buffer Memory Batch Monitor" or "Intelligent Function Module Monitor"). If the set value is incorrect, correct the value with the engineering tool or a program.
Check whether 'Operating condition setting request' (Y9) has been executed after parameter changes.	Turn on and off 'Operating condition setting request' (Y9) <sup>*1</sup> with the engineering tool and check that a digital output value is stored in 'CH1 Digital output value' (Un\G400). If the stored value is correct, further check the program to verify the description of 'Operating condition setting request' (Y9).

\*1 If 'Operating condition setting request' (Y9) is on, the A/D conversion does not start. Therefore, first turn on 'Operating condition setting request' (Y9), check the off state of 'Operating condition setting completed flag' (X9), and make sure to turn off 'Operating condition setting request' (Y9).

## When the digital output value does not fall within the range of accuracy

Check item	Action
Check whether any measures have been taken to reduce noise.	To reduce noise, take measures such as the use of shielded cables for connection.

## When the synchronization digital output value does not change

Check item	Action
Checking the system parameter settings of GX Works3	Check whether the module is selected as the target module to be synchronized. Check 'Synchronization status monitor' (Un\G9600). If the monitor status is Not inter-module synchronization target (0), the module is not selected as the target module to be synchronized. Set the module as the target to be synchronized in the system parameter of GX Works3.
Checking the operating status of the CPU module	Check whether the RUN/STOP/RESET switch indicates the STOP state or a stop error has occurred. Set the RUN/STOP/RESET switch to RUN. When a stop error has occurred, take actions described in the list of error codes.  Page 146 List of Error Codes
Checking the program	Check whether A/D conversion disable (1) is set in 'CH1 A/D conversion enable/disable setting' (Un\G500). Check 'CH1 A/D conversion enable/disable setting' (Un\G500) and set it to A/D conversion enable (0).
	Check whether 'Operating condition setting request' (Y9) has turned on and off. Turn on and off 'Operating condition setting request' (Y9) to enable the parameter settings of the function.
	Check whether the inter-module synchronous interrupt program (I44) is prepared. When obtaining the synchronization digital output value, run the inter-module synchronous interrupt program to refresh the value.
	Check whether the EI instruction has been executed. To run the inter-module synchronous interrupt program, execute the EI instruction in the program.

## 3.4 List of Error Codes

If an error occurs during operation, the A/D converter module stores the error code into 'Latest error code' (Un\G0) of the buffer memory. In addition, 'Error flag' (XF) turns on. Turning on 'Error clear request' (YF) allows clearing of the error code of 'Latest error code' (Un\G0), and turning off of 'Error flag' (XF).

Error codes of the A/D converter module are classified in minor errors or moderate errors.

- Minor error: This error is caused by a setting failure of programs and parameters. The A/D conversion continues with the parameter setting before the change. (1000H to 1FFFH)
- Moderate error: Hardware failures are included. The A/D conversion do not continue. (2000H to 2FFFH, 3000H to 3FFFH)

The following table lists the error codes that may be stored.

□ in an error code: This symbol indicates the number of the channel where an error has occurred. A numerical value of 0 to 3 is used to correspond to CH1 to 4.  
(CH1: 0, CH2: 1, CH3: 2, CH4: 3)

△ in an error code: For what this symbol indicates, refer to Description and cause.

Error code	Error name	Description and cause	Action
0000H	—	There is no error.	—
1080H	Number of writes to offset/gain settings reach limit error	The number of the offset/gain settings has exceeded the guaranteed maximum number.	Any further setting of offset/gain values may not be reflected correctly.
17E0H	Module-specific backup parameter restore error	Offset/gain values cannot be restored with the module-specific backup parameter.	The module-specific backup parameter file may be damaged. Readjust the user range.
17E1H	Module-specific backup parameter creation error	The module-specific backup parameter has not been created.	Check the free space on the data memory of the control CPU and the SD memory card, and recreate a module-specific backup parameter. For how to create module-specific backup parameters, refer to the following.  Page 127 Creating and updating a module-specific backup parameter
180△H	Interrupt factor generation setting range error	A value other than Interrupt resend request (0) and No interrupt resend request(1) is set in Interrupt factor generation setting [n]. △ indicates the interrupt setting related to the error as follows: 0: Setting 1 to F: Setting 16	Set Interrupt factor generation setting [n] to Interrupt resend request (0) or No interrupt resend request (1).
181△H	Condition target setting range error	A value out of the range is set in Condition target setting [n]. △ indicates the interrupt setting related to the error as follows: 0: Setting 1 to F: Setting 16	■Normal mode (low speed: 20μs/CH), inter-module synchronization mode Set Condition target setting [n] to Disable (0) to Logging read (7). ■Simultaneous conversion mode Set Condition target setting [n] to Disable (0) or Continuous logging data storage (8).
182△H	Condition target channel setting range error	A value out of the range is set in Condition target channel setting [n]. △ indicates the interrupt setting related to the error as follows: 0: Setting 1 to F: Setting 16	Set Condition target channel setting [n] to All channels (0) to CH4 (4).
183△H	Interrupt condition setting overlap error	The same combination of condition target and condition target channel are set to multiple interrupt settings. (Setting 0: All channels in Condition target channel setting is regarded the same as setting 1: CH1 to 4: CH4.)	For each interrupt setting, check and correct the combination of all Condition target setting and Condition target channel setting.
184△H	Condition target setting error	For one channel, both "5: A/D conversion completed" and "7: Logging read" are set as an interrupt condition target.	For each channel, set either "5: A/D conversion completed" or "7: Logging read" in Condition target setting [n].
1860H <sup>*1</sup>	G(P).OGSTOR instruction execution error in offset/gain setting mode	The G(P).OGSTOR instruction has been executed in offset/gain setting mode.	Do not execute the G(P).OGSTOR instruction in the offset/gain setting mode.
1861H	Offset/gain setting continuous write occurrence error	The G(P).OGSTOR instruction has been executed continuously or a setting value has been continuously written to the flash memory 26 times or more in the offset/gain setting.	For the G(P).OGSTOR instruction, execute it only once per module. For the offset/gain setting, write the setting value only once per setting.

Error code	Error name	Description and cause	Action
1862H	Model mismatch error at the execution of OGSTOR	The G(P).OGSTOR instruction has been executed on a module different from the one on which the G(P).OGLOAD instruction was executed. The G(P).OGSTOR instruction has been executed ahead of the G(P).OGLOAD instruction.	Execute the G(P).OGLOAD and G(P).OGSTOR instructions on the same module. As the other way, execute the G(P).OGLOAD instruction on the module whose data is to be restored, and then execute the G(P).OGSTOR instruction on the module to which the data is to be restored.
190□H	Range setting range error	A value out of the range is set in CH□ Range setting.	Set CH□ Range setting to the following values: <ul style="list-style-type: none"><li>• 4 to 20mA (0H) to 0 to 10V (5H)</li><li>• 4 to 20mA (extended mode) (AH)</li><li>• 1 to 5V (extended mode) (BH)</li><li>• User range setting (FH)</li></ul>
191□H	Averaging process specification setting range error	A value out of the range is set in CH□ Averaging process specification.	<ul style="list-style-type: none"><li>■ Normal mode (medium speed: 10μs/CH), normal mode (low speed: 20μs/CH) Set CH□ Averaging process specification to Sampling processing (0) to Band pass filter (7).</li><li>■ Simultaneous conversion mode, inter-module synchronization mode Set CH□ Averaging process specification to Sampling processing (0) or Moving average (3).</li></ul>
192□H	Time average setting range error	When the time average is set in CH□ Averaging process specification, a value other than 1 to 5000 is set in CH□ Time average/Count average/Moving average/Primary delay filter constant setting.	Set CH□ Time average/Count average/Moving average/Primary delay filter constant setting to 1 to 5000.
193□H	Count average setting range error	When the count average is set in CH□ Averaging process specification, a value other than 4 to 62500 is set in CH□ Time average/Count average/Moving average/Primary delay filter constant setting.	Set CH□ Time average/Count average/Moving average/Primary delay filter constant setting to 4 to 62500.
194□H	Moving average setting range error	When the moving average is set in CH□ Averaging process specification, a value other than 2 to 1000 is set in CH□ Time average/Count average/Moving average/Primary delay filter constant setting.	Set CH□ Time average/Count average/Moving average/Primary delay filter constant setting to 2 to 1000.
195□H	Primary delay filter constant setting range error	When the primary delay filter is set in CH□ Averaging process specification, a value other than 1 to 500 is set in CH□ Time average/Count average/Moving average/Primary delay filter constant setting.	Set CH□ Time average/Count average/Moving average/Primary delay filter constant setting to 1 to 500.
196□H	Low pass filter setting range error	A value out of the range is set in CH□ LPF Pass band edge frequency or CH□ Attenuation band width.	Set CH□ LPF Pass band edge frequency and CH□ Attenuation band width to the following values: <ul style="list-style-type: none"><li>■ When the conversion cycle is 10μs<ul style="list-style-type: none"><li>• Pass band edge frequency + Attenuation band width ≤ 48000</li><li>• Attenuation band width ≥ 1300</li><li>• Pass band edge frequency ≥ 0</li></ul></li><li>■ When the conversion cycle is 20μs<ul style="list-style-type: none"><li>• Pass band edge frequency + Attenuation band width ≤ 24000</li><li>• Attenuation band width ≥ 650</li><li>• Pass band edge frequency ≥ 0</li></ul></li><li>■ When the conversion cycle is 30μs<ul style="list-style-type: none"><li>• Pass band edge frequency + Attenuation band width ≤ 16000</li><li>• Attenuation band width ≥ 440</li><li>• Pass band edge frequency ≥ 0</li></ul></li><li>■ When the conversion cycle is 40μs<ul style="list-style-type: none"><li>• Pass band edge frequency + Attenuation band width ≤ 12000</li><li>• Attenuation band width ≥ 330</li><li>• Pass band edge frequency ≥ 0</li></ul></li><li>■ When the conversion cycle is 60μs<ul style="list-style-type: none"><li>• Pass band edge frequency + Attenuation band width ≤ 8000</li><li>• Attenuation band width ≥ 220</li><li>• Pass band edge frequency ≥ 0</li></ul></li><li>■ When the conversion cycle is 80μs<ul style="list-style-type: none"><li>• Pass band edge frequency + Attenuation band width ≤ 6000</li><li>• Attenuation band width ≥ 170</li><li>• Pass band edge frequency ≥ 0</li></ul></li></ul>

Error code	Error name	Description and cause	Action
197□H	High pass filter setting range error	A value out of the range is set in CH□ HPF Pass band edge frequency or CH□ Attenuation band width.	<p>Set CH□ HPF Pass band edge frequency and CH□ Attenuation band width to the following values:</p> <ul style="list-style-type: none"> <li>■ When the conversion cycle is <math>10\mu\text{s}</math> <ul style="list-style-type: none"> <li>• Pass band edge frequency - Attenuation band width <math>&gt; 0</math></li> <li>• Attenuation band width <math>\geq 1300</math></li> <li>• Pass band edge frequency <math>\leq 48000</math></li> </ul> </li> <li>■ When the conversion cycle is <math>20\mu\text{s}</math> <ul style="list-style-type: none"> <li>• Pass band edge frequency - Attenuation band width <math>&gt; 0</math></li> <li>• Attenuation band width <math>\geq 650</math></li> <li>• Pass band edge frequency <math>\leq 24000</math></li> </ul> </li> <li>■ When the conversion cycle is <math>30\mu\text{s}</math> <ul style="list-style-type: none"> <li>• Pass band edge frequency - Attenuation band width <math>&gt; 0</math></li> <li>• Attenuation band width <math>\geq 440</math></li> <li>• Pass band edge frequency <math>\leq 16000</math></li> </ul> </li> <li>■ When the conversion cycle is <math>40\mu\text{s}</math> <ul style="list-style-type: none"> <li>• Pass band edge frequency - Attenuation band width <math>&gt; 0</math></li> <li>• Attenuation band width <math>\geq 330</math></li> <li>• Pass band edge frequency <math>\leq 12000</math></li> </ul> </li> <li>■ When the conversion cycle is <math>60\mu\text{s}</math> <ul style="list-style-type: none"> <li>• Pass band edge frequency - Attenuation band width <math>&gt; 0</math></li> <li>• Attenuation band width <math>\geq 220</math></li> <li>• Pass band edge frequency <math>\leq 8000</math></li> </ul> </li> <li>■ When the conversion cycle is <math>80\mu\text{s}</math> <ul style="list-style-type: none"> <li>• Pass band edge frequency - Attenuation band width <math>&gt; 0</math></li> <li>• Attenuation band width <math>\geq 170</math></li> <li>• Pass band edge frequency <math>\leq 6000</math></li> </ul> </li> </ul>

Error code	Error name	Description and cause	Action
198□H	Band pass filter setting range error	A value out of the range is set in CH□ BPF Pass band edge frequency (Low), CH□ BPF Pass band edge frequency (High), or CH□ Attenuation band width.	<p>Set CH□ BPF Pass band edge frequency (Low), CH□ BPF Pass band edge frequency (High), and CH□ Attenuation band width to the following values:</p> <ul style="list-style-type: none"> <li>■ When the conversion cycle is 10μs <ul style="list-style-type: none"> <li>• Pass band edge frequency (High) + Attenuation band width ≤ 48000</li> <li>• Pass band edge frequency (Low) - Attenuation band width &gt; 0</li> <li>• Attenuation band width ≥ 1300</li> <li>• Pass band edge frequency (Low) &lt; Pass band edge frequency (High)</li> </ul> </li> <li>■ When the conversion cycle is 20μs <ul style="list-style-type: none"> <li>• Pass band edge frequency (High) + Attenuation band width ≤ 24000</li> <li>• Pass band edge frequency (Low) - Attenuation band width &gt; 0</li> <li>• Attenuation band width ≥ 650</li> <li>• Pass band edge frequency (Low) &lt; Pass band edge frequency (High)</li> </ul> </li> <li>■ When the conversion cycle is 30μs <ul style="list-style-type: none"> <li>• Pass band edge frequency (High) + Attenuation band width ≤ 16000</li> <li>• Pass band edge frequency (Low) - Attenuation band width &gt; 0</li> <li>• Attenuation band width ≥ 440</li> <li>• Pass band edge frequency (Low) &lt; Pass band edge frequency (High)</li> </ul> </li> <li>■ When the conversion cycle is 40μs <ul style="list-style-type: none"> <li>• Pass band edge frequency (High) + Attenuation band width ≤ 12000</li> <li>• Pass band edge frequency (Low) - Attenuation band width &gt; 0</li> <li>• Attenuation band width ≥ 330</li> <li>• Pass band edge frequency (Low) &lt; Pass band edge frequency (High)</li> </ul> </li> <li>■ When the conversion cycle is 60μs <ul style="list-style-type: none"> <li>• Pass band edge frequency (High) + Attenuation band width ≤ 8000</li> <li>• Pass band edge frequency (Low) - Attenuation band width &gt; 0</li> <li>• Attenuation band width ≥ 220</li> <li>• Pass band edge frequency (Low) &lt; Pass band edge frequency (High)</li> </ul> </li> <li>■ When the conversion cycle is 80μs <ul style="list-style-type: none"> <li>• Pass band edge frequency (High) + Attenuation band width ≤ 6000</li> <li>• Pass band edge frequency (Low) - Attenuation band width &gt; 0</li> <li>• Attenuation band width ≥ 170</li> <li>• Pass band edge frequency (Low) &lt; Pass band edge frequency (High)</li> </ul> </li> </ul>
19A0H	Across channels average setting error	The averaging processing different from one another is set for each channel in simultaneous conversion mode or in inter-module synchronization mode.	Set values so that the settings of CH□ Averaging process specification and CH□ Time average/Count average/Moving average/Primary delay filter constant setting are the same for all channels where A/D conversion is enabled.
1A0□H	Scaling enable/disable setting range error	A value other than Enable (0) and Disable (1) is set in CH□ Scaling enable/disable setting.	Set CH□ Scaling enable/disable setting to Enable (0) or Disable (1).
1A1□H	Scaling setting range error	A value other than -32000 to 32000 is set in CH□ Scaling lower limit value and/or CH□ Scaling upper limit value.	Set CH□ Scaling lower limit value and CH□ Scaling upper limit value to -32000 to 32000.
1A2□H	Scaling upper/lower limit value setting error	CH□ Scaling upper limit value and CH□ Scaling lower limit value are set as the scaling upper limit value = the scaling lower limit value.	Set CH□ Scaling upper limit value and CH□ Scaling lower limit value as the scaling upper limit value ≠ the scaling lower limit value.
1A5□H	Digital clipping enable/disable setting range error	A value other than Enable (0) and Disable (1) is set in CH□ Digital clipping enable/disable setting.	Set CH□ Digital clipping enable/disable setting to Enable (0) or Disable (1).
1B0□H	Warning output setting (Process alarm) range error	A value other than Enable (0) and Disable (1) is set in CH□ Warning output setting (Process alarm).	Set CH□ Warning output setting (Process alarm) to Enable (0) or Disable (1).

Error code	Error name	Description and cause	Action
1B△□H	Process alarm upper/lower limit value setting range error	The values set in CH□ Process alarm upper/lower limit value to CH□ Process alarm lower/lower limit value do not satisfy the following condition: Upper/lower limit value $\geq$ Upper/lower limit value $\geq$ Lower/lower limit value $\geq$ Lower/lower limit value △ indicates that the set values are as follows: 1: Process alarm lower/lower limit value $>$ Process alarm lower/upper limit value 2: Process alarm lower/upper limit value $>$ Process alarm upper/lower limit value 3: Process alarm upper/lower limit value $>$ Process alarm upper/upper limit value	Set CH□ Process alarm upper/lower limit value to CH□ Process alarm lower/lower limit value so that the values satisfy the following condition: Upper/lower limit value $\geq$ Upper/lower limit value $\geq$ Lower/lower limit value $\geq$ Lower/lower limit value
1B8□H	Warning output setting (Rate alarm) range error	A value other than Enable (0) and Disable (1) is set in CH□ Warning output setting (Rate alarm).	Set CH□ Warning output setting (Rate alarm) to Enable (0) or Disable (1).
1B9□H	Rate alarm warning detection cycle setting range error	A value other than 1 to 32000 is set in CH□ Rate alarm warning detection cycle setting.	Set CH□ Rate alarm warning detection cycle setting to 1 to 32000.
1BA□H	Rate alarm upper/lower limit setting value inversion error	CH□ Rate alarm upper limit value and CH□ Rate alarm lower limit value are set as Lower limit value $\geq$ Upper limit value.	Set CH□ Rate alarm upper limit value and CH□ Rate alarm lower limit value as Lower limit value $<$ Upper limit value.
1C0□H	Input signal error detection setting range error	A value out of the range is set in CH□ Input signal error detection setting.	Set CH□ Input signal error detection setting to Disable (0) to Simple disconnection detection (4).
1C1□H	Input signal error detection value range error	A value other than 0 to 250 is set in CH□ Input signal error detection lower limit setting value or CH□ Input signal error detection upper limit setting value.	Set CH□ Input signal error detection lower limit setting value or CH□ Input signal error detection upper limit setting value to 0 to 250.
1C6□H	Disconnection detection enabled range setting range error	Simple disconnection detection is set in CH□ Input signal error detection setting, and the value set in CH□ Input range setting is other than the following: • 4 to 20mA (extended mode) (AH) • 1 to 5V (extended mode) (BH)	For channels where simple disconnection detection is performed using the input signal error detection function, set CH□ Input range setting to either of the following: • 4 to 20mA (extended mode) (AH) • 1 to 5V (extended mode) (BH)
1D0□H	Logging enable/disable setting range error	A value other than Enable (0) and Disable (1) is set in CH□ Logging enable/disable setting.	Set CH□ Logging enable/disable setting to Enable (0) or Disable (1).
1D1□H	Logging cycle setting value range error	A value out of the range is set in CH□ Logging cycle setting value and/or CH□ Logging cycle unit setting.	Set one or both of CH□ Logging cycle setting value and CH□ Logging cycle unit setting to the values within the range.
1D2□H	Logging cycle setting disable error	CH□ Logging cycle setting value and CH□ Logging cycle unit setting are set so that the set logging cycle falls below the conversion cycle.	Set CH□ Logging cycle setting value and CH□ Logging cycle unit setting so that the logging cycle is not less than the conversion cycle of the object to be logged.
1D3□H	Logging data setting range error	A value other than Digital output value (0) and Digital operation value (1) is set in CH□ Logging data setting.	Set CH□ Logging data setting to Digital output value (0) or Digital operation value (1).
1D4□H	Post-trigger logging points setting range error	A value out of the range of "1 to (the value set in CH□ Logging data points setting) $\times$ 100" is set in CH□ Post-trigger logging points.	Set CH□ Post-trigger logging points to a value within the range of "1 to (the value set in CH□ Logging data points setting) $\times$ 100".
1D5□H	Level trigger condition setting range error	A value out of the range is set in CH□ Level trigger condition setting.	Set CH□ Level trigger condition setting to Disable (0) to Process alarm (upper/lower limit warning) (6).
1D6□H	Trigger data setting range error	A value other than 0 to 9999 is set in CH□ Trigger data.	Set CH□ Trigger data to 0 to 9999.
1D8□H	Loading interrupt enable/disable setting range error	A value other than Enable (0) and Disable (1) is set in CH□ Loading interrupt enable/disable setting.	Set CH□ Loading interrupt enable/disable setting to Enable (0) or Disable (1).
1D9□H	Logging read points setting value range error	A value out of the range of "1 to (the value set in CH□ Logging data points setting)" is set in CH□ Logging read points setting value.	Set CH□ Logging read points setting value to a value within the range of "1 to (the value set in CH□ Logging data points setting)".
1DA□H	Logging data points setting range error	A value other than 0 to 900 is set in CH□ Logging data points setting.	Set CH□ Logging data points setting to 0 to 900.
1DB0H	Logging data points setting total range error	The total of values set in CH□ Logging data points setting is beyond 900.	Set values so that the total of values set in CH□ Logging data points setting of all channels becomes 900 or less.
1DC□H	Logging enable error (logging points setting 0)	For the channel where CH□ Logging enable/disable setting is set to Enable (0), 0 is set in CH□ Logging data points setting.	When using the normal logging function, set CH□ Logging data points setting to 1 to 900. When not using the normal logging function, set CH□ Logging enable/disable setting to Disable (1).

Error code	Error name	Description and cause	Action
1DD0H	Level trigger condition process alarm setting error	CH□ Level trigger condition setting is set to Process alarm (upper limit warning) (4) to Process alarm (upper limit warning/lower limit warning) (6) while CH□ Warning output setting (Process alarm) is set to Disable (1).	When setting CH□ Level trigger condition setting to Process alarm (upper limit warning) (4) to Process alarm (upper limit warning/lower limit warning) (6), set CH□ Warning output setting (Process alarm) to Enable (0).
1E50H	Offset/gain setting channel specification error	In the offset/gain setting, Setting channel (1) is set for both CH□ Offset/gain setting mode (offset specification) and CH□ Offset/gain setting mode (gain specification), or Disable (0) is set for both CH□ Offset/gain setting mode (offset specification) and CH□ Offset/gain setting mode (gain specification) of all channels.	Correctly set CH□ Offset/gain setting mode (offset specification) and CH□ Offset/gain setting mode (gain specification).
1E51H	User range data invalid (CH identification disabled)	An invalid value is set in the offset/gain setting. The number of the channel in which this error occurs cannot be identified.	Perform the offset/gain setting again for all channels where the user range setting is used. If the error occurs again, the possible cause is a failure of the module. Please consult your local Mitsubishi representative.
1E60H	User range data invalid (CH identification enabled)	An invalid value is set in the offset/gain setting for CH□.	Perform the offset/gain setting again for the channels where the error has occurred. If the error occurs again, the possible cause is a failure of the module. Please consult your local Mitsubishi representative.
1E70H	Offset/gain value inversion error	The offset value and gain value to be saved in the flash memory are as follows: Offset value $\geq$ Gain value	Perform the offset/gain setting again so that the following condition is satisfied: Offset value $<$ Gain value
1E80H	Offset/gain setting channel range error	A value other than Disable (0) and Setting channel (1) is set in CH□ Offset/gain setting mode (offset specification) and CH□ Offset/gain setting mode (gain specification).	Set CH□ Offset/gain setting mode (offset specification) and CH□ Offset/gain setting mode (gain specification) to Disable (0) or Setting channel (1).
1EA0H	Synchronization cycle time setting enabled range error	When the oversampling mode is enabled, the inter-module synchronization cycle setting of system parameter is set to either of the following: <ul style="list-style-type: none"><li>• The fixed scan interval setting is other than 0.05ms unit.</li><li>• Inter-module synchronization cycle setting <math>&gt;</math> 1ms</li></ul>	When enabling the oversampling mode, set the inter-module synchronization cycle setting of system parameter so that the following conditions are satisfied. <ul style="list-style-type: none"><li>• The fixed scan interval setting is set to 0.05ms unit.</li><li>• Inter-module synchronization cycle setting <math>\leq</math> 1ms</li></ul>
2610H	Inter-module synchronization signal error	Synchronization loss is detected with the inter-module synchronization function operating.	The module may be affected by noise. Check and adjust the cable wiring and the installation environment of the programmable controllers, and restart the system. If the error reoccurs even after the adjustment, the possible cause is a failure of the module. Please consult your local Mitsubishi representative.
3001H	Hardware failure (moderate)	A hardware failure (moderate) has occurred in the module.	Power off and on the module. If the error occurs again, the possible cause is a failure of the module. Please consult your local Mitsubishi representative.
3030H	Flash memory error	The data in the flash memory is abnormal.	Check the digital output values. If the values are abnormal, please consult your local Mitsubishi representative.

\*1 The error code is not stored in 'Latest error code' (Un\G0). It is written to Completion status area (S)+1 of the G(P).OGSTOR instruction.  
In addition, 'Error flag' (XF) does not turn on.

## 3.5 List of Alarm Codes

If an alarm occurs during operation, the A/D converter module stores the alarm code into 'Latest alarm code' (Un\G2) of the buffer memory. Turning on 'Error clear request' (YF) allows clearing of the alarm code of 'Latest alarm code' (Un\G2).

The following table lists the alarm codes that may be stored.

□ in an alarm code: This symbol indicates the number of the channel where an alarm has occurred. A numerical value of 0 to 3 is used to correspond to CH1 to 4.

(CH1: 0, CH2: 1, CH3: 2, CH4: 3)

Alarm code	Alarm name	Description and cause	Action
080□H	Process alarm (upper limit)	The process alarm (upper limit) has occurred in CH□.	
081□H	Process alarm (lower limit)	The process alarm (lower limit) has occurred in CH□.	Adjust CH□ Digital operation value to fall within the range. As a result, the corresponding bit of CH□ Warning output flag (Process alarm upper limit) or CH□ Warning output flag (Process alarm lower limit), and 'Warning output signal' (X8) turn off automatically.
082□H	Rate alarm (upper limit)	The rate alarm (upper limit) has occurred in CH□.	
083□H	Rate alarm (lower limit)	The rate alarm (lower limit) has occurred in CH□.	Adjust the change rate in CH□ Digital output value to fall within the range. As a result, the corresponding bit of CH□ Warning output flag (Rate alarm upper limit) or CH□ Warning output flag (Rate alarm lower limit), and 'Warning output signal' (X8) turn off automatically.
090□H	Input signal error detection (upper limit)	An input signal error (upper limit) has been detected in CH□.	
091□H	Input signal error detection (lower limit)	An input signal error (lower limit) has been detected in CH□.	The following operations are performed by turning on and off 'Error clear request' (YF) after the analog input value returns within the setting range. <ul style="list-style-type: none"> <li>• All bits of Input signal error detection flag turn to Normal (0).</li> <li>• 'Input signal error detection signal' (XC) turns off.</li> <li>• 'Latest alarm code' (Un\G2) is cleared.</li> </ul>
0A0□H	Input signal error detection (disconnection)	An input signal error (disconnection) has been detected in CH□.	
0B00H	Operating condition setting error during continuous logging	'Operating condition setting request' (Y9) has been turned on during continuous logging operation.	'Operating condition setting request' (Y9) cannot be turned on during continuous logging operation. Therefore, stop the continuous logging before turning on 'Operating condition setting request' (Y9).
0D00H	Mode switching request error	Mode switching has been attempted in the situation where it is not allowed.	For an inter-module synchronization target module, or the module where the operation mode is set to the simultaneous conversion mode, the switching to the offset/gain setting mode is not allowed. When performing the offset/gain setting, set the module as a synchronization non-target in the system parameters, or change the operation mode to the normal mode (medium speed: 10μs/CH) or normal mode (low speed: 20μs/CH). Then shift to the offset/gain setting mode. Turn on and off 'Error clear request' (YF) to clear the alarm.

# APPENDICES

## Appendix 1 Module Label

The functions of the A/D converter module can be set by using module labels.

### Module labels of I/O signals

The module label name of an I/O signal is defined with the following structure:

"Module name"\_"Module number".b"Label name" or "Module name"\_"Module number".b"Label name"\_D

**Ex.**

R60ADH\_1.bModuleREADY\_D

#### ■Module name

The character string of a module model name is given.

#### ■Module number

A number starting from 1 is added to identify modules that have the same module name.

#### ■Label name

The label identifier unique to a module is given.

#### ■\_D

This string indicates that the module label is for the direct access input (DX) or direct access output (DY). A module label without the string is for the input (X) or output (Y) of the refresh processing.

### Module labels of buffer memory areas

A

The module label name of a buffer memory area is defined with the following structure:

"Module name"\_"Module number".Data type"\_D["(Channel)"].Data format""Label name"\_D

**Ex.**

R60ADH\_1.stnMonitor\_D[0].wDigitalOutputValue\_D

#### ■Module name

The character string of a module model name is given.

#### ■Module number

A number starting from 1 is added to identify modules that have the same module name.

#### ■Data type

The data type to sort a buffer memory area is given. Each data type is as follows:

Data type	Description
stnMonitor	Monitor
stnControl	Control
stnSetting	Setting

#### ■Channel

The channel number corresponding to a module label is given. A numerical value of 0 to 3 is used to correspond to CH1 to 4. (CH1: 0, CH2: 1, CH3: 2, CH4: 3)

## ■Data format

The string that represents the data size of a buffer memory area is given. Each data format is as follows:

Data format	Description
u	Word [Unsigned]/Bit string [16-bit]
w	Word [Signed]
d	Double word [Signed]

## ■Label name

The label identifier unique to a module is given.

### ■\_D

This string indicates that the module label is for the direct access. A module label without the string is for the auto refresh. The following table shows the differences between the auto refresh and direct access.

Type	Description	Access timing	Example
Auto refresh	Values that are read from or written to the module label are reflected in the module collectively at the auto refresh. The run time of the program can be reduced. To use the auto refresh, set "Target" to "Module Label" in "Refresh settings" of "Module Parameter".	At auto refresh	R60ADH_1.stnMonitor[0].wDigitalOutputValue
Direct access	Values that are read from or written to the module label are reflected in the module instantly. Compared with the auto refresh, the run time of the program becomes longer. However, the responsiveness is high.	At reading/writing from/to the module label	R60ADH_1.stnMonitor_D[0].wDigitalOutputValue_D

# Appendix 2 I/O Signals

## List of I/O signals

The following table lists the I/O signals of the A/D converter module.

For details on the I/O signals, refer to the following.

☞ Page 156 Details of input signals

☞ Page 163 Details of output signals

### Point

- The I/O number (X/Y) described below shows the case when the start I/O number of the A/D converter module is set to "0".
- Do not use the "Use prohibited" signals shown below because the system uses them. If users use (turn off and on) the signals, the functions of the A/D converter module cannot be guaranteed.

### Input signal

Device number	Signal name
X0	Module READY
X1 to X7	Use prohibited
X8	Warning output signal
X9	Operating condition setting completed flag
XA	Offset/gain setting mode status flag
XB	Channel change completed flag
XC	Input signal error detection signal
XD	Maximum value/minimum value reset completed flag
XE	A/D conversion completed flag
XF	Error flag

### Output signal

Device number	Signal name
Y0	Use prohibited
Y1	CH1 Logging hold request
Y2	CH2 Logging hold request
Y3	CH3 Logging hold request
Y4	CH4 Logging hold request
Y5 to Y8	Use prohibited
Y9	Operating condition setting request
YA	User range write request
YB	Channel change request
YC	Use prohibited
YD	Maximum value/minimum value reset request
YE	Use prohibited
YF	Error clear request

A

## Details of input signals

The following describes the details of the input signals for the A/D converter module which are assigned to the CPU module. The I/O numbers (X/Y) described in this section are for the case when the start I/O number of the A/D converter module is set to 0.

### Point

This section describes buffer memory addresses for CH1. For details on the buffer memory addresses for CH2 and later, refer to the following.

☞ Page 166 List of buffer memory addresses

## Module READY

### Common

Module READY (X0) turns on to indicate the preparation for the A/D conversion is completed after the power-on or after the reset operation of the CPU module.

In the following cases, 'Module READY' (X0) turns off.

- In the offset/gain setting mode (In this case, the A/D conversion is performed.)
- When a watchdog timer error occurs in the A/D converter module (In this case, the A/D conversion is not performed.)

### ■Device number

The following shows the device number of this input signal.

Signal name	CH1	CH2	CH3	CH4
Module READY	X0			

## Warning output signal

### Common

'Warning output signal' (X8) turns on when the process alarm or rate alarm has been detected. When the warning output function is disabled for all channels, 'Warning output signal' (X8) is always off.

### ■Device number

The following shows the device number of this input signal.

Signal name	CH1	CH2	CH3	CH4
Warning output signal	X8			


### ■Process alarm

- 'Warning output signal' (X8) turns on when digital output values or digital operation values of the A/D conversion enabled channels exceed the ranges of the process alarm lower lower limit value to the process alarm upper upper limit value after 'CH1 Warning output setting (Process alarm)' (Un\G512) is set to Enable (0). The ALM LED also turns on.
- 'Warning output signal' (X8) turns off when the digital output values or digital operation values fall within the setting range in all the A/D conversion enabled channels. The ALM LED also turns off.

**■Rate alarm**

- 'Warning output signal' (X8) turns on when the change rate of digital output values of the A/D conversion enabled channels exceed the ranges of the rate alarm lower limit value to rate alarm upper limit value after 'CH1 Warning output setting (Rate alarm)' (Un\G513) is set to Enable (0). The ALM LED also turns on.
- 'Warning output signal' (X8) turns off when the change rate of the digital output values fall within the setting range in all the A/D conversion enabled channels. The ALM LED also turns off.

'Warning output flag (Process alarm upper limit)' (Un\G36)  
 'Warning output flag (Process alarm lower limit)' (Un\G37)  
 'Warning output flag (Rate alarm upper limit)' (Un\G38)  
 'Warning output flag (Rate alarm lower limit)' (Un\G39)



-----► Performed by the A/D converter module.


**Operating condition setting completed flag****Common**

When changing values of the buffer memory, use 'Operating condition setting completed flag' (X9) as an interlock condition to turn on and off 'Operating condition setting request' (Y9). For the buffer memory addresses that require turning on and off of 'Operating condition setting request' (Y9) to enable the new values, refer to the following.

☞ Page 166 List of buffer memory addresses

When 'Operating condition setting completed flag' (X9) is off, the A/D conversion is not performed.

When 'Operating condition setting request' (Y9) is on, 'Operating condition setting completed flag' (X9) turns off.



-----► Performed by the A/D converter module.

——► Performed by a program.

**■Device number**

The following shows the device number of this input signal.

Signal name	CH1	CH2	CH3	CH4
Operating condition setting completed flag	X9			

## Offset/gain setting mode status flag

Medium speed

Low speed

### ■Device number


The following shows the device number of this input signal.

Signal name	CH1	CH2	CH3	CH4
Offset/gain setting mode status flag	XA			

### ■In the offset/gain setting mode

When registering the value, which has been adjusted with the offset/gain setting, use 'Offset/gain setting mode status flag' (XA) as an interlock condition to turn on and off 'User range write request' (YA).

When the offset/gain setting is configured from the offset/gain setting window of an engineering tool, the setting is performed properly on the window. Therefore, a program is not required to perform the setting.




### ■In the normal mode

In the user range setting restoration, use 'Offset/gain setting mode status flag' (XA) as an interlock condition to turn on and off 'User range write request' (YA).

For user range setting restoration, refer to the following.

☞ Page 126 Backing up, Saving, and Restoring Offset/Gain Values




## Channel change completed flag

Medium speed

Low speed

When changing a channel to perform the offset/gain setting, use 'Channel change completed flag' (XB) as an interlock condition to turn on and off 'Channel change request' (YB). When the offset/gain setting is configured from the offset/gain setting window of an engineering tool, the setting is performed properly on the window. Therefore, a program is not required to perform the setting.



## ■ Device number

The following shows the device number of this input signal.

Signal name	CH1	CH2	CH3	CH4
Channel change completed flag	XB			

## Input signal error detection signal

## Common

## ■ Device number

The following shows the device number of this input signal.

Signal name	CH1	CH2	CH3	CH4
Input signal error detection signal	XC			

## ■Turning on 'Input signal error detection signal' (XC)

'Input signal error detection signal' (XC) turns on when an analog input value exceeds the range set with 'CH1 Input signal error detection lower limit setting value' (Un\G529) and 'CH1 Input signal error detection upper limit setting value' (Un\G530) in any of A/D conversion enabled channels, after the detection condition is set in 'CH1 Input signal error detection setting' (Un\G528). When the simple disconnection detection is set, the signal ignores the settings of 'CH1 Input signal error detection lower limit setting value' (Un\G529) and 'CH1 Input signal error detection upper limit setting value' (Un\G530) and turns on at the disconnection detection.

When 'Input signal error detection signal' (XC) turns on, the following operations are performed.

- 'CH1 Digital output value' (Un\G400) and 'CH1 Digital operation value' (Un\G402) hold the digital values just before the error was detected.
- The ALM LED flashes.

## ■Turning off 'Input signal error detection signal' (XC)

Turning off of 'Input signal error detection signal' (XC) varies depending on the setting of 'Input signal error detection auto-clear enable/disable setting' (Un\G302).

'Input signal error detection auto-clear enable/disable setting' (Un\G302)	Operation of when 'Input signal error detection signal' (XC) is off
Enable (0)	<p>When the cause of the input signal error is eliminated and the analog input value falls within the setting range, 'Input signal error detection signal' (XC) automatically turns off. When 'Input signal error detection signal' (XC) turns off, the following operations are performed.</p> <ul style="list-style-type: none"> <li>• The ALM LED turns off.</li> <li>• 'Input signal error detection flag' (Un\G40) turns off.</li> </ul>
Disable (1)	<p>'Input signal error detection signal' (XC) turns off by turning on and off 'Error clear request' (YF) after the cause of the input signal error is eliminated and the analog input value falls within the setting range. When 'Input signal error detection signal' (XC) turns off, the following operations are performed.</p> <ul style="list-style-type: none"> <li>• The ALM LED turns off.</li> <li>• 'Input signal error detection flag' (Un\G40) turns off.</li> <li>• 'Latest alarm code' (Un\G2) is cleared.</li> </ul> <p>The following diagram illustrates the timing of the signals when 'Input signal error detection signal' (XC) turns off:</p> <p>Legend:</p> <ul style="list-style-type: none"> <li>---&gt; Performed by the A/D converter module.</li> <li>—&gt; Performed by a program.</li> </ul>


### Point

- When the analog input value falls within the setting range, the A/D conversion is restarted regardless of turning on and off of 'Error clear request' (YF). However, the on state of 'Input signal error detection signal' (XC) and the flashing state of the ALM LED are not cleared.
- Averaging processing starts from the beginning after the A/D conversion is restarted.
- 'Input signal error detection signal' (XC) operates only when the input signal error detection function is enabled. When the input signal error detection function is disabled, 'Input signal error detection signal' (XC) is always off.

## Maximum value/minimum value reset completed flag

### Common

'Maximum value/minimum value reset completed flag' (XD) turns on after the maximum and minimum values stored in 'CH1 Maximum value' (Un\G404) and 'CH1 Minimum value' (Un\G406) are reset by turning on and off 'Maximum value/minimum value reset request' (YD).



----- → Performed by the A/D converter module.

→ Performed by a program.

### ■Device number

The following shows the device number of this input signal.

Signal name	CH1	CH2	CH3	CH4
Maximum value/minimum value reset completed flag	XD			

## A/D conversion completed flag

A

### Common

'A/D conversion completed flag' (XE) turns on when the first A/D conversion of all the channels where the A/D conversion is enabled is completed. To read digital output values, use this signal or 'A/D conversion completed flag' (Un\G42) as an interlock.

### ■Device number

The following shows the device number of this input signal.


Signal name	CH1	CH2	CH3	CH4
A/D conversion completed flag	XE			

## Error flag

### Common

'Error flag' (XF) turns on when an error occurs.

Turn on and off 'Error clear request' (YF) to clear 'Latest error code' (Un\G0) and 'Latest alarm code' (Un\G2).



-----► Performed by the A/D converter module.

→ Performed by a program.

### ■Device number

The following shows the device number of this input signal.

Signal name	CH1	CH2	CH3	CH4
Error flag	XF			

## Details of output signals

The following describes the details of the output signals for the A/D converter module which are assigned to the CPU module. The I/O numbers (X/Y) described in this section are for the case when the start I/O number of the A/D converter module is set to 0.

### Point

This section describes buffer memory addresses for CH1. For details on the buffer memory addresses for CH2 and later, refer to the following.

☞ Page 166 List of buffer memory addresses

### CH1 Logging hold request

#### Low speed

Use this signal as a trigger to hold (stop) logging at any timing during the logging.

When 'CH1 Logging enable/disable setting' (Un\G535) is set to Disable (1), the on or off of 'CH1 Logging hold request' (Y1) is ignored.

For details on the normal logging function, refer to the following.

☞ Page 69 Normal Logging Function

#### ■Device number

The following shows the device number of this output signal.

Signal name	CH1	CH2	CH3	CH4
Logging hold request	Y1	Y2	Y3	Y4

#### ■Operation of the logging hold processing

- When 'CH1 Level trigger condition setting' (Un\G542) is set to Disable (0), the logging hold processing starts by turning on 'CH1 Logging hold request' (Y1).
- When 'CH1 Level trigger condition setting' (Un\G542) is not set to Disable (0), the logging hold processing starts when the set trigger condition is satisfied after turning on 'CH1 Logging hold request' (Y1). When the level trigger is enabled, use this signal as an interlock condition to operate the level trigger.
- If 'CH1 Logging hold request' (Y1) is turned off during the logging hold processing, the hold (stop) state is cleared and the logging restarts.

### Point

The stop state of the logging can be checked with 'CH1 Logging hold flag' (Un\G409).

A

### Operating condition setting request

#### Common

Turn on and off 'Operating condition setting request' (Y9) to enable the setting of the A/D converter module.

For the timing of turning on and off the signal, refer to the following.

☞ Page 157 Operating condition setting completed flag

For details on the buffer memory areas to be enabled, refer to the following.

☞ Page 166 List of buffer memory addresses

#### ■Device number

The following shows the device number of this output signal.

Signal name	CH1	CH2	CH3	CH4
Operating condition setting request	Y9			

## User range write request

Medium speed

Low speed

### ■Device number

The following shows the device number of this output signal.

Signal name	CH1	CH2	CH3	CH4
User range write request	YA			

### ■In the offset/gain setting mode

Turn on and off 'User range write request' (YA) to register values adjusted with the offset/gain setting in the A/D converter module. The data is written to the flash memory when this signal is turned on from off.

For the timing of turning on and off the signal, refer to the following.

☞ Page 158 Offset/gain setting mode status flag

### ■In the normal mode

Turn on and off 'User range write request' (YA) to restore the user range.

For the timing of turning on and off the signal, refer to the following.

☞ Page 158 Offset/gain setting mode status flag

## Channel change request

Medium speed

Low speed

Turn on and off 'Channel change request' (YB) to change a channel to perform the offset/gain setting.

For the timing of turning on and off the signal, refer to the following.

☞ Page 159 Channel change completed flag

### ■Device number

The following shows the device number of this output signal.

Signal name	CH1	CH2	CH3	CH4
Channel change request	YB			

## Maximum value/minimum value reset request

Common

Turn on and off 'Maximum value/minimum value reset request' (YD) to clear the maximum and minimum values stored in 'CH1 Maximum value' (Un\G404) and 'CH1 Minimum value' (Un\G406).

For the timing of turning on and off the signal, refer to the following.

☞ Page 161 Maximum value/minimum value reset completed flag

### ■Device number

The following shows the device number of this output signal.

Signal name	CH1	CH2	CH3	CH4
Maximum value/minimum value reset request	YD			

## Error clear request

Common

Turn on and off 'Error clear request' (YF) to clear 'Error flag' (XF), 'Input signal error detection signal' (XC), 'Latest error code' (Un\G0), and 'Latest alarm code' (Un\G2). For the timing of turning on and off the signal, refer to the following.

☞ Page 159 Input signal error detection signal

☞ Page 162 Error flag

### ■Device number

The following shows the device number of this output signal.

Signal name	CH1	CH2	CH3	CH4
Error clear request	YF			

A

# Appendix 3 Buffer Memory Areas

## List of buffer memory addresses

This section shows the lists of buffer memory addresses of the A/D converter module. For details on the buffer memory addresses, refer to the following.

 Page 176 Details of buffer memory addresses

The buffer memory areas of the A/D converter module are classified by the following data types.

Data type	Description	
Setting data	Description	Set this data according to the connected device and the application of the system.
	Write/read attribute	Data can be read and written from/to this area.
	Setting method	Set this data using an engineering tool or a program.
	Setting timing	After changing values, turn on and off 'Operating condition setting request' (Y9) to enable the set values.
Control data	Description	Use this data to control the A/D converter module.
	Write/read attribute	Data can be read and written from/to this area.
	Setting method	Set this data using an engineering tool or a program.
	Setting timing	As soon as values are changed, the set values are enabled.
Monitor data	Description	Use this data to monitor the status of the A/D converter module.
	Write/read attribute	Reading data is only allowed. Writing data is not allowed.
	Setting method	—
	Setting timing	—
User range setting data	Description	Use this data to update the user range setting of the A/D converter module.
	Write/read attribute	Data can be read and written from/to this area.
	Setting method	Set this data using an engineering tool or a program.
	Setting timing	After changing values, turn on and off 'User range write request' (YA) to enable the set values.

### Point

Do not write data to the system areas and areas whose data types are monitor in the buffer memory. Writing data into these areas can cause the malfunction of the module.

## Un\G0 to Un\G399

Address (decimal)	Address (hexadecimal)	Name	Default value	Data type	Auto refresh
0	0H	Latest error code	0	Monitor	○
1	1H	Latest address of error history	0	Monitor	○
2	2H	Latest alarm code	0	Monitor	○
3	3H	Latest address of alarm history	0	Monitor	○
4 to 19	4H to 13H	Interrupt factor detection flag [n] <sup>*1</sup>	0	Monitor	○
20 to 35	14H to 23H	System area	—	—	—
36	24H	Warning output flag (Process alarm upper limit)	0000H	Monitor	○
37	25H	Warning output flag (Process alarm lower limit)	0000H	Monitor	○
38	26H	Warning output flag (Rate alarm upper limit)	0000H	Monitor	○
39	27H	Warning output flag (Rate alarm lower limit)	0000H	Monitor	○
40	28H	Input signal error detection flag	0000H	Monitor	○
41	29H	System area	—	—	—
42	2AH	A/D conversion completed flag	0000H	Monitor	○
43 to 59	2BH to 3BH	System area	—	—	—
60	3CH	Operation mode monitor	2	Monitor	×
61	3DH	Continuous logging status monitor	0	Monitor	×
62 to 69	3EH to 45H	System area	—	—	—
70	46H	RUN LED status monitor	0000H	Monitor	×
71	47H	ERR LED status monitor	0000H	Monitor	×
72	48H	ALM LED status monitor	0000H	Monitor	×
73 to 89	49H to 59H	System area	—	—	—
90	5AH	Level data 0	0	Control	○
91	5BH	Level data 1	0	Control	○
92	5CH	Level data 2	0	Control	○
93	5DH	Level data 3	0	Control	○
94	5EH	Level data 4	0	Control	○
95	5FH	Level data 5	0	Control	○
96	60H	Level data 6	0	Control	○
97	61H	Level data 7	0	Control	○
98	62H	Level data 8	0	Control	○
99	63H	Level data 9	0	Control	○
100	64H	Continuous logging start/stop request	0	Control	×
101 to 123	65H to 7BH	System area	—	—	—
124 to 139	7CH to 8BH	Interrupt factor mask [n] <sup>*1</sup>	0	Control	×
140 to 155	8CH to 9BH	System area	—	—	—
156 to 171	9CH to ABH	Interrupt factor reset request [n] <sup>*1</sup>	0	Control	×
172 to 199	ACH to C7H	System area	—	—	—
200 to 215	C8H to D7H	Interrupt factor generation setting [n] <sup>*1</sup>	0	Setting	×
216 to 231	D8H to E7H	System area	—	—	—
232 to 247	E8H to F7H	Condition target setting [n] <sup>*1</sup>	0	Setting	×
248 to 263	F8H to 107H	System area	—	—	—
264 to 279	108H to 117H	Condition target channel setting [n] <sup>*1</sup>	0	Setting	×
280	118H	Continuous logging cycle setting value	1	Setting	×
281 to 295	119H to 127H	System area	—	—	—
296, 297	128H, 129H	Mode switching setting	0	Setting	×
298 to 301	12AH to 12DH	System area	—	—	—
302	12EH	Input signal error detection auto-clear enable/disable setting	1	Setting	×
303 to 399	12FH to 18FH	System area	—	—	—

<sup>\*1</sup> [n] in the table indicates an interrupt setting number. (n = 1 to 16)

## Un\G400 to Un\G3599

Address Decimal (hexadecimal)				Name	Default value	Data type	Auto refresh
CH1	CH2	CH3	CH4				
400 (190H)	600 (258H)	800 (320H)	1000 (3E8H)	CH□ Digital output value	0	Monitor	○
401 (191H)	601 (259H)	801 (321H)	1001 (3E9H)	System area	—	—	—
402 (192H)	602 (25AH)	802 (322H)	1002 (3EAH)	CH□ Digital operation value	0	Monitor	○
403 (193H)	603 (25BH)	803 (323H)	1003 (3EBH)	System area	—	—	—
404 (194H)	604 (25CH)	804 (324H)	1004 (3ECH)	CH□ Maximum value	0	Monitor	○
405 (195H)	605 (25DH)	805 (325H)	1005 (3EDH)	System area	—	—	—
406 (196H)	606 (25EH)	806 (326H)	1006 (3EEH)	CH□ Minimum value	0	Monitor	○
407 (197H)	607 (25FH)	807 (327H)	1007 (3EFH)	System area	—	—	—
408 (198H)	608 (260H)	808 (328H)	1008 (3F0H)	CH□ Difference conversion status flag	0	Monitor	○
409 (199H)	609 (261H)	809 (329H)	1009 (3F1H)	CH□ Logging hold flag	0	Monitor	○
410 to 429 (19AH to 1ADH)	610 to 629 (262H to 275H)	810 to 829 (32AH to 33DH)	1010 to 1029 (3F2H to 405H)	System area	—	—	—
430 (1AEH)	630 (276H)	830 (33EH)	1030 (406H)	CH□ Range setting monitor	0	Monitor	×
431 (1AFH)	631 (277H)	831 (33FH)	1031 (407H)	System area	—	—	—
432 (1B0H)	632 (278H)	832 (340H)	1032 (408H)	CH□ Difference conversion reference value	0	Monitor	×
433 (1B1H)	633 (279H)	833 (341H)	1033 (409H)	System area	—	—	—
434 (1B2H)	634 (27AH)	834 (342H)	1034 (40AH)	CH□ Logging start address monitor (L)	0	Monitor	×
435 (1B3H)	635 (27BH)	835 (343H)	1035 (40BH)	CH□ Logging start address monitor (H)			
436 (1B4H)	636 (27CH)	836 (344H)	1036 (40CH)	CH□ Head pointer (L)	0	Monitor	×
437 (1B5H)	637 (27DH)	837 (345H)	1037 (40DH)	CH□ Head pointer (H)			
438 (1B6H)	638 (27EH)	838 (346H)	1038 (40EH)	CH□ Latest pointer (L)	0	Monitor	×
439 (1B7H)	639 (27FH)	839 (347H)	1039 (40FH)	CH□ Latest pointer (H)			
440 (1B8H)	640 (280H)	840 (348H)	1040 (410H)	CH□ Number of logging data (L)	0	Monitor	×
441 (1B9H)	641 (281H)	841 (349H)	1041 (411H)	CH□ Number of logging data (H)			
442 (1BAH)	642 (282H)	842 (34AH)	1042 (412H)	CH□ Trigger pointer (L)	0	Monitor	×
443 (1BBH)	643 (283H)	843 (34BH)	1043 (413H)	CH□ Trigger pointer (H)			
444 (1BCH)	644 (284H)	844 (34CH)	1044 (414H)	CH□ Current logging read pointer (L)	-1	Monitor	×
445 (1BDH)	645 (285H)	845 (34DH)	1045 (415H)	CH□ Current logging read pointer (H)			

Address Decimal (hexadecimal)				Name	Default value	Data type	Auto refresh
CH1	CH2	CH3	CH4				
446 (1BEH)	646 (286H)	846 (34EH)	1046 (416H)	CH□ Previous logging read pointer (L)	-1	Monitor	x
447 (1BFH)	647 (287H)	847 (34FH)	1047 (417H)	CH□ Previous logging read pointer (H)			
448 (1C0H)	648 (288H)	848 (350H)	1048 (418H)	CH□ Logging read points monitor value (L)	0	Monitor	x
449 (1C1H)	649 (289H)	849 (351H)	1049 (419H)	CH□ Logging read points monitor value (H)			
450 (1C2H)	650 (28AH)	850 (352H)	1050 (41AH)	CH□ Logging cycle monitor value (s)	0	Monitor	x
451 (1C3H)	651 (28BH)	851 (353H)	1051 (41BH)	CH□ Logging cycle monitor value (ms)	0	Monitor	x
452 (1C4H)	652 (28CH)	852 (354H)	1052 (41CH)	CH□ Logging cycle monitor value (μs)	0	Monitor	x
453 (1C5H)	653 (28DH)	853 (355H)	1053 (41DH)	CH□ Trigger generation time (First/Last two digits of the year)	0	Monitor	x
454 (1C6H)	654 (28EH)	854 (356H)	1054 (41EH)	CH□ Trigger generation time (Month/Day)	0	Monitor	x
455 (1C7H)	655 (28FH)	855 (357H)	1055 (41FH)	CH□ Trigger generation time (Hour/Minute)	0	Monitor	x
456 (1C8H)	656 (290H)	856 (358H)	1056 (420H)	CH□ Trigger generation time (Second/Day of the week)	0	Monitor	x
457 (1C9H)	657 (291H)	857 (359H)	1057 (421H)	CH□ Trigger generation time (Millisecond)	0	Monitor	x
458 (1CAH)	658 (292H)	858 (35AH)	1058 (422H)	CH□ Logging status monitor value	000FH	Monitor	x
459 (1CBH)	659 (293H)	859 (35BH)	1059 (423H)	CH□ A/D conversion status monitor	0	Monitor	x
460 (1CCH)	660 (294H)	860 (35CH)	1060 (424H)	CH□ Averaging process status monitor	0	Monitor	x
461 to 469 (1CDH to 1D5H)	661 to 669 (295H to 29DH)	861 to 869 (35DH to 365H)	1061 to 1069 (425H to 42DH)	System area	—	—	—
470 (1D6H)	670 (29EH)	870 (366H)	1070 (42EH)	CH□ Difference conversion trigger	0	Control	○
471 (1D7H)	671 (29FH)	871 (367H)	1071 (42FH)	System area	—	—	—
472 (1D8H)	672 (2A0H)	872 (368H)	1072 (430H)	CH□ Conversion value shift amount	0	Control	○
473 (1D9H)	673 (2A1H)	873 (369H)	1073 (431H)	System area	—	—	—
474 (1DAH)	674 (2A2H)	874 (36AH)	1074 (432H)	CH□ Continuous logging data A side storage flag	0	Control	x
475 (1DBH)	675 (2A3H)	875 (36BH)	1075 (433H)	CH□ Continuous logging data B side storage flag	0	Control	x
476 to 499 (1DCH to 1F3H)	676 to 699 (2A4H to 2BBH)	876 to 899 (36CH to 383H)	1076 to 1099 (434H to 44BH)	System area	—	—	—
500 (1F4H)	700 (2BCH)	900 (384H)	1100 (44CH)	CH□ A/D conversion enable/disable setting	1	Setting	x
501 (1F5H)	701 (2BDH)	901 (385H)	1101 (44DH)	CH□ Averaging process specification	0	Setting	x
502 (1F6H)	702 (2BEH)	902 (386H)	1102 (44EH)	CH□ Time average/Count average/Moving average/Primary delay filter constant setting	0	Setting	x
503 (1F7H)	703 (2BFH)	903 (387H)	1103 (44FH)	System area	—	—	—

Address Decimal (hexadecimal)				Name	Default value	Data type	Auto refresh
CH1	CH2	CH3	CH4				
504 (1F8H)	704 (2C0H)	904 (388H)	1104 (450H)	CH□ Scaling enable/disable setting	1	Setting	×
505 (1F9H)	705 (2C1H)	905 (389H)	1105 (451H)	System area	—	—	—
506 (1FAH)	706 (2C2H)	906 (38AH)	1106 (452H)	CH□ Scaling upper limit value	0	Setting	×
507 (1FBH)	707 (2C3H)	907 (38BH)	1107 (453H)	System area	—	—	—
508 (1FCH)	708 (2C4H)	908 (38CH)	1108 (454H)	CH□ Scaling lower limit value	0	Setting	×
509 (1FDH)	709 (2C5H)	909 (38DH)	1109 (455H)	System area	—	—	—
510 (1FEH)	710 (2C6H)	910 (38EH)	1110 (456H)	CH□ Digital clipping enable/disable setting	1	Setting	×
511 (1FFH)	711 (2C7H)	911 (38FH)	1111 (457H)	System area	—	—	—
512 (200H)	712 (2C8H)	912 (390H)	1112 (458H)	CH□ Warning output setting (Process alarm)	1	Setting	×
513 (201H)	713 (2C9H)	913 (391H)	1113 (459H)	CH□ Warning output setting (Rate alarm)	1	Setting	×
514 (202H)	714 (2CAH)	914 (392H)	1114 (45AH)	CH□ Process alarm upper upper limit value	0	Setting	×
515 (203H)	715 (2CBH)	915 (393H)	1115 (45BH)	System area	—	—	—
516 (204H)	716 (2CCH)	916 (394H)	1116 (45CH)	CH□ Process alarm upper lower limit value	0	Setting	×
517 (205H)	717 (2CDH)	917 (395H)	1117 (45DH)	System area	—	—	—
518 (206H)	718 (2CEH)	918 (396H)	1118 (45EH)	CH□ Process alarm lower upper limit value	0	Setting	×
519 (207H)	719 (2CFH)	919 (397H)	1119 (45FH)	System area	—	—	—
520 (208H)	720 (2D0H)	920 (398H)	1120 (460H)	CH□ Process alarm lower lower limit value	0	Setting	×
521 (209H)	721 (2D1H)	921 (399H)	1121 (461H)	System area	—	—	—
522 (20AH)	722 (2D2H)	922 (39AH)	1122 (462H)	CH□ Rate alarm warning detection cycle setting	0	Setting	×
523 (20BH)	723 (2D3H)	923 (39BH)	1123 (463H)	System area	—	—	—
524 (20CH)	724 (2D4H)	924 (39CH)	1124 (464H)	CH□ Rate alarm upper limit value	0	Setting	×
525 (20DH)	725 (2D5H)	925 (39DH)	1125 (465H)	System area	—	—	—
526 (20EH)	726 (2D6H)	926 (39EH)	1126 (466H)	CH□ Rate alarm lower limit value	0	Setting	×
527 (20FH)	727 (2D7H)	927 (39FH)	1127 (467H)	System area	—	—	—
528 (210H)	728 (2D8H)	928 (3A0H)	1128 (468H)	CH□ Input signal error detection setting	0	Setting	×
529 (211H)	729 (2D9H)	929 (3A1H)	1129 (469H)	CH□ Input signal error detection lower limit setting value	50	Setting	×
530 (212H)	730 (2DAH)	930 (3A2H)	1130 (46AH)	CH□ Input signal error detection upper limit setting value	50	Setting	×
531 to 534 (213H to 216H)	731 to 734 (2DBH to 2DEH)	931 to 934 (3A3H to 3A6H)	1131 to 1134 (46BH to 46EH)	System area	—	—	—
535 (217H)	735 (2DFH)	935 (3A7H)	1135 (46FH)	CH□ Logging enable/disable setting	1	Setting	×

Address Decimal (hexadecimal)				Name	Default value	Data type	Auto refresh
CH1	CH2	CH3	CH4				
536 (218H)	736 (2E0H)	936 (3A8H)	1136 (470H)	CH□ Logging data points setting	200	Setting	×
537 (219H)	737 (2E1H)	937 (3A9H)	1137 (471H)	CH□ Logging data setting	1	Setting	×
538 (21AH)	738 (2E2H)	938 (3AAH)	1138 (472H)	CH□ Logging cycle setting value	4	Setting	×
539 (21BH)	739 (2E3H)	939 (3ABH)	1139 (473H)	CH□ Logging cycle unit setting	1	Setting	×
540 (21CH)	740 (2E4H)	940 (3ACH)	1140 (474H)	CH□ Post-trigger logging points (L)	10000	Setting	×
541 (21DH)	741 (2E5H)	941 (3ADH)	1141 (475H)	CH□ Post-trigger logging points (H)			
542 (21EH)	742 (2E6H)	942 (3AEH)	1142 (476H)	CH□ Level trigger condition setting	0	Setting	×
543 (21FH)	743 (2E7H)	943 (3AFH)	1143 (477H)	CH□ Trigger data	*1	Setting	×
544 (220H)	744 (2E8H)	944 (3B0H)	1144 (478H)	CH□ Trigger setting value	0	Setting	×
545 (221H)	745 (2E9H)	945 (3B1H)	1145 (479H)	CH□ Trigger judgment count setting value	1	Setting	×
546 (222H)	746 (2EAH)	946 (3B2H)	1146 (47AH)	CH□ Loading interrupt enable/disable setting	1	Setting	×
547 (223H)	747 (2EBH)	947 (3B3H)	1147 (47BH)	CH□ Logging read points setting value	10	Setting	×
548 to 559 (224H to 22FH)	748 to 759 (2ECH to 2F7H)	948 to 959 (3B4H to 3BFH)	1148 to 1159 (47CH to 487H)	System area	—	—	—
560 (230H)	760 (2F8H)	960 (3C0H)	1160 (488H)	CH□ LPF Pass band edge frequency	0	Setting	×
561 (231H)	761 (2F9H)	961 (3C1H)	1161 (489H)	System area	—	—	—
562 (232H)	762 (2FAH)	962 (3C2H)	1162 (48AH)	CH□ HPF Pass band edge frequency	0	Setting	×
563 (233H)	763 (2FBH)	963 (3C3H)	1163 (48BH)	System area	—	—	—
564 (234H)	764 (2FCH)	964 (3C4H)	1164 (48CH)	CH□ BPF Pass band edge frequency (Low)	0	Setting	×
565 (235H)	765 (2FDH)	965 (3C5H)	1165 (48DH)	System area	—	—	—
566 (236H)	766 (2FEH)	966 (3C6H)	1166 (48EH)	CH□ BPF Pass band edge frequency (High)	0	Setting	×
567 (237H)	767 (2FFH)	967 (3C7H)	1167 (48FH)	System area	—	—	—
568 (238H)	768 (300H)	968 (3C8H)	1168 (490H)	CH□ Attenuation band width	0	Setting	×
569 to 597 (239H to 255H)	769 to 797 (301H to 31DH)	969 to 997 (3C9H to 3E5H)	1169 to 1197 (491H to 4ADH)	System area	—	—	—
598 (256H)	798 (31EH)	998 (3E6H)	1198 (4AEH)	CH□ Range setting	0	Setting	×
599 (257H)	799 (31FH)	999 (3E7H)	1199 (4AFH)	System area	—	—	—
1200 to 3599 (4B0H to E0FH)				System area	—	—	—

\*1 The following shows the default values.

CH1: 402, CH2: 602, CH3: 802, CH4: 1002

## Error history and alarm history (Un\G3600 to Un\G3999)

Address (decimal)	Address (hexadecimal)	Name				Default value	Data type	Auto refresh			
3600	E10H	Error history 1	Error code			0	Monitor	x			
3601	E11H		Error time	First two digits of the year	Last two digits of the year						
3602	E12H		Month	Day							
3603	E13H		Hour	Minute							
3604	E14H		Second	Day of the week							
3605	E15H		Millisecond								
3606 to 3609	E16H to E19H		System area								
3610 to 3615	E1AH to E1FH	Error history 2	Same as error history 1			0	Monitor	x			
3616 to 3619	E20H to E23H	System area				—	—	—			
3620 to 3625	E24H to E29H	Error history 3	Same as error history 1			0	Monitor	x			
3626 to 3629	E2AH to E2DH	System area				—	—	—			
3630 to 3635	E2EH to E33H	Error history 4	Same as error history 1			0	Monitor	x			
3636 to 3639	E34H to E37H	System area				—	—	—			
3640 to 3645	E38H to E3DH	Error history 5	Same as error history 1			0	Monitor	x			
3646 to 3649	E3EH to E41H	System area				—	—	—			
3650 to 3655	E42H to E47H	Error history 6	Same as error history 1			0	Monitor	x			
3656 to 3659	E48H to E4BH	System area				—	—	—			
3660 to 3665	E4CH to E51H	Error history 7	Same as error history 1			0	Monitor	x			
3666 to 3669	E52H to E55H	System area				—	—	—			
3670 to 3675	E56H to E5BH	Error history 8	Same as error history 1			0	Monitor	x			
3676 to 3679	E5CH to E5FH	System area				—	—	—			
3680 to 3685	E60H to E65H	Error history 9	Same as error history 1			0	Monitor	x			
3686 to 3689	E66H to E69H	System area				—	—	—			
3690 to 3695	E6AH to E6FH	Error history 10	Same as error history 1			0	Monitor	x			
3696 to 3699	E70H to E73H	System area				—	—	—			
3700 to 3705	E74H to E79H	Error history 11	Same as error history 1			0	Monitor	x			
3706 to 3709	E7AH to E7DH	System area				—	—	—			
3710 to 3715	E7EH to E83H	Error history 12	Same as error history 1			0	Monitor	x			
3716 to 3719	E84H to E87H	System area				—	—	—			
3720 to 3725	E88H to E8DH	Error history 13	Same as error history 1			0	Monitor	x			
3726 to 3729	E8EH to E91H	System area				—	—	—			
3730 to 3735	E92H to E97H	Error history 14	Same as error history 1			0	Monitor	x			
3736 to 3739	E98H to E9BH	System area				—	—	—			
3740 to 3745	E9CH to EA1H	Error history 15	Same as error history 1			0	Monitor	x			
3746 to 3749	EA2H to EA5H	System area				—	—	—			
3750 to 3755	EA6H to EABH	Error history 16	Same as error history 1			0	Monitor	x			
3756 to 3759	EACH to EAFH	System area				—	—	—			
3760	EB0H	Alarm history 1	Alarm code			0	Monitor	x			
3761	EB1H		Alarm time	First two digits of the year	Last two digits of the year						
3762	EB2H		Month	Day							
3763	EB3H		Hour	Minute							
3764	EB4H		Second	Day of the week							
3765	EB5H		Millisecond								
3766 to 3769	EB6H to EB9H		System area								
3770 to 3775	EBAH to EBFH	Alarm history 2	Same as alarm history 1			0	Monitor	x			

Address (decimal)	Address (hexadecimal)	Name	Default value	Data type	Auto refresh
3776 to 3779	EC0H to EC3H	System area	—	—	—
3780 to 3785	EC4H to EC9H	Alarm history 3	Same as alarm history 1	0	Monitor
3786 to 3789	ECAH to ECDH	System area	—	—	—
3790 to 3795	ECEH to ED3H	Alarm history 4	Same as alarm history 1	0	Monitor
3796 to 3799	ED4H to ED7H	System area	—	—	—
3800 to 3805	ED8H to EDDH	Alarm history 5	Same as alarm history 1	0	Monitor
3806 to 3809	EDEH to EE1H	System area	—	—	—
3810 to 3815	EE2H to EE7H	Alarm history 6	Same as alarm history 1	0	Monitor
3816 to 3819	EE8H to EEBH	System area	—	—	—
3820 to 3825	EECH to EF1H	Alarm history 7	Same as alarm history 1	0	Monitor
3826 to 3829	EF2H to EF5H	System area	—	—	—
3830 to 3835	EF6H to EFBH	Alarm history 8	Same as alarm history 1	0	Monitor
3836 to 3839	EFCH to EFFH	System area	—	—	—
3840 to 3845	F00H to F05H	Alarm history 9	Same as alarm history 1	0	Monitor
3846 to 3849	F06H to F09H	System area	—	—	—
3850 to 3855	F0AH to F0FH	Alarm history 10	Same as alarm history 1	0	Monitor
3856 to 3859	F10H to F13H	System area	—	—	—
3860 to 3865	F14H to F19H	Alarm history 11	Same as alarm history 1	0	Monitor
3866 to 3869	F1AH to F1DH	System area	—	—	—
3870 to 3875	F1EH to F23H	Alarm history 12	Same as alarm history 1	0	Monitor
3876 to 3879	F24H to F27H	System area	—	—	—
3880 to 3885	F28H to F2DH	Alarm history 13	Same as alarm history 1	0	Monitor
3886 to 3889	F2EH to F31H	System area	—	—	—
3890 to 3895	F32H to F37H	Alarm history 14	Same as alarm history 1	0	Monitor
3896 to 3899	F38H to F3BH	System area	—	—	—
3900 to 3905	F3CH to F41H	Alarm history 15	Same as alarm history 1	0	Monitor
3906 to 3909	F42H to F45H	System area	—	—	—
3910 to 3915	F46H to F4BH	Alarm history 16	Same as alarm history 1	0	Monitor
3916 to 3929	F4CH to F59H	System area	—	—	—
3930	F5AH	Clear setting of error history	0	Setting <sup>*1</sup>	×
3931 to 3999	F5CH to F9FH	System area	—	—	—

\*1 As soon as a setting value is input, the setting is enabled. Turning on and off 'Operating condition setting request' (Y9) is not required.

## Offset/gain setting (Un\G4000 to Un\G9499)

Address Decimal (hexadecimal)				Name	Default value	Data type	Auto refresh
CH1	CH2	CH3	CH4				
4000, 4001 (FA0H, FA1H)				System area	—	—	—
4002 (FA2H)				Save data type setting	0000H	Setting	×
4003 (FA3H)				System area	—	—	—
4004 (FA4H)	4008 (FA8H)	4012 (FACH)	4016 (FB0H)	CH□ Factory default setting offset value (L)	0	User range setting	×
4005 (FA5H)	4009 (FA9H)	4013 (FADH)	4017 (FB1H)	CH□ Factory default setting offset value (H)	0	User range setting	×
4006 (FA6H)	4010 (FAAH)	4014 (FAEH)	4018 (FB2H)	CH□ Factory default setting gain value (L)	0	User range setting	×
4007 (FA7H)	4011 (FABH)	4015 (FAFH)	4019 (FB3H)	CH□ Factory default setting gain value (H)	0	User range setting	×
4020 (FB4H)	4024 (FA8H)	4028 (FACH)	4032 (FC0H)	CH□ User range setting offset value (L)	0	User range setting	×
4021 (FB5H)	4025 (FA9H)	4029 (FADH)	4033 (FC1H)	CH□ User range setting offset value (H)	0	User range setting	×
4022 (FB6H)	4026 (FAAH)	4030 (FAEH)	4034 (FC2H)	CH□ User range setting gain value (L)	0	User range setting	×
4023 (FB7H)	4027 (FABH)	4031 (FAFH)	4035 (FC3H)	CH□ User range setting gain value (H)	0	User range setting	×
4036 to 4131 (FC4H to 1023H)				System area	—	—	—
4132 (1024H)	4134 (1026H)	4136 (1028H)	4138 (102AH)	CH□ Offset/gain setting mode (offset specification)	0	User range setting	×
4133 (1025H)	4135 (1027H)	4137 (1029H)	4139 (102BH)	CH□ Offset/gain setting mode (gain specification)	0	User range setting	×
4140 to 4163 (102CH to 1043H)				System area	—	—	—
4164	4165	4166	4167	CH□ Offset/gain setting mode (range specification)	0	User range setting	×
4168 to 9499 (1048H to 251BH)				System area	—	—	—

## Inter-module synchronization (Un\G9500 to Un\G9999)

Address Decimal (hexadecimal)				Name	Default value	Data type	Auto refresh
CH1	CH2	CH3	CH4				
9500 (251CH)	9502 (251EH)	9504 (2520H)	9506 (2522H)	CH□ Synchronization digital output value	0	Monitor	○
9501 (251DH)	9503 (251FH)	9505 (2521H)	9507 (2523H)	System area	—	—	—
9508 to 9599 (2524H to 257FH)				System area	—	—	—
9600 (2580H)				Synchronization status monitor	0	Monitor	○
9601 (2581H)				Oversampling mode monitor	0	Monitor	×
9602 to 9999 (2582H to 270FH)				System area	—	—	—

**Logging data (Un\G10000 to Un\G99999)****■When the normal logging function is used**

Address (decimal)	Address (hexadecimal)	Name	Default value	Data type	Auto refresh
10000 to 99999	2710H to 1869FH	Logging data area	0	Monitor	×

**■When the continuous logging function is used**

Address Decimal (hexadecimal)				Name	Default value	Data type	Auto refresh
CH1	CH2	CH3	CH4				
10000 to 19999 (2710H to 4E1FH)	20000 to 29999 (4E20H to 752FH)	30000 to 39999 (7530H to 9C3FH)	40000 to 49999 (9C40H to C34FH)	CH□ Logging data area	0	Monitor	×
50000 to 99999 (C350H to 1869FH)				System area	—	—	—

# Details of buffer memory addresses

The following describes the details of the buffer memory addresses of the A/D converter module.



This chapter describes I/O signals and buffer memory addresses for CH1. For details on the I/O signals for CH2 and later, refer to the following.

Page 155 List of I/O signals

## Latest error code

Common

The latest error code detected in the A/D converter module is stored. For details, refer to the following.

Page 146 List of Error Codes

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
Latest error code	0			

### ■Clearing an error

Turn on and off 'Error clear request' (YF) or 'Operating condition setting request' (Y9). However, when 'Operating condition setting request' (Y9) is turned on and off, the A/D conversion is reset and the processing is started from the beginning.

## Latest address of error history

Common

Among Error history □ (UnlG3600 to UnlG3759), a buffer memory address which stores the latest error code is stored.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
Latest address of error history	1			

## Latest alarm code

Common

The latest alarm code detected in the A/D converter module is stored. For details, refer to the following.

Page 152 List of Alarm Codes

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
Latest alarm code	2			

### ■Clearing an alarm

Turn on and off 'Error clear request' (YF) or 'Operating condition setting request' (Y9). However, when 'Operating condition setting request' (Y9) is turned on and off, the A/D conversion is reset and the processing is started from the beginning.

## Latest address of alarm history

Common

Among Alarm history □ (Un\G3760 to Un\G3919), a buffer memory address which stores the latest alarm code is stored.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
Latest address of alarm history	3			

## Interrupt factor detection flag [n]

Low speed

Simultaneous conversion

Synchronization

The detection status of the interrupt factor is stored.

Monitored value	Description
0	No interrupt factor
1	Interrupt factor

When an interrupt factor occurs, an interrupt request is sent to the CPU module at the same time as when 'Interrupt factor detection flag [n]' (Un\G4 to Un\G19) is turned to Interrupt factor (1).

"n" indicates an interrupt setting number. (n = 1 to 16)

### ■Buffer memory address


The following shows the buffer memory address of this area.

Buffer memory name	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Interrupt factor detection flag [n]	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19

## Warning output flag (Process alarm upper limit)

Common

The upper limit warning of the process alarm can be checked for each channel.



(1) 0: Normal, 1: Alarm ON

(2) b4 to b15 are fixed to 0.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
Warning output flag (Process alarm upper limit)	36			

### ■Warning output flag status

- When a value is out of the range specified in 'CH1 Process alarm upper upper limit value' (Un\G514), Alarm ON (1) is stored in the corresponding bit of 'Warning output flag (Process alarm upper limit)' (Un\G36).
- When a warning is detected in any channel where the A/D conversion and the warning output setting (process alarm) are enabled, 'Warning output signal' (X8) also turns on.

### ■Clearing Warning output flag


- When the digital operation value falls within the set range, the flag is automatically cleared.
- When 'Operating condition setting request' (Y9) is turned on and off, the flag is cleared.

A

## Warning output flag (Process alarm lower limit)

Common

The lower limit warning of the process alarm can be checked for each channel.



(1) 0: Normal, 1: Alarm ON

(2) b4 to b15 are fixed to 0.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
Warning output flag (Process alarm lower limit)	37			

### ■Warning output flag status

- When a value is out of the range specified in 'CH1 Process alarm lower lower limit value' (Un\G520), Alarm ON (1) is stored in the corresponding bit of 'Warning output flag (Process alarm lower limit)' (Un\G37).
- When a warning is detected in any channel where the A/D conversion and the warning output setting (process alarm) are enabled, 'Warning output signal' (X8) also turns on.

### ■Clearing Warning output flag


- When the digital operation value falls within the set range, the flag is automatically cleared.
- When 'Operating condition setting request' (Y9) is turned on and off, the flag is cleared.

## Warning output flag (Rate alarm upper limit)

Medium speed

Low speed

The upper limit warning of the rate alarm can be checked for each channel.



(1) 0: Normal, 1: Alarm ON

(2) b4 to b15 are fixed to 0.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
Warning output flag (Rate alarm upper limit)	38			

### ■Warning output flag status

- When a value is out of the range specified in 'CH1 Rate alarm upper limit value' (Un\G524), Alarm ON (1) is stored in the corresponding bit of 'Warning output flag (Rate alarm upper limit)' (Un\G38).
- When a warning is detected in any channel where the A/D conversion and the warning output setting (rate alarm) are enabled, 'Warning output signal' (X8) also turns on.

### ■Clearing Warning output flag


- When the change rate of the digital output value falls within the set range, the flag is automatically cleared.
- When 'Operating condition setting request' (Y9) is turned on and off, the flag is cleared.

## Warning output flag (Rate alarm lower limit)

Medium speed

Low speed

The lower limit warning of the rate alarm can be checked for each channel.



(1) 0: Normal, 1: Alarm ON

(2) b4 to b15 are fixed to 0.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
Warning output flag (Rate alarm lower limit)	39			

### ■Warning output flag status

- When a value is out of the range specified in 'CH1 Rate alarm lower limit value' (Un\G526), Alarm ON (1) is stored in the corresponding bit of 'Warning output flag (Rate alarm lower limit)' (Un\G39).
- When a warning is detected in any channel where the A/D conversion and the warning output setting (rate alarm) are enabled, 'Warning output signal' (X8) also turns on.

### ■Clearing Warning output flag


- When the change rate of the digital output value falls within the set range, the flag is automatically cleared.
- When 'Operating condition setting request' (Y9) is turned on and off, the flag is cleared.

## Input signal error detection flag

Common

A

The status of an input signal can be checked for each channel.



(1) 0: Normal, 1: Input signal error

(2) b4 to b15 are fixed to 0.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
Input signal error detection flag	40			

### ■Input signal error detection flag status

- When an analog input value out of the range set with 'CH1 Input signal error detection lower limit setting value' (Un\G529) and 'CH1 Input signal error detection upper limit setting value' (Un\G530) is detected, Input signal error (1) is stored in the corresponding bit of 'Input signal error detection flag' (Un\G40).
- When an error is detected in any channel where the A/D conversion and the input signal error detection are enabled, 'Input signal error detection signal' (XC) turns on.

## ■Clearing Input signal error detection flag


Turning off of 'Input signal error detection flag' (Un\G40) varies depending on the setting of 'Input signal error detection auto-clear enable/disable setting' (Un\G302).

'Input signal error detection auto-clear enable/disable setting' (Un\G302)		Operations when 'Input signal error detection flag' (Un\G40) is turned off
Enable (0)		<p>When the cause of the input signal error is eliminated and the analog input value falls within the set range, 'Input signal error detection flag' (Un\G40) automatically turns off. When 'Input signal error detection flag' (Un\G40) turns off, the following operations are performed.</p> <ul style="list-style-type: none"> <li>• The ALM LED turns off.</li> <li>• 'Input signal error detection signal' (XC) turns off.</li> </ul>
Disable (1)		<p>When 'Error clear request' (YF) is turned on and off after the cause of the input signal error is eliminated and the analog input value falls within the set range, 'Input signal error detection flag' (Un\G40) turns off. When 'Input signal error detection flag' (Un\G40) turns off, the following operations are performed.</p> <ul style="list-style-type: none"> <li>• The ALM LED turns off.</li> <li>• 'Input signal error detection signal' (XC) turns off.</li> <li>• 'Latest alarm code' (Un\G2) is cleared.</li> </ul> <p>Turning on and off 'Operating condition setting request' (Y9) also clears 'Input signal error detection flag' (Un\G40). However, the A/D conversion is reset and the processing is started from the beginning.</p>

## A/D conversion completed flag

Common

The A/D conversion status can be checked.



(1) 0: During A/D conversion or unused, 1: A/D conversion completed

(2) b4 to b15 are fixed to 0.

## ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
A/D conversion completed flag	42			

## ■A/D conversion completed flag status

When the first A/D conversion is completed in the channel where the A/D conversion is enabled, the flag turns to A/D conversion completed (1). 'A/D conversion completed flag' (XE) turns on when the conversion in all the channels where the A/D conversion is enabled is completed.

## ■Clearing A/D conversion completed flag

Turning on and off 'Operating condition setting request' (Y9) turns the flag back to the default (During A/D conversion or unused (0)), and when the first A/D conversion is completed, the flag turns to A/D conversion completed (1) again.

## Operation mode monitor

Common

The current operation mode is stored.

Monitored value	Description
1	Normal mode (medium speed: 10μs/CH)
2	Normal mode (low speed: 20μs/CH)
3	Simultaneous conversion mode (5μs/4CH)
4	Inter-module synchronization mode
5	Offset/gain setting mode

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
Operation mode monitor	60			

## Continuous logging status monitor

Simultaneous  
conversion

Synchronization

The execution status of the continuous logging function is stored.

Monitored value	Description
0	Continuous logging disable status
1	Continuous logging start request waiting
2	Continuous logging in process

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
Continuous logging status monitor	61			

A

## RUN LED status monitor

Common

The current status of the RUN LED is stored.

Monitored value	Description
0	Off
1	On
2	Flashing (1s cycle)
3	Flashing (400ms cycle)

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
RUN LED status monitor	70			

## ERR LED status monitor

Common

The current status of the ERR LED is stored.

Monitored value	Description
0	Off
1	On

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
ERR LED status monitor	71			

## ALM LED status monitor

Common

The current status of the ALM LED is stored.

Monitored value	Description
0	Off
1	On
2	Flashing

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
ALM LED status monitor	72			

## Level data 0 to 9

Low speed

This area stores data to be monitored when a level trigger of the normal logging function is used. Ten types of data are available: 'Level data 0' (Un\G90) to 'Level data 9' (Un\G99). Use the area to generate triggers while monitoring the values in devices other than the A/D converter module.

For details on the normal logging function, refer to the following.

☞ Page 69 Normal Logging Function

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	0	1	2	3	4	5	6	7	8	9
Level data□	90	91	92	93	94	95	96	97	98	99

### ■Setting range

The setting range is from -32768 to 32767.

### ■Default value

The default value is 0 for all areas.

## Continuous logging start/stop request

Simultaneous  
conversion

Synchronization

Starting or stopping of continuous logging can be set collectively for all channels.

For details on the continuous logging function, refer to the following.

☞ Page 94 Continuous Logging Function

Setting value	Setting details
0	Stop
1	Start

- Changing 'Continuous logging start/stop request' (Un\G100) from Stop (0) to Start (1) starts the continuous logging.
- Changing 'Continuous logging start/stop request' (Un\G100) from Start (1) to Stop (0) stops the continuous logging.
- If a value other than the above is set, the request is ignored and the operation of continuous logging does not change.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
Continuous logging start/stop request	100			

### ■Default value

The default value is Stop (0).

## Interrupt factor mask [n]

Low speed

Simultaneous  
conversion

Synchronization

Set whether to mask interrupt factors.

Setting value	Setting details
0	Mask (Interrupt unused)
1	Mask clear (Interrupt used)

When 'Interrupt factor mask [n]' (Un\G124 to Un\G139) is changed to Mask clear (Interrupt used) (1) and an interrupt factor occurs, an interrupt request is sent to the CPU module. When the set value is two or larger, the setting is regarded as Mask clear (Interrupt used) (1).

"n" indicates an interrupt setting number. (n = 1 to 16)

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Interrupt factor mask [n]	124	125	126	127	128	129	130	131	132	133	134	135	136	137	138	139

### ■Default value

The default value is Mask (Interrupt unused) (0) for all areas.

A

## Interrupt factor reset request [n]

Low speed

Simultaneous conversion

Synchronization

Set whether to send the interrupt factor reset request.

Setting value	Setting details
0	No reset request
1	Reset request

When Reset request (1) is set in 'Interrupt factor reset request [n]' (Un\G156 to Un\G171) corresponding to the interrupt factor, the interrupt factor of the specified interrupt is reset. After that, 'Interrupt factor reset request [n]' (Un\G156 to Un\G171) turns to No reset request (0). When the set value is two or larger, the setting is regarded as Reset request (1).

Turning on and off 'Operating condition setting request' (Y9) also resets interrupt factors.

"n" indicates an interrupt setting number. (n = 1 to 16)

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Interrupt factor reset request [n]	156	157	158	159	160	161	162	163	164	165	166	167	168	169	170	171

### ■Default value

The default value is No reset request (0) for all areas.

## Interrupt factor generation setting [n]

Low speed

Simultaneous conversion

Synchronization

Set whether to send an interrupt request when the same interrupt factor occurs during the interrupt factor detection.

Setting value	Setting details
0	Interrupt resend request
1	No interrupt resend request

- If a value other than the above is set, an interrupt factor generation setting range error (error code: 180△H) occurs.
- When 'Interrupt factor generation setting [n]' (Un\G200 to Un\G215) is Interrupt resend request (0) and the same interrupt factor occurs while the interrupt factor has been detected, an interrupt request is sent to the CPU module again.
- When 'Interrupt factor generation setting [n]' (Un\G200 to Un\G215) is No interrupt resend request (1) and the same interrupt factor occurs while the interrupt factor has been detected, an interrupt request is not sent to the CPU module. To send an interrupt request to the CPU module, do it after setting Reset request (1) in 'Interrupt factor reset request [n]' (Un\G156 to Un\G171) and resetting the interrupt factor.

"n" indicates an interrupt setting number. (n = 1 to 16)

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Interrupt factor generation setting [n]	200	201	202	203	204	205	206	207	208	209	210	211	212	213	214	215

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is Interrupt resend request (0) for all areas.

## Condition target setting [n]

Low speed

Simultaneous conversion

Synchronization

Set an interrupt factor to be detected.

Setting value	Setting details	Available operation mode
0	Disable	Low speed Simultaneous conversion Synchronization
1	Error flag (XF)	
2	Warning output flag (Process alarm)	
3	Warning output flag (Rate alarm)	
4	Input signal error detection flag	
5	A/D conversion completed	
6	Logging hold flag	
7	Logging read	
8	Continuous logging data storage	Simultaneous conversion

- When a value out of the setting range for each operation mode is set, a condition target setting range error (error code:  $181\triangle H$ ) occurs.
- When an input signal (X) or a buffer memory area set in 'Condition target setting [n]' (Un\G232 to Un\G247) turns on, an interrupt request is sent to the CPU module. However, when A/D conversion completed (5) is set, turning on 'A/D conversion completed flag' (Un\G42) sends an interrupt request to the CPU module.
- The same combination of the settings in 'Condition target setting [n]' (Un\G232 to Un\G247) and 'Condition target channel setting [n]' (Un\G264 to Un\G279) cannot be used for multiple interrupt settings (1 to 16). If the same setting combination is used for two or more interrupt settings, an interrupt condition setting overlap error (error code:  $183\triangle H$ ) occurs. Note that setting All channels (0) in 'Condition target channel setting [n]' (Un\G264 to Un\G279) is regarded the same as setting CH1 (1), CH2 (2), CH3 (3), or CH4 (4) in 'Condition target channel setting [n]' (Un\G264 to Un\G279). Thus, the condition target where all channels are specified cannot be used for multiple interrupt settings.

"n" indicates an interrupt setting number. (n = 1 to 16)

A

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Condition target setting [n]	232	233	234	235	236	237	238	239	240	241	242	243	244	245	246	247

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is Disable (0) for all areas.

## Condition target channel setting [n]

Low speed

Simultaneous conversion

Synchronization

Set a channel where an interrupt is detected.

Setting value	Setting details
0	All channels
1	CH1
2	CH2
3	CH3
4	CH4

When an interrupt factor with channel specification is set in 'Condition target setting [n]' (Un\G232 to Un\G247), an interrupt factor is monitored in the channel set by this area. When an input signal (X) is set as an interrupt factor, the setting in this area is ignored.

If a value other than the above is set, a condition target channel setting range error (error code: 182△H) occurs.

"n" indicates an interrupt setting number. (n = 1 to 16)

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Condition target channel setting [n]	264	265	266	267	268	269	270	271	272	273	274	275	276	277	278	279

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is All channels (0) for all areas.

## Continuous logging cycle setting value

Simultaneous conversion

Set a cycle for storing data logged by the continuous logging function collectively for all channels.

### ■Setting range

The setting range is from 1 to 1000.

- The value 0 is regarded as 1.
- A value within the range of 1001 to 65535 is regarded as 1000.

The continuous logging cycle is the value obtained by the value in this area × 5μs (conversion cycle). Thus, the actual continuous logging cycle can be set within the range of 5μs to 5000μs.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
Continuous logging cycle setting value	280			

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 1.

## Mode switching setting

Medium speed

Low speed

Set a setting value for the mode to be switched.

Switching mode	Setting value		
<b>Buffer memory address</b>	<b>296</b>		
Normal mode	5260H	4144H	
Offset/gain setting mode	4144H	5260H	

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
Mode switching setting	296, 297			

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■After the mode is switched

When the mode is switched, this area is cleared to 0 and 'Operating condition setting completed flag' (X9) turns off.

After checking that 'Operating condition setting completed flag' (X9) is off, turn off 'Operating condition setting request' (Y9).



- If a value other than the above is set, the mode is not switched but only the operating condition is changed.
- In the simultaneous conversion mode or the inter-module synchronization mode, a mode switching request error (alarm code: 0D00H) occurs when 'Operating condition setting request' (Y9) is turned on and the mode is not switched.

## Input signal error detection auto-clear enable/disable setting

Common

A

Set whether to enable or disable the auto-clearing of an input signal error detected with the input signal error detection function.

For details on the input signal error detection function, refer to the following.

☞ Page 59 Input Signal Error Detection Function

Setting value	Setting details
0	Enable
1	Disable

If a value other than the above is set, the value is regarded as Disable (1).

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
Input signal error detection auto-clear enable/disable setting	302			

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).


### ■Default value

The default value is Disable (1).

## CH1 Digital output value

### Common

The A/D-converted digital output value is stored as a 16-bit signed binary value.



### Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Digital output value	400	600	800	1000

### Updating cycle

The updating cycle of this area varies depending on the mode.


Mode	Updating cycle
Normal mode (medium speed: 10μs/CH)	When time average or count average is performed, values are updated at every averaging process cycle. When the processing other than them is performed, values are updated at every sampling cycle.
Normal mode (low speed: 20μs/CH)	Values are always updated every 5μs cycle. However, when the continuous logging function is used, values are updated every time 'CH1 Continuous logging data A side storage flag' (Un\G474) or 'CH1 Continuous logging data B side storage flag' (Un\G475) is turned on.
Simultaneous conversion mode	Values are always updated every 5μs cycle. However, when the continuous logging function is used, values are updated every time 'CH1 Continuous logging data A side storage flag' (Un\G474) or 'CH1 Continuous logging data B side storage flag' (Un\G475) is turned on.
Inter-module synchronization mode	Values are not updated at the same timing as 'CH1 Synchronization digital output value' (Un\G9500). Thus, the values cannot be referred to with the interrupt program executed by the CPU module at the synchronization cycle.

## CH1 Digital operation value

### Medium speed

### Low speed

A digital operation value obtained by the scaling function, shift function, digital clipping function, or difference conversion function is stored as a 16-bit signed binary value.



### Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Digital operation value	402	602	802	1002

### Updating cycle

When time average or count average is performed, values are updated at every averaging process cycle. When the processing other than them is performed, values are updated at every sampling cycle.



When the scaling function, shift function, digital clipping function, or difference conversion function is not used, a value same as the one in 'CH1 Digital output value' (Un\G400) is stored.

## CH1 Maximum value, CH1 Minimum value

Common

The maximum value and minimum value of digital operation values or digital output values are stored as 16-bit signed binary values.

In the following cases, 'CH1 Maximum value' (Un\G404) and 'CH1 Minimum value' (Un\G406) are updated with the current values.

- When 'Operating condition setting request' (Y9) is turned on and off and the setting is changed
- When 'Maximum value/minimum value reset request' (YD) is turned on and off

### ■ Stored value

The value to be stored varies depending on the mode.

Mode	Stored value
Normal mode (medium speed: 10μs/CH) Normal mode (low speed: 20μs/CH)	The maximum and minimum values of the digital operation values are stored.
Simultaneous conversion mode Inter-module synchronization mode	The maximum and minimum values of the digital output values are stored.

### ■ Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Maximum value	404	604	804	1004
CH□ Minimum value	406	606	806	1006

#### Point

- For the channel to which the averaging processing is specified, the maximum and minimum values are stored at every averaging processing time.
- When the scaling function, shift function, digital clipping function, or difference conversion function is used, values calculated by each function are stored in Maximum value and Minimum value.

A

## CH1 Difference conversion status flag

Medium speed

Low speed

The difference conversion status can be checked.

Monitored value	Description
0	Not converted
1	Converting difference

When the difference conversion starts after 'CH1 Difference conversion trigger' (Un\G470) is changed from No request (0) to Trigger request (1), 'CH1 Difference conversion status flag' (Un\G408) turns to Converting difference (1).

When 'CH1 Difference conversion trigger' (Un\G470) is changed from Trigger request (1) to No request (0), 'CH1 Difference conversion status flag' (Un\G408) is changed from Converting difference (1) to Not converted (0).

'CH1 Difference conversion status flag' (Un\G408) is Converting difference (1) during the difference conversion; Not converted (0) while the difference conversion is not in process.

### ■ Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Difference conversion status flag	408	608	808	1008

## CH1 Logging hold flag

Low speed

When the normal logging function is used, the logging holding status can be checked.

For details on the normal logging function, refer to the following.

☞ Page 69 Normal Logging Function

Monitored value	Description
0	OFF
1	ON

When the state in which data is being collected in Logging data area (Un\G10000 to Un\G99999) changes to the stop state, 'CH1 Logging hold flag' (Un\G409) turns to ON (1).

When 'CH1 Logging hold request' (Y1) is changed from ON (1) to OFF (0) to restart logging, 'CH1 Logging hold flag' (Un\G409) turns to OFF (0).

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Logging hold flag	409	609	809	1009

## CH1 Range setting monitor

Common

The input range value set in the input range setting or 'CH1 Range setting' (Un\G598) can be checked.

Monitored value	Description
0H	4 to 20mA
1H	0 to 20mA
2H	1 to 5V
3H	0 to 5V
4H	-10 to 10V
5H	0 to 10V
AH	4 to 20mA (extended mode)
BH	1 to 5V (extended mode)
FH	User range setting

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Range setting monitor	430	630	830	1030

## CH1 Difference conversion reference value

Medium speed

Low speed

This area stores the value in 'CH1 Digital operation value' (Un\G402) at the start of the difference conversion as the difference conversion reference value.

The difference conversion reference value is updated when 'CH1 Difference conversion trigger' (Un\G470) is changed from No request (0) to Trigger request (1).

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Difference conversion reference value	432	632	832	1032

### ■Storage range

The storage range is from -32768 to 32767.



Even if 'CH1 Difference conversion status flag' (Un\G408) is changed from Converting difference (1) to Not converted (0), 'CH1 Difference conversion reference value' (Un\G432) is not cleared.

## CH1 Logging start address monitor

Low speed

The start address of Logging data area (Un\G10000 to Un\G99999) of each channel can be checked.

### ■Stored value

Values are updated when 'CH1 Logging data points setting' (Un\G536) is updated.

A

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Logging start address monitor	434, 435	634, 635	834, 835	1034, 1035

## CH1 Head pointer

Low speed

The buffer memory address of the oldest data of each channel in Logging data area (Un\G10000 to Un\G99999) can be checked with this buffer memory area.

The offset value counted from the start address of each channel is stored.

### ■Buffer memory address

The following shows the buffer memory address of this area.


Buffer memory name	CH1	CH2	CH3	CH4
CH□ Head pointer	436, 437	636, 637	836, 837	1036, 1037

Ex.

When the value of 'CH2 Head pointer' (Un\G636, Un\G637) is 8550 with the following settings

- 'CH1 Logging data points setting' (Un\G536): 100 (10000 points)
- 'CH2 Logging data points setting' (Un\G736): 100 (10000 points)

In this case, the start address of CH2 is Un\G20000.



Point

- At the first round of data logging, while data is being logged for the number of data points set in 'CH1 Logging data points setting' (Un\G536), the oldest data is stored in the start address of Logging data area (Un\G10000 to Un\G99999). Thus, the value of 'CH1 Head pointer' (Un\G436, Un\G437) has been fixed to 0. As for data logging for points set in 'CH1 Logging data points setting' (Un\G536) + 1 and larger, the value in 'CH1 Head pointer' (Un\G436, Un\G437) increases by one every time the data is stored.
- When 'CH1 Logging hold request' (Y1) is turned off, 'CH1 Head pointer' (Un\G436, Un\G437) is cleared to 0.

## CH1 Latest pointer

Low speed

The buffer memory address of the latest data of each channel in Logging data area (Un\G10000 to Un\G99999) can be checked with this buffer memory area.

The offset value counted from the start address of each channel is stored.

### ■Buffer memory address

The following shows the buffer memory address of this area.


Buffer memory name	CH1	CH2	CH3	CH4
CH□ Latest pointer	438, 439	638, 639	838, 839	1038, 1039

Ex.

When the value of 'CH2 Latest pointer' (Un\G638, Un\G639) is 8549 with the following settings

- 'CH1 Logging data points setting' (Un\G536): 100 (10000 points)
- 'CH2 Logging data points setting' (Un\G736): 100 (10000 points)

In this case, the start address of CH2 is Un\G20000.



Point

- 'CH1 Latest pointer' (Un\G438, Un\G439) increases by one every time data is stored after the start of the logging.
- When 'CH1 Logging hold request' (Y1) is turned off, 'CH1 Latest pointer' (Un\G438, Un\G439) is cleared to 0.

A

## CH1 Number of logging data

Low speed

Simultaneous conversion

Synchronization

The number of logging data points stored in Logging data area of each channel can be checked during the logging.

### ■ Updating the number of logging data

The process of update varies depending on the logging function in use.

Logging function in use	Updating the number of logging data
Normal logging function	<ul style="list-style-type: none"><li>The value in 'CH1 Number of logging data' (Un\G440, Un\G441) increases by one every time data is stored after the start of the logging. When the number of logging data points reaches the value set in 'CH1 Logging data points setting' (Un\G536) <math>\times</math> 100, the logging data area is overwritten with new data from the start address. Thus, the value in 'CH1 Number of logging data' (Un\G440, Un\G441) is fixed to the value of 'CH1 Logging data points setting' (Un\G536) <math>\times</math> 100.</li><li>When 'CH1 Logging hold request' (Y1) is turned off, 'CH1 Number of logging data' (Un\G440, Un\G441) is cleared to 0.</li></ul>
Continuous logging function	<ul style="list-style-type: none"><li>When continuous logging is started, Number of logging data increases by 5000 every time logging data of 5000 points is stored. When the data count reaches to 720000000, Number of logging data returns to 0 and then increases by 5000 again.</li><li>When 'Continuous logging start/stop request' (Un\G100) is changed from Stop (0) to Start (1), 'CH1 Number of logging data' (Un\G440, Un\G441) is cleared to 0.</li></ul>

For details on each logging function, refer to the following.

☞ Page 69 Normal Logging Function

☞ Page 94 Continuous Logging Function

### ■ Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Number of logging data	440, 441	640, 641	840, 841	1040, 1041

## CH1 Trigger pointer

Low speed

This buffer memory area enables users to check which buffer memory address of Logging data area (Un\G10000 to Un\G99999) stores the data at the hold trigger generation.

Trigger pointer stores the difference between the address storing the data at the hold trigger generation and the start address of Logging data area (Un\G10000 to Un\G99999).

For details on the normal logging function, refer to the following.

☞ Page 69 Normal Logging Function

### ■ Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Trigger pointer	442, 443	642, 643	842, 843	1042, 1043



When 'CH1 Logging hold request' (Y1) is turned off, 'CH1 Trigger pointer' (Un\G442, Un\G443) is cleared to 0.

## CH1 Current logging read pointer

Low speed

Every time data is logged for the amount equivalent to the logging read points monitor value, a value calculated by the following formula is stored in this area.

CH1 Current logging read pointer = CH1 Latest pointer - CH1 Logging read points monitor value + 1

For details on the normal logging function, refer to the following.

☞ Page 69 Normal Logging Function

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Current logging read pointer	444, 445	644, 645	844, 845	1044, 1045

## CH1 Previous logging read pointer

Low speed

Immediately before an interrupt request is sent to the CPU module, the value in Current logging read pointer, which is not yet updated by the interrupt, is stored in this area.

For details on the normal logging function, refer to the following.

☞ Page 69 Normal Logging Function

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Previous logging read pointer	446, 447	646, 647	846, 847	1046, 1047

## CH1 Logging read points monitor value

Low speed

The number of the actual logging read points is stored.

When 'Operating condition setting request' (Y9) is turned on and off, the value is not stored in the corresponding area of the channel where the logging read function is disabled.

For details on the normal logging function, refer to the following.

☞ Page 69 Normal Logging Function

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Logging read points monitor value	448, 449	648, 649	848, 849	1048, 1049

A

## CH1 Logging cycle monitor value

Low speed

Simultaneous conversion

Simultaneous conversion

This area stores the actual logging cycle that is calculated from the updating cycle of data to be logged.

When 'Operating condition setting request' (Y9) is turned on and off, the actual logging cycle is stored in Logging cycle monitor value in the corresponding channel where a logging function is enabled.

For details on each logging function, refer to the following.

☞ Page 69 Normal Logging Function

☞ Page 94 Continuous Logging Function

The following values are stored in 'CH1 Logging cycle monitor value' (Un\G450 to Un\G452).

	b15	...	b0
(1)		s	
(2)		ms	
(3)		μs	

(1) 'CH1 Logging cycle monitor value (s)' (Un\G450)\*1

(2) 'CH1 Logging cycle monitor value (ms)' (Un\G451)\*1

(3) 'CH1 Logging cycle monitor value (μs)' (Un\G452)

\*1 Logging cycle monitor value is not updated in the simultaneous conversion mode or the inter-module synchronization mode.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Logging cycle monitor value (s)	450	650	850	1050
CH□ Logging cycle monitor value (ms)	451	651	851	1051
CH□ Logging cycle monitor value (μs)	452	652	852	1052

## CH1 Trigger generation time

Low speed

Simultaneous  
conversionSimultaneous  
conversion

When the normal logging function is used, the time when a trigger was generated is recorded. When the continuous logging function is used, the time when the continuous logging has started is recorded.

For details on each logging function, refer to the following.

☞ Page 69 Normal Logging Function

☞ Page 94 Continuous Logging Function

	b15	...	b8 b7	...	b0
Un\G453		First two digits of the year		Last two digits of the year	
Un\G454		Month		Day	
Un\G455		Hour		Minute	
Un\G456		Second		Day of the week	
Un\G457		Millisecond (higher-order digits)		Millisecond (lower-order digits)	

Item	Storage contents	Storage example <sup>*1</sup>
First two digits of the year	Stored in BCD code.	2015H
Month		1224H
Hour		1234H
Second		56H
Day of the week	One of the following values is stored in BCD code. Sunday: 0, Monday: 1, Tuesday: 2, Wednesday: 3 Thursday: 4, Friday: 5, Saturday: 6	4H
Millisecond (upper)	Stored in BCD code.	7H
Millisecond (lower)		89H

\*1 Values stored when a trigger is generated at 12:34:56.789 on Saturday, December 24th, 2015.

### Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Trigger generation time (First/Last two digits of the year)	453	653	853	1053
CH□ Trigger generation time (Month/Day)	454	654	854	1054
CH□ Trigger generation time (Hour/Minute)	455	655	855	1055
CH□ Trigger generation time (Second/Day of the week)	456	656	856	1056
CH□ Trigger generation time (Millisecond)	457	657	857	1057

A

## CH1 Logging status monitor value

Common

This area stores the execution status of logging.

For details on the normal logging function, refer to the following.

☞ Page 69 Normal Logging Function

Execution status of logging	Stored value
Stop (disabled)	FH
Logging hold request waiting (during logging)	0H
Level trigger waiting (during logging)	1H
Trigger existing (during logging)	2H
Logging hold completed (stop)	3H

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Logging status monitor value	458	658	858	1058

## CH1 A/D conversion status monitor

Common

This area stores the A/D conversion status.

A/D conversion status	Description	Stored value
Conversion disabled	The A/D conversion is disabled. The A/D conversion in the corresponding channel is not executed.	0
Conversion started	Status until the completion of the first A/D conversion after the A/D conversion is enabled	1
Conversion completed	Status after the completion of the first A/D conversion. The A/D conversion is being executed.	2
Input signal error detected	Status when an input signal error has been detected.	3

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ A/D conversion status monitor	459	659	859	1059

## CH1 Averaging process status monitor

Common

This area stores the A/D conversion method that is being executed.

Averaging processing status	Stored value
Sampling processing	0
Time average	1
Count average	2
Moving average	3
Primary delay filter	4
Low pass filter	5
High pass filter	6
Band pass filter	7

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Averaging process status monitor	460	660	860	1060

## CH1 Difference conversion trigger

Medium speed      Low speed

Use this buffer memory area as a trigger to start or stop the difference conversion.

For details on the difference conversion function, refer to the following.

☞ Page 46 Difference Conversion Function

Setting value	Setting details
0	No request
1	Trigger request

If a value other than the above is set, the value is regarded as Trigger request (1).

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Difference conversion trigger	470	670	870	1070

### ■Starting and stopping the difference conversion

- When 'CH1 Difference conversion trigger' (Un\G470) is changed from No request (0) to Trigger request (1), the difference conversion starts.
- When 'CH1 Difference conversion trigger' (Un\G470) is changed from Trigger request (1) to No request (0), the difference conversion stops.

### ■Default value

The default value is No request (0) for all channels.

## CH1 Conversion value shift amount

Medium speed      Low speed


A

Set the conversion value shift amount to be used by the shift function.

The digital operation value to which the conversion value shift amount is applied is stored in 'CH1 Digital operation value' (Un\G402).

For details on the shift function, refer to the following.

☞ Page 41 Shift Function



(1) Data section  
(2) Sign bit 0: Positive, 1: Negative

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Conversion value shift amount	472	672	872	1072

### ■Setting range

The setting range is from -32768 to 32767.

### ■Enabling the setting

Regardless of turning on and off 'Operating condition setting request' (Y9), the conversion value shift amount becomes enabled when it is set.

### ■Default value

The default value is 0 for all channels.

## CH1 Continuous logging data storage flag

Simultaneous conversion

Synchronization

Use this buffer memory area to check that data of 5000 points is stored in Logging data area of each channel during continuous logging.

This area has two flags; 'CH1 Continuous logging data A side storage flag' (Un\G474) for checking that data is stored in the first 5000 points area (A side) of Logging data area and 'CH1 Continuous logging data B side storage flag' (Un\G475) for checking that data is stored in the last 5000 points area (B side) of Logging data area.

For details on the continuous logging function, refer to the following.

☞ Page 94 Continuous Logging Function

Setting value	Setting details
0	<ul style="list-style-type: none"><li>Logging data storage in A side not completed</li><li>Logging data storage in B side not completed</li></ul>
1	<ul style="list-style-type: none"><li>Logging data storage in A side completed</li><li>Logging data storage in B side completed</li></ul>

- Logging data storage completed (1) is stored every time logging data for the first 5000 points (A side) or the last 5000 points (B side) has been stored.
- When logging data storage in the file registers of the CPU module is completed, Logging data storage not completed (0) is stored in this area. With this timing, the area becomes ready to accept the next storage flag.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Continuous logging data A side storage flag	474	674	874	1074
CH□ Continuous logging data B side storage flag	475	675	875	1075

### ■Default value

The default value is 0 for all channels.

## CH1 A/D conversion enable/disable setting

Common

Set whether to enable or disable the A/D conversion.

For details on the A/D conversion enable/disable setting function, refer to the following.

☞ Page 21 A/D Conversion Enable/Disable Setting Function

Setting value	Setting details
0	A/D conversion enable
1	A/D conversion disable

When a value other than the above is set, the value is regarded as A/D conversion disable (1).

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ A/D conversion enable/disable setting	500	700	900	1100

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is A/D conversion disable (1) for all channels.

## CH1 Averaging process specification

### Common

Set the processing to be performed among the sampling processing, averaging processing, and filter processing. The available processing varies depending on the mode.

Setting value <sup>*1</sup>	Setting details	Available mode	
0	Sampling processing	Common	
1	Time average <sup>*2</sup>	Medium speed Low speed	
2	Count average <sup>*2</sup>	Medium speed Low speed	
3	Moving average	Common	
4	Primary delay filter <sup>*2</sup>	Medium speed Low speed	
5	Low pass filter <sup>*2</sup>	Medium speed Low speed	
6	High pass filter <sup>*2</sup>	Medium speed Low speed	
7	Band pass filter <sup>*2</sup>	Medium speed Low speed	

\*1 If a value other than the setting values is set, an averaging process specification setting range error (error code: 1910H) occurs.

\*2 If a value other than Sampling processing (0) and Moving average (3) is set in the simultaneous conversion mode or the inter-module synchronization mode, an averaging process specification setting range error (error code: 1910H) occurs.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH0 Averaging process specification	501	701	901	1101

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is Sampling processing (0) for all channels.

A

## CH1 Time average/Count average/Moving average/Primary delay filter constant setting

### Common

Set the time (for averaging), count (for averaging), moving average count, and primary delay filter constant for when Time average (1), Count average (2), Moving average (3), or Primary delay filter (4) is set in 'CH1 Averaging process specification' (Un\G501).

The following table lists the setting ranges.

Setting value	Setting details
1 to 5000 (ms)	Time average
4 to 62500 (times)	Count average
2 to 1000 (times)	Moving average
1 to 500 (times)	Primary delay filter constant

If a value other than the above is set, any of a time average setting range error (error code: 192□H), count average setting range error (error code: 193□H), moving average setting range error (error code: 194□H), or primary delay filter constant setting range error (error code: 195□H) occurs, and the A/D conversion processing is performed with the setting before the occurrence of the error.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Time average/Count average/Moving average/Primary delay filter constant setting	502	702	902	1102

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 0 for all channels.



- Set a primary delay filter constant for the primary delay filter. The value of the time constant (ms) is the product of the primary delay filter constant and the sampling cycle.
- Since the default value is 0, change the value depending on the processing.
- When Sampling processing (0), Low pass filter (5), High pass filter (6), or Band pass filter (7) is set in 'CH1 Averaging process specification' (Un\G501), the setting of this area is ignored.

## CH1 Scaling enable/disable setting

Medium speed

Low speed

Set whether to enable or disable the scaling.

For details on the scaling function, refer to the following.

☞ Page 38 Scaling Function

Setting value	Setting details
0	Enable
1	Disable

If a value other than the above is set, a scaling enable/disable setting range error (error code: 1A0□H) occurs.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Scaling enable/disable setting	504	704	904	1104

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is Disable (1) for all channels.

## CH1 Scaling upper limit value

Medium speed

Low speed

Set an upper limit value for the range of the scale conversion.

For details on the scaling function, refer to the following.

☞ Page 38 Scaling Function

A

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Scaling upper limit value	506	706	906	1106

### ■Setting range

- The setting range is from -32000 to 32000.
- In the channel where a set value does not satisfy the condition "the scaling upper limit value ≠ the scaling lower limit value", a scaling upper/lower limit value setting error (error code: 1A2□H) occurs.
- In the channel where a value out of the setting range is set, a scaling setting range error (error code: 1A1□H) occurs.
- When 'CH1 Scaling enable/disable setting' (Un\G504) is set to Disable (1), the setting of 'CH1 Scaling upper limit value' (Un\G506) is ignored.

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 0 for all channels.

## CH1 Scaling lower limit value

Medium speed

Low speed

Set a lower limit value for the range of the scale conversion.

For details on the scaling function, refer to the following.

☞ Page 38 Scaling Function

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Scaling lower limit value	508	708	908	1108

### ■Setting range

- The setting range is from -32000 to 32000.
- In the channel where a set value does not satisfy the condition "the scaling upper limit value ≠ the scaling lower limit value", a scaling upper/lower limit value setting error (error code: 1A2□H) occurs.
- In the channel where a value out of the setting range is set, a scaling setting range error (error code: 1A1□H) occurs.
- When 'CH1 Scaling enable/disable setting' (Un\G504) is set to Disable (1), the setting of 'CH1 Scaling lower limit value' (Un\G508) is ignored.

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 0 for all channels.

## CH1 Digital clipping enable/disable setting

Medium speed

Low speed

Set whether to enable or disable the digital clipping function.

For details on the digital clipping function, refer to the following.

☞ Page 44 Digital Clipping Function

Setting value	Setting details
0	Enable
1	Disable

If a value other than the above is set, a digital clipping enable/disable setting range error (error code: 1A5□H) occurs.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Digital clipping enable/disable setting	510	710	910	1110

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is Disable (1) for all channels.

## CH1 Warning output setting (Process alarm)

Common

Set whether to enable or disable the warning output of a process alarm.

For details on the warning output function (process alarm), refer to the following.

☞ Page 51 Process alarm

Setting value	Setting details
0	Enable
1	Disable

If a value other than the above is set, a warning output setting (Process alarm) range error (error code: 1B0□H) occurs.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Warning output setting (Process alarm)	512	712	912	1112

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is Disable (1) for all channels.

## CH1 Warning output setting (Rate alarm)

Medium speed

Low speed

Set whether to enable or disable the warning output of a rate alarm.

For details on the warning output function (rate alarm), refer to the following.

☞ Page 54 Rate alarm

Setting value	Setting details
0	Enable
1	Disable

If a value other than the above is set, a warning output setting (Rate alarm) range error (error code: 1B8□H) occurs.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Warning output setting (Rate alarm)	513	713	913	1113

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is Disable (1) for all channels.

A

## CH1 Process alarm upper upper limit value

Common

Set an upper upper limit value of the warning output function (process alarm).

For details on the warning output function (process alarm), refer to the following.

☞ Page 51 Process alarm

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Process alarm upper upper limit value	514	714	914	1114

### ■Setting range

The setting range is from -32768 to 32767.

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 0 for all channels.

## CH1 Process alarm upper lower limit value

Common

Set an upper lower limit value of the warning output function (process alarm).

For details on the warning output function (process alarm), refer to the following.

☞ Page 51 Process alarm

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Process alarm upper lower limit value	516	716	916	1116

### ■Setting range

The setting range is from -32768 to 32767.

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 0 for all channels.

## CH1 Process alarm lower upper limit value

Common

Set a lower upper limit value of the warning output function (process alarm).

For details on the warning output function (process alarm), refer to the following.

☞ Page 51 Process alarm

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Process alarm lower upper limit value	518	718	918	1118

### ■Setting range

The setting range is from -32768 to 32767.

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 0 for all channels.

## CH1 Process alarm lower lower limit value

Common

Set a lower lower limit value of the warning output function (process alarm).

For details on the warning output function (process alarm), refer to the following.

☞ Page 51 Process alarm

A

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Process alarm lower lower limit value	520	720	920	1120

### ■Setting range

The setting range is from -32768 to 32767.

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 0 for all channels.



- When using the process alarm, configure the 4-step settings of the process alarm upper upper limit value, upper lower limit value, lower upper limit value, and lower lower limit value.
- In the channel where a set value does not satisfy the condition "the upper upper limit value  $\geq$  the upper lower limit value  $\geq$  the lower upper limit value  $\geq$  the lower lower limit value", a process alarm upper lower limit value setting range error (error code: 1B△□H) occurs.
- Since the default value is 0, change the value.
- When the scaling function, shift function, digital clipping function, or difference conversion function is used, warning targets are digital operation values to which the operation of each function was reflected. Be sure to consider operation results of each function to set values.

## CH1 Rate alarm warning detection cycle setting

Medium speed

Low speed

Set the cycle to check the change rate of digital output values.

The value of the cycle to detect a rate alarm warning is the product of the value in 'CH1 Rate alarm warning detection cycle setting' (Un(G522) and the conversion cycle.

For details on the warning output function (rate alarm), refer to the following.

☞ Page 54 Rate alarm

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Rate alarm warning detection cycle setting	522	722	922	1122

### ■Setting range

The setting range is from 1 to 32000 (times).

In the channel where a value out of the range is set, a rate alarm warning detection cycle setting range error (error code: 1B9□H) occurs.

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 0 for all channels.

## CH1 Rate alarm upper limit value

Medium speed

Low speed

For rate alarm, the digital output value is checked at every warning detection cycle and the change rate is calculated from the check result. Use this area to set an upper limit value of the change rate of digital output values for each channel.

For details on the warning output function (rate alarm), refer to the following.

☞ Page 54 Rate alarm

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Rate alarm upper limit value	524	724	924	1124

### ■Setting range

The setting range is from -32768 to 32767 (-3276.8 to 3276.7%). (Set it in increments of 0.1%.)

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 0 for all channels.

## CH1 Rate alarm lower limit value

Medium speed

Low speed

For rate alarm, the digital output value is checked at every warning detection cycle and the change rate is calculated from the check result. Use this area to set a lower limit value of the change rate of digital output values for each channel.

For details on the warning output function (rate alarm), refer to the following.

☞ Page 54 Rate alarm

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH0 Rate alarm lower limit value	526	726	926	1126

### ■Setting range

The setting range is from -32768 to 32767 (-3276.8 to 3276.7%). (Set it in increments of 0.1%).

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 0 for all channels.

**Point**

- When using rate alarms, configure the 2-step settings of the rate alarm upper limit value and lower limit value.
- In the channel where a set value satisfies the condition the "rate alarm lower limit value  $\geq$  the rate alarm upper limit value", a rate alarm upper/lower limit setting value inversion error (error code: 1BA0H) occurs.
- Since the default value is 0, change the value.

## CH1 Input signal error detection setting

Common

A

Set a condition for detecting an input signal error.

For details on the input signal error detection function, refer to the following.

☞ Page 59 Input Signal Error Detection Function

Setting value	Setting details
0	Disable
1	Upper and lower limit detection
2	Lower limit detection
3	Upper limit detection
4	Simple disconnection detection

If a value other than the above is set, an input signal error detection setting range error (error code: 1C00H) occurs. If Simple disconnection detection (4) is selected for the channel where the set input range is other than the extended mode, a disconnection detection enabled range setting range error (error code: 1C60H) occurs.

## ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Input signal error detection setting	528	728	928	1128

## ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

## ■Default value

The default value is 0 for all channels.

## CH1 Input signal error detection lower limit setting value

Common

Set a lower limit setting value to detect an error for the input analog value.

For details on the input signal error detection function, refer to the following.

☞ Page 59 Input Signal Error Detection Function

## ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Input signal error detection lower limit setting value	529	729	929	1129

## ■Setting range

The setting range is from 0 to 250 (0 to 25.0%). Set it in increments of 1 (0.1%).

In the channel where a value out of the range is set, an input signal error detection setting value range error (error code: 1C1□H) occurs.

## ■How to calculate the input signal error detection lower limit value

The input signal error detection lower limit value is calculated based on the input signal error detection lower limit setting value as follows. The input signal error detection lower limit value to be calculated varies depending on the input range used.

- Input signal error detection lower limit value = Lower limit value of each range - (Gain value of each range - Offset value of each range) × (Input signal error detection lower limit setting value/1000)

Ex.

When 'CH1 Input signal error detection lower limit setting value' (Un\G529) is set to 100 (10%) with the input range of 4 to 20mA, the input signal error detection lower limit value is calculated as follows:

- Input signal error detection lower limit value =  $4 - (20 - 4) \times (100/1000) = 2.4\text{mA}$

## ■Detection condition

Detection conditions vary depending on the setting of 'CH1 Input signal error detection setting' (Un\G528) as follows:

- When 'CH1 Input signal error detection setting' (Un\G528) is set to Upper and lower limit detection (1), the detection is performed with both the input signal error detection upper limit value and input signal error detection lower limit value.
- When 'CH1 Input signal error detection setting' (Un\G528) is set to Lower limit detection (2), the detection is performed only with the input signal error detection lower limit value.
- When 'CH1 Input signal error detection setting' (Un\G528) is set to Upper limit detection (3), the value set in this area is ignored.
- When 'CH1 Input signal error detection setting' (Un\G528) is set to Simple disconnection detection (4), the value set in this area is ignored.

## ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

## ■Default value

The default value is 50 for all channels.

## CH1 Input signal error detection upper limit setting value

### Common

Set an upper limit setting value to detect an error for the input analog value.

For details on the input signal error detection function, refer to the following.

 Page 59 Input Signal Error Detection Function

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH1 Input signal error detection upper limit setting value	530	730	930	1130

### ■Setting range

The setting range is from 0 to 250 (0 to 25.0%). Set it in increments of 1 (0.1%).

In the channel where a value out of the range is set, an input signal error detection setting value range error (error code: 1C10H) occurs.

### ■How to calculate the input signal error detection upper limit value

The input signal error detection upper limit value is calculated based on the input signal error detection upper limit setting value as follows. The input signal error detection upper limit value to be calculated varies depending on the input range used.

- Input signal error detection upper limit value = Gain value of each range + (Gain value of each range - Offset value of each range) × (Input signal error detection upper limit setting value/1000)

#### Ex.

When 'CH1 Input signal error detection upper limit setting value' (Un\G530) is set to 100 (10%) with the input range of 4 to 20mA, the input signal error detection upper limit value is calculated as follows:

- Input signal error detection upper limit value =  $20 + (20 - 4) \times (100/1000) = 21.6\text{mA}$

### ■Detection condition

Detection conditions vary depending on the setting of 'CH1 Input signal error detection setting' (Un\G528) as follows:

- When 'CH1 Input signal error detection setting' (Un\G528) is set to Upper and lower limit detection (1), the detection is performed with both the input signal error detection upper limit value and input signal error detection lower limit value.
- When 'CH1 Input signal error detection setting' (Un\G528) is set to Lower limit detection (2), the value set in this area is ignored.
- When 'CH1 Input signal error detection setting' (Un\G528) is set to Upper limit detection (3), the detection is performed only with the input signal error detection upper limit value.
- When 'CH1 Input signal error detection setting' (Un\G528) is set to Simple disconnection detection (4), the value set in this area is ignored.

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 50 for all channels.

A

## CH1 Logging enable/disable setting

Low speed

Set whether to enable or disable the normal logging function.

For details on the normal logging function, refer to the following.

☞ Page 69 Normal Logging Function

Setting value	Setting details
0	Enable
1	Disable

If a value other than the above is set, a logging enable/disable setting range error (error code: 1D0□H) occurs.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Logging enable/disable setting	535	735	935	1135

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is Disable (1) for all channels.

## CH1 Logging data points setting

Low speed

Set the number of logging data points for each channel in the normal logging function.

For details on the normal logging function, refer to the following.

☞ Page 69 Normal Logging Function

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Logging data points setting	536	736	936	1136

### ■Setting range

- The setting range is from 0 to 900 (0 to 90000 points). Set it in increments of 1 (100 points). The areas that store the data logged are distributed to each channel for the number of logging data points set in this area.
- In the channel where a value out of the range is set, a logging data points setting range error (error code: 1DA□H) occurs.
- Regardless of whether logging is enabled or disabled, set the number of logging data points for each channel so that the total of values set in this area does not exceed 900 (90000 points). If the total of the values is greater than 900, a logging data points setting total range error (error code: 1DB0H) occurs.

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 200 (20000 points) for all channels.

## CH1 Logging data setting

Low speed

Determine the target to be collected: digital output value or digital operation value.

For details on the normal logging function, refer to the following.

☞ Page 69 Normal Logging Function

Setting value	Setting details
0	Digital output value
1	Digital operation value

If a value other than the above is set, a logging data setting range error (error code: 1D3□H) occurs.

When 'CH1 Logging enable/disable setting' (Un\G535) is set to Disable (1), the setting of 'CH1 Logging data setting' (Un\G537) is ignored.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Logging data setting	537	737	937	1137

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is Digital operation value (1) for all channels.

## CH1 Logging cycle setting value

Low speed

A

Set a cycle for storing logging data in the normal logging function.

For details on the normal logging function, refer to the following.

☞ Page 69 Normal Logging Function

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Logging cycle setting value	538	738	938	1138

### ■Setting range

The setting range varies depending on the setting in 'CH1 Logging cycle unit setting' (Un\G539).

'CH1 Logging cycle unit setting' (Un\G539)	Setting range
μs(0)	20 to 32767
ms(1)	1 to 32767
s(2)	1 to 3600

- If a value out of the range is set, a logging cycle setting value range error (error code: 1D1□H) occurs. Logging cannot be performed.
- If the set logging cycle is below the updating cycle of data to be logged, a logging cycle setting disable error (error code: 1D2□H) occurs. Logging cannot be performed.

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 4 for all channels.

## CH1 Logging cycle unit setting

Low speed

Set a cycle unit for storing logging data in the normal logging function.

For details on the normal logging function, refer to the following.

☞ Page 69 Normal Logging Function

Setting value	Setting details
0	μs
1	ms
2	s

- If a value out of the range is set, a logging cycle setting value range error (error code: 1D1□H) occurs. Logging cannot be performed.
- If the set logging cycle is below the updating cycle of data to be logged, a logging cycle setting disable error (error code: 1D2□H) occurs. Logging cannot be performed.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Logging cycle unit setting	539	739	939	1139

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default is ms (1) for all channels.

## CH1 Post-trigger logging points

Low speed

Set the number of data points to be collected for the time period from the occurrence of a hold trigger to when logging stops in the normal logging function.

For details on the normal logging function, refer to the following.

☞ Page 69 Normal Logging Function

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Post-trigger logging points	540, 541	740, 741	940, 941	1140, 1141

### ■Setting range

The setting range is from 1 to (setting value of 'CH1 Logging data points setting' (Un\G536)) × 100.

If a value out of the range is set, a post-trigger logging points setting range error (error code: 1D4□H) occurs. Logging cannot be performed.

When 'CH1 Logging enable/disable setting' (Un\G535) is set to Disable (1), the setting of 'CH1 Post-trigger logging points' (Un\G540, Un\G541) is ignored.

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 10000 for all channels.

## CH1 Level trigger condition setting

Low speed

Set the condition for the occurrence of a hold trigger when using the level trigger in the normal logging function. For details on the normal logging function, refer to the following.

☞ Page 69 Normal Logging Function

To use the level trigger, set Level trigger condition setting to one of the following values except Disable (0).

Setting value	Setting details
0	Disable
1	Level trigger (Rise)
2	Level trigger (Fall)
3	Level trigger (Rise and fall)
4	Process alarm (upper limit warning)
5	Process alarm (lower limit warning)
6	Process alarm (upper limit warning/lower limit warning)

If a value other than the above is set, a level trigger condition setting range error (error code: 1D5□H) occurs.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Level trigger condition setting	542	742	942	1142

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is Disable (0) for all channels.

A

## CH1 Trigger data

Low speed

Set a buffer memory address to be monitored for a level trigger in the normal logging function. Set the buffer memory address where the monitoring target data is stored.

For details on the normal logging function, refer to the following.

☞ Page 69 Normal Logging Function

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Trigger data	543	743	943	1143

### ■Setting range

The setting range is from 0 to 9999.

If a value out of the above setting range is set, a trigger data setting range error (error code: 1D6□H) occurs. Logging cannot be performed.

When 'CH1 Logging enable/disable setting' (Un\G535) is set to Disable (1), the setting of 'CH1 Trigger data' (Un\G543) is ignored.

When 'CH1 Level trigger condition setting' (Un\G542) is set to Process alarm (upper limit warning) (4), Process alarm (lower limit warning) (5), Process alarm (upper limit warning/lower limit warning) (6), the setting of 'CH1 Trigger data' (Un\G543) is ignored.

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default values are set as shown below.

Channel	Default value	Buffer memory area to be monitored
CH1	402	'CH1 Digital operation value' (Un\G402)
CH2	602	'CH2 Digital operation value' (Un\G602)
CH3	802	'CH3 Digital operation value' (Un\G802)
CH4	1002	'CH4 Digital operation value' (Un\G1002)

## CH1 Trigger setting value

Low speed

Set a level to generate a level trigger in the normal logging function.

For details on the normal logging function, refer to the following.

☞ Page 69 Normal Logging Function

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Trigger setting value	544	744	944	1144

### ■Setting range

The setting range is from -32768 to 32767.

When 'CH1 Level trigger condition setting' (Un\G542) is set to Process alarm (upper limit warning) (4), Process alarm (lower limit warning) (5), Process alarm (upper limit warning/lower limit warning) (6), the setting of 'CH1 Trigger setting value' (Un\G544) is ignored.

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 0 for all channels.

## CH1 Trigger judgment count setting value

Low speed

Set how many level triggers need to be counted to generate a hold trigger in the normal logging function. When level triggers are generated for the set number of times, a hold trigger is generated.

For details on the normal logging function, refer to the following.

☞ Page 69 Normal Logging Function

A

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Trigger judgment count setting value	545	745	945	1145

### ■Setting range

The setting range is from 1 to 10 (times).

When a value out of the range is set, the value is regarded as 1 (time).

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 1 (time) for all channels.

## CH1 Loading interrupt enable/disable setting

Low speed

Set whether to enable or disable the logging read function.

For details on the logging read function, refer to the following.

☞ Page 88 Logging read function

Setting value	Setting details
0	Enable
1	Disable

- If a value other than the above is set, a loading interrupt enable/disable setting range error (error code: 1D8□H) occurs. Logging cannot be performed.
- When 'CH1 Loading interrupt enable/disable setting' (Un\G546) is set to Enable (0), a read pointer is set every time data is logged for the amount equivalent to the logging read points setting value, and an interrupt is generated and sent to the CPU module.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Loading interrupt enable/disable setting	546	746	946	1146

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is Disable (1) for all channels.

## CH1 Logging read points setting value

Low speed

An interrupt is generated and sent to the CPU module every time data is logged for the set number of data points with the logging read function.

For details on the logging read function, refer to the following.

☞ Page 88 Logging read function

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Logging read points setting value	547	747	947	1147

### ■Setting range

The setting range is from 1 to (setting value of 'CH1 Logging data points setting' (Un\G536)). Set it in increments of 1 (100 points). Thus, the actual range of Logging read points setting value is from 100 to 90000 at a maximum.

If a value out of the range is set, a logging read points setting value range error (error code: 1D9□H) occurs. Logging cannot be performed.

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 10 (1000 points) for all channels.

## CH1 LPF Pass band edge frequency

Medium speed

Low speed

Set a pass band edge frequency for the low pass filter.

For details on the digital filters, refer to the following.

☞ Page 30 Digital filter

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ LPF Pass band edge frequency	560	760	960	1160

### ■Setting range

For the setting range, refer to the following.

☞ Page 32 How to use the digital filters

If a value out of the range is set, a low pass filter setting range error (error code: 196□H) occurs.

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 0 for all channels.

## CH1 HPF Pass band edge frequency

Medium speed

Low speed

Set a pass band edge frequency for the high pass filter.

For details on the digital filters, refer to the following.

☞ Page 30 Digital filter

A

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ HPF Pass band edge frequency	562	762	962	1162

### ■Setting range

For the setting range, refer to the following.

☞ Page 32 How to use the digital filters

If a value out of the range is set, a high pass filter setting range error (error code: 197□H) occurs.

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 0 for all channels.

## CH1 BPF Pass band edge frequency (Low)

Medium speed

Low speed

Set a pass band edge frequency at the low frequency side for the band pass filter.

For details on the digital filters, refer to the following.

☞ Page 30 Digital filter

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ BPF Pass band edge frequency (Low)	564	764	964	1164

### ■Setting range

For the setting range, refer to the following.

☞ Page 32 How to use the digital filters

If a value out of the range is set, a band pass filter setting range error (error code: 198□H) occurs.

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 0 for all channels.

## CH1 BPF Pass band edge frequency (High)

Medium speed

Low speed

Set a pass band edge frequency at the high frequency side for the band pass filter.

For details on the digital filters, refer to the following.

☞ Page 30 Digital filter

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ BPF Pass band edge frequency (High)	566	766	966	1166

### ■Setting range

For the setting range, refer to the following.

☞ Page 32 How to use the digital filters

If a value out of the range is set, a band pass filter setting range error (error code: 198□H) occurs.

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 0 for all channels.

## CH1 Attenuation band width

Medium speed

Low speed

Specify the attenuation band width for each digital filter.

For details on the digital filters, refer to the following.

☞ Page 30 Digital filter

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Attenuation band width	568	768	968	1168

### ■Setting range

For the setting range, refer to the following.

☞ Page 32 How to use the digital filters

If a value out of the range is set, any of a low pass filter setting range error (error code: 196□H), high pass filter setting range error (error code: 197□H), or band pass filter setting range error (error code: 198□H) occurs.

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 0 for all channels.

## CH1 Range setting

Common

A

This area is for setting an input range.

Setting value	Setting details
0H	4 to 20mA
1H	0 to 20mA
2H	1 to 5V
3H	0 to 5V
4H	-10 to 10V
5H	0 to 10V
AH	4 to 20mA (extended mode)
BH	1 to 5V (extended mode)
FH	User range setting

If a value other than the above is set, a range setting range error (error code: 190□H) occurs.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Range setting	598	798	998	1198

### ■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

### ■Default value

The default value is 4 to 20mA (0H) for all channels.

## Error history

### Common

Up to 16 errors that occurred in the module are recorded.

**Ex.**

For error history 1

b15	...	b8 b7	...	b0		
Error code						
First two digits of the year		Last two digits of the year				
Month		Day				
Hour		Minute				
Second		Day of the week				
Millisecond (higher-order digits)		Millisecond (lower-order digits)				
Un\G3600						
Un\G3601						
Un\G3602						
Un\G3603						
Un\G3604						
Un\G3605						
Un\G3606						
⋮						
Un\G3609						
System area						

Item	Storage contents	Storage example <sup>*1</sup>
Error code	An error code is stored.	3030H
First two digits of the year	Stored in BCD code.	2015H
Month	Day	1224H
Hour	Minute	1234H
Second		56H
Day of the week	One of the following values is stored in BCD code. Sunday: 0, Monday: 1, Tuesday: 2, Wednesday: 3 Thursday: 4, Friday: 5, Saturday: 6	4H
Millisecond (upper)	Stored in BCD code.	7H
Millisecond (lower)		89H
System area	—	—

\*1 Values stored when a flash memory error (error code: 3030H) occurs at 12:34:56.789 on Thursday, December 24th, 2015.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	No.1 to No.16
Error history	3600 to 3759

## Alarm history

### Common

Up to 16 alarms that occurred in the module are recorded.

**Ex.**

For alarm history 1

b15	...	b8 b7	...	b0			
Alarm code							
First two digits of the year		Last two digits of the year					
Month		Day					
Hour		Minute					
Second		Day of the week					
Millisecond (higher-order digits)		Millisecond (lower-order digits)					
System area							
Un\G3760							
Un\G3761							
Un\G3762							
Un\G3763							
Un\G3764							
Un\G3765							
Un\G3766							
:							
Un\G3769							

Item	Storage contents	Storage example <sup>*1</sup>
Alarm code	An alarm code is stored.	0D00H
First two digits of the year	Stored in BCD code.	2015H
Month		1224H
Hour		1234H
Second		56H
Day of the week	One of the following values is stored in BCD code. Sunday: 0, Monday: 1, Tuesday: 2, Wednesday: 3 Thursday: 4, Friday: 5, Saturday: 6	4H
Millisecond (upper)	Stored in BCD code.	7H
Millisecond (lower)		89H
System area	—	—

\*1 Values stored when a mode switching request error (alarm code: 0D00H) occurs at 12:34:56.789 on Thursday, December 24th, 2015.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	No.1 to No.16
Alarm history	3760 to 3919

A

## Clear setting of error history

Common

Set whether to clear Error history 1 to 16 (Un\G3600 to Un\G3759) and Alarm history 1 to 16 (Un\G3760 to Un\G3919) when 'Error clear request' (YF) or 'Operating condition setting request' (Y9) is turned on.

Setting value	Setting details
0	Not clear
1	Clear

When a value other than the above is set, the value is regarded as Not clear (0).

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
Clear setting of error history	3930			

### ■Enabling the setting

As soon as a setting value is input, the setting is enabled. Turning on and off 'Operating condition setting request' (Y9) is not required.

### ■Default value


The default value is Not clear (0) for all channels.

## Save data type setting

Medium speed

Low speed

This area saves and restores the offset/gain setting value in the user range setting. Specify the data type of the offset/gain value to be saved and restored: voltage or current.



(1) 0: Voltage, 1: Current

(2) b4 to b15 are fixed to 0.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
Save data type setting	4002			

### ■Default value

The default value is Voltage (0) for all channels.

## CH1 Factory default setting offset/gain value

Medium speed

Low speed

This area restores the offset/gain setting value in the user range setting. For details, refer to the following.

☞ Page 225 CH1 User range setting offset/gain value

## CH1 User range setting offset/gain value

Medium speed

Low speed

This area restores the offset/gain setting value in the user range setting.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Factory default setting offset value (L)	4004	4008	4012	4016
CH□ Factory default setting offset value (H)	4005	4009	4013	4017
CH□ Factory default setting gain value (L)	4006	4010	4014	4018
CH□ Factory default setting gain value (H)	4007	4011	4015	4019
CH□ User range setting offset value (L)	4020	4024	4028	4032
CH□ User range setting offset value (H)	4021	4025	4029	4033
CH□ User range setting gain value (L)	4022	4026	4030	4034
CH□ User range setting gain value (H)	4023	4027	4031	4035

When the following operations are performed, the data to be used is stored (saved).

- Writing the initial setting with an engineering tool
- Turning on 'Operating condition setting request' (Y9) (Data is not saved when the mode is switched from the normal mode to the offset/gain setting mode by 'Mode switching setting' (Un\G296, Un\G297).)
- Writing an offset/gain value in the offset/gain setting mode (When 'User range write request' (YA) is turned on)

When restoring the offset/gain setting value in the user range setting, set the same data as the saved data in this area to the corresponding area of the A/D converter module that is the restoration destination.

For the offset/gain setting, refer to the following.

 MELSEC iQ-R High Speed Analog-Digital Converter Module User's Manual (Startup)

### ■Default value

The default value is 0 for all channels.

A

## CH1 Offset/gain setting mode

Medium speed

Low speed

Specify the channel where the offset/gain setting is adjusted.

- Offset/gain setting mode (offset specification): Channel where the offset value is adjusted
- Offset/gain setting mode (gain specification): Channel where the gain value is adjusted

Setting value	Setting details
0	Disable
1	Setting channel

Set one of the offset specification or gain specification to Setting channel (1), and the other to Disable (0). When a value other than 0 and 1 is set, an offset/gain setting channel range error (error code: 1E8□H) occurs.

Multiple channels can be set at the same time. In that case, do not set both the offset specification and gain specification of multiple channels to Setting channel (1).

When 'Channel change request' (YB) is turned on and the following settings are enabled, an offset/gain setting channel specification error (error code: 1E50H) occurs.

- When both the offset specification and gain specification of the same channel are set to Setting channel (1)
- When both the offset specification and gain specification of all channels are set to Disable (0)
- When both the offset specification and gain specification of multiple channels are set to Setting channel (1) at the same time

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Offset/gain setting mode (offset specification)	4132	4134	4136	4138
CH□ Offset/gain setting mode (gain specification)	4133	4135	4137	4139

### ■Enabling the setting

Turn on 'Channel change request' (YB).

### ■Default value

The default value is Disable (0) for all channels.

## CH1 Offset/gain setting mode (range specification)

Medium speed

Low speed

In the offset/gain setting, specify the current input or voltage input for each channel.

Setting value	Setting details
0	Voltage
1	Current

When a value other than 0 and 1 is set, the value is regarded as Current (1).

- When an offset/gain value is written in the offset/gain setting mode (when 'User range write request' (YA) is turned on), this setting is written to a flash memory.
- When the mode is switched to the offset/gain setting mode or 'Operating condition setting request' (Y9) is turned on, the value stored in the flash memory is set.
- This setting is saved in the module-specific backup parameter at the online module change. After the module replacement, the factory default setting to be referred to is determined according to this setting when the offset/gain setting is restored.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Offset/gain setting mode (range specification)	4164	4165	4166	4167

### ■Default value


The default value is Voltage (0) for all channels.

## CH1 Synchronization digital output value

Synchronization

A

When the module is set as the target of the inter-module synchronization function, a digital output value is stored at the timing of the inter-module synchronization cycle. The digital output value is stored as a 16-bit signed binary value.



When the module is not set as the target of the inter-module synchronization function, 0 is always stored.

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
CH□ Synchronization digital output value	9500	9502	9504	9506

## Synchronization status monitor

### Synchronization

The status of the inter-module synchronization and whether the currently checked module is the target of the inter-module synchronization function can be checked.

Monitored value	Description
0	Not inter-module synchronization target
1	Inter-module synchronization target (synchronization stopped)
2	Inter-module synchronization target (synchronization in process)

If the currently checked module is not the inter-module synchronization target, the monitor value is Not inter-module synchronization target (0).

If the currently checked module is the inter-module synchronization target and the inter-module synchronization is being executed, the monitor value is Inter-module synchronization target (synchronization in process) (2).

When an error occurs in the CPU module or the A/D converter module and the synchronization stops, the monitor value is Inter-module synchronization target (synchronization stopped) (1).

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
Synchronization status monitor	9600			

## Oversampling mode monitor

### Synchronization

When the continuous logging function is used in the inter-module synchronization mode, whether the oversampling mode is enabled or disabled can be checked.

Monitored value	Description
0	Oversampling mode disabled
1	Oversampling mode enabled

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
Oversampling mode monitor	9601			

## Logging data area

Low speed

This area stores the data logged with the normal logging function. The area of 90000 points can be distributed to each channel by setting 'CH1 Logging data points setting' (Un\G536). After the number of stored data points reaches the points set in 'CH1 Logging data points setting' (Un\G536), data is continuously collected overwriting the data in the start address and later.

For details on the normal logging function, refer to the following.

☞ Page 69 Normal Logging Function

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
Logging data area	10000 to 99999			



- When 'Operating condition setting request' (Y9) is turned on, the logging data in all the channels are cleared.
- When 'CH1 Logging hold request' (Y1) is turned off while 'CH1 Logging hold flag' (Un\G409) is on, data logging resumes. In this case, the logged data is not cleared.

## CH1 Logging data area

Simultaneous conversion

Synchronization

This area stores the data logged with the continuous logging function. Up to 10000 points of data can be stored per channel. For details on the continuous logging function, refer to the following.

☞ Page 94 Continuous Logging Function

A

### ■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4
Logging data area	10000 to 19999	20000 to 29999	30000 to 39999	40000 to 49999

### ■Updating data

The update timing of this area varies depending on the operation mode.

- In the simultaneous conversion mode, data is updated every time logging 5000 points of data is completed.
- In the inter-module synchronization mode, data is updated at every inter-module synchronization cycle.



When 'Operating condition setting request' (Y9) is turned on, the logging data in all the channels are cleared.

# Appendix 4 Dedicated Instructions

## Instruction list

The following table lists the dedicated instructions that can be used in the A/D converter module.

Instruction	Description
G(P).OFFGAN	Switches the normal mode to the offset/gain setting mode. Switches the offset/gain setting mode to the normal mode.
G(P).OGLOAD	Reads out the offset/gain setting value in the user range setting to write it into the CPU module.
G(P).OGSTOR	Restores the offset/gain setting value in the user range setting stored in the CPU module into the A/D converter module.

For details on the dedicated instructions, refer to the following.

 MELSEC iQ-R Programming Manual (Instructions, Standard Functions/Function Blocks)

# MEMO

---


A

# Appendix 5 Operation Examples of When the Remote Head Module Is Mounted

This section describes operation examples of when the remote head module is mounted

## System configuration example

The following system configuration is used to explain an example of operation.



(1) Master station (Network number 1, station number 0)

- Power supply module: R61P
- CPU module: R04CPU
- Master/local module: RJ71GF11-T2 (Start I/O number: 0000H to 001FH)
- Input module: RX10 (Start I/O number: 0020H to 002FH)

(2) Intelligent device station (Network number 1, station number 1)

- Power supply module: R61P
- Remote head module: RJ72GF15-T2
- A/D converter module: R60ADH4 (Start I/O number: 0000H to 000FH)<sup>\*1</sup>


\*1 In the RX/RY setting of the master station, set 1000H to 100FH as the start I/O number of the A/D converter module.

## Setting in the master station


Connect the engineering tool to the CPU module of the master station and set parameters.

1. Create the project with the following settings.

🔗 [Project] ⇒ [New]




2. Configure the setting to use the module labels and add the module labels of the CPU module.




3. Add the master/local module with the following settings.

🔗 [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Right-click ⇒ [Add New Module]



A

4. Configure the setting to use the module labels and add the module labels of the master/local module.




5. Set "Required Settings" of "Module Parameter" of the master/local module as shown below.

☞ [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ [RJ71GF11-T2] ⇒ [Module Parameter] ⇒ [Required Settings]

Item	Setting
Station Type	Master Station
Network Number	1
Station Number	Parameter Editor
Parameter Setting Method	0
Setting Method of Basic/Application Settings	Parameter Editor

6. Set "Network Configuration Settings" of "Module Parameter" of the master/local module as shown below.

☞ [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ [RJ71GF11-T2] ⇒ [Module Parameter] ⇒ [Basic Settings] ⇒ [Network Configuration Settings]



7. Set "Refresh Setting" of "Module Parameter" of the master/local module as shown below.

☞ [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ [RJ71GF11-T2] ⇒ [Module Parameter] ⇒ [Basic Settings]  
⇒ [Refresh Setting]

No.	Link Side					CPU Side				
	Device Name	Points	Start	End		Target	Device Name	Points	Start	End
-	SB				↔	Specify Devic	X	256	01000	010FF
-	SW				↔	Specify Devic	Y	256	01000	010FF
1	RX	256	00000	000FF	↔	Specify Devic	W	256	00000	000FF
2	RY	256	00000	000FF	↔	Specify Devic	W	256	01000	010FF
3	RWw	256	00000	000FF	↔	Specify Devic	W	256	01000	010FF
4	RWt	256	00000	000FF	↔	Specify Devic	W	256	01000	010FF
5					↔					

8. Write the set parameters to the CPU module on the master station. Then reset the CPU module or power off and on the system.

☞ [Online] ⇒ [Write to PLC]

**Point**

For parameters of the master/local module which are not described in this procedure, set default values. For details on parameters of the master/local module, refer to the following.


☞ MELSEC iQ-R CC-Link IE Field Network User's Manual (Application)

# Setting in the intelligent device station

Connect the engineering tool to the remote head module of the intelligent device station and set parameters.

1. Create the project with the following settings.

🔗 [Project] ⇒ [New]




2. Set "Network Required Setting" of "CPU Parameter" of the remote head module as shown below.

🔗 [Navigation window] ⇒ [Parameter] ⇒ [RJ72GF15-T2] ⇒ [CPU Parameter] ⇒ [Network Required Setting]


Setting Item	
Item	Setting
Network Number	
Network Number	1
Station Number	
Station No.	1

3. Add the A/D converter module with the following settings.

🔗 [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Right-click ⇒ [Add New Module]



4. Configure the setting not to use the module labels.



## 5. Set "Basic setting" of "Module Parameter" of the A/D converter module as shown below.

⌚ [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ [R60ADH4] ⇒ [Module Parameter] ⇒ [Basic setting]

Setting Item	CH1	CH2	CH3	CH4
<b>Range switching function</b>	<b>The input range of the analog input can be set for each channel and the input conversion attribute can be changed.</b>			
Input range setting	0 to 10V	0 to 10V	0 to 20mA	4 to 20mA
<b>Operation mode setting function</b>	<b>Set the operation mode.</b>			
Operation mode setting	Normal mode (low speed: 20 μs/CH)			
<b>A/D conversion enable/disable setting function</b>	<b>Set whether to enable or disable the output of the A/D conversion value.</b>			
A/D conversion enable/disable setting	A/D conversion enable	A/D conversion enable	A/D conversion enable	A/D conversion enable
<b>A/D conversion method</b>	<b>Set the A/D conversion control method.</b>			
Average processing setting	Sampling processing	Count average	Moving average	Sampling processing
Time average/Count average/Moving average/Primary delay filter constant setting	0	50 times	10 times	0
LPF Pass band edge frequency	0	0	0	0
HPF Pass band edge frequency	0	0	0	0
BPF Pass band edge frequency (Low)	0	0	0	0
BPF Pass band edge frequency (High)	0	0	0	0
Attenuation band width	0	0	0	0

## 6. Set "Application setting" of "Module Parameter" of the A/D converter module as shown below.

⌚ [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ [R60ADH4] ⇒ [Module Parameter] ⇒ [Application setting]

Setting Item	CH1	CH2	CH3	CH4
<b>Scaling function</b>	<b>Configure the setting for the scaling at the A/D conversion.</b>			
Scaling enable/disable setting	Disable	Disable	Enable	Disable
Scaling upper limit value	0	0	16000	0
Scaling lower limit value	0	0	0	0
<b>Shift function</b>	<b>Configure the setting for the shift function at the A/D conversion.</b>			
Conversion value shift amount	0	0	2000	0
<b>Digital clipping function</b>	<b>Configure the setting for the digital clipping function at the A/D conversion.</b>			
Digital clipping enable/disable setting	Disable	Disable	Enable	Disable
<b>Warning output function (Process alarm)</b>	<b>Set a warning at the A/D conversion.</b>			
Warning output setting (Process alarm)	Disable	Enable	Disable	Disable
Process alarm upper upper limit value	0	32000	0	0
Process alarm upper lower limit value	0	28000	0	0
Process alarm lower upper limit value	0	4000	0	0
Process alarm lower lower limit value	0	0	0	0
<b>Warning output function (Rate alarm)</b>	<b>Set a warning at the A/D conversion.</b>			
Warning output function (Rate alarm)	Enable	Disable	Disable	Disable
Rate alarm detection cycle setting	5 times	0 times	0 times	0 times
Rate alarm upper limit value	25.0 %	0.0 %	0.0 %	0.0 %
Rate alarm lower limit value	-5.0 %	0.0 %	0.0 %	0.0 %
<b>Input signal error detection function</b>	<b>Configure the setting for the input signal error detection function at the A/D conversion.</b>			
Input signal error detection setting	Upper limit detection	Disable	Disable	Disable
Input signal error detection lower limit setting value	5.0 %	5.0 %	5.0 %	5.0 %
Input signal error detection upper limit setting value	10.0 %	5.0 %	5.0 %	5.0 %
Input signal error detection auto clear enable/disable setting	Disable			
<b>Normal logging function</b>	<b>Configure the setting for the normal logging function at the A/D conversion.</b>			
Logging enable/disable setting	Disable	Disable	Disable	Disable
Logging data points setting	200	200	200	200
Logging data setting	Digital operation value	Digital operation value	Digital operation value	Digital operation value
Logging cycle setting value	4 ms	4 ms	4 ms	4 ms
Logging cycle unit setting	ms	ms	ms	ms
Level trigger condition setting	Disable	Disable	Disable	Disable
Logging points after trigger	10000	10000	10000	10000
Trigger data	402	602	802	1002
Trigger setting value	0	0	0	0
Trigger judgment count setting value	1 times	1 times	1 times	1 times
Logging loading enable/disable setting	Disable	Disable	Disable	Disable
Logging read points setting value	10	10	10	10
Continuous logging cycle setting value	1			
<b>Inter-module synchronization function</b>	<b>A/D conversion function in accordance with the inter-module synchronization cycle.</b>			
Oversampling mode	Disable			
<b>Online module change</b>	<b>The module can be changed without the system being stopped.</b>			
Auto restore of Offset/ gain setting with the module change	Enable			

A

7. Set "Refresh settings" of "Module Parameter" of the A/D converter module as shown below.

☞ [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ [R60ADH4] ⇒ [Module Parameter] ⇒ [Refresh settings]

Setting Item

Target	Device	Number of transfers to intelligent function module	0	
		Number of transfers to CPU	13	
Item	CH1	CH2	CH3	CH4
<input checked="" type="checkbox"/> Refresh at the setting time.				
<input checked="" type="checkbox"/> Transfer to the intelligent function module.	Transfer the buffer memory data to the specified device.			
<input checked="" type="checkbox"/> Transfer to the CPU.	Transfer the buffer memory data to the specified device.			
Latest error code				
Latest address of error history				
Latest alarm code				
Latest address of alarm history				
Interrupt factor detection flag 1				
Interrupt factor detection flag 2				
Interrupt factor detection flag 3				
Interrupt factor detection flag 4				
Interrupt factor detection flag 5				
Interrupt factor detection flag 6				
Interrupt factor detection flag 7				
Interrupt factor detection flag 8				
Interrupt factor detection flag 9				
Interrupt factor detection flag 10				
Interrupt factor detection flag 11				
Interrupt factor detection flag 12				
Interrupt factor detection flag 13				
Interrupt factor detection flag 14				
Interrupt factor detection flag 15				
Interrupt factor detection flag 16				
Warning output flag (Process alarm upper limit)	W1010			
Warning output flag (Process alarm lower limit)	W1011			
Warning output flag (Rate alarm upper limit)	W1012			
Warning output flag (Rate alarm lower limit)	W1013			
Input signal error detection flag	W1014			
A/D conversion completed flag	W1000			
Digital output value	W1001			
Digital operation value	W1002			
Maximum value	W1003			
Minimum value	W1005			
Difference conversion state flag	W1006			
Logging hold flag				
<input checked="" type="checkbox"/> Refresh Timing	Set refresh timing.			
Refresh Timing	-			
Refresh Group [1/16: 1-64]	1			

8. Write the set parameters to the remote head module on the intelligent device station. Then reset the remote head module or power off and on the system.

☞ [Online] ⇒ [Write to PLC]



For parameters of the remote head module which are not described in this procedure, set default values. For details on parameters of the remote head module, refer to the following.

MELSEC iQ-R CC-Link IE Field Network Remote Head Module User's Manual (Application)

## Checking the network status

After setting parameters to the master station and the intelligent device station, check whether data link is normally performed between the master station and the intelligent device station. Check the network status using the CC-Link IE Field Network diagnostics of the engineering tool.

For how to perform the CC-Link IE Field Network diagnostics from the master station, refer to the following.

 MELSEC iQ-R CC-Link IE Field Network User's Manual (Application)

## Program examples

For the program examples, the module labels of the master/local module are used.


Write the programs to the CPU module on the master station.

Classification	Label name	Description			Device
Module label	GF11_1.bnSts_DataLinkError	Data link error status of own station			SB0049
	GF11_1.bnSts_DataLinkError_Station[1]	Data link status of each station (station number 1)			SW00B0.0
Label to be defined	Define global labels as shown below:				
		Label Name	Data Type	Class	Assign (Device/Label)
	1	CH1_DigOutValTempArea	Word [Signed]	... VAR_GLOBAL	▼ D11
	2	CH2_DigOutValTempArea	Word [Signed]	... VAR_GLOBAL	▼ D12
	3	CH3_DigCalcValTempArea	Word [Signed]	... VAR_GLOBAL	▼ D13
	4	CH4_DigOutValTempArea	Word [Signed]	... VAR_GLOBAL	▼ D14
	5	CH3_DigMaxValTempArea	Word [Signed]	... VAR_GLOBAL	▼ D15
	6	CH3_DigMinValTempArea	Word [Signed]	... VAR_GLOBAL	▼ D16
	7	CH1_DigOutVal	Word [Signed]	... VAR_GLOBAL	▼ W1001
	8	CH2_DigOutVal	Word [Signed]	... VAR_GLOBAL	▼ W1002
	9	CH3_DigCalcVal	Word [Signed]	... VAR_GLOBAL	▼ W1003
	10	CH4_DigOutVal	Word [Signed]	... VAR_GLOBAL	▼ W1004
	11	CH3_DigMaxVal	Word [Signed]	... VAR_GLOBAL	▼ W1005
	12	CH3_DigMinVal	Word [Signed]	... VAR_GLOBAL	▼ W1006
	13	CH1_A_D_conversionCompletedFlag	Bit	... VAR_GLOBAL	▼ W1000.0
	14	CH2_A_D_conversionCompletedFlag	Bit	... VAR_GLOBAL	▼ W1000.1
	15	CH3_A_D_conversionCompletedFlag	Bit	... VAR_GLOBAL	▼ W1000.2
	16	CH4_A_D_conversionCompletedFlag	Bit	... VAR_GLOBAL	▼ W1000.3
	17	CH2_WarningOutputFlagProcessAlarmUpperLimit	Bit	... VAR_GLOBAL	▼ W1010.1
	18	CH2_WarningOutputFlagProcessAlarmLowerLimit	Bit	... VAR_GLOBAL	▼ W1011.1
	19	CH1_WarningOutputFlagRateAlarmUpperLimit	Bit	... VAR_GLOBAL	▼ W1012.0
	20	CH1_WarningOutputFlagRateAlarmLowerLimit	Bit	... VAR_GLOBAL	▼ W1013.0
	21	CH1_InputSignalErrorDetectionFlag	Bit	... VAR_GLOBAL	▼ W1014.0
	22	CH2_ProcAImUpLimit	Bit	... VAR_GLOBAL	▼ F0
	23	CH2_ProcAImLowLimit	Bit	... VAR_GLOBAL	▼ F1
	24	CH1_RateAImUpLimit	Bit	... VAR_GLOBAL	▼ F2
	25	CH1_RateAImLowLimit	Bit	... VAR_GLOBAL	▼ F3
	26	CH1_InputSigErr	Bit	... VAR_GLOBAL	▼ F4
	27	DigitOutValSig	Bit	... VAR_GLOBAL	▼ X20
	28	MaxMinReadSig	Bit	... VAR_GLOBAL	▼ X21
	29	MaxMinResetSig	Bit	... VAR_GLOBAL	▼ X22
	30	ErrResetSig	Bit	... VAR_GLOBAL	▼ X23
	31	ConnectFormationFlag_St1	Bit	... VAR_GLOBAL	▼ M0
	32	ModuleREADY	Bit	... VAR_GLOBAL	▼ X1000
	33	InputSignalErrorDetectionSignal	Bit	... VAR_GLOBAL	▼ X100C
	34	.MaxValueMinValueResetCompletedFlag	Bit	... VAR_GLOBAL	▼ X100D
	35	A_D_conversionCompletedFlag	Bit	... VAR_GLOBAL	▼ X100E
	36	ErrorFlag	Bit	... VAR_GLOBAL	▼ X100F
	37	OperatingConditionSettingRequest	Bit	... VAR_GLOBAL	▼ Y1009
	38	.MaxValueMinValueResetRequest	Bit	... VAR_GLOBAL	▼ Y100D
	39	ErrorClearRequest	Bit	... VAR_GLOBAL	▼ Y100F

A

## Common program

The following figure shows an example of the program to check the data link status of the remote head module (station number 1).




(0) Checks the data link status of the remote head module (station number 1).

When creating programs shown later, add the MCR instruction to the last of the program as shown below.



## Program example 1


The following figure shows an example of the program to read digital output values of CH1, CH2, and CH4 and digital operation values of CH3 and save them.



(32) Reads values of CH1 Digital output value, CH2 Digital output value, CH3 Digital operation value, and CH4 Digital output value.

## Program example 2

The following figure shows an example of the program to read a maximum value and a minimum value of CH3 and reset them.



(66) Reads values of CH3 Maximum value and CH3 Minimum value.

(88) Turns on 'Maximum value/minimum value reset request' (Y100D).

(91) Turns off 'Maximum value/minimum value reset request' (Y100D).

## Program example 3

The following figure shows an example of the program to perform operations reacting to a warning (process alarm upper/lower limit) occurs in CH2.




(94) Performs a processing of when a warning (process alarm upper limit) has occurred in CH2.

(113) Performs a processing of when a warning (process alarm lower limit) has occurred in CH2.

## Program example 4

The following figure shows an example of the program to perform operations reacting to a warning (rate alarm upper/lower limit) occurs in CH1.




(118) Performs a processing of when a warning (rate alarm upper limit) has occurred in CH1.

(136) Performs a processing of when a warning (rate alarm lower limit) has occurred in CH1.

## Program example 5

The following figure shows an example of the program to clear Input signal error detection flag, Error flag, and Latest error code if an input signal error is detected in CH1 or an error occurs in any of the channels.



(141) Performs a processing of when an input signal error was detected in CH1.

(155) Turns on 'Error clear request' (Y100F).

(170) Turns off 'Error clear request' (Y100F).

# INDEX

---

## A

---

A/D conversion completed flag . . . . .	161, 180
A/D conversion enable/disable setting function . . . . .	21
A/D conversion method . . . . .	22
Alarm history . . . . .	223
ALM LED status monitor . . . . .	182
Application setting . . . . .	134
Attenuation characteristic . . . . .	35
Averaging processing . . . . .	25

## B

---

Band pass filter . . . . .	31
Basic setting . . . . .	133

## C

---

CH1 A/D conversion enable/disable setting . . . . .	200
CH1 A/D conversion status monitor . . . . .	198
CH1 Attenuation band width . . . . .	221
CH1 Averaging process specification . . . . .	201
CH1 Averaging process status monitor . . . . .	198
CH1 BPF Pass band edge frequency (High) . . . . .	220
CH1 BPF Pass band edge frequency (Low) . . . . .	220
CH1 Continuous logging data storage flag . . . . .	200
CH1 Conversion value shift amount . . . . .	199
CH1 Current logging read pointer . . . . .	195
CH1 Difference conversion reference value . . . . .	191
CH1 Difference conversion status flag . . . . .	189
CH1 Difference conversion trigger . . . . .	199
CH1 Digital clipping enable/disable setting . . . . .	204
CH1 Digital operation value . . . . .	188
CH1 Digital output value . . . . .	188
CH1 Factory default setting offset/gain value . . . . .	224
CH1 Head pointer . . . . .	192
CH1 HPF Pass band edge frequency . . . . .	219
CH1 Input signal error detection lower limit setting value . . . . .	210
CH1 Input signal error detection setting . . . . .	209
CH1 Input signal error detection upper limit setting value . . . . .	211
CH1 Latest pointer . . . . .	193
CH1 Level trigger condition setting . . . . .	215
CH1 Loading interrupt enable/disable setting . . . . .	218
CH1 Logging cycle monitor value . . . . .	196
CH1 Logging cycle setting value . . . . .	213
CH1 Logging cycle unit setting . . . . .	214
CH1 Logging data area . . . . .	229
CH1 Logging data points setting . . . . .	212
CH1 Logging data setting . . . . .	213
CH1 Logging enable/disable setting . . . . .	212
CH1 Logging hold flag . . . . .	190
CH1 Logging hold request . . . . .	163
CH1 Logging read points monitor value . . . . .	195
CH1 Logging read points setting value . . . . .	218
CH1 Logging start address monitor . . . . .	191
CH1 Logging status monitor value . . . . .	198
CH1 LPF Pass band edge frequency . . . . .	219
CH1 Maximum value . . . . .	189
CH1 Minimum value . . . . .	189
CH1 Number of logging data . . . . .	194

CH1 Offset/gain setting mode . . . . .	226
CH1 Offset/gain setting mode (range specification) . . . . .	227
CH1 Post-trigger logging points . . . . .	214
CH1 Previous logging read pointer . . . . .	195
CH1 Process alarm lower lower limit value . . . . .	207
CH1 Process alarm lower upper limit value . . . . .	207
CH1 Process alarm upper lower limit value . . . . .	206
CH1 Process alarm upper upper limit value . . . . .	206
CH1 Range setting . . . . .	221
CH1 Range setting monitor . . . . .	190
CH1 Rate alarm lower limit value . . . . .	209
CH1 Rate alarm upper limit value . . . . .	208
CH1 Rate alarm warning detection cycle setting . . . . .	208
CH1 Scaling enable/disable setting . . . . .	203
CH1 Scaling lower limit value . . . . .	204
CH1 Scaling upper limit value . . . . .	203
CH1 Synchronization digital output value . . . . .	227
CH1 Time average/Count average/Moving average/Primary delay filter constant setting . . . . .	202
CH1 Trigger data . . . . .	216
CH1 Trigger generation time . . . . .	197
CH1 Trigger judgment count setting value . . . . .	217
CH1 Trigger pointer . . . . .	194
CH1 Trigger setting value . . . . .	217
CH1 User range setting offset/gain value . . . . .	225
CH1 Warning output setting (Process alarm) . . . . .	205
CH1 Warning output setting (Rate alarm) . . . . .	205
Channel change completed flag . . . . .	159
Channel change request . . . . .	164
Clear setting of error history . . . . .	224
Condition target channel setting . . . . .	186
Condition target setting . . . . .	185
Continuous logging cycle setting value . . . . .	186
Continuous logging function . . . . .	94
Continuous logging status monitor . . . . .	181
Conversion cycle . . . . .	22
Count average . . . . .	26

## D

---

Difference conversion function . . . . .	46
Digital clipping function . . . . .	44
Digital filter . . . . .	30
Digital operation value . . . . .	20
Digital output value . . . . .	20

## E

---

ERR LED status monitor . . . . .	182
Error clear request . . . . .	165
Error flag . . . . .	162
Error history . . . . .	222
Error history function . . . . .	122
Event history function . . . . .	125

## H

---

High pass filter . . . . .	31
----------------------------	----

<b>I</b>	
Input signal error detection auto-clear	
enable/disable setting	187
Input signal error detection flag	179
Input signal error detection function	59
Input signal error detection signal	159
Inter-module synchronization function	114
Inter-module synchronization mode	16
Interrupt factor detection flag	177
Interrupt factor generation setting	184
Interrupt factor mask	183
Interrupt factor reset request	184
Interrupt function	110
Interrupt setting	135
<b>L</b>	
Latest address of alarm history	177
Latest address of error history	176
Latest alarm code	176
Latest error code	176
Level data 0 to 9	182
Logging cycle	72
Logging data area	20,229
Logging read function	88
Low pass filter	31
<b>M</b>	
Maximum and minimum value	20
Maximum value/minimum value hold function	50
Maximum value/minimum value reset completed flag	161
Maximum value/minimum value reset request	164
Mode switching setting	187
Module label	153
Module READY	156
Module-specific backup parameter	126
Moving average	26
<b>N</b>	
Normal logging function	69
Normal mode	16
<b>O</b>	
Offset/gain setting mode	16
Offset/gain setting mode status flag	158
Operating condition setting completed flag	157
Operating condition setting request	163
Operation mode monitor	181
Oversampling	106
Oversampling mode monitor	228
<b>P</b>	
Parameter settings	133
Primary delay filter	28
Process alarm	51
<b>R</b>	
Range reference table	132
Range switching function	21
<b>S</b>	
Sampling cycle	22
Sampling processing	23
Save data type setting	224
Scaling function	38
Shift function	41
Simple disconnection detection	61
Simultaneous conversion mode	16
Synchronization status monitor	228
<b>T</b>	
Time average	25
<b>U</b>	
User range write request	164
<b>W</b>	
Warning output flag (Process alarm lower limit)	178
Warning output flag (Process alarm upper limit)	177
Warning output flag (Rate alarm lower limit)	179
Warning output flag (Rate alarm upper limit)	178
Warning output function	51
Warning output signal	156

# REVISIONS

\*The manual number is given on the bottom left of the back cover.

Revision date	*Manual number	Description
January 2016	SH(NA)-081581ENG-A	First edition
July 2016	SH(NA)-081581ENG-B	■Added or modified parts Section 1.13, 1.15, Appendix 5

Japanese manual number: SH-081579-B

This manual confers no industrial property rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

© 2016 MITSUBISHI ELECTRIC CORPORATION

# WARRANTY

Please confirm the following product warranty details before using this product.

## **1. Gratis Warranty Term and Gratis Warranty Range**

If any faults or defects (hereinafter "Failure") found to be the responsibility of Mitsubishi occurs during use of the product within the gratis warranty term, the product shall be repaired at no cost via the sales representative or Mitsubishi Service Company.

However, if repairs are required onsite at domestic or overseas location, expenses to send an engineer will be solely at the customer's discretion. Mitsubishi shall not be held responsible for any re-commissioning, maintenance, or testing on-site that involves replacement of the failed module.

[Gratis Warranty Term]

The gratis warranty term of the product shall be for one year after the date of purchase or delivery to a designated place. Note that after manufacture and shipment from Mitsubishi, the maximum distribution period shall be six (6) months, and the longest gratis warranty term after manufacturing shall be eighteen (18) months. The gratis warranty term of repair parts shall not exceed the gratis warranty term before repairs.

[Gratis Warranty Range]

- (1) The range shall be limited to normal use within the usage state, usage methods and usage environment, etc., which follow the conditions and precautions, etc., given in the instruction manual, user's manual and caution labels on the product.
- (2) Even within the gratis warranty term, repairs shall be charged for in the following cases.
  1. Failure occurring from inappropriate storage or handling, carelessness or negligence by the user. Failure caused by the user's hardware or software design.
  2. Failure caused by unapproved modifications, etc., to the product by the user.
  3. When the Mitsubishi product is assembled into a user's device, Failure that could have been avoided if functions or structures, judged as necessary in the legal safety measures the user's device is subject to or as necessary by industry standards, had been provided.
  4. Failure that could have been avoided if consumable parts (battery, backlight, fuse, etc.) designated in the instruction manual had been correctly serviced or replaced.
  5. Failure caused by external irresistible forces such as fires or abnormal voltages, and Failure caused by force majeure such as earthquakes, lightning, wind and water damage.
  6. Failure caused by reasons unpredictable by scientific technology standards at time of shipment from Mitsubishi.
  7. Any other failure found not to be the responsibility of Mitsubishi or that admitted not to be so by the user.

## **2. Onerous repair term after discontinuation of production**

- (1) Mitsubishi shall accept onerous product repairs for seven (7) years after production of the product is discontinued. Discontinuation of production shall be notified with Mitsubishi Technical Bulletins, etc.

- (2) Product supply (including repair parts) is not available after production is discontinued.

## **3. Overseas service**

Overseas, repairs shall be accepted by Mitsubishi's local overseas FA Center. Note that the repair conditions at each FA Center may differ.

## **4. Exclusion of loss in opportunity and secondary loss from warranty liability**

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to:

- (1) Damages caused by any cause found not to be the responsibility of Mitsubishi.
- (2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products.
- (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products.
- (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

## **5. Changes in product specifications**

The specifications given in the catalogs, manuals or technical documents are subject to change without prior notice.

# TRADEMARKS

---

The company names, system names and product names mentioned in this manual are either registered trademarks or trademarks of their respective companies.

In some cases, trademark symbols such as <sup>TM</sup> or <sup>®</sup> are not specified in this manual.



SH(NA)-081581ENG-B(1607)MEE

MODEL: R60ADH4-U-OU-E

MODEL CODE: 13JX46

## **MITSUBISHI ELECTRIC CORPORATION**

HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN  
NAGOYA WORKS : 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA, JAPAN

When exported from Japan, this manual does not require application to the  
Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.