

## Voltage transform module for the energy measuring module of Mitsubishi general-purpose sequencer MELSEC-Q series

### Model QE8WH4VT

#### User's Manual

- This product is a voltage transform unit specially designed for the three-phase 4-wire energy measuring module of the MELSEC-Q series.
- Read carefully this manual and the manual for the energy measuring module used in combination with this product before use, and use this product properly.
- After reading this manual, please keep it in a safe, handy place for ready reference, and read it as necessary.
- Ensure that this manual is delivered to the end user.

#### Before Use

The warning signs used in this manual and their meanings are shown as follows.

The following signs are used to categorize and describe the degrees of risk associated with the improper use of the product.

 <b>Danger</b>	Risk that may result in death, serious injury or other severe consequences if the product is used improperly
 <b>Caution</b>	Risk that may result in injury or damage to buildings/properties if the product is used improperly

#### 1. Safety Precautions

##### 1.1 Precautions concerning the operating environment and usage conditions

Do not use the product in the following places or manners. Doing so may result in a malfunction or a reduced life of the product.

- Where the ambient temperature exceeds the operating temperature range (0°C to +55°C).
- Where the humidity exceeds the operating humidity range (5% to 95% RH) or condensation occurs.
- Where dust, corrosive gas, saline, or oil smoke exists.
- Under strong electromagnetic field or noise.
- Where metal pieces or conductive materials are scattered.
- Where the product is exposed to direct sunlight.
- Where the product is exposed to rain fall or water drop.
- Where frequent vibration or impact exists.
- On other than the control board.
- Where the altitude exceeds 2000 m.

##### 1.2 Precautions concerning the preparation before use

Make sure that your installation site meets the requirements for the operation environment and usage conditions.

Before supplying voltage, check that the circuit voltage you use falls within the rated primary voltage range of the product.

##### 1.3 Precautions for safety

For safety reasons, the product should be installed and wired by a technician who has expertise in electric work. Read this instruction manual before installation and wiring.

 <b>Danger</b>	• Before installation and wiring works, shut off the power source of all phases externally. Failure to do so may cause an electric shock or product damage.
--	---

##### 1.5 Precautions for maintenance

 <b>Danger</b>	<ul style="list-style-type: none"> <li>Make sure periodic inspection is performed with the electricity off. Failure to do so may cause an electric shock or malfunction.</li> <li>Perform the following inspections to use the product for a longer time.           <ul style="list-style-type: none"> <li>[Daily inspection] (1) Check for any damage to this product.</li> <li>(2) Check for any abnormal noise, odor, or heat generation.</li> </ul> </li> <li>[Periodic inspection] (1) Check for any loose installation or terminal connection (every six months to one year).</li> </ul>
--	--

##### 1.6 Storage precautions

When storing this product, shut down the inputs, disconnect the wires, and put it in a plastic bag. For long-time storage, avoid the following places. Failure to do so may result in a failure or a reduced life of the product.


- Where the ambient temperature exceeds -25°C to +75°C (or the average daily temperature exceeds 35°C).
- Where the relative humidity exceeds 5% to 95% or condensation occurs.
- Where dust, corrosive gas, saline, or oil smoke exists.
- Where frequent vibration or impact exists.
- Where the product is exposed to rain fall, water drop, or direct sunlight.
- Where metal pieces or conductive materials are scattered.

##### 1.7 Precautions for disposal

This product should be disposed of properly in compliance with the Wastes Disposal and Public Cleansing Act.


#### 2. Name and Function of Each Part

##### 2.1 Name of each part of voltage transform unit (QE8WH4VT)



#### Additional information


To measure the length to be stripped off, align the connecting wire onto the groove of the STRIP GAUGE.



#### 4. Wiring Method

##### 4.1 Wiring

Install the wiring according to the following wiring diagram. This product is specially designed for the three-phase 4-wire system. It does not support circuits using any other phase wire systems.



- The rated voltage of the voltage transform unit is 63.5/110 to 277/480 V AC. Do not use it for any circuits exceeding 277/480 V AC.
- Up to five energy measuring modules can be connected to one voltage transform unit.
- For more information on the wiring, refer to the wiring diagrams contained in the user's manual of the energy measuring module used in combination with this product.

##### 4.2 How to connect wires

- Use the electric wires and solderless terminals shown in the table below, and tighten them to the tightening torque indicated in the table below.
- The strip length of the sheaths of the electric wires used on the output side should be 6 to 7 mm. Measure the length of the electric wire sheaths to be stripped using the strip gauge on this product.
- After connecting wires, check to see if they are properly connected, and then install the terminal cover of the input terminal block.
- The output signal wires drawn from the output terminal block should be shielded.

Wire	Input terminal block	Output terminal block
Single wire	AWG22 - 10	AWG24 - 12
Stranded wire		
Solderless terminal	For M4 screw having an external dimension of 8.5 mm or less	-
Tightening torque	1.4 N·m	0.5 N·m

• UL/c-UL listed corresponds, use the wires according to the following conditions. Input terminals: AWG22-12 (Single wire / Stranded wire) / Output terminals: AWG24-14 (Single wire / Stranded wire) 60/75°C copper conductor only.

• Pour être conforme à UL/c-UL standard, utilisez le fil électrique selon les conditions suivantes. Terminals d'entrée: AWG22-12 (Câble simple / Câble brin) Terminals de sortie: AWG24-14 (Câble simple / Câble brin) Seulement le conduit en cuivre 60°C/75°C.

#### 6. Specifications

Item	Specification
Model	QE8WH4VT
Phase wire system	Three-phase 4-wire
Input voltage range	63.5/110 to 277/480 V AC (The product does not operate on the voltage below 55/95 V AC.)
Frequency	50 Hz/60 Hz
Voltage output tolerance	±1.0% (against the rated primary voltage)
Measurement category	III
Pollution degree	II
Maximum number of connections	5 modules
Operating condition	0°C to +55°C (Average daily temperature 35°C or below)
Operating humidity	5% to 95% RH (without condensation)
Storage temperature	-25°C to +75°C
Altitude	2000 m or lower
Commercial frequency withstand voltage	Between voltage input terminals (P1, P2, P3, P0) and FG terminal: 2210 VAC 5 sec
	Between voltage input terminals (P1, P2, P3, P0) and secondary output terminals (PA, PB, PC, PD) (except for SLD terminal): 2210 VAC 5 sec
Insulation resistance	10 MΩ or more (500V DC) at the same locations as above
Consumption VA	P1-P0: 2 VA, P2-P0: 0.3 VA, P3-P0: 0.3 VA (when inputting 277/480 V AC)
Installation location	Inside the control panel
Secondary wire length	5m or less
Installation method	Installation on IEC rails, installation with screws
Weight	0.3kg
CE marking compliance	EN 61312-1, EN 61010-1, EN 61326-1
Combined device for CE marking compliance	Compliant with CE when combined with the energy measuring module of Mitsubishi general-purpose sequencer MELSEC-Q series.
Combined device for UL/c-UL compliance	Compliant with UL/c-UL when combined with the energy measuring module of Mitsubishi general-purpose sequencer MELSEC-Q series.
Accessories	Screw M3 x 16, User's Manual


#### 8. Customer Service

##### MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, Japan

Please refer to "catalog" or "user's manual (Details)" for more detail.

#### 5. External Dimensions



##### Caution

**<Usage as a CE-marked product>** Follow the instructions below.

- As for the voltage to ground / line Maximum voltage, 277V / 480VAC, the measurement category and pollution degree should be III and II respectively.
- Connect the product to the secondary side of the circuit breaker.
- Be sure to install the product inside the grounded metal panel.

#### 7. After-sales Service

If you have any question or technical troubles in using the product, contact your nearest branch of Mitsubishi Electric Corporation.

- The charge-free warranty period for the product shall be 36 months from the date of your purchase or the date of delivery to your specified location. However, the maximum limit of the charge-free warranty period shall be 42 months from the time of manufacture considering that the distribution period of the product is six months at the longest after shipment from our manufacturing factory. Also, the charge-free warranty period for the replacement product shall not be extended exceeding the charge-free warranty period for the original product.
- Our company shall not be liable to compensate for any loss arising from events not attributable to us, opportunity loss and lost earning of the customer due to a failure of the product, and loss, secondary loss, accident compensation, damage to other products besides our products and other operations caused by a special reason regardless of our predictability in both within and beyond the charge-free warranty period.

##### Caution

When the product emits abnormal noise, odor, smoke, or heat, turn off the power immediately and stop using it.



KCC-REI-MEK-19H044  
Applicant MITSUBISHI ELECTRIC AUTOMATION KOREA CO.,Ltd  
Equipment Name Voltage Transform Unit  
Model QE8WH4VT  
Made in JAPAN  
Manufacturer MITSUBISHI ELECTRIC CORPORATION FUKUYAMA WORKS

사용자안내문 A급 기기 (업무용 방송통신기자재)  
이 기기는 업무용(A급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.

Additional information  
To measure the length to be stripped off, align the connecting wire onto the groove of the STRIP GAUGE.