



■ Features :

- Charger for lead-acid batteries (flooded, Gel and AGM) and Li-ion batteries (lithium iron and lithium manganese) (Note.1)
- 2/3/8 stage charging selectable on output panel (Note 5)
- Built-in battery rescue function
- Universal AC input / Full range
- Controlled by microprocessor
- Built-in active PFC function $PF>0.95$
- Protection: Reverse Polarity / Short circuit / Over voltage / Over temperature
- 3 color LED loading indicator
- Built-in remote ON-OFF control
- 2-Bank charger
- Temperature compensation function
- FAN on/off control (depends on charging current)
- 3 years warranty




SPECIFICATION

MODEL	PB-1000-12	PB-1000-24	PB-1000-48
OUTPUT	BOOST CHARGE VOLTAGE V_{boost}	14.4V	28.8V
	FLOAT CHARGE VOLTAGE V_{float}	13.8V	27.6V
	OUTPUT CURRENT	60A	34.7A
	RECOMMENDED BATTERY CAPACITY(AMP HOURS)(Note 4)	200 ~ 600Ah	120 ~ 350Ah
	BATTERY TYPE	Open & Sealed Lead Acid	
	LEAKAGE CURRENT FROM BATTERY (Typ.)	<1mA	
INPUT	VOLTAGE RANGE	90 ~ 264VAC	127 ~ 370VDC
	FREQUENCY RANGE	47 ~ 63Hz	
	POWER FACTOR (Typ.)	0.95/230VAC	0.98/115VAC at full load
	EFFICIENCY (Typ.)	85%	88%
	AC CURRENT (Typ.)	12A/115VAC	5.2A/230VAC
	INRUSH CURRENT (Typ.)	25A/115VAC	50A/230VAC
PROTECTION	LEAKAGE CURRENT	<3.5mA / 240VAC	
	OVER VOLTAGE	16 ~ 18V	32 ~ 35V
		Protection type : Shut down o/p voltage, re-power on to recover	
	OVER TEMPERATURE	Shut down o/p voltage, recovers automatically after temperature goes down	
FUNCTION	SHORT CIRCUIT	YES, protected by internal circuit	
	REVERSE POLARITY	YES, protected by internal circuit	
	REMOTE CONTROL	Open: Normal work	Short: Stop Charging
	BATTER BANKS	2 banks (A & B)	
	FAST CHARGE	2 / 3 / 8 stage selectable	
ENVIRONMENT	CHARGER OK	Relay contact rating(max.): 30V/1A resistive ; "Short" when the unit is working properly, "Open" when the unit is failure or the protection function is activating	
	OUTPUT OK	Relay contact rating(max.): 30V/1A resistive ; "Short" when the battery is full, "Open" when the battery is still charging	
	TEMPERATURE COMPENSATION	By NTC, compensate both banks at the same time	
	WORKING TEMP.	-20 ~ +60°C (Refer to "Derating Curve")	
	WORKING HUMIDITY	20 ~ 90% RH non-condensing	
SAFETY & EMC (Note 3)	STORAGE TEMP., HUMIDITY	-40 ~ +85°C, 10 ~ 95% RH non-condensing	
	TEMP. COEFFICIENT	$\pm 0.05\%/\text{C}$ (0 ~ 50°C)	
	VIBRATION	10 ~ 500Hz, 2G 10min./1cycle, 60min. each along X, Y, Z axes	
	SAFETY STANDARDS	UL62368-1, TUV BS EN/EN62368-1, EAC TP TC 004 approved	
OTHERS	WITHSTAND VOLTAGE	I/P-O/P:3KVAC	I/P-FG:2KVAC
	ISOLATION RESISTANCE	I/P-O/P, I/P-FG, O/P-FG:100M Ohms	500VDC / 25°C / 70% RH
	EMC EMISSION	Compliance to BS EN/EN55032 (CISPR32), BS EN/EN61000-3-2,-3, EAC TP TC 020	
	EMC IMMUNITY	Compliance to BS EN/EN61000-4-2,3,4,5,6,8,11, BS EN/EN55024, light industry level, criteria A, EAC TP TC 020	
NOTE	MTBF	127.4K hrs min. MIL-HDBK-217F (25°C)	
	DIMENSION	300*184*70mm(L*W*H)	
	PACKING	3.5Kg; 4pcs/15Kg/1.83CUFT	
1. Modification for charger specification may be required for different battery specification. Please contact battery vendor and MEAN WELL for details. 2. All parameters NOT specially mentioned are measured at 230VAC input, rated load and 25°C of ambient temperature. 3. The power supply is considered a component which will be installed into a final equipment. The final equipment must be re-confirmed that it still meets EMC directives. 4. This is Mean Well's suggested range. Please consult your battery manufacturer for their suggestions about maximum charging current limitation. 5. Please choose the "3 stage" selection when the charger is used to charge the batteries and power the loads in the same time. 6. The ambient temperature derating of 3.5°C/1000m with fanless models and of 5°C/1000m with fan models for operating altitude higher than 2000m(6500ft). ※ Product Liability Disclaimer : For detailed information, please refer to https://www.meanwell.com/serviceDisclaimer.aspx			

■ Mechanical Specification


Case No. 804B Unit:mm



※ LED Loading Indicator Status Table

Color	Status	Steady	Flashing
Red	Abnormal status		
Orange			Charging
Green	Full		Charging

※ Control Pin No. Assignment(CN100) : HRS DF11-10DP-2DS or equivalent

 CN100	Mating Housing	HRS DF11-10DS or equivalent
	Terminal	HRS DF11-**SC or equivalent


Pin No.	Function	Description
1,2	RY13	RY13 : Battery Bank A OK relay. Relay contact rating(max.) : 30V/1A resistive. ; "Short" when the battery A is full, "Open" when the battery A is still charging.
3,4	RY14	RY14 : Battery Bank B OK relay. Relay contact rating(max.) : 30V/1A resistive. ; "Short" when the battery B is full, "Open" when the battery B is still charging.
5,6	RY15	RY15 : Charger OK relay. Relay contact rating(max.) : 30V/1A resistive. ; "Short" when the unit is working properly, "Open" when the unit is failure or the protection function is activating.
7	GND	NTC / GND : Temperature sense Temperature sensor comes along with the charger can be connected to the unit to allow temperature compensation of the charging voltage.
8	NTC(5KΩ) RTH	If the temperature sensor is not used, the charger still works normally.
9,10	RC- / RC+	Remote ON/OFF function. Turn the output on and off by electrical or dry contact between pin 10 (RC+) and pin 9(RC-). "Open" : Normal work ; "Short" : Stop charging




1000W Intelligent Single Output Battery Charger

PB-1000 series


Block Diagram



Derating Curve




Charging Curve



State	PB-1000-12	PB-1000-24	PB-1000-48
Constant Current	60A	34.7A	17.4A
Vboost	14.4V	28.8V	57.6V


◎ Suitable for lead-acid batteries (flooded, Gel and AGM) and Li-ion batteries (lithium iron and lithium manganese).



State	PB-1000-12	PB-1000-24	PB-1000-48
Constant Current	60A	34.7A	17.4A
Vboost	14.4V	28.8V	57.6V
Vfloat	13.8V	27.6V	55.2V

◎ Suitable for lead-acid batteries (flooded, Gel and AGM) and Li-ion batteries (lithium iron and lithium manganese).

8 Stage



◎ Suitable for lead-acid batteries (flooded, Gel and AGM).

◎ "stage 1"(Pulse) and "stage 2"(Soft Start) provide battery rescue function.


2,3, or 8 Stage Charging Select

(1) The charger features user selectable 2,3, or 8 stage charging.

The charging profile is selected by moving the slide switch on the back panel.

Switch	Charging mode
Right	2 stage charging
Middle	3 stage charging
Left	8 stage charging

(2) Please choose the "3 stage" selection when the charger is used to charge the batteries and power the loads in the same time.




CN100	
1	RY13 RY13
	RY14 RY14
	RY15 RY15
	GND RTH
9	RC- RC+ 10

Function Manual

1. Remote Control

The charger can be turned ON/OFF by using the "Remote Control" function.

Between RC+(pin 10) and RC-(pin 9)	Charger
SW Open	ON
SW Short	OFF








1000W Intelligent Single Output Battery Charger

PB-1000 series



2.Two Battery Banks (2/8 stage only)

The charger may be hooked up two battery banks (A and/or B). Connect the battery bank(s) as below. If you are connecting 2 battery banks in the same time, keep in mind that they must share a common ground.

NOTE: The charger will charge bank A first then bank B if both channels are connected.

**3.Charger OK Relay(RY15)**



Charger	Between pin5 and pin6(RY15)
Normal work	ON (Short)
Failure or the protection function is activating	OFF (Open)

**4.Output OK Relay(RY13 & RY14)****1.Bank A OK (RY13)**

Bank A	Between pin1 and pin2(RY13)	Color of LED A
Battery A Full	ON (Short)	Green
Charging	OFF (Open)	Orange

2.Bank B OK (RY14)


Bank B	Between pin3 and pin4(RY14)	Color of LED B
Battery B Full	ON (Short)	Green
Charging	OFF (Open)	Orange



5. Temperature Compensation

Temperature sensor comes along with the charger can be connected to the unit to allow temperature compensation of the charging voltage.

If the temperature sensor is not used, the charger still works normally.



The temperature sensor can either be attached to the battery or placed in its surrounding environment.