




**Benutzeranleitung
VARISTAR CP
SCHWERLASTSCHIENEN
1600KG (1000T > 1200T)**

**User Manual
VARISTAR CP
HEAVY LOAD CROSSBARS
1600KG (1000D > 1200D)**


**Instructions utilisateur
VARISTAR CP
TRAVERSES CH. LOURDE
1600KG (1000P > 1200P)**






Toleranz von $\pm 15\%$ auf alle Anziehdrehmomente, sofern nicht anders angegeben.
Tightening couples are given with a tolerance of $\pm 15\%$ unless otherwise stated.
Les couples de serrages sont donnés avec une tolérance de $\pm 15\%$ sauf autre indication.



1



2



2 (5Nm)




2A

Varistar 19" Winkelprofil Befestigung auf den 1600kg Schwerlastchiene
Varistar 19" uprights fixing on the 1600kg heavy load crossbars
Fixation des montants 19" Varistar sur les traverses charge lourde 1600kg

Forderseite
Front
Avant

Hinterseite
Rear
Arrière




Standardmontage / Default installation / Montage par défaut

Tiefe Depth Profondeur	Winkelprofil Position uprights position Position des montants		XF	C
	Forderseite / Front / Avant	Hinterseite / Rear / Arriere		
1000	145	110	144,75	740
1100	145	210	144,75	740
1200	145	310	144,75	740

2B Varistar CP 19" Winkelprofil Befestigung auf den 1600kg Schwerlastchiene Varistar CP 19" uprights fixing on the 1600kg heavy load crossbars Fixation des montants 19" Varistar CP sur les traverses charge lourde 1600kg

Forderseite
Front
Avant

Hinterseite
Rear
Arrière



Standardmontage / Default installation / Montage par défaut

Tiefe Depth Profondeur	Winkelprofil Position uprights position Position des montants		XF	C
	Forderseite / Front / Avant	Hinterseite / Rear / Arrière		
1000	145	110	144,75	740
1100	145	210	144,75	740
1200	145	310	144,75	740