

Technical data sheet

Safety light curtain receiver

Part no.: 68001225

MLC510R20-2550



For illustration purposes only

Contents

- Technical data
- Dimensioned drawings
- Electrical connection
- Circuit diagrams
- Operation and display
- Suitable transmitters
- Part number code
- Notes
- Accessories



[illegible][illegible][illegible]

The diagram illustrates the wiring for two Leuze electronic sensors, MLCx00T and MLCx10R, connected to a power supply and a control unit. The sensors are shown in dashed boxes, with their internal components and pin connections labeled. The power supply is +24V, and the ground is 0V. The control unit is represented by a series of terminals labeled -W1, -W2, -A1, -A2, -A3, -K3, -K4, -S1, -S2, -S3, -S4, -S5, -S6, -S7, -S8, -S9, -S10, -S11, -S12, -S13, -S14, -S15, -S16, -S17, -S18, -S19, -S20, -S21, -S22, -S23, -S24, -S25, -S26, -S27, -S28, -S29, -S30, -S31, -S32, -S33, -S34, -S35, -S36, -S37, -S38, -S39, -S40, -S41, -S42, -S43, -S44, -S45, -S46, -S47, -S48, -S49, -S50, -S51, -S52, -S53, -S54, -S55, -S56, -S57, -S58, -S59, -S60, -S61, -S62, -S63, -S64, -S65, -S66, -S67, -S68, -S69, -S70, -S71, -S72, -S73, -S74, -S75, -S76, -S77, -S78, -S79, -S80, -S81, -S82, -S83, -S84, -S85, -S86, -S87, -S88, -S89, -S90, -S91, -S92, -S93, -S94, -S95, -S96, -S97, -S98, -S99, -S100.

Power and Ground Connections:

- +24V:** Connected to the VIN1 pin of both sensors.
- 0V:** Connected to the VIN2 pin of both sensors.

Signal Connections:

- W1:** Connected to the IBN pin of the MLCx00T sensor.
- W2:** Connected to the IBN pin of the MLCx10R sensor.
- A1:** Connected to the FE pin of the MLCx00T sensor.
- A2:** Connected to the FE pin of the MLCx10R sensor.
- A3:** Connected to the A1 pin of the MLCx00T sensor.
- K3:** Connected to the A2 pin of the MLCx00T sensor.
- K4:** Connected to the A2 pin of the MLCx10R sensor.
- S1:** Connected to the A1 pin of the MLCx10R sensor.
- S2:** Connected to the A2 pin of the MLCx10R sensor.
- S3:** Connected to the A1 pin of the MLCx10R sensor.
- S4:** Connected to the A2 pin of the MLCx10R sensor.
- S5:** Connected to the A1 pin of the MLCx10R sensor.
- S6:** Connected to the A2 pin of the MLCx10R sensor.
- S7:** Connected to the A1 pin of the MLCx10R sensor.
- S8:** Connected to the A2 pin of the MLCx10R sensor.
- S9:** Connected to the A1 pin of the MLCx10R sensor.
- S10:** Connected to the A2 pin of the MLCx10R sensor.
- S11:** Connected to the A1 pin of the MLCx10R sensor.
- S12:** Connected to the A2 pin of the MLCx10R sensor.
- S13:** Connected to the A1 pin of the MLCx10R sensor.
- S14:** Connected to the A2 pin of the MLCx10R sensor.
- S15:** Connected to the A1 pin of the MLCx10R sensor.
- S16:** Connected to the A2 pin of the MLCx10R sensor.
- S17:** Connected to the A1 pin of the MLCx10R sensor.
- S18:** Connected to the A2 pin of the MLCx10R sensor.
- S19:** Connected to the A1 pin of the MLCx10R sensor.
- S20:** Connected to the A2 pin of the MLCx10R sensor.
- S21:** Connected to the A1 pin of the MLCx10R sensor.
- S22:** Connected to the A2 pin of the MLCx10R sensor.
- S23:** Connected to the A1 pin of the MLCx10R sensor.
- S24:** Connected to the A2 pin of the MLCx10R sensor.
- S25:** Connected to the A1 pin of the MLCx10R sensor.
- S26:** Connected to the A2 pin of the MLCx10R sensor.
- S27:** Connected to the A1 pin of the MLCx10R sensor.
- S28:** Connected to the A2 pin of the MLCx10R sensor.
- S29:** Connected to the A1 pin of the MLCx10R sensor.
- S30:** Connected to the A2 pin of the MLCx10R sensor.
- S31:** Connected to the A1 pin of the MLCx10R sensor.
- S32:** Connected to the A2 pin of the MLCx10R sensor.
- S33:** Connected to the A1 pin of the MLCx10R sensor.
- S34:** Connected to the A2 pin of the MLCx10R sensor.
- S35:** Connected to the A1 pin of the MLCx10R sensor.
- S36:** Connected to the A2 pin of the MLCx10R sensor.
- S37:** Connected to the A1 pin of the MLCx10R sensor.
- S38:** Connected to the A2 pin of the MLCx10R sensor.
- S39:** Connected to the A1 pin of the MLCx10R sensor.
- S40:** Connected to the A2 pin of the MLCx10R sensor.
- S41:** Connected to the A1 pin of the MLCx10R sensor.
- S42:** Connected to the A2 pin of the MLCx10R sensor.
- S43:** Connected to the A1 pin of the MLCx10R sensor.
- S44:** Connected to the A2 pin of the MLCx10R sensor.
- S45:** Connected to the A1 pin of the MLCx10R sensor.
- S46:** Connected to the A2 pin of the MLCx10R sensor.
- S47:** Connected to the A1 pin of the MLCx10R sensor.
- S48:** Connected to the A2 pin of the MLCx10R sensor.
- S49:** Connected to the A1 pin of the MLCx10R sensor.
- S50:** Connected to the A2 pin of the MLCx10R sensor.
- S51:** Connected to the A1 pin of the MLCx10R sensor.
- S52:** Connected to the A2 pin of the MLCx10R sensor.
- S53:** Connected to the A1 pin of the MLCx10R sensor.
- S54:** Connected to the A2 pin of the MLCx10R sensor.
- S55:** Connected to the A1 pin of the MLCx10R sensor.
- S56:** Connected to the A2 pin of the MLCx10R sensor.
- S57:** Connected to the A1 pin of the MLCx10R sensor.
- S58:** Connected to the A2 pin of the MLCx10R sensor.
- S59:** Connected to the A1 pin of the MLCx10R sensor.
- S60:**

LED	Display	Meaning
1	Off	Device switched off
	Red, continuous light	OSSD off.
	Red, flashing, 1 Hz	External error
	Red, flashing, 10 Hz	Internal error
	Green, flashing, 1 Hz	OSSD on, weak signal
	Green, continuous light	OSSD on
2	Off	Transmission channel C1
	Red, continuous light	OSSD off, transmission channel C2

	Part no.	Designation	Article	Description
	68000225	MLC500T20-2550	Safety light curtain transmitter	Resolution: 20 mm Protective field height: 2,550 mm Operating range: 0 ... 15 m Connection: Connector, M12, Metal, 5 -pin

MLC **Safety light curtain**

x	Series 3: MLC 300 5: MLC 500
yy	Function classes 00: transmitter 01: transmitter (AIDA) 02: transmitter with test input 10: basic receiver - automatic restart 11: basic receiver - automatic restart (AIDA) 20: standard receiver - EDM/RES selectable 30: Extended receiver blanking/muting or gating 35: Extended receiver – Gating
z	Device type T: transmitter R: receiver
a	Resolution 14: 14 mm 20: 20 mm 30: 30 mm 40: 40 mm 90: 90 mm
hhhh	Protective field height 150 ... 3000: from 150 mm to 3000 mm
e	Host/Guest (optional) H: Host MG: Middle Guest G: Guest
i	Interface (optional) /A: AS-i

Accessories

Services

	Part no.	Designation	Article	Description
	S981050	CS40-I-140	Safety inspection	Details: Checking of a safety light barrier application in accordance with current standards and guidelines. Inclusion of the device and machine data in a database, production of a test log per application. Conditions: It must be possible to stop the machine, support provided by customer's employees and access to the machine for Leuze employees must be ensured.
	S981046	CS40-S-140	Start-up support	Details: For safety devices including stopping time measurement and initial inspection. Conditions: Devices and connection cables are already mounted, price not including travel costs and, if applicable, accommodation expenses.

Note



🔗 A list with all available accessories can be found on the Leuze website in the Download tab of the article detailed page.