

FX3-EBX300002

Passive distribution boxes

CONNECTORS AND CABLES





Ordering information

| Туре | part no. |
|---------------|----------|
| FX3-EBX300002 | 2068728 |

Other models and accessories → www.sick.com/Passive_distribution_boxes



Detailed technical data

Technical specifications

| Accessory family | Connection modules |
|----------------------|--------------------|
| Slot connection type | A-coded |

Classifications


| ECLASS 5.0 | 27243092 |
|----------------|----------|
| ECLASS 5.1.4 | 27243092 |
| ECLASS 6.0 | 27249204 |
| ECLASS 6.2 | 27249204 |
| ECLASS 7.0 | 27249204 |
| ECLASS 8.0 | 27249204 |
| ECLASS 8.1 | 27249204 |
| ECLASS 9.0 | 27243192 |
| ECLASS 10.0 | 27243192 |
| ECLASS 11.0 | 27243192 |
| ECLASS 12.0 | 27243192 |
| ETIM 5.0 | EC001604 |
| ETIM 6.0 | EC001604 |
| ETIM 7.0 | EC000474 |
| ETIM 8.0 | EC000474 |
| UNSPSC 16.0901 | 32151705 |

Certificates

| EU declaration of conformity | ✓ |
|--------------------------------|---|
| UK declaration of conformity | ✓ |
| ACMA declaration of conformity | ✓ |


| China-RoHS | ✓ |
|-------------------|---|
| cULus certificate | ✓ |

Dimensional drawing



Dimensions in mm (inch)

PIN assignment




| Spring terminals | PIN | Signal | Description |
|------------------|-----|-----------|---|
| C1 | 1 | NC2 | Do not connect. Used to forward a signal. |
| | 2 | NC1 | Do not connect. Used to forward a signal. |
| | 3 | U_{out} | Encoder voltage supply of the on-board voltage supply of this motor feedback splitter box |
| | 4 | ENCx_OV | GND encoder connection |

FX3-EBX300002 | Passive distribution boxes

CONNECTORS AND CABLES

| Spring terminals | PIN | Signal | Description |
|------------------|------|----------------------|--|
| | 5 | ENCx_C- | Encoder, channel C, negative signal |
| | 6 | ENCx_C+ | Encoder, channel C, positive signal |
| | 7 | ENCx_B- | Encoder, channel B, negative signal |
| | 8 | ENCx_B+ | Encoder, channel B, positive signal |
| | 9 | ENCx_A- | Encoder, channel A, negative signal |
| | 10 | ENCx_A+ | Encoder, channel A, positive signal |
| - | - | - | - |
| C1 | 1 | NC | Do not connect. Used |
| | 2 NC | to forward a signal. | |
| | 3 | NC | |
| | 4 | NC | |
| | 5 | NC | |
| | 6 | NC | |
| | 7 | NC | |
| | 8 | NC | |


PIN assignment



| PIN | Signal | Description |
|-----|---------|--|
| 1 | ENC_A+ | Encoder, channel A, positive signal |
| 2 | ENC_B+ | Encoder, channel B, positive signal |
| 3 | ENC_C+ | Encoder, channel C, positive signal |
| 4 | ENC_24V | 24 V voltage supply for encoder/hardware ID connection box |
| 5 | ENC_ID | Encoder splitter box ID |
| 6 | ENC_A- | Encoder, channel A, negative signal |
| 7 | ENC_B- | Encoder, channel B, negative signal |
| 8 | ENC_C- | Encoder, channel C, negative signal |
| 9 | ENC_OV | GND encoder connection |

CONNECTORS AND CABLES

PIN assignment



| PIN | Signal | Description |
|-----|----------|--|
| 1 | ENC1_A+ | Encoder 1, signal pair A, positive signal |
| 2 | ENC1_A- | Encoder 1, signal pair A, negative signal |
| 3 | ENC1_24V | 24 V voltage supply for encoder 1 |
| 4 | ENC2_A+ | Encoder 2, signal pair A, positive signal |
| 5 | ENC2_A- | Encoder 2, signal pair A, negative signal |
| 6 | ENC1_B+ | Encoder 1, signal pair B, positive signal |
| 7 | ENC1_B- | Encoder 1, signal pair B, negative signal |
| 8 | ENC_OV | 0 V voltage supply for encoder 1 and encoder 2 |
| 9 | ENC2_B+ | Encoder 2, signal pair B, positive signal |
| 10 | ENC2_B- | Encoder 2, signal pair B, negative signal |
| 11 | ENC1_C+ | Encoder 1, signal pair C, positive signal |
| 12 | ENC1_C- | Encoder 1, signal pair C, negative signal |
| 13 | ENC2_24V | 24 V voltage supply for encoder 2 |
| 14 | ENC2_C+ | Encoder 2, signal pair C, positive signal |
| 15 | ENC2_C- | Encoder 2, signal pair C, negative signal |

SICK AT A GLANCE

SICK is one of the leading manufacturers of intelligent sensors and sensor solutions for industrial applications. A unique range of products and services creates the perfect basis for controlling processes securely and efficiently, protecting individuals from accidents and preventing damage to the environment.

We have extensive experience in a wide range of industries and understand their processes and requirements. With intelligent sensors, we can deliver exactly what our customers need. In application centers in Europe, Asia and North America, system solutions are tested and optimized in accordance with customer specifications. All this makes us a reliable supplier and development partner.

Comprehensive services complete our offering: SICK LifeTime Services provide support throughout the machine life cycle and ensure safety and productivity.

For us, that is "Sensor Intelligence."

WORLDWIDE PRESENCE:

Contacts and other locations -www.sick.com

